




# FR-E740-016 to 300 - EC



OUTLINE

WIRING

PRECAUTIONS FOR USE OF THE INVERTER

PARAMETERS

4

TROUBLESHOOTING

PRECAUTIONS FOR

**SPECIFICATIONS** 

MAINTENANCE AND INSPECTION

7/

6

Thank you for choosing this Mitsubishi Inverter.

This Instruction Manual provides instructions for advanced use of the FR-E700 series inverters.

Incorrect handling might cause an unexpected fault. Before using the inverter, always read this instruction manual and the Installation Guideline [IB-0600335ENG] packed with the product carefully to use the equipment to its optimum performance.

#### This section is specifically about safety matters

Do not attempt to install, operate, maintain or inspect the inverter until you have read through the Instruction Manual and appended documents carefully and can use the equipment correctly. Do not use this product until you have a full knowledge of the equipment, safety information and instructions.

In this Instruction Manual, the safety instruction levels are classified into "WARNING" and "CAUTION".

## **≜WARNING**

Assumes that incorrect handling may cause hazardous conditions, resulting in death or severe injury.

## **⚠CAUTION**

Assumes that incorrect handling may cause hazardous conditions, resulting in medium or slight injury, or may cause physical damage only.

Note that even the  $\triangle CAUTION$  level may lead to a serious consequence according to conditions. Please follow the instructions of both levels because they are important to personnel safety.

## 1. Electric Shock Prevention

### **AWARNING**

- While power is on or when the inverter is running, do not open the front cover. Otherwise you may get an electric shock.
- Do not run the inverter with the front cover or wiring cover removed. Otherwise, you may access the exposed highvoltage terminals or the charging part of the circuitry and get an electric shock.
- Even if power is off, do not remove the front cover except for wiring or periodic inspection. You may access the charged inverter circuits and get an electric shock.
- Before starting wiring or inspection, switch off power, check to make sure that the operation panel indicator is off, wait for at least 10 minutes after the power supply has been switched off, and check that there are no residual voltage using a tester or the like. The capacitor is charged with high voltage for some time after power off and it is dangerous.
- This inverter must be earthed (grounded). Earthing (grounding) must conform to the requirements of national and local safety regulations and electrical code. (NEC section 250, IEC 536 class 1 and other applicable standards)

Use an neutral-point earthed (grounded) power supply for 400V class inverter in compliance with EN standard.

- Any person who is involved in the wiring or inspection of this equipment should be fully competent to do the work.
- Always install the inverter before wiring. Otherwise, you may get an electric shock or be injured.
- Perform setting dial and key operations with dry hands to prevent an electric shock. Otherwise you may get an electric shock.
- Do not subject the cables to scratches, excessive stress, heavy loads or pinching. Otherwise, you may get an electric shock.
- Do not change the cooling fan while power is on. It is dangerous to change the cooling fan while power is on.
- Do not touch the printed circuit board with wet hands.
   Otherwise, you may get an electric shock.
- When measuring the main circuit capacitor capacity, the DC voltage is applied to the motor for 1s at powering off.
   Never touch the motor terminal, etc. right after powering off to prevent an electric shock.

#### 2. Fire Prevention

## **ACAUTION**

- Install the inverter on an incombustible wall without holes, etc. Mounting it to or near combustible material can cause a fire.
- If the inverter has become faulty, switch off the inverter power. A continuous flow of large current could cause a fire.
- When using a brake resistor, make up a sequence that will turn off power when an alarm signal is output. Otherwise, the brake resistor may excessively overheat due to damage of the brake transistor and such, causing a fire.
- Do not connect a resistor directly to the DC terminals P/+, N/-. This could cause a fire.

## **ACAUTION**

- Apply only the voltage specified in the instruction manual to each terminal. Otherwise, burst, damage, etc. may
- Ensure that the cables are connected to the correct terminals. Otherwise, burst, damage, etc. may occur.
- Always make sure that polarity is correct to prevent damage, etc. Otherwise, burst, damage, etc. may occur.
- While power is on or for some time after power-off, do not touch the inverter as they will be extremely hot. Doing so can cause burns

#### 4. Additional Instructions

Also note the following points to prevent an accidental failure, injury, electric shock, etc.

#### (1) Transportation and mounting

## **ACAUTION**

- Transport the product using the correct method that corresponds to the weight. Failure to observe this could lead to injuries.
- Do not stack the inverter boxes higher than the number recommended.
- Ensure that installation position and material can withstand the weight of the inverter. Install according to the information in the instruction manual.
- Do not install or operate the inverter if it is damaged or has parts missing.
- When carrying the inverter, do not hold it by the front cover; it may fall off or fail.
- Do not stand or rest heavy objects on the product.
- Check the inverter mounting orientation is correct.
- Prevent other conductive bodies such as screws and metal fragments or other flammable substance such as oil from entering the inverter.
- As the inverter is a precision instrument, do not drop or subject it to impact.
- Use the brake unit under the following environmental conditions: Otherwise, the inverter may be damaged.

	Ambient Temperature	-10°C to +50°C (non-freezing)
<u>.</u>	Ambient humidity	90%RH maximum (non-condensing)
nvironment	Storage temperature	-20°C to +65°C *1
nviro	Atmosphere	Indoors (free from corrosive gas, flammable gas, oil mist, dust and dirt)
ш	Altitude/ vibration	Maximum 1000m above sea level for standard operation. After that derate by 3% for every extra 500m up to 2500m (91%). 5.9m/s <sup>2</sup> or less

\*1 Temperature applicable for a short time, e.g. in transit.

#### (2) Wiring

## **ACAUTION**

- Do not install a power factor correction capacitor or surge suppressor/capacitor type filter on the inverter output side.
- The connection orientation of the output cables U, V, W to the motor will affect the direction of rotation of the motor.

#### (3) Trial run

### **ACAUTION**

 Before starting operation, confirm and adjust the parameters. A failure to do so may cause some machines to make unexpected motions.

#### (4) Usage

## **MARNING**

- When you have chosen the retry function, stay away from the equipment as it will restart suddenly after trip.
- Since (STOP) is valid only when functions are set (Refer to page 173), provide a circuit and switch separately to make an emergency stop (power off, mechanical brake operation for emergency stop, etc).
- Make sure that the start signal is off before resetting the inverter alarm. A failure to do so may restart the motor suddenly.
- The load used should be a three-phase induction motor only.
   Connection of any other electrical equipment to the inverter output may damage the equipment.
- Do not modify the equipment.
- Do not perform parts removal which is not instructed in this manual. Doing so may lead to fault or damage of the product.

## **⚠CAUTION**

- The electronic thermal relay function does not guarantee protection of the motor from overheating.
- Do not use a magnetic contactor on the inverter input for frequent starting/stopping of the inverter.
- Use a noise filter to reduce the effect of electromagnetic interference. Otherwise nearby electronic equipment may be affected.
- Take measures to suppress harmonics. Otherwise power supply harmonics from the inverter may heat/damage the power factor correction capacitor and generator.
- When a 400V class motor is inverter-driven, please use an insulation-enhanced motor or measures taken to suppress surge voltages. Surge voltages attributable to the wiring constants may occur at the motor terminals, deteriorating the insulation of the motor.
- When parameter clear or all parameter clear is performed, reset the required parameters before starting operations.
   Each parameter returns to the initial value.
- The inverter can be easily set for high-speed operation.
   Before changing its setting, fully examine the performances of the motor and machine.
- In addition to the inverter's holding function, install a holding device to ensure safety.
- Before running an inverter which had been stored for a long period, always perform inspection and test operation.
- For prevention of damage due to static electricity, touch nearby metal before touching this product to eliminate static electricity from your body.

## (5) Emergency stop

## **ACAUTION**

- Provide a safety backup such as an emergency brake which will prevent the machine and equipment from hazardous conditions if the inverter fails.
- When the breaker on the inverter input side trips, check for the wiring fault (short circuit), damage to internal parts of the inverter, etc. Identify the cause of the trip, then remove the cause and power on the breaker.
- When any protective function is activated, take the appropriate corrective action, then reset the inverter, and resume operation.

## (6) Maintenance, inspection and parts replacement

## **⚠CAUTION**

 Do not carry out a megger (insulation resistance) test on the control circuit of the inverter.

#### (7) Disposal

## **ACAUTION**

• Treat as industrial waste.

#### **General instruction**

Many of the diagrams and drawings in this Instruction Manual show the inverter without a cover, or partially open. Never operate the inverter in this manner. Always replace the cover and follow this Instruction Manual when operating the inverter.

1	OUT	LINE	1
1	l.1 P	roduct checking and parts identification	2
1	l.2 lr	nverter and peripheral devices	3
	1.2.1	Peripheral devices	
1	l.3 R	emoval and reinstallation of the cover	
	1.3.1 1.3.2	Front cover Wiring cover	
4		· ·	
		nstallation of the inverter and enclosure design	
	1.4.1 1.4.2	Inverter installation environment	
	1.4.3	Inverter placement	
2	WIR	·	13
	VVII		
2	2.1 W	/iring	14
	2.1.1	Terminal connection diagram	14
2	2.2 N	lain circuit terminal specifications	15
	2.2.1	Specification of main circuit terminal	15
	2.2.2	Terminal arrangement of the main circuit terminal, power supply and the motor wiring	15
	2.2.3	Cables and wiring length	16
2	2.3 C	ontrol circuit specifications	19
	2.3.1	Standard control circuit terminal	19
	2.3.2	Changing the control logic	22
	2.3.3	Wiring of control circuit	
	2.3.4	Wiring instructions	
	2.3.5	Connection to the PU connector	26
2	2.4 C	onnection of stand-alone option unit	28
	2.4.1	Connection of a dedicated external brake resistor (FR-ABR)	20
	2.4.2	Connection of the brake unit (FR-BU2)	
	2.4.3	Connection of the high power factor converter (FR-HC)	
	2.4.4	Connection of the power regeneration common converter (FR-CV)	32
	2.4.5	Connection of a DC reactor (FR-HEL)	32
3	PRE	CAUTIONS FOR USE OF THE INVERTER	33
3	3.1 E	MC and leakage currents	34

3.1.1	Leakage currents and countermeasures	
3.1.2	EMC measures	
3.1.3	Power supply harmonics	38
3.2 I	nstallation of power factor improving reactor	39
3.3 F	Power-off and magnetic contactor (MC)	40
3.4 I	nverter-driven 400V class motor	41
3.5 F	Precautions for use of the inverter	42
3.6 F	Failsafe of the system which uses the inverter	44
4 PAR	AMETERS	47
4.1	Operation panel	48
4.1.1	Names and functions of the operation panel	48
4.1.2	Basic operation (factory setting)	49
4.1.3	Easy operation mode setting (easy setting mode)	50
4.1.4	Change the parameter setting value	51
4.1.5	Setting dial push	51
4.2 F	Parameter list	52
4.2.1	Parameter list	52
4.3	Control mode	73
4.3.1	Change the control method (Pr. 80, Pr. 81, Pr. 800)	74
4.4	Adjust the output torque (current) of the motor	75
4.4.1	Manual torque boost (Pr. 0, Pr. 46)	75
4.4.2	Advance magnetic flux vector control (Pr. 71, Pr. 80, Pr. 81, Pr.89, Pr. 800)	
4.4.3	General-purpose magnetic flux vector control (Pr. 71, Pr. 80, Pr. 81, Pr. 800)	
4.4.4	Slip compensation (Pr. 245 to Pr. 247)	
4.4.5	Stall prevention operation (Pr. 22, Pr. 23, Pr. 48, Pr. 66, Pr. 156, Pr. 157, Pr. 277)	
4.5 L	imit the output frequency	86
4.5.1	Maximum/minimum frequency (Pr. 1, Pr. 2, Pr. 18)	86
4.5.2	Avoid mechanical resonance points (frequency jumps) (Pr. 31 to Pr. 36)	
	Set V/F pattern	
	•	
4.6.1 4.6.2	Base frequency, voltage (Pr. 3, Pr. 19, Pr. 47)  Load pattern selection (Pr. 14)	
	requency setting by external terminals	
4.7.1	Operation by multi-speed operation (Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239)	
4.7.2	Jog operation (Pr. 15, Pr. 16)	94

4.7.3	Remote setting function (Pr. 59)	96
	etting of acceleration/deceleration time and acceleration/	
de	eceleration pattern	99
4.8.1	Setting of the acceleration and deceleration time (Pr. 7, Pr. 8, Pr. 20, Pr. 21, Pr. 44, Pr. 45, Pr. 147)	99
4.8.2	Starting frequency and start-time hold function (Pr. 13, Pr. 571)	102
4.8.3	Acceleration/deceleration pattern (Pr. 29)	103
4.8.4	Shortest acceleration/deceleration (automatic acceleration/deceleration) (Pr. 61 to Pr. 63, Pr. 292, Pr. 293)	104
4.9 S	election and protection of a motor	106
4.9.1	Motor overheat protection (Electronic thermal O/L relay) (Pr. 9, Pr. 51)	106
4.9.2	Applied motor (Pr. 71, Pr. 450)	108
4.9.3	To exhibit the best performance of the motor performance (offline auto tuning) (Pr. 71, Pr. 80 to Pr. 84, Pr. 90 to Pr. 94, Pr. 96, Pr. 859)	110
4.10 M	otor brake and stop operation	118
4.10.1	DC injection brake (Pr. 10 to Pr. 12)	118
4.10.2		
4.10.3		
4.10.4	Stop-on contact control function (Pr. 6, Pr. 48, Pr. 270, Pr. 275, Pr. 276)	122
4.10.5	Brake sequence function (Pr. 278 to Pr. 283, Pr. 292)	
4.11 Fu	unction assignment of external terminal and control	128
4.11.1	Input terminal function selection (Pr. 178 to Pr. 184)	128
4.11.2	Inverter output shutoff signal (MRS signal, Pr. 17)	130
4.11.3	Condition selection of function validity by second function selection signal (RT)	131
4.11.4	Start signal operation selection (STF, STR, STOP signal, Pr. 250)	132
4.11.5	Output terminal function selection (Pr. 190 to Pr. 192)	134
4.11.6	Detection of output frequency (SU, FU signal, Pr. 41 to Pr. 43)	138
4.11.7	Output current detection function (Y12 signal, Y13 signal, Pr. 150 to Pr. 153)	139
4.11.8	Remote output selection (REM signal, Pr. 495 to Pr. 497)	141
4.12 M	onitor display and monitor output signal	142
4.12.1	Speed display and speed setting (Pr. 37)	142
4.12.2	Monitor display selection of DU/PU and terminal AM (Pr. 52, Pr.158, Pr. 170, Pr. 171, Pr. 268, Pr. 563, Pr. 564)	143
4.12.3	Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)	148
4.12.4	Terminal AM calibration (calibration parameter Pr. 645, C1 (Pr.901))	149
	peration selection at power failure and instantaneous power	
4.13.1	Automatic restart after instantaneous power failure/flying start	
	(Pr. 30, Pr. 57, Pr. 58, Pr. 96, Pr. 162, Pr. 165, Pr. 298, Pr. 299, Pr. 611)	
4.13.2	Power-failure deceleration stop function (Pr. 261)	157

4.14 U	peration setting at fault occurrence	157
4.14.1	Retry function (Pr. 65, Pr. 67 to Pr. 69)	159
4.14.2	Input/output phase loss protection selection (Pr. 251, Pr. 872)	161
4.14.3	Earth (ground) fault detection at start (Pr. 249)	161
4.15 E	nergy saving operation	162
4.15.1	Optimum excitation control (Pr. 60)	162
4.16 M	otor noise, EMI measures, mechanical resonance	163
4.16.1	PWM carrier frequency and soft-PWM control (Pr. 72, Pr. 240)	163
	Speed smoothing control (Pr. 653)	
4.17 Fı	requency setting by analog input (terminal 2, 4)	165
4.17.1	Analog input selection (Pr. 73, Pr. 267)	165
4.17.2	Response level of analog input and noise elimination (Pr. 74)	167
4.17.3	Bias and gain of frequency setting voltage (current) (Pr. 125, Pr. 126, Pr. 241, C2 (Pr. 902) to C7 (Pr. 905))	168
4.18 M	isoperation prevention and parameter setting restriction	
4.18.1	Reset selection/disconnected PU detection/PU stop selection (Pr. 75)	
4.18.2		
4.18.3	· · · · ·	
4.18.4	Extended parameter display and user group function (Pr. 160, Pr. 172 to Pr. 174)	
4.19 S	election of operation mode and operation location	180
4.19.1	Operation mode selection (Pr. 79)	180
4.19.2	Operation mode at power-on (Pr. 79, Pr. 340)	190
4.19.3	Start command source and frequency command source during communication operation (Pr. 338, Pr. 339, Pr. 550, Pr. 551)	191
4.20 C	ommunication operation and setting	197
4.20.1	Wiring and configuration of PU connector	
4.20.2		107
	(Pr. 117 to Pr. 120, Pr. 123, Pr. 124, Pr. 549)	200
4.20.3		
4.20.4	Communication EEPROM write selection (Pr. 342)	
4.20.5	Mitsubishi inverter protocol (computer link communication)	205
4.20.6	Modbus RTU communication specifications (Pr. 117, Pr. 118, Pr. 120, Pr. 122, Pr. 343, Pr. 502, Pr. 549)	217
4.20.7	USB communication (Pr. 547, Pr. 548)	230
4.21 S	pecial operation and frequency control	231
4.21.1	PID control (Pr. 127 to Pr. 134)	231
4.21.2	Dancer control (Pr. 44, Pr. 45, Pr. 128 to Pr. 134)	238
4.21.3	Droop control (Pr. 286 to Pr. 287)	244
4.21.4	Regeneration avoidance function (Pr. 665, Pr. 882, Pr. 883, Pr. 885, Pr. 886)	245

<ul> <li>4.22.1 Cooling fan operation selection (Pr. 244)</li></ul>	
	247
4.22.3 Maintenance timer alarm (Pr. 503, Pr. 504)	248
	252
4.22.4 Current average value monitor signal (Pr. 555 to Pr. 557)	253
4.22.5 Free parameter (Pr. 888, Pr. 889)	255
4.23 Setting from the parameter unit and operation panel	. 256
4.23.1 RUN key rotation direction selection (Pr. 40)	256
4.23.2 PU display language selection(Pr.145)	256
4.23.3 Operation panel frequency setting/key lock operation selection (Pr. 161)	257
4.23.4 Magnitude of frequency change setting (Pr. 295)	259
4.23.5 Buzzer control (Pr. 990)	260
4.23.6 PU contrast adjustment (Pr. 991)	260
4.24 Parameter clear/ All parameter clear	. 261
4.25 Initial value change list	. 262
4.26 Check and clear of the faults history	. 263
TROUBLESHOOTING	265
5.1 Reset method of protective function	266
5.2 List of fault or alarm indications	
5.3 Causes and corrective actions	268
5.4 Correspondences between digital and actual characters	276
5.5 Check first when you have some troubles	277
5.5.1 Motor will not start	277
5.5.2 Motor generates abnormal noise	277
5.5.3 Motor generates heat abnormally	278
5.5.4 Motor rotates in opposite direction	278
5.5.5 Speed greatly differs from the setting	278
5.5.5 Speed greatly differs from the setting	278
5.5.6 Acceleration/deceleration is not smooth	
	278
5.5.6 Acceleration/deceleration is not smooth	
5.5.6 Acceleration/deceleration is not smooth	278
5.5.6 Acceleration/deceleration is not smooth	278 279
5.5.6 Acceleration/deceleration is not smooth	278 279 279
5.5.6 Acceleration/deceleration is not smooth  5.5.7 Motor current is large	278 279 279 279

6.1 li	nspection items	282
6.1.1	Daily inspection	282
6.1.2	Periodic inspection	282
6.1.3	Daily and periodic inspection	283
6.1.4	Display of the life of the inverter parts	284
6.1.5	Checking the inverter and converter modules	284
6.1.6	Cleaning	284
6.1.7	Replacement of parts	285
6.1.8	Inverter replacement	288
6.2 N	leasurement of main circuit voltages, currents and powers	s 289
6.2.1	Measurement of powers	291
6.2.2	Measurement of voltages and use of PT	291
6.2.3	Measurement of currents	292
6.2.4	Use of CT and transducer	292
6.2.5	Measurement of inverter input power factor	292
6.2.6	Measurement of converter output voltage (across terminals P-N)	292
6.2.7	Insulation resistance test using megger	293
6.2.8	Pressure test	293
7 SPE	CIFICATIONS	295
7.1 R	eating	296
7.1.1	Inverter rating	296
	· ·	
	common specifications	291
7.3 C	Outline dimension drawings	298
APPEN	DIX	301
Append	dix1 For customers who have replaced the conventional model with this inverter	302
Apper	dix 1-1 Replacement of the FR-E500 series	302
Annend	liv2 Index	304

## **MEMO**

# 1 / OUTLINE

# This chapter explains the "OUTLINE" for use of this product. Always read the instructions before using the equipment


1.1	Product checking and parts identification	2
	Inverter and peripheral devices	
	Removal and reinstallation of the cover	
1.4	Installation of the inverter and enclosure design	. 7

<abbreviations></abbreviations>	
PU	Operation panel and parameter unit (FR-PU04/FR-PU07)
Inverter	Mitsubishi inverter FR-E700 series
FR-E700	Mitsubishi inverter FR-E700 series
Pr	Parameter number
PU operation	Operation using the PU (operation panel/FR-PU04/FR-PU07)
External operation	Operation using the control circuit signals
Combined operation	Operation using both the PU (operation panel/FR-PU04/FR-
ļ F	PU07) and external operation
Operation panel for E500, PA02 F	FR-E500 series operation panel (FR-PA02-02)
Mitsubishi standard motor	SF-JR
Mitsubishi constant-torque motor S	SF-HRCA

#### <Trademarks>

- Microsoft and Visual C++ are registered trademarks of Microsoft Corporation in the United States and/or other countries.
- LonWorks® is a registered trademark of Echelon Corporation in the U.S.A and other countries.
- DeviceNet® is a registered trademark of ODVA (Open DeviceNet Vender Association, Inc.).
- Company and product names herein are the trademarks and registered trademarks of their respective owners.

## <Mark>





**NOTE** :Contents requiring caution or cases when set functions are not

activated are stated.



**POINT** :Useful contents and points are stated.

**Parameters referred to**: related parameters are stated.

2

3

ŀ

5


6

7

## 1.1 Product checking and parts identification

Unpack the inverter and check the capacity plate on the front cover and the rating plate on the inverter side face to ensure that the product agrees with your order and the inverter is intact.

#### ●Inverter type



Location of the capacity plate and the rating plate differs according to the inverter capacity.
 Refer to the outline dimension drawing. (Refer to page 298)


#### Accessory

• Fan cover fixing screws (M3 × 35mm)
These screws are necessary for compliance with the European Directive (*Refer to Installation Guideline*)

Туре	Number
FR-E740-040 to 095	1
FR-E740-120 to 300	2



## 1.2 Inverter and peripheral devices



## NOTE

- Do not install a power factor correction capacitor, surge suppressor or capacitor type filter on the inverter output side. This will cause the inverter to trip or the capacitor and surge suppressor to be damaged. If any of the above devices are connected, immediately remove them.
- Electromagnetic wave interference
   The input/output (main circuit) of the inverter includes high frequency components, which may interfere with the communication devices (such as AM radios) used near the inverter. In this case, install the FR-BIF optional capacitor type filter (for use in the input side only) or FR-BSF01 or FR-BLF common mode filter to minimize interference. (Refer to page 36).
- · Refer to the instruction manual of each option and peripheral devices for details of peripheral devices.


## 1.2.1 Peripheral devices

Check the inverter type of the inverter you purchased. Appropriate peripheral devices must be selected according to the capacity.

Refer to the following list and prepare appropriate peripheral devices:

	Incomes Tone	Motor	Moulded Case Circuit Breaker (MCCB) *1 or Earth Leakage Circuit Breaker (ELB) *4 Reactor connection		Magnetic Contactor (MC) *5	
	Inverter Type	Output (kW)			Reactor connection	
			without	with	without	with
	FR-E740-016	0.4	30AF 5A	30AF 5A	S-N10	S-N10
	FR-E740-026	0.75	30AF 5A	30AF 5A	S-N10	S-N10
400V	FR-E740-040	1.5	30AF 10A	30AF 10A	S-N10	S-N10
se 4	FR-E740-060	2.2	30AF 15A	30AF 10A	S-N10	S-N10
ha	FR-E740-095	3.7	30AF 20A	30AF 15A	S-N10	S-N10
e-P	FR-E740-120	5.5	30AF 30A	30AF 20A	S-N20	S-N11, S-N12
Three-P	FR-E740-170	7.5	30AF 30A	30AF 30A	S-N20	S-N20
	FR-E740-230	11	50AF 50A	50AF 40A	S-N20	S-N20
	FR-E740-300	15	100AF 60A	50AF 50A	S-N25	S-N20

<sup>\*1 •</sup>Select an MCCB according to the power supply capacity.



<sup>\*2</sup> When the inverter capacity is larger than the motor capacity, select an MCCB and a magnetic contactor according to the inverter type and cable and reactor according to the motor output.

When using the MC for emergency stop during motor driving or using on the motor side during commercial-power supply operation, select the MC with class AC-3 rated current for the motor rated current.

<sup>•</sup>Install one MCCB per inverter.

<sup>\*3</sup> When the breaker on the inverter primary side trips, check for the wiring fault (short circuit), damage to internal parts of the inverter, etc. Identify the cause of the trip, then remove the cause and power on the breaker.

<sup>\*4</sup> For installations in the United States or Canada, use the class T type fuse certified by the UL and cUL.

<sup>\*5</sup> Magnetic contactor is selected based on the AC-1 class. The electrical durability of magnetic contactor is 500,000 times. When the magnetic contactor is used for emergency stop during motor driving, the electrical durability is 25 times.


## 1.3 Removal and reinstallation of the cover


## 1.3.1 Front cover

#### FR-E740-170 or less

## ●Removal (Example of FR-E740-095)


Remove the front cover by pulling it toward you in the direction of arrow.






## ● Reinstallation (Example of FR-E740-095)

To reinstall, match the cover to the inverter front and install it straight.







## FR-E740-230, 300

## ●Removal (Example of FR-E740-230)

- 1) Loosen the installation screws of the front cover 1.
- 2) Remove the front cover 1 by pulling it toward you in the direction of arrow.
- 3) Remove the front cover 2 by pulling it toward you in the direction of arrow.








### **NOTE**

- Fully make sure that the front cover has been reinstalled securely.
- The same serial number is printed on the capacity plate of the front cover and the rating plate of the inverter. Since
  these plates have the same serial numbers, always reinstall the removed cover onto the original inverter.

## 1.3.2 Wiring cover

#### Removal and reinstallation

The cover can be removed easily by pulling it toward you. To reinstall, fit the cover to the inverter along the guides.





## 1.4 Installation of the inverter and enclosure design

When an inverter panel is to be designed and manufactured, heat generated by contained equipment, etc., the environment of an operating place, and others must be fully considered to determine the panel structure, size and equipment layout. The inverter unit uses many semiconductor devices. To ensure higher reliability and long period of operation, operate the inverter in the ambient environment that completely satisfies the equipment specifications.

#### 1.4.1 Inverter installation environment

As the inverter installation environment should satisfy the standard specifications indicated in the following table, operation in any place that does not meet these conditions not only deteriorates the performance and life of the inverter, but also causes a failure. Refer to the following points and take adequate measures.

#### **Environmental standard specifications of inverter**

Item	Description
Ambient temperature	-10 to +50°C (non-freezing)
Ambient humidity	90%RH maximum (non-condensing)
Atmosphere	Free from corrosive and explosive gases, free from dust and dirt
Maximum altitude	1,000m or less
Vibration	5.9m/s <sup>2</sup> or less

### (1) Temperature

The permissible ambient temperature of the inverter is between -10 and +50°C. Always operate the inverter within this temperature range. Operation outside this range will considerably shorten the service lives of the semiconductors, parts, capacitors and others. Take the following measures so that the ambient temperature of the inverter falls within the specified range.

- 1) Measures against high temperature
  - Use a forced ventilation system or similar cooling system. (Refer to page 9)
  - · Install the panel in an air-conditioned electrical chamber.
  - · Block direct sunlight.
  - Provide a shield or similar plate to avoid direct exposure to the radiated heat and wind of a heat source.
  - · Ventilate the area around the panel well.
- 2) Measures against low temperature
  - Provide a space heater in the enclosure.
  - Do not power off the inverter. (Keep the start signal of the inverter off.)
- 3) Sudden temperature changes
  - Select an installation place where temperature does not change suddenly.
  - Avoid installing the inverter near the air outlet of an air conditioner.
  - If temperature changes are caused by opening/closing of a door, install the inverter away from the door.

## (2) Humidity

Normally operate the inverter within the 45 to 90% range of the ambient humidity. Too high humidity will pose problems of reduced insulation and metal corrosion. On the other hand, too low humidity may produce a spatial electrical breakdown. The insulation distance specified in JEM1103 "Control Equipment Insulator" is defined as humidity 45 to 85%.

- 1) Measures against high humidity
  - Make the panel enclosed, and provide it with a hygroscopic agent.
  - Take dry air into the enclosure from outside.
  - · Provide a space heater in the enclosure.
- 2) Measures against low humidity

What is important in fitting or inspection of the unit in this status is to discharge your body (static electricity) beforehand and keep your body from contact with the parts and patterns, besides blowing air of proper humidity into the panel from outside.

3) Measures against condensation

Condensation may occur if frequent operation stops change the in-panel temperature suddenly or if the outside-air temperature changes suddenly.

Condensation causes such faults as reduced insulation and corrosion.

- Take the measures against high humidity in 1).
- Do not power off the inverter. (Keep the start signal of the inverter off.)

## Installation of the inverter and enclosure design

## (3) Dust, dirt, oil mist

Dust and dirt will cause such faults as poor contact of contact points, reduced insulation or reduced cooling effect due to moisture absorption of accumulated dust and dirt, and in-panel temperature rise due to clogged filter. In the atmosphere where conductive powder floats, dust and dirt will cause such faults as malfunction, deteriorated insulation and short circuit in a short time.

Since oil mist will cause similar conditions, it is necessary to take adequate measures.

#### Countermeasures

- Place in a totally enclosed enclosure.
  - Take measures if the in-enclosure temperature rises. (Refer to page 9)
- Purge air.

Pump clean air from outside to make the in-panel pressure higher than the outside-air pressure.

## (4) Corrosive gas, salt damage

If the inverter is exposed to corrosive gas or to salt near a beach, the printed board patterns and parts will corrode or the relays and switches will result in poor contact.

In such places, take the measures given in Section 3.

## (5) Explosive, flammable gases

As the inverter is non-explosion proof, it must be contained in an explosion proof enclosure. In places where explosion may be caused by explosive gas, dust or dirt, an enclosure cannot be used unless it structurally complies with the guidelines and has passed the specified tests. This makes the enclosure itself expensive (including the test charges). The best way is to avoid installation in such places and install the inverter in a non-hazardous place.

#### (6) Highland

Use the inverter at the altitude of within 1000m. If it is used at a higher place, it is likely that thin air will reduce the cooling effect and low air pressure will deteriorate dielectric strength.

## (7) Vibration, impact

The vibration resistance of the inverter is up to 5.9m/s<sup>2</sup> at 10 to 55Hz frequency and 1mm amplitude. Vibration or impact, if less than the specified value, applied for a long time may make the mechanism loose or cause poor contact to the connectors. Especially when impact is imposed repeatedly, caution must be taken as the part pins are likely to break.

#### Countermeasures

- · Provide the panel with rubber vibration isolators.
- Strengthen the structure to prevent the panel from resonance.
- Install the panel away from sources of vibration.



## 1.4.2 Cooling system types for inverter panel

From the panel that contains the inverter, the heat of the inverter and other equipment (transformers, lamps, resistors, etc.) and the incoming heat such as direct sunlight must be dissipated to keep the in-panel temperature lower than the permissible temperatures of the in-panel equipment including the inverter.


The cooling systems are classified as follows in terms of the cooling calculation method.

- 1) Cooling by natural heat dissipation from the enclosure surface (totally enclosed type)
- 2) Cooling by heat sink (aluminum fin, etc.)
- 3) Cooling by ventilation (forced ventilation type, pipe ventilation type)
- 4) Cooling by heat exchanger or cooler (heat pipe, cooler, etc.)

	Cooling System	Panel Structure	Comment
Netural	Natural ventilation (enclosed, open type)	INV	Low in cost and generally used, but the panel size increases as the inverter capacity increases. For relatively small capacities.
Natural cooling	Natural ventilation (totally enclosed type)	INV	Being a totally enclosed type, the most appropriate for hostile environment having dust, dirt, oil mist, etc. The panel size increases depending on the inverter capacity.
Forced cooling	Fin cooling	Heatsink NV	Having restrictions on the heatsink mounting position and area, and designed for relative small capacities.
	Forced ventilation		For general indoor installation. Appropriate for panel downsizing and cost reduction, and often used.
	Heat pipe	Heat pipe	Totally enclosed type for panel downsizing.

## 1.4.3 Inverter placement


## (1) Installation of the inverter Enclosure surface mounting






#### NOTE


- When encasing multiple brake units, install them in parallel as a cooling measure.
- · Install the inverter vertically.




#### (2) Clearances around inverter

To ensure ease of heat dissipation and maintenance, leave at least the shown clearances around the inverter. At least the following clearances are required under the inverter as a wiring space, and above the inverter as a heat dissipation space.






Leave enough clearances and take cooling measures.



\* When using the inverters at the ambient temperature of 40°C or less, the inverters can be installed without any clearance between them (0cm clearance).

When ambient temperature exceeds 40°C, clearances between the inverters should be 1cm or more (5cm or more for the FR-E740-120 or more).



\* 5cm or more for the FR-E740-120 or more

## (3) Inverter mounting orientation

Mount the inverter on a wall as specified. Do not mount it horizontally or any other way.

## (4) Above inverter

Heat is blown up from inside the inverter by the small fan built in the unit. Any equipment placed above the inverter should be heat resistant.



## (5) Arrangement of multiple inverters

When multiple inverters are placed in the same enclosure, generally arrange them horizontally as shown in the right figure (a). When it is inevitable to arrange them vertically to minimize space, take such measures as to provide guides since heat from the bottom inverters can increase the temperatures in the top inverters, causing inverter failures.


When mounting multiple inverters, fully take caution not to make the ambient temperature of the inverter higher than the permissible value by providing ventilation and increasing the panel size.

## Inverter Inverter Inverter Guide Guide Guide Inverter Inverter Enclosure Enclosure (b) Vertical arrangement (a) Horizontal arrangement

#### Arrangement of multiple inverters

#### Arrangement of ventilation fan and inverter (6)

Heat generated in the inverter is blown up from the bottom of the unit as warm air by the cooling fan. When installing a ventilation fan for that heat, determine the place of ventilation fan installation after fully considering an air flow. (Air passes through areas of low resistance. Make an airway and airflow plates to expose the inverter to cool air.)



Placement of ventilation fan and inverter

## **MEMO**

2 WIRING

This chapter describes the basic "WIRING" for use of this product.

Always read the instructions before using the equipment

2.1	Wiring	14
	Main circuit terminal specifications	
	Control circuit specifications	
	Connection of stand-alone ontion unit	

2

3

ļ

5


6

7

## 2.1 Wiring

## 2.1.1 Terminal connection diagram

●Three-phase 400V power input



## 7

## NOTE

- To prevent a malfunction caused by noise, separate the signal cables more than 10cm from the power cables.
- After wiring, wire offcuts must not be left in the inverter.
  - Wire offcuts can cause an alarm, failure or malfunction. Always keep the inverter clean. When drilling mounting holes in an enclosure etc., take care not to allow chips and other foreign matter to enter the inverter.




## 2.2 Main circuit terminal specifications

## 2.2.1 Specification of main circuit terminal

Terminal	Terminal Name	Description			
Symbol	Terminai Name	Description			
R/L1,		Connect to the commercial power supply.			
S/L2,	AC power input	Keep these terminals open when using the high power factor converter (FR-HC) or			
T/L3		power regeneration common converter (FR-CV).			
U, V, W	Inverter output Connect a three-phase squirrel-cage motor.				
P/+, PR	Brake resistor connection	Connect a brake transistor (FR-ABR) across terminals P/+-PR.			
P/+, N/-	Brake unit connection	Connect the brake unit (FR-BU2), power regeneration common converter (FR-CV)			
F/+, IN/-	Brake unit connection	or high power factor converter (FR-HC).			
P/+, P1	DC reactor connection	Remove the jumper across terminals P/+-P1 and connect a DC reactor.			
	Earth (Ground)	For earthing (grounding) the inverter chassis. Must be earthed (grounded).			

# 2.2.2 Terminal arrangement of the main circuit terminal, power supply and the motor wiring

#### 400V class





### **NOTE**

- Make sure the power cables are connected to the R/L1, S/L2, T/L3. Never connect the power cable to the U, V, W of the inverter. Doing so will damage the inverter. (Phase need not be matched.)
- Connect the motor to U, V, W. Turning on the forward rotation switch (signal) at this time rotates the motor counterclockwise when viewed from the load shaft.

## 2.2.3 Cables and wiring length

### (1) Applied wire size

Select the recommended cable size to ensure that a voltage drop will be 2% max.

If the wiring distance is long between the inverter and motor, a main circuit cable voltage drop will cause the motor torque to decrease especially at the output of a low frequency.

The following table indicates a selection example for the wiring length of 20m.

### 400V class (when input power supply is 440V)

			Crit	mnina	Cable Size							
Applicable Inverter	Terminal Screw Size *4		Crimping Terminal		HIV Cables, etc. (mm <sup>2</sup> ) *1			AWG *2		PVC Cables, etc. (mm <sup>2</sup> )		
Model			R/L1		R/L1		Earth	R/L1		R/L1		Earth
			S/L2 T/L3	U, V, W	S/L2 T/L3	U, V, W	(ground) cable	S/L2 T/L3	U, V, W	S/L2 T/L3	U, V, W	(ground) cable
			I/L3		I/L3		Cable	I/L3		I/L3		Cable
FR-E740-016 to 095	M4	1.5	2-4	2-4	2	2	2	14	14	2.5	2.5	2.5
FR-E740-120	M4	1.5	5.5-4	2-4	3.5	2	3.5	12	14	4	2.5	4
FR-E740-170	M4	1.5	5.5-4	5.5-4	3.5	3.5	3.5	12	12	4	4	4
FR-E740-230	M4	1.5	5.5-4	5.5-4	5.5	5.5	8	10	10	6	6	10
FR-E740-300	M5	2.5	8-5	8-5	8	8	8	8	8	10	10	10

- \*1 The cable size is that of the cable (HIV cable (600V class 2 vinyl-insulated cable) etc.) with continuous maximum permissible temperature of 75°C. Assumes that the ambient temperature is 50°C or less and the wiring distance is 20m or less.
- \*2 The recommended cable size is that of the cable (THHW cable) with continuous maximum permissible temperature of 75°C. Assumes that the ambient temperature is 40°C or less and the wiring distance is 20m or less.

  (Selection example for use mainly in the United States.)
- \*3 The recommended cable size is that of the cable (THHW cable) with continuous maximum permissible temperature of 70°C. Assumes that the ambient temperature is 40°C or less and the wiring distance is 20m or less.

  (Selection example for use mainly in Europe.)
- \*4 The terminal screw size indicates the terminal size for R/L1, S/L2, T/L3, U, V, W, and a screw for earthing (grounding).



#### NOTE

- Tighten the terminal screw to the specified torque. A screw that has been tighten too loosely can cause a short circuit
  or malfunction. A screw that has been tighten too tightly can cause a short circuit or malfunction due to the unit
  breakage.
- · Use crimping terminals with insulation sleeve to wire the power supply and motor.

The line voltage drop can be calculated by the following formula:

line voltage drop [V]= 
$$\frac{\sqrt{3} \times \text{wire resistance}[\text{m}\Omega/\text{m}] \times \text{wiring distance}[\text{m}] \times \text{current}[\text{A}]}{1000}$$

Use a larger diameter cable when the wiring distance is long or when it is desired to decrease the voltage drop (torque reduction) in the low speed range.



### (2) Earthing (Grounding) precautions

- Always earth (ground) the motor and inverter.
  - 1) Purpose of earthing (grounding)

Generally, an electrical apparatus has an earth (ground) terminal, which must be connected to the ground before use. An electrical circuit is usually insulated by an insulating material and encased. However, it is impossible to manufacture an insulating material that can shut off a leakage current completely, and actually, a slight current flow into the case. The purpose of earthing (grounding) the case of an electrical apparatus is to prevent operator from getting an electric shock from this leakage current when touching it.

To avoid the influence of external noises, this earthing (grounding) is important to audio equipment, sensors, computers and other apparatuses that handle low-level signals or operate very fast.

2) Earthing (grounding) methods and earthing (grounding) work


As described previously, earthing (grounding) is roughly classified into an electrical shock prevention type and a noise-affected malfunction prevention type. Therefore, these two types should be discriminated clearly, and the following work must be done to prevent the leakage current having the inverter's high frequency components from entering the malfunction prevention type earthing (grounding):


(a)Where possible, use independent earthing (grounding) for the inverter. If independent earthing (grounding) (I) is impossible, use joint earthing (grounding) (II) where the inverter is connected with the other equipment at an earthing (grounding) point. Joint earthing (grounding) as in (III) must be avoided as the inverter is connected with the other equipment by a common earth (ground) cable.


Also a leakage current including many high frequency components flows in the earth (ground) cables of the inverter and inverter-driven motor. Therefore, they must use the independent earthing (grounding) method and be separated from the earthing (grounding) of equipment sensitive to the aforementioned noises.

In a tall building, it will be a good policy to use the noise malfunction prevention type earthing (grounding) with steel frames and carry out electric shock prevention type earthing (grounding) in the independent earthing (grounding) method.

- (b)This inverter must be earthed (grounded). Earthing (Grounding) must conform to the requirements of national and local safety regulations and electrical codes. (NEC section 250, IEC 536 class 1 and other applicable standards). Use an neutral-point earthed (grounded) power supply for 400V class inverter in compliance with EN standard.
- (c)Use the thickest possible earth (ground) cable. The earth (ground) cable should be of not less than the size indicated in the table on the previous page 16.
- (d)The grounding point should be as near as possible to the inverter, and the ground wire length should be as short as possible.
- (e)Run the earth (ground) cable as far away as possible from the I/O wiring of equipment sensitive to noises and run them in parallel in the minimum distance.










### POINT

To be compliant with the European Directive (Low Voltage Directive), Prefer to the Installation Guideline.

## (3) Total wiring length

The overall wiring length for connection of a single motor or multiple motors should be within the value in the table below.

Pr. 72 PWM frequency selection Setting (carrier frequency)	016	026	040	060	095 or More
1 (1kHz) or less	200m	200m	300m	500m	500m
2 to15 (2kHz to 14.5kHz)	30m	100m	200m	300m	500m



When driving a 400V class motor by the inverter, surge voltages attributable to the wiring constants may occur at the motor terminals, deteriorating the insulation of the motor.(*Refer to page 86*)



#### **NOTE**

- Especially for long-distance wiring, the inverter may be affected by a charging current caused by the stray capacitances of the wiring, leading to a malfunction of the overcurrent protective function, fast response current limit function, or stall prevention function or a malfunction or fault of the equipment connected on the inverter output side. If fast-response current limit malfunctions, disable this function. When the stall prevention function misoperates, increase the stall level. (Refer to page 82 for Pr. 22Stall prevention operation level and Pr. 156 Stall prevention operation selection)
- Refer to page 163 for details of *Pr. 72 PWM frequency selection*. Refer to the manual of the option for details of surge voltage suppression filter (FR-ASF-H/FR-BMF-H).
- When using the automatic restart after instantaneous power failure function with wiring length exceeding than 100m, select without frequency search (Pr. 162 = "1, 11"). (Refer to page 151)



## 2.3 Control circuit specifications

## 2.3.1 Standard control circuit terminal

indicates that terminal functions can be selected using *Pr. 178 to Pr. 184*, *Pr. 190 to Pr. 192* (*I/O terminal function selection*). (*Refer to page 128*).

## (1) Input signal

Туре	Terminal Symbol	Terminal Name	Descrip	tion	Rated Specifications	Refer to Page
	STF	Forward rotation start	Turn on the STF signal to start forward rotation and turn it off to stop.	When the STF and STR signals are turned on		132
	STR	Reverse rotation start	Turn on the STR signal to start reverse rotation and turn it off to stop.	simultaneously, the stop command is given.		132
	RH, RM, RL	Multi-speed selection	Multi-speed can be selected a combination of RH, RM and R		Input resistance 4.7kΩ Voltage when contacts are open	92
	MRS	Output stop	Turn on the MRS signal (20minverter output. Use to shut off the inverter output motor by electromagnetic brain	tput when stopping the	21 to 26VDC When contacts are short- circuited 4 to 6mADC	130
Contact input	RES	Reset	Used to reset fault output provous Turn on the RES signal for mooff. Factory setting is for reset always reset can be set to enabled on Recover about 1s after reset is	ore than 0.1s, then turn it ways. By setting <i>Pr. 75</i> , nly at fault occurrence.		173
Conta	SD	Contact input common (sink)	Common terminal for contact logic).	input terminal (sink		
		External transistor common (source) (initial setting)	When connecting the transistre output), such as a programma source logic is selected, conn supply common for transistor prevent a malfunction caused	able controller, when ect the external power output to this terminal to	_	_
		24VDC power supply common	Common output terminal for 2 supply (PC terminal). Isolated from terminals 5 and	·		
	PC	External transistor common (sink)	When connecting the transistor output), such as a programma logic is selected, connect the common for transistor output the a malfunction caused by under	able controller, when sink external power supply to this terminal to prevent	when sink er supply Power supply voltage range 22 to 26VDC	
		Contact input common (source) (initial setting)	Common terminal for contact logic).	input terminal (source	100mA	
<u> </u>		24VDC power supply	Can be used as 24VDC 0.1A	power supply.		

Туре	Terminal Symbol	Terminal Name	Description	Rated Specifications	Refer to Page
	10	Frequency setting power supply	Used as power supply when connecting potentiometer for frequency setting (speed setting) from outside of the inverter. (Refer to Pr.73 Analog input selection.)	5.2V ± 0.2VDC permissible load current 10mA	165
Frequency setting	2	Frequency setting (voltage)	Inputting 0 to 5VDC (or 0 to 10V) provides the maximum output frequency at 5V (10V) and makes input and output proportional. Use <i>Pr</i> 73 to switch		165
	4	Frequency setting (current)	Inputting 4 to 20mADC (or 0 to 5V, 0 to 10V) provides the maximum output frequency at 20mA and makes input and output proportional. This input signal is valid only when the AU signal is on (terminal 2 input is invalid). Use <i>Pr.</i> 267 to switch from among input 4 to 20mA (initial setting), 0 to 5VDC and 0 to 10VDC. Set the voltage/current input switch in the "V" position to select voltage input (0 to 5V/0 to 10V).	Current input: Input resistance $233\Omega \pm 5\Omega$ Maximum permissible current 30mA Voltage input: Input resistance10k $\Omega \pm 1k\Omega$ Permissible maximum voltage 20VDC Current input (initial status) Voltage input	165
	5	Frequency setting common	Common terminal for frequency setting signal (terminal 2 or 4) and analog output terminal AM. Do not earth (ground).	_	_

NOTE

Set Pr. 267 and a voltage/current input switch correctly, then input analog signals in accordance with the settings. Applying a voltage with voltage/current input switch in "I" position (current input is selected) or a current with switch in "V" position (voltage input is selected) could cause component damage of the inverter or analog circuit of output devices. Refer to page 165 for details.




## (2) Output signal

Туре	Terminal Symbol	Terminal Name	Descrip	tion	Rated Specifications	Reference Page
Relay	A, B, C	Relay output (fault output)	1 changeover contact output inc protective function has activated Fault: discontinuity across B-C ( Normal: continuity across B-C (	d and the output stopped. continuity across A-C),	Contact capacity:230VAC 0.3A (power factor =0.4) 30VDC 0.3A	134
ctor	RUN	Inverter running	Switched low when the inverter output frequency is equal to or higher than the starting frequency (initial value 0.5Hz).  Switched high during stop or DC injection brake operation.*		Permissible load 24VDC (maximum 27VDC) 0.1A (a voltage drop is 3.4V maximum when the signal is on)	134
Open collector	FU	Frequency detection	Switched low when the inverter or higher than the preset detected less than the preset detected free	<ul> <li>Low indicates that the open collector output transistor is on (conducts).</li> <li>High indicates that the transistor is off (does not conduct).</li> </ul>	138	
	SE	Open collector output common	Common terminal of terminal RI	JN and FU.	_	_
Analog	АМ	Analog signal output	Select one e.g. output frequency from monitor items. Not output during inverter reset. The output signal is proportional to the magnitude of the corresponding monitoring item.	Output item: Output frequency (initial setting)	Output signal 0 to 10VDC Permissible load current 1mA (load impedance 10kΩ or more) Resolution 8 bit	143

## (3) Communication

Туре	Terminal Symbol	Terminal Name	Description	Reference Page
RS-485	-	PU connector	With the PU connector, communication can be made through RS-485.  • Conforming standard: EIA-485 (RS-485)  • Transmission format: Multidrop link  • Communication speed: 4800 to 38400bps  • Overall length: 500m	197
USB	_	USB connector	The FR Configurator can be operated by connecting the inverter to the personnel computer through USB.  Interface: conforms to USB1.1 Transmission speed: 12Mbps Connector: USB mini B connector (receptacle mini B type)	230

## 2.3.2 Changing the control logic



The input signals are set to source logic (SOURCE) when shipped from the factory.

To change the control logic, the jumper connector above the control terminal must be moved to the other position.

•To change to sink logic, change the jumper connector in the source logic (SOURCE) position to sink logic (SINK) position using tweezers, a pair of long-nose pliers etc. Change the jumper connector position before switching power on.



#### NOTE


- Fully make sure that the front cover has been reinstalled securely.
- The capacity plate is placed on the front cover and the rating plate is on the inverter. Since these plates have the same serial numbers, always reinstall the removed cover onto the original inverter.
- The sink-source logic change-over jumper connector must be fitted in only one of those positions. If it is fitted in both positions at the same time, the inverter may be damaged.



- (1) Sink logic type and source logic type
  - In sink logic, a signal switches on when a current flows from the corresponding signal input terminal.

    Terminal SD is common to the contact input signals. Terminal SE is common to the open collector output signals.
  - In source logic, a signal switches on when a current flows into the corresponding signal input terminal.


    Terminal PC is common to the contact input signals. Terminal SE is common to the open collector output signals.
- Current flow concerning the input/output signal when sink logic is selected
- Current flow concerning the input/output signal when source logic is selected



- •When using an external power supply for transistor output
- Use terminal PC as a common terminal, and perform wiring as shown below. (Do not connect terminal SD of the inverter with terminal 0V of the external power supply. When using terminals PC-SD as a 24VDC power supply,


Sink logic type

When using terminals PC-SD as a 24VDC power supply, do not install an external power supply in parallel with the inverter. Doing so may cause a malfunction in the inverter due to undesirable currents.)



Source logic type


Use terminal SD as a common terminal, and perform wiring as shown below. (Do not connect terminal PC of the inverter with terminal +24V of the external power supply. When using terminals PC-SD as a 24VDC power supply, do not install an external power supply in parallel with the inverter. Doing so may cause a malfunction in the inverter due to undesirable currents.)



## 2.3.3 Wiring of control circuit

## (1) Standard control circuit terminal layout


Terminal screw size
M3: (Terminal A, B, C)
M2: (Other than the above)



### (2) Wiring method

1) Strip off the sheath of the cable of the control circuit to wire.

Strip off the sheath about the size below. If the length of the sheath peeled is too long, a short circuit may occur among neighboring wires. If the length is too short, wires might come off.



Wire the stripped cable after twisting it to prevent it from becoming loose. In addition, do not solder it. Use a bar terminal as necessary.

	L(mm)
Terminal A, B, C	6
Other than the above	5

Introduced products on bar terminals

Terminal Screw Size	Wina Sina (mm²)	Bar Term	Maker	
Terminal Screw Size	Wire Size (mm <sup>2</sup> )	With Insulation Sleeve	Without Insulation Sleeve	Wakei
M3 (terminal A, B, C)	0.3 to 0.5	AI 0,5-6WH	A 0,5-6	Phoenix Contact
wis (terminal A, B, C)	0.5 to 0.75	AI 0,75-6GY	A 0,75-6	CoLtd.
M2 (other than the above)	0.3 to 0.5	AI 0,5-6WH	A 0,5-6	Co.,Lia.

Bar terminal crimping tool: CRIMPFOX ZA3 (Phoenix Contact Co., Ltd.)

- 2) Loosen the terminal screw and insert the cable into the terminal.
- 3) Tighten the screw to the specified torque.

Undertightening can cause cable disconnection or malfunction. Overtightening can cause a short circuit or malfunction due to damage to the screw or unit.

Tightening torque: 0.5N·m to 0.6N·m (terminal A, B, C)

0.22N·m to 0.25N·m (other than the above)

#### (3) Control circuit common terminals (PC, 5, SE)

Terminals PC, SE and 5 are common terminals for I/O signals.(All common terminals are isolated from each other.) Do not earth them. Avoid connecting the terminal PC and 5 and the terminal SE and 5.

Terminal PC is a common terminal for the contact input terminals (STF, STR, RH, RM, RL, MRS, RES). The open collector circuit is isolated from the internal control circuit by photocoupler


Terminal 5 is a common terminal for the frequency setting signals (terminals 2 or 4) and analog signal output (AM). It should be protected from external noise using a shielded or twisted cable.

Terminal SE is a common terminal for the open collector output terminal (RUN, FU). The contact input circuit is isolated from the internal control circuit by photocoupler

<sup>\*</sup> Screwdriver:  $\bigcirc$ Small flathead screwdriver (Tip thickness: 0.4mm/tip width: 2.5mm)

## (4) Signal inputs by contactless switches

The contacted input terminals of the inverter (STF, STR, RH, RM, RL, MRS, RES) can be controlled using a transistor instead of a contacted switch as shown on the right.



External signal input using transistor

## 2.3.4 Wiring instructions

- 1) Use shielded or twisted cables for connection to the control circuit terminals and run them away from the main and power circuits (including the 200V relay sequence circuit).
- 2) Use two or more parallel micro-signal contacts or twin contacts to prevent contact faults when using contact inputs since the control circuit input signals are micro-currents.






Twin contacts

- 3) Do not apply a voltage to the contact input terminals (e.g. STF) of the control Micro signal contacts circuit.
- 4) Always apply a voltage to the fault output terminals (A, B, C) via a relay coil, lamp, etc.
- 5) It is recommended to use the cables of 0.3mm<sup>2</sup> to 0.75mm<sup>2</sup> gauge for connection to the control circuit terminals.

  If the cable gauge used is 1.25mm<sup>2</sup> or more, the front cover may be lifted when there are many cables running or the cables are run improperly, resulting in an operation panel contact fault.
- 6) The maximum wiring length should be 30m.

#### 2.3.5 Connection to the PU connector


Using the PU connector, you can perform communication operation from the FR-PU07, a personal computer etc. Refer to the figure below to open the PU connector cover.



#### •When connecting the parameter unit using a connection cable

Use the optional FR-CB2□□ or connector and cable available on the market.

Insert the cable plugs securely into the PU connector of the inverter and the connection connector of the FR-PU07 along the guide until the tabs snap into place.



#### > REMARKS

- Overall wiring length when the parameter unit is connected: max 20m
- Refer to the following when fabricating the cable on the user side.

Examples of product available on the market (as of September, 2006)

	Product	Туре	Maker
1)	10BASE-T cable	SGLPEV-T 0.5mm × 4P	Mitsubishi Cable Industries, Ltd.




#### ●RS-485 communication

When the PU connector is connected with a personal, FA or other computer by a communication cable, a user program can run and monitor the inverter or read and write to parameters.

The protocol can be selected from Mitsubishi inverter and Modbus RTU.

#### · PU connector pin-outs



Pin Number	Name	Description	
1)	SG	Earth (ground)	
''	30	(connected to terminal 5)	
2)	_	Parameter unit power supply	
3)	RDA	Inverter receive+	
4)	SDB	Inverter send-	
5)	SDA	Inverter send+	
6)	RDB	Inverter receive-	
7)	SG	Earth (ground)	
7)	36	(connected to terminal 5)	
8)	_	Parameter unit power supply	



#### **NOTE**

- Pins No. 2 and 8 provide power to the operation panel or parameter unit. Do not use these pins for RS-485 communication.
- When making RS-485 communication between the FR-E700 series, FR-E500 series and FR-S500 series, incorrect
  connection of pins No.2 and 8 (parameter unit power supply) of the above PU connector may result in the inverter
  malfunction or failure.
- Do not connect the PU connector to the computer's LAN board, FAX modem socket or telephone modular connector.

  The product could be damaged due to differences in electrical specifications.

For further details, refer to page 197.

•Conforming standard: EIA-485 (RS-485)

•Transmission form: Multidrop link

•Communication speed: Maximum 38400 bps

•Overall extension: 500m

#### 2.4 Connection of stand-alone option unit

The inverter accepts a variety of stand-alone option units as required.

Incorrect connection will cause inverter damage or accident. Connect and operate the option unit carefully in accordance with the corresponding option unit manual.

#### 2.4.1 Connection of a dedicated external brake resistor (FR-ABR)

Install a dedicated brake resistor (FR-ABR) outside when the motor is made to run by the load, quick deceleration is required, etc. Connect a dedicated brake resistor (FR-ABR) to terminal P/+ and PR.

(For the locations of terminal P/+ and PR, refer to the terminal block layout (page 15).) Set parameters below.

Connected Brake Resistor	Pr. 30 Regenerative function selection Setting	Pr. 70 Special regenerative brake duty Setting		rake duty Setting
FR-ABR 1	1	FR-E740-170 or less	10%	Refer to page 119
	1	FR-E740-230 or more	6%	Kejer to page 119



#### **NOTE**

The brake resistor connected should only be the dedicated brake resistor.


FR-E740-016 to 095	FR-E740-120 to 300
Connect the brake resistor across terminals P/+ and PR.	Connect the brake resistor across terminals P/+ and PR.
Jumper *1 Terminal PR Brake resistor	Jumper *1*2  Terminal P/+  Terminal PR  Brake resistor

- \*1 Do not remove a jumper across terminal P/+ and P1 except when connecting a DC reactor.
- \*2 The shape of jumper differs according to capacities.




#### (1) When using the high-duty brake resistor (FR-ABR)

• It is recommended to configure a sequence, which shuts off power in the input side of the inverter by the external thermal relay as shown below, to prevent overheat and burnout of the high duty brake resistor (FR-ABR) in case the regenerative brake transistor is damaged.



- \*1 Refer to the table below for the type number of each capacity of thermal relay and the diagram below for the connection.
- \*2 When the power supply is 400V class, install a step-down transformer.

Power Supply Voltage	High-duty Brake Resistor	Thermal Relay Type (Mitsubishi product)	Contact Rating
	FR-ABR-H0.4K	TH-N20CXHZ-0.24A	
	FR-ABR-H0.75K	TH-N20CXHZ-0.35A	
	FR-ABR-H1.5K	TH-N20CXHZ-0.9A	110VAC 5A, 220VAC 2A(AC11 class) 110VDC 0.5A,
	FR-ABR-H2.2K	TH-N20CXHZ-1.3A	
400V	FR-ABR-H3.7K	TH-N20CXHZ-2.1A	
	FR-ABR-H5.5K	TH-N20CXHZ-2.5A	
	FR-ABR-H7.5K	TH-N20CXHZ-3.6A	220VDC 0.25A(DC11 class)
	FR-ABR-H11K	TH-N20CXHZ-6.6A	
	FR-ABR-H15K	TH-N20CXHZ-6.6A	






- Brake resistor can not be used with the brake unit, high power factor converter, power supply regeneration converter, etc.
- Do not use the brake resistor with a lead wire extended.
- Do not connect a resistor directly to the DC terminals P/+ and N/-. This could cause a fire.

#### 2.4.2 Connection of the brake unit (FR-BU2)

Connect the brake unit (FR-BU2(-H)) as shown below to improve the braking capability at deceleration. If the transistors in the brake unit should become faulty, the resistor can be unusually hot. To prevent unusual overheat and fire, install a magnetic contactor on the inverter's input side to configure a circuit so that a current is shut off in case of fault.

#### (1) Connection example with the GRZG type discharging resistor



- \*1 Connect the inverter terminals (P/+, N/-) and brake unit (FR-BU2) terminals so that their terminal names match with each other.
  - (Incorrect connection will damage the inverter and brake unit.)
- \*2 When the power supply is 400V class, install a step-down transformer.
- \*3 The wiring distance between the inverter, brake unit (FR-BU2) and discharging resistor should be within 5m. Even when the wiring is twisted, the cable length must not exceed 10m.
- \*4 It is recommended to install an external thermal relay to prevent overheat of brake resistors.


#### <Recommended external thermal relay>

Brake Unit	Discharging Posister	Recommended External
Brake Unit	Unit Discharging Resistor	Thermal Relay
FR-BU2-1.5K	GZG 300W-50Ω	TH-N20CXHZ 1.3A
FR-BU2-3.7K	GRZG 200-10Ω	TH-N20CXHZ 3.6A
FR-BU2-7.5K	GRZG 300-5Ω	TH-N20CXHZ 6.6A
FR-BU2-15K	GRZG 400-2Ω	TH-N20CXHZ 1.1A
FR-BU2-H7.5K	GRZG 200-10Ω	TH-N20CXHZ 3.6A
FR-BU2-H15K	GRZG 300-5Ω	TH-N20CXHZ 6.6A



- Set "1" in Pr. 0 Brake mode selection of the FR-BU2 to use GRZG type discharging resistor.
- Do not remove a jumper across terminal P/+ and P1 except when connecting a DC reactor.

#### (2) Connection example with the FR-BR(-H) type resistor



- \*1 Connect the inverter terminals (P/+, N/-) and brake unit (FR-BU2) terminals so that their terminal names match with
  - (Incorrect connection will damage the inverter and brake unit.)
- \*2 When the power supply is 400V class, install a step-down transformer.
- \*3 The wiring distance between the inverter, brake unit (FR-BU2) and resistor unit (FR-BR) should be within 5m. Even when the wiring is twisted, the cable length must not exceed 10m.
- \*4 Normal: across TH1-TH2...close, Alarm: across TH1-TH2...open
- \*5 A jumper is connected across BUE and SD in the initial status.




#### NOTE

• Do not remove a jumper across terminal P/+ and P1 except when connecting a DC reactor.

#### 2.4.3 Connection of the high power factor converter (FR-HC)

When connecting the high power factor converter (FR-HC) to suppress power harmonics, perform wiring securely as shown below. Incorrect connection will damage the high power factor converter and inverter.




\*1 Do not insert an MCCB between the terminals P/+-N/- (between P-P/+, between N-N/-). Opposite polarity of terminals N/-, P/+ will damage the inverter.



- The voltage phases of terminals R/L1, S/L2, T/L3 and terminals R4, S4, T4 must be matched.
- Use sink logic when the FR-HC is connected. The FR-HC cannot be connected when source logic (factory setting) is selected.
- Do not remove a jumper across terminal P/+ and P1 except when connecting a DC reactor.

#### 2.4.4 Connection of the power regeneration common converter (FR-CV)

When connecting the power regeneration common converter (FR-CV), connect the inverter terminals (P/+, N/-) and power regeneration common converter (FR-CV) terminals as shown below so that their symbols match with each other.



- \*1 Always keep the power input terminals R/L1, S/L2, T/L3 open. Incorrect connection will damage the inverter.
- \*2 Do not insert an MCCB between the terminals P/+-N/- (between P/L+-P/+, between N/L--N/-). Opposite polarity of terminals N/-, P/+ will damage the inverter.
- \*3 Always connect the power supply and terminals R/L11, S/L21, T/MC1. Operating the inverter without connecting them will damage the power regeneration common converter.




#### NOTE

- The voltage phases of terminals R/L11, S/L21, T/MC1 and terminals R2/L1, S2/L2, T2/L3 must be matched.
- Use sink logic when the FR-CV is connected. The FR-CV cannot be connected when source logic (factory setting) is selected.
- Do not remove a jumper across terminal P/+ and P1.

#### 2.4.5 Connection of a DC reactor (FR-HEL)

When using the DC reactor (FR-HEL), connect it across terminals P/+-P1.

In this case, the jumper connected across terminals P/+-P1 must be removed. Otherwise, the reactor will not exhibit its performance.





- · The wiring distance should be within 5m.
- The size of the cables used should be equal to or larger than that of the power supply cables (R/L1, S/L2, T/L3). (Refer to page 16)

# PRECAUTIONS FOR USE OF THE INVERTER

This chapter explains the "PRECAUTIONS FOR USE OF THE INVERTER" for use of this product.

Always read the instructions before using the equipment

3.1	EMC and leakage currents	34
3.2	Installation of power factor improving reactor	39
3.3	Power-off and magnetic contactor (MC)	40
3.4	Inverter-driven 400V class motor	41
3.5	Precautions for use of the inverter	42
3.6	Failsafe of the system which uses the inverter	44

2

•

.

5

6

7

#### 3.1 EMC and leakage currents

#### 3.1.1 Leakage currents and countermeasures

Capacitances exist between the inverter I/O cables, other cables and earth and in the motor, through which a leakage current flows. Since its value depends on the static capacitances, carrier frequency, etc., low acoustic noise operation at the increased carrier frequency of the inverter will increase the leakage current. Therefore, take the following measures. Select the earth leakage current breaker according to its rated sensitivity current, independently of the carrier frequency setting.

#### (1) To-earth (ground) leakage currents

Leakage currents may flow not only into the inverter's own line but also into the other lines through the earth (ground) cable, etc. These leakage currents may operate earth (ground) leakage circuit breakers and earth leakage relays unnecessarily.

#### Suppression technique

- If the carrier frequency setting is high, decrease the *Pr. 72 PWM frequency selection* setting.

  Note that motor noise increases. Selecting *Pr. 240 Soft-PWM operation selection* makes the sound inoffensive.
- By using earth leakage circuit breakers designed for harmonic and surge suppression in the inverter's own line and other line, operation can be performed with the carrier frequency kept high (with low noise).
- •To-earth (ground) leakage currents
  - Take caution as long wiring will increase the leakage current. Decreasing the carrier frequency of the inverter reduces the leakage current.
  - Increasig the motor capacity increases the leakage current.


#### (2) Line-to-line leakage currents

Harmonics of leakage currents flowing in static capacitances between the inverter output cables may operate the external thermal relay unnecessarily. When the wiring length is long (50m or more) for the 400V class small-capacity model (FR-E740-170 or less), the external thermal relay is likely to operate unnecessarily because the ratio of the leakage current to the rated motor current increases.

#### •Line-to-line leakage current data example

Motor Capacity	Rated Motor	Leakage Current (mA)		
(kW)	Current (A)	Wiring length 50m	Wiring length 100m	
0.4	1.1	620	1000	
0.75	1.9	680	1060	
1.5	3.5	740	1120	
2.2	4.1	800	1180	
3.7	6.4	880	1260	
5.5	9.7	980	1360	
7.5	12.8	1070	1450	

Dedicated motor SF-JR 4P
Carrier frequency: 14.5kHz
Used wire: 2mm<sup>2</sup>, 4 cores
Cabtyre cable



Line-to-line leakage currents path

#### Measures

- Use Pr. 9 Electronic thermal O/L relay.
- If the carrier frequency setting is high, decrease the Pr. 72 PWM frequency selection setting.
   Note that motor noise increases. Selecting Pr. 240 Soft-PWM operation selection makes the sound inoffensive.
   To ensure that the motor is protected against line-to-line leakage currents, it is recommended to use a temperature sensor to directly detect motor temperature.
- Installation and selection of moulded case circuit breaker

Install a moulded case circuit breaker (MCCB) on the power receiving side to protect the wiring of the inverter input side. Select the MCCB according to the inverter input side power factor (which depends on the power supply voltage, output frequency and load). Especially for a completely electromagnetic MCCB, one of a slightly large capacity must be selected since its operation characteristic varies with harmonic currents. (Check it in the data of the corresponding breaker.) As an earth leakage current breaker, use the Mitsubishi earth leakage current breaker designed for harmonics and surge suppression.




#### (3) Selection of rated sensitivity current of earth (ground) leakage current breaker


When using the earth leakage current breaker with the inverter circuit, select its rated sensitivity current as follows, independently of the PWM carrier frequency.

- Breaker designed for harmonic and surge suppression
   Rated sensitivity current:
   I∆n≥10×(Ig1+Ign+Igi+Ig2+Igm)
- Standard breaker
   Rated sensitivity current:
   I∆n≥10×{Ig1+Ign+Igi+3×(Ig2+Igm)}
- lg1, lg2: Leakage currents in wire path during commercial power supply operation
- Ign:Leakage current of inverter input side noise filter
- Igm:Leakage current of motor during commercial power supply operation
- Igi:Leakage current of inverter unit

Example of leakage current per 1km during the commercial power supply operation when the CV cable is routed in metal conduit (Three-phase three-wire delta connection 400V60Hz)




Example of leakage current of threephase induction motor during the commercial power supply operation (Totally-enclosed fan-cooled type motor 400V60Hz)



For "  $\not\downarrow$  " connection, the amount of leakage current is appox.1/3 of the above value.

#### <Example>



	Breaker Designed for Harmonic and Surge Suppression	Standard Breaker	
Leakage current lg1 (mA)	$\frac{1}{3} \times 66 \times \frac{5m}{1000m} = 0.11$		
Leakage current Ign (mA)	0 (without noise filter)		
Leakage current Igi (mA)	1		
Leakage current lg2 (mA)	$\frac{1}{3} \times 66 \times \frac{60}{100}$	)m = 1.32	
Leakage current ig2 (IIIA)	$\frac{1}{3}$ $^{600}$ $^{6}$ 1000m		
Motor leakage current Igm (mA)	0.36		
Total leakage current (mA)	2.79	6.15	
Rated sensitivity current (mA) (≥ Ig × 10)	30	100	




- Install the earth leakage breaker (ELB) on the input side of the inverter.
- In the connection earthed-neutral system, the sensitivity current is blunt against an earth (ground) fault in the
  inverter output side. Earthing (Grounding) must conform to the requirements of national and local safety regulations
  and electrical codes. (NEC section 250, IEC 536 class 1 and other applicable standards)
- When the breaker is installed on the output side of the inverter, it may be unnecessarily operated by harmonics even if the effective value is less than the rating.
- In this case, do not install the breaker since the eddy current and hysteresis loss will increase, leading to temperature rise.
- General products indicate the following models. ..... BV-C1, BC-V, NVB, NV-L, NV-G2N, NV-G3NA, NV-2F earth leakage relay (except NV-ZHA), NV with AA neutral wire open-phase protection
  - The other models are designed for harmonic and surge suppression ....NV-C/NV-S/MN series, NV30-FA, NV50-FA, BV-C2, earth leakage alarm breaker (NF-Z), NV-ZHA, NV-H


#### 3.1.2 EMC measures

Some electromagnetic noises enter the inverter to malfunction it and others are radiated by the inverter to malfunction peripheral devices. Though the inverter is designed to have high immunity performance, it handles low-level signals, so it requires the following basic techniques. Also, since the inverter chops outputs at high carrier frequency, that could generate electromagnetic noises. If these electromagnetic noises cause peripheral devices to malfunction, EMI measures should be taken to suppress noises. These techniques differ slightly depending on EMI paths.

- (1) Basic techniques
  - Do not run the power cables (I/O cables) and signal cables of the inverter in parallel with each other and do not bundle them.
  - Use twisted shield cables for the detector connecting and control signal cables and connect the sheathes of the shield cables to terminal SD.
  - Earth (Ground) the inverter, motor, etc. at one point.
- (2) Techniques to reduce electromagnetic noises that enter and malfunction the inverter (Immunity measures) When devices that generate many electromagnetic noises (which use magnetic contactors, magnetic brakes, many relays, for example) are installed near the inverter and the inverter may be malfunctioned by electromagnetic noises, the following measures must be taken:
  - Provide surge suppressors for devices that generate many electromagnetic noises to suppress electromagnetic noises.
  - Fit data line filters (page 37) to signal cables.
  - · Earth (Ground) the shields of the detector connection and control signal cables with cable clamp metal.
- (3) Techniques to reduce electromagnetic noises that are radiated by the inverter to malfunction peripheral devices (EMI measures)

Inverter-generated electromagnetic noises are largely classified into those radiated by the cables connected to the inverter and inverter main circuits (I/O), those electromagnetically and electrostatically induced to the signal cables of the peripheral devices close to the main circuit power supply, and those transmitted through the power supply cables.








<b>Propagation Path</b>	Measures	
	When devices that handle low-level signals and are liable to malfunction due to electromagnetic noises, e.g.	
	instruments, receivers and sensors, are contained in the enclosure that contains the inverter or when their signal	
	cables are run near the inverter, the devices may be malfunctioned by air-propagated electromagnetic noises. The	
	following measures must be taken:	
(1)(2)(3)	Install easily affected devices as far away as possible from the inverter.	
	Run easily affected signal cables as far away as possible from the inverter and its I/O cables.	
	Do not run the signal cables and power cables (inverter I/O cables) in parallel with each other and do not bundle them.	
	Insert common mode filters into I/O and capacitors between the input lines to suppress cable-radiated noises.	
	Use shield cables as signal cables and power cables and run them in individual metal conduits to produce further effects.	
	When the signal cables are run in parallel with or bundled with the power cables, magnetic and static induction noises	
	may be propagated to the signal cables to malfunction the devices and the following measures must be taken:	
(4)(5)(6)	Install easily affected devices as far away as possible from the inverter.	
(4)(5)(6)	Run easily affected signal cables as far away as possible from the I/O cables of the inverter.	
	Do not run the signal cables and power cables (inverter I/O cables) in parallel with each other and do not bundle them.	
	Use shield cables as signal cables and power cables and run them in individual metal conduits to produce further effects.	
	When the power supplies of the peripheral devices are connected to the power supply of the inverter in the same line,	
(7)	inverter-generated noises may flow back through the power supply cables to malfunction the devices and the	
(7)	following measures must be taken:	
	Install the common mode filter (FR-BLF, FR-BSF01) to the power cables (output cable) of the inverter.	
	When a closed loop circuit is formed by connecting the peripheral device wiring to the inverter, leakage currents may	
(8)	flow through the earth (ground) cable of the inverter to malfunction the device. In such a case, disconnection of the	
	earth (ground) cable of the device may cause the device to operate properly.	

#### Data line filter

As immunity measures it may effective, provide a data line filter for the detector cable etc.

#### **EMC** measures





For compliance with the EU EMC directive, please refer the Installation Guideline.



#### 3.1.3 Power supply harmonics

The inverter may generate power supply harmonics from its converter circuit to affect the power generator, power capacitor etc. Power supply harmonics are different from noise and leakage currents in source, frequency band and transmission path. Take the following countermeasure suppression techniques.


•The differences between harmonics and RF noises are indicated below:

Item	Harmonics	Noise	
Frequency	Normally 40th to 50th degrees or less	High frequency (several 10kHz to 1GHz order)	
requency	(up to 3kHz or less)	riigh hequency (several Tokriz to TOTIZ order)	
Environment To-electric channel, power imped		To-space, distance, wiring path	
Quantitative understanding	Theoretical calculation possible	Random occurrence, quantitative grasping difficult	
Generated amount	Nearly proportional to load capacity	Change with current variation ratio (larger as switching	
Generated amount	Nearly proportional to load capacity	speed increases)	
Affected equipment immunity Specified in standard per equipment		Different depending on maker's equipment specifications	
Suppression example Provide reactor.		Increase distance.	

#### Suppression technique

The harmonic current generated from the inverter to the input side differs according to various conditions such as the wiring impedance, whether a reactor is used or not, and output frequency and output current on the load side.

For the output frequency and output current, we understand that they should be calculated in the conditions under the rated load at the maximum operating frequency.






#### **NOTE**


The power factor improving capacitor and surge suppressor on the inverter output side may be overheated or damaged by the harmonic components of the inverter output. Also, since an excessive current flows in the inverter to activate overcurrent protection, do not provide a capacitor and surge suppressor on the inverter output side when the motor is driven by the inverter. For power factor improvement, install a reactor on the inverter input side or in the DC circuit.



#### 3.2 Installation of power factor improving reactor

When the inverter is connected near a large-capacity power transformer (500kVA or more) or when a power capacitor is to be switched over, an excessive peak current may flow in the power input circuit, damaging the converter circuit. To prevent this, always install an optional reactor (FR-HAL, FR-HEL).





When connecting the FR-HEL, remove the jumper across terminals P/+-P1.
 The wiring length between the FR-HEL and inverter should be 5m maximum and minimized.



Use the same wire size as that of the power supply wire (R/L1, S/L2, T/L3). (Refer to page 16)

#### 3.3 Power-off and magnetic contactor (MC)


#### (1) Inverter input side magnetic contactor (MC)

On the inverter input side, it is recommended to provide an MC for the following purposes. (Refer to  $page\ 4$  for selection.)

- 1) To release the inverter from the power supply when the fault occurs or when the drive is not functioning (e.g. emergency stop operation). When cycle operation or heavy-duty operation is performed with an optional brake resistor connected, overheat and burnout of the discharging resistor can be prevented if a regenerative brake transistor is damaged due to insufficient heat capacity of the discharging resistor and excess regenerative brake duty.
- 2) To prevent any accident due to an automatic restart at restoration of power after an inverter stop made by a power failure
- 3) The control power supply for inverter is always running and consumes a little power. When stopping the inverter for an extended period of time, powering off the inverter will save power slightly.
- 4) To separate the inverter from the power supply to ensure safe maintenance and inspection work. The inverter's input side MC is used for the above purpose, select class JEM1038-AC3 MC for the inverter input side current when making an emergency stop during normal operation.

#### • REMARKS

Since repeated inrush currents at power on will shorten the life of the converter circuit (switching life is about 1,000,000 times.), frequent starts and stops of the MC must be avoided. Turn on/off the inverter start controlling terminals (STF, STR) to run/stop the inverter.



#### Inverter start/stop circuit example

As shown on the right, always use the start signal (ON or OFF across terminals STF or STR-PC) to make a start or stop.

\*When the power supply is 400V class, install a step-down transformer.

#### (2) Handling of inverter output side magnetic contactor

Switch the magnetic contactor between the inverter and motor only when both the inverter and motor are at a stop. When the magnetic contactor is turned on while the inverter is operating, overcurrent protection of the inverter and such will activate. When an MC is provided for switching to the commercial power supply, for example, switch it on/off after the inverter and motor have stopped.



#### Inverter-driven 400V class motor 3.4

In the PWM type inverter, a surge voltage attributable to wiring constants is generated at the motor terminals. Especially for a 400V class motor, the surge voltage may deteriorate the insulation. When the 400V class motor is driven by the inverter, consider the following measures:

#### Measures

It is recommended to take either of the following measures:

#### (1) Rectifying the motor insulation and limiting the PWM carrier frequency according to the wiring length

For the 400V class motor, use an insulation-enhanced motor.

Specifically,

- 1) Specify the "400V class inverter-driven insulation-enhanced motor".
- 2) For the dedicated motor such as the constant-torque motor and low-vibration motor, use the "inverter-driven, dedicated
- 3) Set Pr. 72 PWM frequency selection as indicated below according to the wiring length

	Wiring Length		
	50m or less 50m to 100m exceeding 100m		
Pr. 72 PWM frequency selection	15 (14.5kHz) or less	8 (8kHz) or less	2 (2kHz) or less

#### (2) Suppressing the surge voltage on the inverter side

Connect the surge voltage suppression filter (FR-ASF-H/FR-BMF-H) on the inverter output side.



- For details of *Pr. 72 PWM frequency selection*, *refer to page 163*.

  For explanation of surge voltage suppression filter (FR-ASF-H/FR-BMF-H), refer to the manual of each option

#### 3.5 Precautions for use of the inverter

The FR-E700 series is a highly reliable product, but incorrect peripheral circuit making or operation/handling method may shorten the product life or damage the product.

Before starting operation, always recheck the following items.


- (1) Use crimping terminals with insulation sleeve to wire the power supply and motor.
- (2) Application of power to the output terminals (U, V, W) of the inverter will damage the inverter. Never perform such wiring.
- (3) After wiring, wire offcuts must not be left in the inverter.
  - Wire offcuts can cause an alarm, failure or malfunction. Always keep the inverter clean.
  - When drilling mounting holes in an enclosure etc., take care not to allow chips and other foreign matter to enter the inverter.
- (4) Use cables of the size to make a voltage drop 2% maximum.
  - If the wiring distance is long between the inverter and motor, a main circuit cable voltage drop will cause the motor torque to decrease especially at the output of a low frequency.
  - Refer to page 16 for the recommended wire sizes.
- (5) The overall wiring length should be 500m maximum.
  - Especially for long distance wiring, the fast-response current limit function may decrease or the equipment connected to the secondary side may malfunction or become faulty under the influence of a charging current due to the stray capacity of the wiring. Therefore, note the overall wiring length. (*Refer to page 18*)
- (6) Electromagnetic wave interference
  - The input/output (main circuit) of the inverter includes high frequency components, which may interfere with the communication devices (such as AM radios) used near the inverter. In this case, install the FR-BIF optional capacitor type filter (for use in the input side only) or FR-BSF01 or FR-BLF common mode filter to minimize interference.
- (7) Do not install a power factor correction capacitor, surge suppressor or capacitor type filter on the inverter output side. This will cause the inverter to trip or the capacitor and surge suppressor to be damaged. If any of the above devices are connected, immediately remove them.
- (8) Before starting wiring or other work after the inverter is operated, wait for at least 10 minutes after the power supply has been switched off, and check that there are no residual voltage using a tester or the like. The capacitor is charged with high voltage for some time after power off and it is dangerous.
- (9) A short circuit or earth (ground) fault on the inverter output side may damage the inverter modules.
  - Fully check the insulation resistance of the circuit prior to inverter operation since repeated short circuits caused by
    peripheral circuit inadequacy or an earth (ground) fault caused by wiring inadequacy or reduced motor insulation
    resistance may damage the inverter modules.
  - Fully check the to-earth (ground) insulation and phase to phase insulation of the inverter output side before power-on. Especially for an old motor or use in hostile atmosphere, securely check the motor insulation resistance etc.
- (10) Do not use the inverter input side magnetic contactor to start/stop the inverter.

  Always use the start signal (turn on/off terminals STF, STR-PC) to start/stop the inverter. (*Refer to page 40*)
- (11) Across P/+ and PR terminals, connect only an external regenerative brake discharging resistor.
  - Do not connect a mechanical brake.
    - Also, never short between these terminals.



- (12) Do not apply a voltage higher than the permissible voltage to the inverter I/O signal circuits.

  Application of a voltage higher than the permissible voltage to the inverter I/O signal circuits or opposite polarity may damage the I/O devices. Especially check the wiring to prevent the speed setting potentiometer from being connected incorrectly to short terminals 10-5.
- (13) Provide electrical and mechanical interlocks for MC1 and MC2 which are used for bypass operation. When the wiring is incorrect and if there is a bypass operation circuit as shown right, the inverter will be damaged when the power supply is connected to the inverter U, V, W terminals, due to arcs generated at the time of switch-over or chattering caused by a sequence error.



- (14) If the machine must not be restarted when power is restored after a power failure, provide a magnetic contactor in the inverter's input side and also make up a sequence which will not switch on the start signal.
  If the start signal (start switch) remains on after a power failure, the inverter will automatically restart as soon as the power is restored.
- (15) Instructions for overload operation

When performing operation of frequent start/stop of the inverter, rise/fall in the temperature of the transistor element of the inverter will repeat due to a repeated flow of large current, shortening the life from thermal fatigue. Since thermal fatigue is related to the amount of current, the life can be increased by reducing current at locked condition, starting current, etc. Decreasing current may increase the life. However, decreasing current will result in insufficient torque and the inverter may not start. Therefore, choose the inverter which has enough allowance for current (up to 2 rank larger in capacity).

- (16) Make sure that the specifications and rating match the system requirements.
- (17) When the motor speed is unstable, due to change in the frequency setting signal caused by electromagnetic noises from the inverter, take the following measures when applying the motor speed by the analog signal.
  - Do not run the signal cables and power cables (inverter I/O cables) in parallel with each other and do not bundle them.
  - Run signal cables as far away as possible from power cables (inverter I/O cables).
  - Use shield cables as signal cables.
  - Install a ferrite core on the signal cable (Example: ZCAT3035-1330 TDK).

#### 3.6 Failsafe of the system which uses the inverter

When a fault occurs, the inverter trips to output a fault signal. However, a fault output signal may not be output at an inverter fault occurrence when the detection circuit or output circuit fails, etc. Although Mitsubishi assures best quality products, provide an interlock which uses inverter status output signals to prevent accidents such as damage to machine when the inverter fails for some reason and at the same time consider the system configuration where failsafe from outside the inverter, without using the inverter, is enabled even if the inverter fails.

(1) Interlock method which uses the inverter status output signals By combining the inverter status output signals to provide an interlock as shown below, an inverter alarm can be


No	Interlock Method	Check Method	Used Signals	Refer to Page
1)	Inverter protective function operation	Operation check of an alarm contact Circuit error detection by negative logic	Fault output signal (ALM signal)	137
2)	Inverter running status	Operation ready signal check	Operation ready signal (RY signal)	136
3)	Inverter running status	Logic check of the start signal and running signal	Start signal (STF signal, STR signal) Running signal (RUN signal)	132, 136
4)	Inverter running status	Logic check of the start signal and output current	Start signal (STF signal, STR signal) Output current detection signal (Y12 signal)	132, 139

1) Check by the output of the inverter fault signal

When the fault occurs and trips the inverter, the fault output signal (ALM signal) is output (ALM signal is assigned to terminal ABC in the initial setting).

Check that the inverter functions properly.

In addition, negative logic can be set (on when the inverter is normal, off when the fault occurs).




Inverter fault occurrence

- 2) Checking the inverter operating status by the inverter operation ready completion signal
  - Operation ready signal (RY signal) is output when the inverter power is on and the inverter becomes operative.

Check if the RY signal is output after powering on the inverter.

- 3) Checking the inverter operating status by the start signal input to the inverter and inverter running signal.
  - The inverter running signal (RUN signal) is output when the inverter is running (RUN signal is assigned to terminal RUN in the initial setting).

Check if RUN signal is output when inputting the start signal to the inverter (forward signal is STF signal and reverse signal is STR signal). For logic check, note that RUN signal is output for the period from the inverter decelerates until output to the motor is stopped, configure a sequence considering the inverter deceleration time





4) Checking the motor operating status by the start signal input to the inverter and inverter output current detection signal. The output current detection signal (Y12 signal) is output when the inverter operates and currents flows in the motor. Check if Y12 signal is output when inputting the start signal to the inverter (forward signal is STF signal and reverse signal is STR signal). Note that the current level at which Y12 signal is output is set to 150% of the inverter rated current in the initial setting, it is necessary to adjust the level to around 20% using no load current of the motor as reference with *Pr.150 Output current detection level*.

For logic check, as same as the inverter running signal (RUN signal), the inverter outputs for the period from the inverter decelerates until output to the motor is stopped, configure a sequence considering the inverter deceleration time.

Output	Pr. 190 to Pr. 192 Setting					
signal	Positive logic	Negative logic				
ALM	99	199				
RY	11	111				
RUN	0	100				
Y12	12	112				

 When using various signals, assign functions to Pr.190 to Pr.192 (output terminal function selection) referring to the table on the left.



#### NOTE

• Changing the terminal assignment using *Pr. 190 to Pr. 192 (output terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.

#### (2) Backup method outside the inverter

Even if the interlock is provided by the inverter status signal, enough failsafe is not ensured depending on the failure status of the inverter itself. For example, even if the interlock is provided using the inverter fault output signal, start signal and RUN signal output, there is a case where a fault output signal is not output and RUN signal is kept output even if an inverter fault occurs.


Provide a speed detector to detect the motor speed and current detector to detect the motor current and consider the backup system such as checking up as below according to the level of importance of the system.

#### 1) Start signal and actual operation check

Check the motor running and motor current while the start signal is input to the inverter by comparing the start signal to the inverter and detected speed of the speed detector or detected current of the current detector. Note that the motor current runs as the motor is running for the period until the motor stops since the inverter starts decelerating even if the start signal turns off. For the logic check, configure a sequence considering the inverter deceleration time. In addition, it is recommended to check the three-phase current when using the current detector.

#### 2) Command speed and actual operation check

Check if there is no gap between the actual speed and commanded speed by comparing the inverter speed command and detected speed of the speed detector.



# **MEMO**

# 4 / PARAMETERS

This chapter explains the "PARAMETERS" for use of this product.

Always read the instructions before using the equipment

The abbreviations in the explanations below are as follows:

.....V/F control,

ADMFVC ......Advanced magnetic flux vector control,

GPMFVC ......General-purpose magnetic-flux vector control

(Parameters without any indication are valid for all control)

1

2

3

1

5

6

7

#### **Operation panel**

#### 4.1.1 Names and functions of the operation panel

The operation panel cannot be removed from the inverter.

#### Operation mode indication

PU: Lit to indicate PU operation mode. EXT: Lit to indicate external operation mode.

NET: Lit to indicate network operation

PU, EXT: Lit to indicate external/PU combined operation mode 1, 2.

#### **Unit indication**

Hz: Lit to indicate frequency. A: Lit to indicate current. (Off to indicate voltage and flicker to indicate set frequency monitor.)

#### Monitor (4-digit LED)

Shows the frequency, parameter number,

#### Setting dial

(Setting dial: Mitsubishi inverter dial) Used to change the frequency setting and parameter values.

Press to display the following.

- Displays the set frequency in the monitor mode
- · Currently set value is displayed during calibration
- · Displays the order in the faults history mode

#### Mode switchover

Used to change each setting mode.


Pressing (PU/EXT) simultaneously changes


the operation mode. (Refer to page 50) Pressing for a while (2s) can lock operation.

(Refer to page 257)

#### **Determination of each setting**

If pressed during operation, monitor changes as below;





#### Operating status display

Lit or flicker during inverter operation. \*

On: Indicates that forward rotation operation is being performed. Slow flickering (1.4s cycle): Reverse rotation operation Fast flickering (0.2s cycle):

When (RUN) was pressed or the start

command was given, but the operation can not be made.

- · When the start command is given and the frequency command is less than the starting frequency.
- When the MRS signal is input.

#### Parameter setting mode

Lit to indicate parameter setting mode.

#### **Monitor indication**

Lit to indicate monitoring mode.

#### Stop operation

Used to stop Run command. Fault can be reset when protective function is activated (fault).

#### Operation mode switchover

Used to switch between the PU and external operation mode.

When using the external operation mode (operation using a separately connected frequency setting potentiometer and start signal), press this key to light up the EXT indication.


(Press (MODE) simultanesouly (0.5s) (Refer

to page 50), or change Pr. 79 setting to change to combined mode .) PU: PU operation mode EXT: External operation mode Cancels PU stop also.

#### Start command

The rotation direction can be selected by setting Pr. 40.

#### 4.1.2 Basic operation (factory setting)



#### Easy operation mode setting (easy setting mode)

Setting of Pr. 79 Operation mode selection according to combination of the start command and speed command can be easily made.

Operation example

Start command: external (STF/STR), frequency command: operate with



Operation -

1. Screen at powering on The monitor display appears.

2. Press  $\left(\frac{PU}{FXT}\right)$  and  $\left(MODE\right)$  for 0.5s.



Display -

3. Turn until 79 - 3 appears. (refer to the table below for other settings)





Operation Panel Indication	Operatio	n Method
Operation Faller indication	Start command	Frequency command
Flickering  Flickering	RUN	
Flickering	External (STF, STR)	Analog voltage input
Flickering	External (STF, STR)	
Flickering	RUN	Analog voltage input

4. Press(SET) to set.







Flicker --- Parameter setting complete!! , The monitor display appears after 3s.





#### REMARKS

Er I is displayed ... Why?

Pr. 79 is not registered in user group with "1" in Pr. 160 User group read selection.

Parameter write is disabled with "1" set in Pr. 77.

E r ∂ is displayed ... Why?

Setting can not be made during operation. Turn the start switch ((RUN), STF or STR) off.


- Press (MODE) before pressing (SET) to return to the monitor display without setting. In this case, the mode changes to external operation mode when performed in the PU operation mode (PU JOG operation mode) and PU operation mode when performed in the external operation mode.
- Reset can be made with (STOP)



#### 4.1.4 Change the parameter setting value

Changing example

Change the Pr. 1 Maximum frequency setting.



" **5 [] [] []** " (50.00Hz).


7. Press (SET) to set.



Flicker...Parameter setting complete!!

- to read another parameter.
- Press (SET) to show the setting again.
- Press (SET) twice to show the next parameter.
- Press (MODE) twice to return the monitor to frequency monitor.

### • REMARKS



The number of digits displayed on the operation panel is four. Only the upper four digits of values can be displayed and set. If the values to be displayed have five digits or more including decimal places, the fifth or later numerals can not be displayed nor set. (Example) For Pr. 1

When 50Hz is set, 50.00 is displayed.

When 120Hz is set, 120.0 is displayed and second decimal place is not displayed nor set.

#### 4.1.5 Setting dial push



Push the setting dial ( ) to display the set frequency\* currently set.

<sup>\*</sup> Appears when PU operation mode or external/PU combined operation mode 1 is selected (Pr. 79 = "3").

#### 4.2.1 Parameter list

For simple variable-speed operation of the inverter, the initial setting of the parameters may be used as they are. Set the necessary parameters to meet the load and operational specifications. Parameter setting, change and check can be made from the operation panel. For details of parameters, refer to the instruction manual.

## • REMARKS

- @ indicates simple mode parameters. (initially set to extended mode)
- The parameters surrounded by a black border in the table allow its setting to be changed during operation even if "0" (initial value) is set in *Pr. 77 Parameter write selection*.

Func- tion	Parameter	Name	Setting Range	tting Range Setting Value to		Refer to Page	Customer Setting
	⊚ 0	Torque boost	0 to 30%	0.1%	6/4/3/2% *1	75	
	<b>©</b> 1	Maximum frequency	0 to 120Hz	0.01Hz	120Hz	86	
	@ 2	Minimum frequency	0 to 120Hz	0.01Hz	0Hz	86	
(A)	<b>©</b> 3	Base frequency	0 to 400Hz	0.01Hz	50Hz	88	
Basic functions	<b>©</b> 4	Multi-speed setting (high speed)	0 to 400Hz	0.01Hz	50Hz	92	
ınct	<b>©</b> 5	Multi-speed setting (middle speed)	0 to 400Hz	0.01Hz	30Hz	92	
c fu	<b>©</b> 6	Multi-speed setting (low speed)	0 to 400Hz	0.01Hz	10Hz	92	
asi	<b>©</b> 7	Acceleration time	0 to 3600/360s	0.1/0.01s	5/10/15s *2	99	
Ш	<b>®</b> 8	Deceleration time	0 to 3600/360s	0.1/0.01s	5/10/15s *2	99	
	<b>©</b> 9	Electronic thermal O/L relay	0 to 500A	0.01A	Rated inverter current	106	
tion	10	DC injection brake operation frequency	0 to 120Hz	0.01Hz	3Hz	118	
DC injection brake	11	DC injection brake operation time	0 to 10s	0.1s	0.5s	118	
20	12	DC injection brake operation voltage	0 to 30%	0.1%	4/2% *3	118	
_	13	Starting frequency	0 to 60Hz	0.01Hz	0.5Hz	102	
_	14	Load pattern selection	0 to 3	1	0	90	
JOG operation	15	Jog frequency	0 to 400Hz	0.01Hz	5Hz	94	
JC	16	Jog acceleration/deceleration time	0 to 3600/360s	0.1/0.01s	0.5s	94	
	17	MRS input selection	0, 2, 4	1	0	130	
_	18	High speed maximum frequency	120 to 400Hz	0.01Hz	120Hz	86	
_	19	Base frequency voltage	0 to 1000V, 8888, 9999	0.1V	8888	88	
Acceleration/ deceleration time	20	Acceleration/deceleration reference frequency	1 to 400Hz	0.01Hz	50Hz	99	
Accele decelera	21	Acceleration/deceleration time increments	0, 1	1	0	99	
all	22	Stall prevention operation level	0 to 200%	0.1%	150%	82	
Stall prevention	23	Stall prevention operation level compensation factor at double speed	0 to 200%, 9999	0.1%	9999	82	
D.	24	Multi-speed setting (speed 4)	0 to 400Hz, 9999	0.01Hz	9999	92	
pee	25	Multi-speed setting (speed 5)	0 to 400Hz, 9999	0.01Hz	9999	92	
Multi-speed setting	26	Multi-speed setting (speed 6)	0 to 400Hz, 9999	0.01Hz	9999	92	
Mul	27	Multi-speed setting (speed 7)	0 to 400Hz, 9999	0.01Hz	9999	92	
_	29	Acceleration/deceleration pattern selection	0, 1, 2	1	0	103	

•	Symbols in the table indicate parameters which function when an option is mounted.
	AX FR-A7AX E kit, AY FR-A7AY E kit, AR FR-A7AR E kit, NC FR-A7NC E kit, ND FR-A7ND E kit, NLFR-A7NL E kit,
	NP FR-A7NP E kit

- These instruction codes are used for parameter read and write by using Mitsubishi inverter protocol with the RS-485 communication. (Refer to page 200 for RS-485 communication)
- "O" indicates valid and "x" indicates invalid of "control mode-based correspondence table", "parameter copy", "parameter clear", and "all parameter clear".

Parameter	Remarks	Inst	ruction C	Code		trol Mode-basspondence		Parameter		er
		Read	Write	Extended	<b>_V/F</b> _	AD MFVC	GP MFVC	Сору	Clear	All clear
⊚ 0		00	80	0	0	×	×	0	0	0
<b>©</b> 1		01	81	0	0	0	0	0	0	0
© 2		02	82	0	0	0	0	0	0	0
<b>©</b> 3		03	83	0	0	×	×	0	0	0
<b>©</b> 4		04	84	0	0	0	0	0	0	0
<b>©</b> 5		05	85	0	0	0	0	0	0	0
<u>© 6</u>		06	86	0	0	0	0	0	0	0
© 7		07	87	0	0	0	0	0	0	0
<b>®</b> 8		08	88	0	0	0	0	0	0	0
<b>©</b> 9		09	89	0	0	0	0	0	0	0
10		0A	8A	0	0	0	0	0	0	0
11		0B	8B	0	0	0	0	0	0	0
12		0C	8C	0	0	0	0	0	0	0
13		0D	8D	0	0	0	0	0	0	0
14		0E	8E	0	0	×	×	0	0	0
15		0F	8F	0	0	0	0	0	0	0
16		10	90	0	0	0	0	0	0	0
17		11	91	0	0	0	0	0	0	0
18		12	92	0	0	0	0	0	0	0
19		13	93	0	0	×	×	0	0	0
20		14	94	0	0	0	0	0	0	0
21		15	95	0	0	0	0	0	0	0
22		16	96	0	0	0	0	0	0	0
23		17	97	0	0	0	0	0	0	0
24		18	98	0	0	0	0	0	0	0
25		19	99	0	0	0	0	0	0	0
26		1A	9A	0	0	0	0	0	0	0
27		1B	9B	0	0	0	0	0	0	0
29		1D	9D	0	0	0	0	0	0	0

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
_	30	Regenerative function selection	0, 1, 2	1	0	119, 151	
٩	31	Frequency jump 1A	0 to 400Hz, 9999	0.01Hz	9999	87	
Frequency jump	32	Frequency jump 1B	0 to 400Hz, 9999	0.01Hz	9999	87	
<u>ئ</u>	33	Frequency jump 2A	0 to 400Hz, 9999	0.01Hz	9999	87	
ren	34	Frequency jump 2B	0 to 400Hz, 9999	0.01Hz	9999	87	
ıbə.	35	Frequency jump 3A	0 to 400Hz, 9999	0.01Hz	9999	87	
Œ	36	Frequency jump 3B	0 to 400Hz, 9999	0.01Hz	9999	87	
_	37	Speed display	0, 0.01 to 9998	0.001	0	142	
_	40	RUN key rotation direction selection	0, 1	1	0	256	
<u>ک</u> د	41	Up-to-frequency sensitivity	0 to 100%	0.1%	10%	138	
enc	42	Output frequency detection	0 to 400Hz	0.01Hz	6Hz	138	
Frequency detection	43	Output frequency detection for reverse rotation	0 to 400Hz, 9999	0.01Hz	9999	138	
	44	Second acceleration/deceleration time	0 to 3600/360s	0.1/0.01s	5/10/15s *2	99, 238	
Suc	45	Second deceleration time	0 to 3600/360s, 9999	0.1/0.01s	9999	99, 238	
octic	46	Second torque boost	0 to 30%, 9999	0.1%	9999	75	
fur	47	Second V/F (base frequency)	0 to 400Hz, 9999	0.01Hz	9999	88	
Second functions	48	Second stall prevention operation current	0 to 200%, 9999	0.1%	9999	82	
()	51	Second electronic thermal O/L relay	0 to 500A, 9999	0.01A	9999	106	
ons	52	DU/PU main display data selection	0, 5, 7 to 12, 14, 20, 23 to 25, 52 to 57, 61, 62, 100	1	0	143	
ncti	55	Frequency monitoring reference	0 to 400Hz	0.01Hz	50Hz	148	
Monitor functions	56 Current monitoring reference		0 to 500A	0.01A	Rated inverter current	148	
utomatic restart functions	57	Restart coasting time	0, 0.1 to 5s, 9999	0.1s	9999	151	
Autom	58	Restart cushion time	0 to 60s	0.1s	1s	151	
_	59	Remote function selection	0, 1, 2, 3	1	0	96	
_	60	Energy saving control selection	0, 9	1	0	162	
eration	61	Reference current	0 to 500A, 9999	0.01A	9999	104	
Automatic acceleration /deceleration	62	Reference value at acceleration	0 to 200%, 9999	1%	9999	104	
Automa /de	63	Reference value at deceleration	0 to 200%, 9999	1%	9999	104	
_	65	Retry selection	0 to 5	1	0	159	
_	66	Stall prevention operation reduction starting frequency	0 to 400Hz	0.01Hz	50Hz	82	
	67	Number of retries at fault occurrence	0 to 10, 101 to 110	1	0	159	
Retry	68	Retry waiting time	0.1 to 360s	0.1s	1s	159	
~	69	Retry count display erase	0	1	0	159	
_	70	Special regenerative brake duty	0 to 30%	0.1%	0%	119	
_	71	Applied motor	0, 1, 3 to 6, 13 to 16, 23, 24, 40, 43, 44, 50, 53, 54	16, 23, 0, 53, 1 0 108		76, 79, 108, 110,	
	72	PWM frequency selection	0 to 15	1	1	163	
	73	Analog input selection	0, 1, 10, 11	1	1	165	
	74	Input filter time constant	0 to 8	1	1	167	

Parameter	Remarks	Inst	ruction C	ode		trol Mode-baspondence		I	Paramete	arameter	
T di diniotoi	romano	Read	Write	Extended		AD MFVC	GP-MFVC	Сору	Clear	All clear	
30		1E	9E	0	0	0	0	0	0	0	
31		1F	9F	0	0	0	0	0	0	0	
32		20	A0	0	0	0	0	0	0	0	
33		21	A1	0	0	0	0	0	0	0	
34		22	A2	0	0	0	0	0	0	0	
35		23	A3	0	0	0	0	0	0	0	
36		24	A4	0	0	0	0	0	0	0	
37		25	A5	0	0	0	0	0	0	0	
40		28	A8	0	0	0	0	0	0	0	
41		29	A9	0	0	0	0	0	0	0	
42		2A	AA	0	0	0	0	0	0	0	
43		2B	AB	0	0	0	0	0	0	0	
44		2C	AC	0	0	0	0	0	0	0	
45		2D	AD	0	0	0	0	0	0	0	
46		2E	AE	0	0	×	×	0	0	0	
47		2F	AF	0	0	×	×	0	0	0	
48		30	В0	0	0	0	0	0	0	0	
51		33	В3	0	0	0	0	0	0	0	
52		34	B4	0	0	0	0	0	0	0	
55		37	B7	0	0	0	0	0	0	0	
56		38	B8	0	0	0	0	0	0	0	
57		39	В9	0	0	0	0	0	0	0	
58		ЗА	BA	0	0	0	0	0	0	0	
59		3B	BB	0	0	0	0	0	0	0	
60		3C	BC	0	0	×	×	0	0	0	
61		3D	BD	0	0	0	0	0	0	0	
62		3E	BE	0	0	0	0	0	0	0	
63		3F	BF	0	0	0	0	0	0	0	
65		41	C1	0	0	0	0	0	0	0	
66		42	C2	0	0	0	0	0	0	0	
67		43	C3	0	0	0	0	0	0	0	
68		44	C4	0	0	0	0	0	0	0	
69		45	C5	0	0	0	0	0	0	0	
70		46	C6	0	0	0	0	0	0	0	
71		47	C7	0	0	0	0	0	0	0	
72		48	C8	0	0	0	0	0	0	0	
73		49	C9	0	0	0	0	0	×	0	
74		4A	CA	0	0	0	0	0	0	0	

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
_	75	Reset selection/disconnected PU detection/PU stop selection	0 to 3, 14 to 17	1	14	173	
_	77	Parameter write selection	0, 1, 2	1	0	176	
_	78	Reverse rotation prevention selection	0, 1, 2	1	0	177	
_	<b>©</b> 79	Operation mode selection	0, 1, 2, 3, 4, 6, 7	1	0	180, 190	
	80	Motor capacity	0.1 to 15kW, 9999	0.01kW	9999	74, 76, 79, 110	
	81	Number of motor poles	2, 4, 6, 8, 10, 9999	1	9999	74, 76, 79, 110	
	82	Motor excitation current	0 to 500A (0 to ****), 9999 *5	0.01A (1) *5	9999	110	
	83	Motor rated voltage	0 to 1000V	0.1V	400V	110	
δ	84	Rated motor frequency	10 to 120Hz	0.01Hz	50Hz	110	
onstant	89	Speed control gain (advanced magnetic flux vector)	0 to 200%, 9999	0.1%	9999	76	
Motor constants	90	Motor constant (R1)	0 to $50\Omega$ (0 to ****), 9999 *5	0.001Ω (1) *5	9999	110	
2	91	Motor constant (R2)	0 to $50\Omega$ (0 to ****) , 9999 *5	0.001Ω (1) *5	9999	110	
	92	Motor constant (L1)	0 to 1000mH (0 to 50Ω, 0 to ****), 9999 *5	0.1mH (0.001Ω, 1) *5	9999	110	
	93	Motor constant (L2)	0 to 1000mH (0 to 50Ω, 0 to ****), 9999 *5	0.1mH (0.001Ω, 1) *5	9999	110	
	94	Motor constant (X)	0 to 100% (0 to 500Ω, 0 to ****) , 9999 *5	0.1% (0.01Ω, 1) *5	9999	110	
	96	Auto tuning setting/status	0, 1, 11, 21	1	1 0 110,		
E	117	PU communication station number	0 to 31 (0 to 247)	1	0	200, 217	
unicatio	118	PU communication speed	48, 96, 192, 384	1	192	200, 217	
J W	119	PU communication stop bit length	0, 1, 10, 11	1	1	200	
PU connector communication	120	PU communication parity check	0, 1, 2	1	2	200, 217	
Dec	121	Number of PU communication retries	0 to 10, 9999	1	1	201	
U con	122	PU communication check time interval	0, 0.1 to 999.8s, 9999	0.1s	0	201, 217	
	123	PU communication waiting time setting	0 to 150ms, 9999	1	9999	200	
	124	PU communication CR/LF selection	0, 1, 2	1	1	200	
_	<b>©</b> 125	Terminal 2 frequency setting gain frequency	0 to 400Hz	0.01Hz	50Hz	168	
_	<b>©126</b>	Terminal 4 frequency setting gain frequency	0 to 400Hz	0.01Hz	50Hz	168	

Parameter	Remarks	Inst	ruction C	ode		trol Mode-ba			Paramete	eter
1 diameter	Kemarks	Read	Write	Extended		AD MFVC	GP MFVC	Сору	Clear	All clear
75		4B	СВ	0	0	0	0	0	×	×
77		4D	CD *4	0	0	0	0	0	0	0
78		4E	CE	0	0	0	0	0	0	0
<b>©</b> 79		4F	CF*4	0	0	0	0	0	0	0
80		50	D0	0	×	0	0	0	0	0
81		51	D1	0	×	0	0	0	0	0
82		52	D2	0	×	0	0	0	×	0
83		53	D3	0	×	0	0	0	0	0
84		54	D4	0	×	0	0	0	0	0
89		59	D9	0	×	0	×	0	×	0
90		5A	DA	0	0	0	0	0	×	0
91		5B	DB	0	×	0	0	0	×	0
92		5C	DC	0	×	0	0	0	×	0
93		5D	DD	0	×	0	0	0	×	0
94		5E	DE	0	×	0	0	0	×	0
96		60	E0	0	0	0	0	0	×	0
117		11	91	1	0	0	0	0	0	0
118		12	92	1	0	0	0	0	0	0
119		13	93	1	0	0	0	0	0	0
120		14	94	1	0	0	0	0	0	0

1A

9A

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments  Initial Value Refer to Page		to	Customer Setting
	127	PID control automatic switchover frequency	0 to 400Hz, 9999	0.01Hz	9999	231	
	128	PID action selection	0, 20, 21, 40 to 43, 50, 51, 60, 61	1	0	231, 238	
	129	PID proportional band	0.1 to 1000%, 9999	0.1%	100%	231, 238	
PID operation	130	PID integral time	0.1 to 3600s, 9999	0.1s	1s	231, 238	
PID op	131	PID upper limit	0 to 100%, 9999	0.1%	9999	231, 238	
	132	PID lower limit	0 to 100%, 9999	0.1%	9999	231, 238	
	133	PID action set point	0 to 100%, 9999	0.01%	9999	231, 238	
	134	PID differential time	0.01 to 10.00s, 9999	0.01s	9999	231, 238	
PU	145	PU display language selection	0 to 7	1	1	256	
_	146	Parameter for manufacturer setting. Do not set.					
_	147	Acceleration/deceleration time switching frequency	0 to 400Hz, 9999	0.01Hz	9999	99	
	150	Output current detection level	0 to 200%	0.1%	150%	139	
Current	151	Output current detection signal delay time	0 to 10s	0.1s	0s	139	
g S	152	Zero current detection level	0 to 200%	0.1%	5%	139	
	153	Zero current detection time	0 to 1s	0.01s	0.5s	139	
_	156	Stall prevention operation selection	0 to 31, 100, 101	1	0	82	
_	157	OL signal output timer	0 to 25s, 9999	0.1s	0s	82	
_	158	AM terminal function selection	1 to 3, 5, 7 to 12, 14, 21, 24, 52, 53, 61, 62	1	1	143	
_	<b>©</b> 160	User group read selection	0, 1, 9999	1	0	177	
_	161	Frequency setting/key lock operation selection	0, 1, 10, 11	1	0	257	
c restart ions	162	Automatic restart after instantaneous power failure selection	0, 1, 10, 11	1	1	151	
Automatic restart functions	165	Stall prevention operation level for restart 0 to 200% 0.1% 150		150%	151		
_	168	Parameter for manufacturer setting. Do	not set.				
_	169		1				
Cumulative monitor clear	170	Watt-hour meter clear 0, 10, 9999 1 9999		9999	143		
Cumu	171	Operation hour meter clear	0, 9999	1 9999 143		143	
on dn	172	User group registered display/batch clear	9999, (0 to 16)	1	0	177	
User group	173	User group registration	0 to 999, 9999	1	9999	177	
	174	User group clear	0 to 999, 9999	1	9999	177	

Parameter list `
------------------

Parameter	Remarks	Inst	ruction C	ode		trol Mode-basspondence		I	Paramete	r
i arameter	Remarks	Read	Write	Extended	V/F	AD MFVC	GP MFVC	Сору	Clear	All clear
127		1B	9B	1	0	0	0	0	0	0
128		1C	9C	1	0	0	0	0	0	0
129		1D	9D	1	0	0	0	0	0	0
130		1E	9E	1	0	0	0	0	0	0
131		1F	9F	1	0	0	0	0	0	0
132		20	A0	1	0	0	0	0	0	0
133		21	A1	1	0	0	0	0	0	0
134		22	A2	1	0	0	0	0	0	0
145 146	Parameter for manufa	2D	AD	1 ot set	0	0	0	0	×	×
147	T didinotor for manage	2F	AF	1	0	0	0	0	0	0
150		32	B2	1	0	0	0	0	0	0
151		33	В3	1	0	0	0	0	0	0
152		34	B4	1	0	0	0	0	0	0
153		35	B5	1	0	0	0	0	0	0
156		38	B8	1	0	0	0	0	0	0
157		39	B9	1	0	0	0	0	0	0
158		3A	BA	1	0	0	0	0	0	0
<b>©</b> 160		00	80	2	0	0	0	0	0	0
161		01	81	2	0	0	0	0	×	0
162		02	82	2	0	0	0	0	0	0
165		05	85	2	0	0	0	0	0	0
168 169	Parameter for manufa	cturer set	ting. Do no	ot set.						
170		0A	8A	2	0	0	0	0	×	0
171		0B	8B	2	0	0	0	×	×	×
172		0C	8C	2	0	0	0	0	×	×
173		0D	8D	2	0	0	0	×	×	×
174		0E	8E	2	0	0	0	×	×	×

	Initial	Refer to	Customer	omer	Parameter	Remarks	Inst	ruction (	ode		trol Mode-baspondence		Parameter		
ts	Value	Page	Setting	ting	raiailletei	Remarks	Read	Write	Extended	<b>&gt;-V/F-</b>	AD MFVC	GP MFVC	Сору	Clear	All clea
	60	128			178		12	92	2	0	0	0	0	×	0
	61	128			179		13	93	2	0	0	0	0	×	0
	0	128			180		14	94	2	0	0	0	0	×	0
	1	128			181		15	95	2	0	0	0	0	×	0
	2	128			182		16	96	2	0	0	0	0	×	0
	24	128			183		17	97	2	0	0	0	0	×	0
	62	128			184		18	98	2	0	0	0	0	×	0
	0	134			190		1E	9E	2	0	0	0	0	×	0
	4	134			191		1F	9F	2	0	0	0	0	×	0
	99	134			192		20	AO	2	0	0	0	0	×	0
	9999	92			232		28	A8	2	0	0	0	0	0	0
	9999	92			233		29	A9	2	0	0	0	0	0	0
	9999	92			234		2A	AA	2	0	0	0	0	0	0
	9999	92			235		2B	AB	2	0	0	0	0	0	0
	9999	92			236		2C	AC	2	0	0	0	0	0	0
	9999 9999	92 92			237		2D 2E	AD AE	2	0	0	0	0	0	0
	9999	92			239		2F	AF	2	0	0	0	0	0	0
	1	163			240		30	B0	2	0	0	0	0	0	0
	0	168			241		31	B1	2	0	0	0	0	0	0
	1	247			244		34	B4	2	0	0	0	0	0	0
	9999	81			245		35	B5	2	0	×	0	0	0	0
	0.5s	81			246		36	В6	2	0	×	0	0	0	0
	9999	81			247		37	В7	2	0	×	0	0	0	0
	1	161			249		39	B9	2	0	0	0	0	0	0
	9999	121, 132			250		3A	BA	2	0	0	0	0	0	0
	1	161			251		3B	BB	2	0	0	0	0	0	0
	0	248			255		3F	BF	2	0	0	0	×	×	×
	100%	248			256		40	C0	2	0	0	0	×	×	×
	100%	248			257		41	C1	2	0	0	0	×	×	×
	100%	248			258		42	C2	2	0	0	0	×	×	×
	0	248	1		259		43	C3	2	0	0	0	0	0	0

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
gnment	178	STF terminal function selection	0 to 5, 7, 8, 10, 12, 14 to 16, 18, 24, 25, 60, 62, 65 to 67, 9999	1	60	128	
nput terminal function assignment	179	STR terminal function selection	0 to 5, 7, 8, 10, 12, 14 to 16, 18, 24, 25,	1	61	128	
fun	100	RL terminal function selection	61, 62, 65 to 67, 9999	1	0	128	
nal	180		0 to 5 7 0 10 10		_		
Т	181	RM terminal function selection	0 to 5, 7, 8, 10, 12,	1	1	128	
t te	182	RH terminal function selection	14 to 16, 18, 24, 25,	1	2	128	
ndı	183	MRS terminal function selection	62, 65 to 67, 9999	1	24	128	
7	184	RES terminal function selection		1	62	128	
	190	RUN terminal function selection	0, 1, 3, 4, 7, 8, 11 to 16, 20, 25, 26, 46, 47, 64, 90, 91, 93, 95, 96, 98, 99, 100, 101, 103,	1	0	134	
nction assignment	191	FU terminal function selection	104, 107, 108, 111 to 116, 120, 125, 126, 146, 147, 164, 190, 191, 193, 195, 196, 198, 199, 9999	1	4	134	
Output terminal function assignment	192	A,B,C terminal function selection	0, 1, 3, 4, 7, 8, 11 to 16, 20, 25, 26, 46, 47, 64, 90, 91, 95, 96, 98, 99, 100, 101, 103, 104, 107, 108, 111 to 116, 120, 125, 126, 146, 147, 164, 190, 191, 195, 196, 198, 199, 9999	1	99	134	
	232	Multi-speed setting (speed 8)	0 to 400Hz, 9999	0.01Hz	9999	92	
setting	233	Multi-speed setting (speed 9)	0 to 400Hz, 9999	0.01Hz	9999	92	
etti	234	Multi-speed setting (speed 10)	0 to 400Hz, 9999	0.01Hz	9999	92	
ed s	235	Multi-speed setting (speed 11)	0 to 400Hz, 9999	0.01Hz	9999	92	
ээс	236	Multi-speed setting (speed 12)	0 to 400Hz, 9999	0.01Hz	9999	92	
Multi-spe	237	Multi-speed setting (speed 13)	0 to 400Hz, 9999	0.01Hz	9999	92	
Muli	238	Multi-speed setting (speed 14)	0 to 400Hz, 9999	0.01Hz	9999	92	
_	239	Multi-speed setting (speed 15)	0 to 400Hz, 9999	0.01Hz	9999	92	
	240	Soft-PWM operation selection	0, 1	1	1	163	
	241	Analog input display unit switchover	0, 1	1	0	168	
_	244	Cooling fan operation selection	0, 1	1	1	247	
	245	Rated slip	0 to 50%, 9999	0.01%	9999	81	
Slip compensation	246	Slip compensation time constant	0.01 to 10s	0.01s	0.5s	81	
com	247	Constant-power range slip compensation selection	0, 9999	1	9999	81	
_	249	Earth (ground) fault detection at start	0, 1	1	1	161	
_	250	Stop selection	0 to 100s, 1000 to 1100s, 8888, 9999	0.1s	9999	121, 132	
_	251	Output phase loss protection selection	0, 1	1	1	161	
. <u>s</u>	255	Life alarm status display	(0 to 15)	1	0	248	
sou	256	Inrush current limit circuit life display	(0 to 100%)	1%	100%	248	
Life diagnosis	257	Control circuit capacitor life display	(0 to 100%)	1%	100%	248	
ib e	258	Main circuit capacitor life display	(0 to 100%)	1%	100%	248	
,≝	259	Main circuit capacitor life measuring	0, 1 (2, 3, 8, 9)	1	0	248	

Func-	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
Power failure stop	261	Power failure stop selection	0, 1, 2	1	0	157	
_	267	Terminal 4 input selection	0, 1, 2	1	0	165	
_	268	Monitor decimal digits selection	0, 1, 9999	1	9999	143	
_	269	Parameter for manufacturer setting. Do			_		1
	270	Stop-on contact control selection	0, 1	1	0	122	
contact	275	Stop-on contact excitation current low- speed multiplying factor	0 to 300%, 9999	0.1%	9999	122	
Stop-on contact control	276	PWM carrier frequency at stop-on contact	0 to 9, 9999	1	9999	122	
_	277	Stall prevention operation current switchover	0, 1	1	0	82	
e	278	Brake opening frequency	0 to 30Hz	0.01Hz	3Hz	124	
Brake sequence function	279	Brake opening current	0 to 200%	0.1%	130%	124	
ce seque function	280	Brake opening current detection time	0 to 2s	0.1s	0.3s	124	
(e s	281	Brake operation time at start	0 to 5s	0.1s	0.3s	124	
3rał	282	Brake operation frequency	0 to 30Hz	0.01Hz	6Hz	124	
	283 286	Brake operation time at stop	0 to 5s 0 to 100%	0.1s 0.1%	0.3s 0%	124	
Droop	287	Droop gain  Droop filter time constant	0 to 1s	0.1% 0.01s	0.3s	244	
	292	Automatic acceleration/deceleration	0, 1, 7, 8, 11	1	0	104	
_	293	Acceleration/deceleration separate	0 to 2	1	0	104	
_	295	selection  Magnitude of frequency change setting	0, 0.01, 0.10, 1.00, 10.00	0.01	0	259	
_	298	Frequency search gain	0 to 32767, 9999	1	9999	151	
_	299	Rotation direction detection selection at restarting	0, 1, 9999	1	0	151	
	300	BCD input bias	0 to 400Hz	0.01Hz	0	_	
	301	BCD input gain	0 to 400Hz, 9999	0.01Hz	50Hz	_	
ont	302	BIN input bias	0 to 400Hz	0.01Hz	0	_	
li in	303	BIN input gain	0 to 400Hz, 9999	0.01Hz	50Hz	_	
Digital input	304	Digital input and analog input	0, 1, 10, 11, 9999	1	9999		
	305	compensation enable/disable selection  Read timing operation selection	0, 1, 10	1	0	_	
	306	Analog output signal selection	1 to 3, 5, 7 to 12, 14, 21, 24, 52, 53, 61, 62	1	2	_	
	307	Setting for zero analog output	0 to 100%	0.1%	0	_	
	308	Setting for maximum analog output	0 to 100%	0.1%	100		
output	309	Analog output signal voltage/current switchover	0, 1, 10, 11	1	0	_	
Analog output	310	Analog meter voltage output selection	1 to 3, 5, 7 to 12, 14, 21, 24, 52, 53, 61, 62	1	2	_	
	311	Setting for zero analog meter voltage output	0 to 100%	0.1%	0	_	
	312	Setting for maximum analog meter voltage output	0 to 100%	0.1%	100	_	

Parameter	Remarks	Inst	ruction C	ode		trol Mode-ba			Paramete	r
, aramoto.	romano	Read	Write	Extended		AD MFVC	GP MFVC	Сору	Clear	All clear
261		45	C5	2	0	0	0	0	0	0
267		4B	CB	2	0	0	0	0	×	0
268		4C	CC	2	0	0	0	0	0	0
269	Parameter for manufa									
270		4E	CE	2	×	0	0	0	0	0
275		53	D3	2	×	0	0	0	0	0
276		54	D4	2	×	0	0	0	0	0
277		55	D5	2	0	0	0	0	0	0
278		56	D6	2	×	0	0	0	0	0
279		57	D7	2	×	0	0	0	0	0
280		58	D8	2	×	0	0	0	0	0
281		59	D9	2	×	0	0	0	0	0
282		5A	DA	2	×	0	0	0	0	0
283		5B	DB	2	×	0	0	0	0	0
286		5E	DE	2	×	0	X	0	0	0
287		5F	DF	2	×	0	×	0	0	0
292		64	E4	2	0	0	0	0	0	0
293		65	E5	2	0	0	0	0	0	0
295		67	E7	2	0	0	0	0	0	0
298		6A	EA	2	0	0	0	0	×	0
299		6B	EB	2	0	0	0	0	0	0
300	AX	00	80	3	0	0	0	0	0	0
301	AX	01	81	3	0	0	0	0	0	0
302	[AX]	02	82	3	0	0	0	0	0	0
303	[AX]	03	83	3	0	0	0	0	0	0
304	AX	04	84	3	0	0	0	0	0	0
305	AX	05	85	3	0	0	0	0	0	0
306	AY	06	86	3	0	0	0	0	0	0
307	AY	07	87	3	0	0	0	0	0	0
308	AY	08	88	3	0	0	0	0	0	0
309	AY	09	89	3	0	0	0	0	0	0
310	[AY]	0A	8A	3	0	0	0	0	0	0
311	AY	0B	8B	3	0	0	0	0	0	0
312	AY	ос	8C	3	0	0	0	0	0	0

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
	313	DO0 output selection	0, 1, 3, 4, 7, 8, 11 to 16,	1	9999	_	
	314	DO1 output selection	20, 25, 26, 46, 47, 64,	1	9999	_	
put	315	DO2 output selection	90, 91, 93, 95, 96, 98,	1	9999	_	
Digital output	316	DO3 output selection	99, 100, 101, 103, 104, 107, 108,	1	9999	_	
gital	317	DO4 output selection	111 to 116, 120, 125,	1	9999	_	
Ö	318	DO5 output selection	126, 146, 147, 164,	1	9999	_	
	319	DO6 output selection	190, 191, 193, 195, 196, 198, 199, 9999	1	9999	_	
put	320	RA1 output selection	0, 1, 3, 4, 7, 8, 11 to 16,	1	0	_	
Relay output	321	RA2 output selection	20, 25, 26, 46, 47, 64, 90, 91, 95, 96, 98, 99,	1	1	_	
Rel	322	RA3 output selection	9999	1	4	_	
Analog	323	AM0 0V adjustment	900 to 1100%	1%	1000	_	
An	324	AM1 0mA adjustment	900 to 1100%	1%	1000	_	
_	329	Digital input unit selection	0, 1, 2, 3	1	1	_	
ation	338	Communication operation command source	0, 1	1	0	191	
RS-485 communication	339	Communication speed command source	0, 1, 2	1	0	191	
con	340	Communication startup mode selection	0, 1, 10	1	0	190	
S-485	342	Communication EEPROM write selection	0, 1	1	0	204	
	343	Communication error count	_	1	0	217	
Net	345	DeviceNet address	0 to 4095	1	63	_	
DeviceNet communication	346	DeviceNet baud rate	0 to 4095	1	132	_	
_	349	Communication reset selection	0, 1	1	0	_	
	387	Initial communication delay time	0 to 120s	0.1s	0s	_	
(S tion	388	Send time interval at heart beat	0 to 999.8s	0.1s	0s	_	
Vork	389	Minimum sending time at heart beat	0 to 999.8s	0.1s	0.5s	_	
LonWorks communication	390	% setting reference frequency	1 to 400Hz	0.01Hz	50Hz	_	
Cor	391	Receive time interval at heart beat	0 to 999.8s	0.1s	0s		
	392	Event driven detection width	0.00 to 163.83%	0.01%	0%	_	
Second motor constant	450	Second applied motor	0, 1, 9999	1	9999	108	
+	495	Remote output selection	0, 1, 10, 11	1	0	141	
Output	496	Remote output data 1	0 to 4095	1	0	141	
Ō	497	Remote output data 2	0 to 4095	1	0	141	
ication	500	Communication error execution waiting time	0 to 999.8s	0.1s	0	_	
Communication error	501	Communication error occurrence count display	0	1	0	_	
_	502	Stop mode selection at communication error	0, 1, 2, 3	1	0	201, 217	

Parameter	Remarks	Inst	ruction C	ode		trol Mode-ba		1	Paramete	r
T di diliotoi	. tomario	Read	Write	Extended		AD MFVC	GP MFVC	Сору	Clear	All clear
313	AY NC	0D	8D	3	0	0	0	0	0	0
314	AY NC	0E	8E	3	0	0	0	0	0	0
315	AY NC	0F	8F	3	0	0	0	0	0	0
316	AY	10	90	3	0	0	0	0	0	0
317	AY	11	91	3	0	0	0	0	0	0
318	AY	12	92	3	0	0	0	0	0	0
319	AY	13	93	3	0	0	0	0	0	0
320	AR	14	94	3	0	0	0	0	0	0
321	AR	15	95	3	0	0	0	0	0	0
322	AR	16	96	3	0	0	0	0	0	0
323	AY	17	97	3	0	0	0	0	×	0
324	AY	18	98	3	0	0	0	0	×	0
329	AX	1D	9D	3	0	0	0	0	×	0
338		26	A6	3	0	0	0	0	0	0
339		27	A7	3	0	0	0	0	0	0
340		28	A8	3	0	0	0	0	0	0
342		2A	AA	3	0	0	0	0	0	0
343		2B	AB	3	0	0	0	×	×	×
345	ND	2D	AD	3	0	0	0	0	0	0
346	ND	2E	AE	3	0	0	0	0	0	0
349	NC ND NL NP	31	B1	3	0	0	0	0	0	0
387	NL	57	D7	3	0	0	0	0	0	0
388	NL	58	D8	3	0	0	0	0	0	0
389	NL	59	D9	3	0	0	0	0	0	0
390	NL	5A	DA	3	0	0	0	0	0	0
391	NL	5B	DB	3	0	0	0	0	0	0
392	NL	5C	DC	3	0	0	0	0	0	0
450		32	B2	4	0	0	0	0	0	0
495		5F	DF	4	0	0	0	0	0	0
496		60	E0	4	0	0	0	×	×	×
497		61	E1	4	0	0	0	×	×	×
500	NC ND NL NP	00	80	5	0	0	0	0	0	0
501	NC ND NL NP	01	81	5	0	0	0	×	0	0

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
Maintenance	503	Maintenance timer	0 (1 to 9998)	1	0	252	
Mainte	504	Maintenance timer alarm output set time	0 to 9998, 9999	1	9999	252	
>	541	Frequency command sign selection (CC-Link)	0, 1	1	0	_	
CC-Link	542	Communication station number (CC-Link)	1 to 64	1	1	_	
0	543	Baud rate (CC-Link)	0 to 4	1	0	_	
	544	CC-Link extended setting	0, 1, 12, 14, 18	1	0	_	
	547	USB communication station number	0 to 31	1	0	230	
asn	548	USB communication check time interval	0 to 999.8s, 9999	0.1s	9999	230	
ion	549	Protocol selection	0, 1	1	0	217	
Communication	550	NET mode operation command source selection	0, 2, 9999	1	9999	191	
Comr	551	PU mode operation command source selection	2 to 4, 9999	1	9999	191	
age Ir	555	Current average time	0.1 to 1.0s	0.1s	1s	253	
Current average time monitor	556	Data output mask time	0.0 to 20.0s	0.1s	0s	253	
Curre time	557	Current average value monitor signal output reference current	0 to 500A	0.01A	Rated inverter current	253	
_	563	Energization time carrying-over times	(0 to 65535)	1	0	143	
ı	564	Operating time carrying-over times	(0 to 65535)	1	0	143	
_	571	Holding time at a start	0.0 to 10.0s, 9999	0.1s	9999	102	
_	611	Acceleration time at a restart	0 to 3600s, 9999	0.1s	9999	151	
	645	AM 0V adjustment	970 to 1200	1	1000	149	
	653	Speed smoothing control  Regeneration avoidance frequency	0 to 200%	0.1%	0	164	
_	665	gain gain	0 to 200%	0.1%	100	245	
_	800	Control method selection	20, 30 0 to 500A (0 to ****),	1	20	74, 76, 79	
_	859	Torque current	9999 *5	0.01A (1) *5	9999	110	
Protective functions	872	Input phase loss protection selection	0, 1	1	1	161	
ance	882	Regeneration avoidance operation selection	0, 1, 2	1	0	245	
ration avoid function	883	Regeneration avoidance operation level	300 to 800V	0.1V	780VDC	245	
Regeneration avoidance function	885	Regeneration avoidance compensation frequency limit value	0 to 10Hz, 9999	0.01Hz	6Hz	245	
Rege	886	Regeneration avoidance voltage gain	0 to 200%	0.1%	100%	245	
Free parameter	888	Free parameter 1	0 to 9999	1	9999	255	
F	889	Free parameter 2	0 to 9999	1	9999	255	

Parameter	Remarks	Inst	ruction C	ode		trol Mode-ba espondence		-	Paramete	r
i arameter	Kemarks	Read	Write	Extended		AD MFVC	GP MFVC	Сору	Clear	All clear
503		03	83	5	0	0	0	×	×	×
504		04	84	5	0	0	0	0	×	0
541	NC	29	A9	5	0	0	0	0	0	0
542	NC	2A	AA	5	0	0	0	0	0	0
543	NC	2B	AB	5	0	0	0	0	0	0
544	NC	2C	AC	5	0	0	0	0	0	0
547		2F	AF	5	0	0	0	0	0	0
548		30	В0	5	0	0	0	0	0	0
549		31	B1	5	0	0	0	0	0	0
550		32	B2	5	0	0	0	0	0	0
551		33	В3	5	0	0	0	0	0	0
555		37	B7	5	0	0	0	0	0	0
556		38	B8	5	0	0	0	0	0	0
557		39	В9	5	0	0	0	0	0	0
563		3F	BF	5	0	0	0	×	×	×
564		40	C0	5	0	0	0	×	×	×
571		47	C7	5	0	0	0	0	0	0
611		0B	8B	6	0	0	0	0 (	0	0
645		2D	AD	6	0 (	0	0	0	×	0
653		35	B5	6	0	0	0	0	0	0
665		41	C1	6	0	0	0	0	0	0
800		00	80	8	×	0	0	0	0	0
859		3B	BB	8	×	0	0	0	×	0
872		48	C8	8	0	0	0	0	0	0
882		52	D2	8	0	0	0	0	0	0
883		53	D3	8	0	0	0	0	0	0
885		55	D5	8	0	0	0	0	0	0
886		56	D6	8	0	0	0	0	0	0
888		58	D8	8	0	0	0	0	×	×
889		59	D9	8	0	0	0	0	×	×

Func- tion	Parameter	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to Page	Customer Setting
	C0 (900) *6	FM terminal calibration	_	_	_	149	
	C1 (901) *6	AM terminal calibration	_	_	_	149	
	C2 (902) *6	Terminal 2 frequency setting bias frequency	0 to 400Hz	0.01Hz	0Hz	168	
eters	C3 (902) *6	Terminal 2 frequency setting bias	0 to 300%	0.1%	0%	168	
Calibration parameters	125 (903) *6	Terminal 2 frequency setting gain frequency	0 to 400Hz	0.01Hz	50Hz	168	
bration	C4 (903) *6	Terminal 2 frequency setting gain	0 to 300%	0.1%	100%	168	
Cali	C5 (904) *6	Terminal 4 frequency setting bias frequency	0 to 400Hz	0.01Hz	0Hz	168	
	C6 (904) *6	Terminal 4 frequency setting bias	0 to 300%	0.1%	20%	168	
	126 (905) *6	Terminal 4 frequency setting gain frequency	0 to 400Hz	0.01Hz	50Hz	168	
	C7 (905) *6	Terminal 4 frequency setting gain	0 to 300%	0.1%	100%	168	
_	C22 to C25 (922 to 923)	Parameter for manufacturer setting. Do	not set.				
PU	990	PU buzzer control	0, 1	1	1	260	
	991	PU contrast adjustment	0 to 63	1	58	260	
e list	Pr.CL	Parameter clear	0, 1	1	0	261	
amete	ALLC	All parameter clear	0, 1	1	0	261	
Clear parameters iial value change I	Er.CL	Faults history clear	0, 1	1	0	263	
in	Pr.CH	Initial value change list	_	_	_	262	

\*1 Differ according to capacities.

6%: FR-E740-026 or less

4%: FR-E740-040 to 095

3%: FR-E740-120 and 170

2%: FR-E740-230 and 300

\*2 Differ according to capacities.

5s: FR-E740-095 or less

10s: FR-E740-120 and 170

15s: FR-E740-230 and 300

\*3 Differ according to capacities. 4%: FR-E740-016 to 170

2%: FR-E740-230 and 300

- \*4 Write is disabled in the communication mode (network operation mode) from the PU connector.
- \*5 The range differs according to the *Pr. 71* setting.
- \*6 The parameter number in parentheses is the one for use with the operation panel (PA02) for the FR-E500 series or parameter unit (FR-PU04/FR-PU07).



	Control Mode-based											
Parameter	Remarks	Inst	ruction C	Code		trol Mode-ba espondence		1	Paramete	r		
raiametei	Remarks	Read	Write	Extended		AD MFVC	GP MFVC	Сору	Clear	All clear		
C0 (900)	AY	5C	DC	1	0	0	0	0	×	0		
C1 (901)		5D	DD	1	0	0	0	0	×	0		
C2 (902)		5E	DE	1	0	0	0	0	×	0		
C3 (902)		5E	DE	1	0	0	0	0	×	0		
125 (903)		5F	DF	1	0	0	0	0	×	0		
C4 (903)		5F	DF	1	0	0	0	0	×	0		
C5 (904)		60	E0	1	0	0	0	0	×	0		
C6 (904)		60	E0	1	0	0	0	0	×	0		
126 (905)		61	E1	1	0	0	0	0	×	0		
C7 (905)		61	E1	1	0	0	0	0	×	0		
C22 to C25 (922 to 923)	Parameter for manufa	acturer set	ting. Do no	ot set.								
990		5A	DA	9	0	0	0	0	0	0		
991		5B	DB	9	0	0	0	0	×	0		
Pr.CL		_	_	_	_	_	_	_	_	_		
ALLC		_	_	_	_	_	_	_	_	_		
Er.CL		_	_	_	_	_	_	_	_	_		
Pr.CH		_	_	_	_	_	_	_	_	_		

# Parameters according to purposes \_\_\_\_

4.3	Control mode	/3
4.3.1	Change the control method (Pr. 80, Pr. 81, Pr. 800)	74
4.4	Adjust the output torque (current) of the motor	75
4.4.1	Manual torque boost (Pr. 0, Pr. 46)	75
4.4.2	Advance magnetic flux vector control (Pr. 71, Pr. 80, Pr. 81, Pr.89, Pr. 800)	
4.4.3	General-purpose magnetic flux vector control (Pr. 71, Pr. 80, Pr. 81, Pr. 800)	79
4.4.4	Slip compensation (Pr. 245 to Pr. 247)	81
4.4.5	Stall prevention operation (Pr. 22, Pr. 23, Pr. 48, Pr. 66, Pr. 156, Pr. 157, Pr. 277)	82
4.5 L	imit the output frequency	86
4.5.1	Maximum/minimum frequency (Pr. 1, Pr. 2, Pr. 18)	86
4.5.2	Avoid mechanical resonance points (frequency jumps) (Pr. 31 to Pr. 36)	87
4.6	Set V/F pattern	88
4.6.1	Base frequency, voltage (Pr. 3, Pr. 19, Pr. 47)	88
4.6.2	Load pattern selection (Pr. 14)	
4.7 F	requency setting by external terminals	92
4.7.1	Operation by multi-speed operation (Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239)	92
4.7.2	Jog operation (Pr. 15, Pr. 16)	
4.7.3	Remote setting function (Pr. 59)	96
4.8	Setting of acceleration/deceleration time and acceleration/	
	leceleration pattern	99
4.8.1	Setting of the acceleration and deceleration time	
	(Pr. 7, Pr. 8, Pr. 20, Pr. 21, Pr. 44, Pr. 45, Pr. 147)	
4.8.2	Starting frequency and start-time hold function (Pr. 13, Pr. 571)	
4.8.3	Acceleration/deceleration pattern (Pr. 29)	103
4.8.4	Shortest acceleration/deceleration (automatic acceleration/deceleration) (Pr. 61 to Pr. 63, Pr. 292, Pr. 293)	104
4.9	Selection and protection of a motor	106
4.9.1	Motor overheat protection (Electronic thermal O/L relay) (Pr. 9, Pr. 51)	106
4.9.2	Applied motor (Pr. 71, Pr. 450)	
4.9.3	To exhibit the best performance of the motor performance (offline auto tuning)	
11010	(Pr. 71, Pr. 80 to Pr. 84, Pr. 90 to Pr. 94, Pr. 96, Pr. 859)	110
4.10 N	Notor brake and stop operation	118
4.10.1	DC injection brake (Pr. 10 to Pr. 12)	118
4.10.2	Selection of a regenerative brake (Pr. 30, Pr. 70)	
4.10.3	Stop selection (Pr. 250)	121
4.10.4	Stop-on contact control function (Pr. 6, Pr. 48, Pr. 270, Pr. 275, Pr. 276)	400
4 40 5	Proke aggregate function (Pr. 279 to Pr. 292, Pr. 202)	
4.10.5	Brake sequence function (Pr. 278 to Pr. 283, Pr. 292)	
4.11 F	function assignment of external terminal and control	128
4.11.1	Input terminal function selection (Pr. 178 to Pr. 184)	128

4.11.2	Inverter output shutoff signal (MRS signal, Pr. 17)	130
4.11.3	Condition selection of function validity by second function selection signal (RT)	131
4.11.4	Start signal operation selection (STF, STR, STOP signal, Pr. 250)	132
4.11.5	Output terminal function selection (Pr. 190 to Pr. 192)	134
4.11.6	Detection of output frequency (SU, FU signal, Pr. 41 to Pr. 43)	138
4.11.7	Output current detection function (Y12 signal, Y13 signal, Pr. 150 to Pr. 153)	139
4.11.8	Remote output selection (REM signal, Pr. 495 to Pr. 497)	141
4.12 N	Nonitor display and monitor output signal	142
4.12.1	Speed display and speed setting (Pr. 37)	142
4.12.2	Monitor display selection of DU/PU and terminal AM (Pr. 52, Pr.158, Pr. 170, Pr. 171, Pr. 268, Pr. 563, Pr. 564)	143
4.12.3	Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)	
4.12.4	Terminal AM calibration (calibration parameter Pr. 645, C1 (Pr.901))	
4.13 C	peration selection at power failure and instantaneous power	
	ailure	151
4.13.1	Automatic restart after instantaneous power failure/flying start	
	(Pr. 30, Pr. 57, Pr. 58, Pr. 96, Pr. 162, Pr. 165, Pr. 298, Pr. 299, Pr. 611)	
4.13.2	Power-failure deceleration stop function (Pr. 261)	157
4.14 C	peration setting at fault occurrence	159
4.14.1	Retry function (Pr. 65, Pr. 67 to Pr. 69)	159
4.14.2	Input/output phase loss protection selection (Pr. 251, Pr. 872)	161
4.14.3	Earth (ground) fault detection at start (Pr. 249)	161
4.15 E	nergy saving operation	162
4.15.1	Optimum excitation control (Pr. 60)	162
4.16 N	Notor noise, EMI measures, mechanical resonance	163
4.16.1	PWM carrier frequency and soft-PWM control (Pr. 72, Pr. 240)	163
4.16.2	Speed smoothing control (Pr. 653)	164
4.17 F	requency setting by analog input (terminal 2, 4)	165
4.17.1	Analog input selection (Pr. 73, Pr. 267)	165
4.17.2	Response level of analog input and noise elimination (Pr. 74)	167
4.17.3	Bias and gain of frequency setting voltage (current)	
	(Pr. 125, Pr. 126, Pr. 241, C2 (Pr. 902) to C7 (Pr. 905))	168
4.18 N	lisoperation prevention and parameter setting restriction	173
4.18.1	Reset selection/disconnected PU detection/PU stop selection (Pr. 75)	173
4.18.2	Parameter write disable selection (Pr. 77)	176
4.18.3	Reverse rotation prevention selection (Pr. 78)	177
4.18.4	Extended parameter display and user group function (Pr. 160, Pr. 172 to Pr. 174)	177
4.19 S	Selection of operation mode and operation location	180
4.19.1	Operation mode selection (Pr. 79)	180
4.19.2	Operation mode at power-on (Pr. 79, Pr. 340)	
4.19.3	Start command source and frequency command source during communication	

	operation (Pr. 338, Pr. 339, Pr. 550, Pr. 551)	191
4.20 (	Communication operation and setting	197
4.20.1	Wiring and configuration of PU connector	197
4.20.2	Initial settings and specifications of RS-485 communication	
	(Pr. 117 to Pr. 120, Pr. 123, Pr. 124, Pr. 549)	
4.20.3	Operation selection at communication error occurrence (Pr. 121, Pr. 122, Pr. 502)	201
4.20.4	Communication EEPROM write selection (Pr. 342)	
4.20.5	Mitsubishi inverter protocol (computer link communication)	205
4.20.6	Modbus RTU communication specifications	0.47
4.00.7	(Pr. 117, Pr. 118, Pr. 120, Pr. 122, Pr. 343, Pr. 502, Pr. 549)	
4.20.7	USB communication (Pr. 547, Pr. 548)	
4.21 \$	pecial operation and frequency control	231
4.21.1	PID control (Pr. 127 to Pr. 134)	231
4.21.2	Dancer control (Pr. 44, Pr. 45, Pr. 128 to Pr. 134)	238
4.21.3	Droop control (Pr. 286 to Pr. 287)	244
4.21.4	Regeneration avoidance function (Pr. 665, Pr. 882, Pr. 883, Pr. 885, Pr. 886)	245
4.22 L	Jseful functions	247
4.22.1	Cooling fan operation selection (Pr. 244)	247
4.22.2	Display of the life of the inverter parts (Pr. 255 to Pr. 259)	248
4.22.3	Maintenance timer alarm (Pr. 503, Pr. 504)	252
4.22.4	Current average value monitor signal (Pr. 555 to Pr. 557)	253
4.22.5	Free parameter (Pr. 888, Pr. 889)	255
4.23 \$	Setting from the parameter unit and operation panel	256
4.23.1	RUN key rotation direction selection (Pr. 40)	256
4.23.2	PU display language selection(Pr.145)	
4.23.3	Operation panel frequency setting/key lock operation selection (Pr. 161)	257
4.23.4	Magnitude of frequency change setting (Pr. 295)	259
4.23.5	Buzzer control (Pr. 990)	260
4.23.6	PU contrast adjustment (Pr. 991)	260
4.24 F	Parameter clear/ All parameter clear	261
4.25 I	nitial value change list	262
4.26 0	Check and clear of the faults history	263
	<del>-</del>	



# 4.3 Control mode

V/F control (initial setting), advanced magnetic flux vector control and general-purpose magnetic flux vector control are available with this inverter.

#### (1) V/F Control

•It controls frequency and voltage so that the ratio of frequency (F) to voltage (V) is constant when changing frequency.

#### (2) Advanced (general-purpose) magnetic flux vector control

- •This control divides the inverter output current into an excitation current and a torque current by vector calculation and makes voltage compensation to flow a motor current which meets the load torque.
- •General-purpose magnetic flux vector control is the same function as the FR-E500 series. For other cases, select advanced magnetic flux vector control.



#### **POINT**

If the following conditions are not satisfied, select V/F control since malfunction such as insufficient torque and uneven rotation may occur.

- The motor capacity should be equal to or one rank lower than the inverter capacity.
- Motor to be used is any of Mitsubishi standard motor, high efficiency motor (SF-JR, SF-HR 0.2kW or more) or Mitsubishi constant torque motor (SF-JRCA, SF-HRCA four-pole 0.4kW to 15kW). When using a motor other than the above (other manufacturer's motor), perform offline auto tuning without fail.
- Single-motor operation (one motor run by one inverter) should be performed.
- Wiring length from inverter to motor should be within 30m. (Perform offline auto tuning in the state where wiring work is performed when the wiring length exceeds 30m.)



#### 4.3.1 Change the control method (Pr. 80, Pr. 81, Pr. 800)

Set when selecting the control method for advanced magnetic flux vector control and general-purpose magnetic flux vector control. The initial value is V/F control.

• Select a control mode using Pr. 800 Control method selection.

Parameter Number	Name	Initial Value	Setting Range	Description		
80	Motor capacity	9999	0.1 to 15kW	Set the applied motor capacity.		
00	Wotor capacity	9999	9999	V/F Contro	V/F Control	
81	Number of motor poles	9999	2, 4, 6, 8, 10	Set the nu	Set the number of motor poles.	
01	Number of motor poles	9999	9999	V/F Control		
200	Control method	00	20	V/F	Advanced magnetic flux vector control *	
800	selection	20	30	Control	General-purpose magnetic flux vector control *	

<sup>\*</sup> Set a value other than "9999" in Pr. 80 and Pr. 81.

#### (1) Setting of the motor capacity and the number of motor poles (Pr. 80, Pr. 81)

- •Motor specifications (motor capacity and number of motor poles) must be set to select advanced magnetic flux vector control or general-purpose magnetic flux vector control.
- •Set the motor capacity (kW) in Pr. 80 Motor capacity and set the number of motor poles in Pr. 81 Number of motor poles.

#### (2) Selection of control method

•Select the inverter control method for V/F control, advanced magnetic flux vector control, and general-purpose magnetic flux vector control.

Pr. 80, 81	Pr. 800 Setting	Control Method
	20	Advanced magnetic flux vector control
Other than 9999	(Pr. 800 initial value)	Advanced magnetic flux vector control
	30	General-purpose magnetic flux vector control
9999	*	V/F control
(Pr. 80, Pr. 81 initial value)		V/I COILLOI

Control method is V/F control regardless of the setting value of Pr. 800 when "9999" is set in Pr. 80 Motor capacity or Pr. 81 Number of motor poles.

#### (3) Control method switching by external terminals (X18 signal)

- •Use the V/F switchover signal (X18) to change the control method (V/F control-advanced magnetic flux vector control (general-purpose magnetic flux vector control)) with external terminal.
- •Turn the X18 signal on to change the currently selected control method (advanced magnetic flux vector control or generalpurpose magnetic flux vector control) to V/F control.

For the terminal used for X18 signal input, set "18" in any of Pr. 178 to Pr. 184 (input terminal function selection) to assign the function.



## REMARKS

When V/F control is selected by V/F switchover (X18 signal), second function is also selected at the same time. Control between V/F and advanced (general-purpose) magnetic flux can not be switched while the inverter is running. In case control is switched between V/F and advanced (general-purpose) magnetic flux, only second function is selected.



#### **NOTE**

· Changing the terminal assignment using Pr. 178 to Pr. 184 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.



#### Parameters referred to

Advanced magnetic flux vector control Refer to page 76

General-purpose magnetic flux vector control Refer to page 79

Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 128

Pr. 450 Second applied motor Refer to page 108

Pr. 44 Second acceleration/deceleration time, Pr. 45 Second deceleration time Refer to page 99

Pr. 46 Second torque boost Refer to page 75

Pr. 47 Second V/F (base frequency) Refer to page 88

Pr. 48 Second stall prevention operation current Refer to page 82

Pr. 51 Second electronic thermal O/L relay Refer to page 106



# 4.4 Adjust the output torque (current) of the motor

Purpose	Parameter that	Refer to Page	
Set starting torque manually	Manual torque boost	Pr. 0, Pr. 46	75
Automatically control output current according to load	Advanced magnetic flux vector control, general-purpose magnetic flux vector control	Pr. 71, Pr. 80, Pr. 81, Pr. 89, Pr. 90, Pr. 450, Pr. 800	76, 79
Compensate for motor slip to secure low-speed torque	Slip compensation (V/F control and general-purpose magnetic flux vector control only)	Pr. 245 to Pr. 247	81
Limit output current to prevent inverter trip	Stall prevention operation	Pr. 22, Pr. 23, Pr. 66, Pr. 156, Pr. 157	82

# 4.4.1 Manual torque boost (Pr. 0, Pr. 46)

You can compensate for a voltage drop in the low-frequency range to improve motor torque reduction in the low-speed range.


- Motor torque in the low-frequency range can be adjusted to the load to increase the starting motor torque.
- •Two kinds of start torque boosts can be changed by switching between terminals.

Parameter Number	Name	Initial Value		Setting Range	Description
		FR-E740-016 and 026	6%	0 to 30%	Set the output voltage at 0Hz as %.
0	Torque boost	FR-E740-040 to 095	4%		
		FR-E740-120 and 170	3%		
		FR-E740-230 and 300	2%		
40 .	Second torque	9999		0 to 30%	Set the torque boost when the RT signal is on.
46 *	boost			9999	Without second torque boost

<sup>\*</sup> The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

#### (1) Starting torque adjustment

- •On the assumption that *Pr. 19 Base frequency voltage* is 100%, set the output voltage at 0Hz in % to *Pr. 0 (Pr. 46)*.
- •Adjust the parameter little by little (about 0.5%), and check the motor status each time. If the setting is too large, the motor will overheat. The guideline is about 10% at the greatest.



#### (2) Set two kinds of torque boosts (RT signal, Pr. 46)

- •When you want to change torque boost according to applications, switch multiple motors with one inverter, etc., use Second torque boost.
- •Pr. 46 Second torque boost is valid when the RT signal is on.
- •For the terminal used for RT signal input, set "3" in any of Pr. 178 to Pr. 184 (input terminal function selection) to assign the function.



#### REMARKS

• The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 131)



#### NOTE

- The amount of current flows in the motor may become large according to the conditions such as the motor characteristics, load, acceleration/deceleration time, wiring length, etc., resulting in an overcurrent trip (OL (overcurrent alarm) then E.OC1 (overcurrent trip during acceleration), overload trip (E.THM (motor overload trip), or E.THT (inverter overload trip)
- (When a fault occurs, release the start command, and decrease the Pr. 0 setting 1% by 1% to reset.) (Refer to page 266.)
- The Pr. 0, Pr. 46 settings are valid only when V/F control is selected.
- When using the inverter dedicated motor (constant torque motor) with the FR-E740-120 and 170, set torque boost value to 2%. When Pr.  $\theta$  = "3%"(initial value), if Pr. 71 value is changed to the setting for use with a constant-torque motor, the Pr.  $\theta$  setting changes to 2%.
- Changing the terminal assignment using Pr. 178 to Pr. 184 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.



#### Parameters referred to

Pr. 3 Base frequency, Pr. 19 Base frequency voltage 🖫 Refer to page 88 Pr. 71 Applied motor 🖫 Refer to page 108

Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 128

# 4.4.2 Advance magnetic flux vector control (Pr. 71, Pr. 80, Pr. 81, Pr.89, Pr. 800)

Advanced magnetic flux vector control can be selected by setting the capacity, poles and type of the motor used in *Pr.* 80 and *Pr.* 81.

• Advanced magnetic flux vector control?

The low speed torque can be improved by providing voltage compensation so that the motor current which meets the load torque to flow. Output frequency compensation (slip compensation) is made so that the motor actual speed approximates a speed command value. Effective when load fluctuates drastically, etc.

When the FR-E500 series used for general-purpose magnetic flux vector control was replaced, select general-purpose magnetic flux vector control only when the same operation characteristic is necessary. (*Refer to page 79*)

Parameter Number	Name	Initial Value	Setting Range	Description
71	Applied motor	0	0,1, 3 to 6, 13 to 16, 23, 24 40, 43, 44 50, 53, 54	By selecting a standard motor or constant-torque motor, thermal characteristic and motor constants of each motor are set.
80	Motor capacity	9999	0.1 to 15kW 9999	Set the applied motor capacity.  V/F control
81	Number of motor poles	9999	2, 4, 6, 8, 10 9999	Set the number of motor poles.  V/F control
89	Speed control gain (advanced magnetic flux	9999	0 to 200%	Motor speed fluctuation due to load fluctuation is adjusted during advanced magnetic flux vector control. 100% is a referenced value.
vector)	vector)		9999	Gain matching with the motor set in <i>Pr.71</i> .
000	Control method		20	Advanced magnetic flux vector control *
800	selection	20	30	General-purpose magnetic flux vector control * (Refer to page 79)

The above parameters can be set when Pr. 160 User group read selection = "0".(Refer to page 177)

<sup>\*</sup> Set a value other than "9999" in Pr.~80 and Pr.~81.



#### **POINT**

If the following conditions are not satisfied, select V/F control since malfunction such as insufficient torque and uneven rotation may occur.

- The motor capacity should be equal to or one rank lower than the inverter capacity.
- Motor to be used is any of Mitsubishi standard motor, high efficiency motor (SF-JR, SF-HR 0.2kW or more) or Mitsubishi constant-torque motor (SF-JRCA, SF-HRCA four-pole 0.4kW to 15kW). When using a motor other than the above (other manufacturer's motor), perform offline auto tuning without fail.
- Single-motor operation (one motor run by one inverter) should be performed.
- The wiring length from inverter to motor should be within 30m. (Perform offline auto tuning in the state where wiring work is performed when the wiring length exceeds 30m.)
- Permissible wiring length between inverter and motor differs according to the inverter capacity and setting value of *Pr. 72 PWM frequency selection* (carrier frequency). *Refer to page 18* for the permissible wiring length.



## <Selection method of advanced magnetic flux vector control>

# Perform secure wiring.

(Refer to page 14)



	Motor	Pr. 71 Setting *1	Remarks
Mitsubishi standard	SF-JR	0 (initial value)	
motor	SF-HR	40	
Mitsubishi high efficiency motor	Others	3	Offline auto tuning is necessary. *2
Mitsubishi constant-	SF-JRCA 4P	1	
torque motor	SF-HRCA	50	
torque motor	Others (SF-JRC, etc.)	13	Offline auto tuning is necessary. *2
Other manufacturer's standard motor	_	3	Offline auto tuning is necessary. *2
Other manufacturer's			
constant-torque	_	13	Offline auto tuning is necessary. *2
motor			

- \*1 Refer to page 108, for other settings of Pr. 71.
- \*2 Refer to page 110 for offline auto tuning.



Set the motor capacity and the number of motor poles.

(Pr. 80, Pr. 81) (Refer to page 76)



Set motor capacity (kW) in *Pr. 80 Motor capacity* and the number of motor poles (number of poles) in *Pr. 81Number of motor poles*.

(V/F control is performed when the setting is "9999" (initial value).

#### Select the control method. (Pr. 800) (Refer to page 76)



Set "20" (initial value) in  $Pr.\ 800$  to make advanced magnetic flux vector control valid.

#### Set the operation command. (Refer to page 180)

Select the start command and speed command.

- (1)Start command
  - 1)Operation panel: Setting by pressing (RUN) of the operation panel
  - 2)External command: Setting by forward rotation or reverse rotation command (terminal STF or STR)
- (2)Speed command
  - 1)Operation panel: Setting by pressing of the operation panel
  - 2)External analog command (terminal 2 or 4):

Give a speed command using the analog signal input to terminal 2 (or terminal 4).

3)Multi-speed command:

The external signals (RH, RM, RL) may also be used to give speed command.

#### **Test run**


As required

• Perform offline auto tuning. (Pr. 96) (Refer to page 110)




#### **NOTE**

- Uneven rotation slightly increases as compared to the V/F control. (It is not suitable for machines such as grinding machine and wrapping machine which requires less uneven rotation at low speed.
- When a surge voltage suppression filter (FR-ASF-H/FR-BMF-H) is connected between the inverter and motor, output torque may decrease.)



The motor speed fluctuation at load fluctuation can be adjusted using  $Pr.\,89$ . (It is useful when the speed command does not match the motor speed after the FR-E500 series inverter is replaced with the FR-E700 series inverter, etc.)





## Parameters referred to

Pr. 71, Pr. 450 Applied motor F Refer to page 108 Pr. 800 Control method selection F Refer to page 74



# 4.4.3 General-purpose magnetic flux vector control (Pr. 71, Pr. 80, Pr. 81, Pr. 800)

General-purpose magnetic flux vector control is the same function as the FR-E500 series. Select this control when the same operation characteristic is necessary. For other cases, select advanced magnetic flux vector control. (*Refer to page 76*)

Parameter Number	Name	Initial Value	Setting Range	Description
71	Applied motor	0	0,1, 3 to 6, 13 to 16, 23, 24 40, 43, 44 50, 53, 54	By selecting a standard motor or constant torque motor, thermal characteristic and motor constants of each motor are set.
80	Motor capacity	9999	0.1 to 15kW	Applied motor capacity.
			9999	V/F control
81	Number of motor	9999	2, 4, 6, 8, 10	Number of motor poles.
01	poles	3399	9999	V/F control
800	Control method	20	20	Advanced magnetic flux vector control * (Refer to page 76)
000	selection	20	30	General-purpose magnetic flux vector control *

The above parameters can be set when Pr. 160 User group read selection = "0".(Refer to page 177)

<sup>\*</sup> Set a value other than "9999" in Pr. 80 and Pr. 81.



#### POINT

If the following conditions are not satisfied, select V/F control since malfunction such as insufficient torque and uneven rotation may occur.

- The motor capacity should be equal to or one rank lower than the inverter capacity.
- Motor to be used is any of Mitsubishi standard motor, high efficiency motor (SF-JR, SF-HR 0.2kW or more) or Mitsubishi constant torque motor (SF-JRCA, SF-HRCA four-pole 0.4kW to 15kW). When using a motor other than the above (other manufacturer's motor), perform offline auto tuning without fail.
- Single-motor operation (one motor run by one inverter) should be performed.
- The wiring length from inverter to motor should be within 30m. (Perform offline auto tuning in the state where wiring work is performed when the wiring length exceeds 30m.)
- Permissible wiring length between inverter and motor differs according to the inverter capacity and setting value of *Pr. 72 PWM frequency selection* (carrier frequency). *Refer to page 18* for the permissible wiring length.

#### <Selection method of general-purpose magnetic flux vector control>

# Perform secure wiring. (Refer to page 14)

#### Set the motor.(Pr. 71)

	Motor	Pr. 71 Setting *1	Remarks
Mitsubishi standard	SF-JR	0 (initial value)	
motor	SF-HR	40	
Mitsubishi high efficiency motor	Others	3	Offline auto tuning is necessary. *2
Mitsubishi constant-	SF-JRCA 4P	1	
torque motor	SF-HRCA	50	
torque motor	Others (SF-JRC, etc.)	13	Offline auto tuning is necessary. *2
Other manufacturer's		3	Offline auto tuning is necessary. *2
standard motor	_	3	Offiline auto turning is necessary. *2
Other manufacturer's			
constant-torque	_	13	Offline auto tuning is necessary. *2
motor			

- Refer to page 108, for other settings of Pr. 71.
- Refer to page 110 for offline auto tuning



Set the motor capacity and the number of motor poles.

(Pr. 80, Pr. 81) (Refer to page 74)



Set motor capacity (kW) in Pr. 80 Motor capacity and

the number of motor poles (number of poles) in Pr. 81 Number of motor poles.

(V/F control is performed when the setting is "9999" (initial value).

Select the control method.(Pr. 800) (Refer to page 74)



Set "30" in Pr. 800 to make general-purpose magnetic flux vector control valid.

#### Set the operation command. (Refer to page 180)

Select the start command and speed command.

- (1)Start command
  - 1)Operation panel: Setting by pressing (RUN) of the operation panel
  - 2)External command: Setting by forward rotation or reverse rotation command (terminal STF or STR)
- (2)Speed command
  - 1)Operation panel: Setting by pressing of the operation panel
  - 2)External analog command (terminal 2 or 4):
    - Give a speed command using the analog signal input to terminal 2 (or
  - 3)Multi-speed command:

The external signals (RH, RM, RL) may also be used to give speed command.

#### **Test run**

#### As required

- Perform offline auto tuning. (Pr. 96) (Refer to page 110)
- Set slip compensation. (Pr. 245, Pr. 246, Pr. 247) (Refer to page 81)



- Uneven rotation slightly increases as compared to the V/F control. (It is not suitable for machines such as grinding machine and wrapping machine which requires less uneven rotation at low speed.
- When a surge voltage suppression filter (FR-ASF-H/FR-BMF-H) is connected between the inverter and motor, output torque may decrease.)



# Parameters referred to

Pr.3 Base frequency, Pr.19 Base frequency voltage Refer to page 88

Pr.71 Applied motor Refer to page 108

Pr.77 Parameter write selection Refer to page 176



#### 4.4.4 Slip compensation (Pr. 245 to Pr. 247) V/F GP MFVC

When V/F control or general-purpose magnetic flux vector control is performed, the inverter output current may be used to assume motor slip to keep the motor speed constant.

Parameter Number	Name	Initial Value	Setting Range	Description
245	Rated slip	9999	0.01 to 50%	Rated motor slip.
245	Rated Slip	9999	0, 9999	No slip compensation
246	Slip compensation time constant	0.5s	0.01 to 10s	Slip compensation response time. When the value is made smaller, response will be faster. However, as load inertia is greater, a regenerative overvoltage fault (E.OV ) is more liable to occur.
247	Constant-power range slip compensation selection	9999	9999	Slip compensation is not made in the constant power range (frequency range above the frequency set in <i>Pr. 3</i> )  Slip compensation is made in the constant power range.

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

• Slip compensation is validated when the motor rated slip calculated by the following formula is set in Pr. 245. Slip compensation is not made when Pr. 245 = "0" or "9999".



# • REMARKS

- When performing slip compensation, the output frequency may become greater than the set frequency. Set the Pr. 1 Maximum frequency value a little higher than the set frequency.
- Slip compensation is always valid when advanced magnetic flux vector control is selected, the Pr. 245 to Pr. 247 settings are invalid.



# Parameters referred to

Pr. 1 Maximum frequency Maximum frequency Refer to page 86

Pr. 3 Base frequency Refer to page 88

# 4.4.5 Stall prevention operation (Pr. 22, Pr. 23, Pr. 48, Pr. 66, Pr. 156, Pr. 157, Pr. 277)

This function monitors the output current and automatically changes the output frequency to prevent the inverter from coming to trip due to overcurrent, overvoltage, etc. In addition, simple torque limit which limits the output torque to the predetermined value can be selected.

It can also limit stall prevention and fast-response current limit operation during acceleration/deceleration, driving or regeneration.

#### Stall prevention

If the output current exceeds the stall prevention operation level, the output frequency of the inverter is automatically varied to reduce the output current.

#### •Fast-response current limit

If the current exceeds the limit value, the output of the inverter is shut off to prevent an overcurrent.


#### Torque limit

The inverter output frequency is controlled so that the output torque (torque current) will not exceed the stall prevention operation level (motor rated torque is referenced).

Parameter Number	Name	Initial Value	Setting Range	Description
	Stall prevention operation		0	Stall prevention operation invalid
22	level	150%	0.1 to 200%	Set the current value to start the stall
	levei		0.1 to 20070	prevention operation.
	Stall prevention			The stall operation level can be reduced
	operation level		0 to 200%	when operating at a high speed above the
23	compensation factor	9999		rated frequency.
	at double speed		9999	Constant according to Pr. 22.
	Second stall prevention		0	Stall prevention operation invalid
48	<u>-</u>	9999	0.1 to 200%	Second stall prevention operation level
	operation current		9999	Same level as Pr. 22.
	Stall prevention		0 to 400Hz	Cat the fraguency at which the stall
66	operation reduction	50Hz		Set the frequency at which the stall
	starting frequency			operation level is started to reduce.
	Stall prevention operation	0		Select whether stall prevention operation
156			0 to 31, 100, 101	and fast-response current limit operation
	selection			will be performed or not.
			0 to 25s	Output start time of the OL signal output
157	OL signal output timer	0s	0 10 205	when stall prevention is activated.
			9999	Without the OL signal output
	Stall prevention operation		0	Output current is the limit level
277		0	1	Output torque (torque current) is the limit
	current switchover		ı	level


The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

#### (1) Block diagram



# Adjust the output torque (current) of the motor

# (2) Setting of stall prevention operation level (Pr. 22)



- •Set in *Pr. 22* the percentage of the output current to the rated inverter current at which stall prevention operation will be performed. Normally set this parameter to 150% (initial value).
- Stall prevention operation stops acceleration (makes deceleration) during acceleration, makes deceleration during constant speed, and stops deceleration (makes acceleration) during deceleration.
- •When stall prevention operation is performed, the OL signal is



• If an overload status lasts long, an inverter trip (e.g. electronic thermal O/L relay (E.THM)) may occur.

#### (3) A machine protection and load limit by torque limit (Pr. 277)

- •When Pr. 277 Stall prevention current switchover = "1", torque limit can be set.
- •When output torque (torque current) exceeds the stall prevention operation level, the output frequency is controlled to limit the output torque. For the stall prevention operation level at this time, the motor rated torque is defined as reference.




## • REMARKS

- When driving multiple motors with one inverter, torque limit does not function properly.
- Since magnetic flux decreases in the constant output range (Pr. 3 Base frequency or more), the inverter operate with lower torque than the stall prevention operation level.
- When toruque limit is activated during regeneration, the output frequency is increased uo to the maximum frequency.
- Torque limit does not function at 5Hz or less during deceleration.
- Note the following when using torque limit under V/F control.
  - (a) Capacity of the inverter and motor should be the same.
  - (b) Stall prevention operation level (torque limit level) is the rated torque reference of the motor whose capacity is equivalent to
  - When Pr. 0 Torque boost setting is large, torque limit is likely to occur in the low speed range.
  - (d) Use the advanced magnetic flux vector control when more appropriate torque limit is necessary.

### (4) Stall prevention operation signal output and output timing adjustment (OL signal, Pr. 157)

- •When the output current exceeds the stall prevention operation level and stall prevention is activated, the stall prevention operation signal (OL signal) turns on for longer than 100ms. When the output current falls to or below the stall prevention operation level, the output signal turns off.
- •Use Pr. 157 OL signal output timer to set whether the OL signal is output immediately or after a preset period of time.
- •This operation is also performed when the regeneration avoidance function or  $\varpi_{k}^{t}$  (overvoltage stall) is executed.
- •For the Y13 signal, set "3 (positive logic) or 103 (negative logic)" in Pr. 190 to Pr. 192 (output terminal function selection) and assign functions to the output terminal.


Pr. 157 Setting	Description
0 (initial value)	Output immediately.
0.1 to 25	Output after the set time (s) has elapsed.
9999	Not output.






- If the frequency has fallen to 1Hz by stall prevention operation and remains for 3s, a fault (E.OLT) appears to trip the
- Changing the terminal assignment using Pr. 190 to Pr. 192 (output terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.

## (5) Setting of stall prevention operation in high frequency range (Pr. 22, Pr. 23, Pr. 66)





- •During high-speed operation above the rated motor frequency, acceleration may not be made because the motor current does not increase. If operation is performed in a high frequency range, the current at motor lockup becomes smaller than the rated output current of the inverter, and the protective function (OL) is not executed even if the motor is at a stop. To improve the operating characteristics of the motor in this case, the stall prevention level can be reduced in the high frequency range. This function is effective for performing operation up to the high-speed range on a centrifugal separator etc. Normally, set 50Hz in *Pr.* 66 and 100% in *Pr.* 23.
- •Formula for stall prevention operation level

Stall prevention operation level in high frequency range (%) = A + B 
$$\times \left[ \frac{Pr. 22 - A}{Pr. 22 - B} \right] \times \left[ \frac{Pr. 23 - 100}{100} \right]$$

However, 
$$A = \frac{Pr. 66 \text{ (Hz)} \times Pr. 22 \text{ (\%)}}{\text{Output frequency (Hz)}}$$
,  $B = \frac{Pr. 66 \text{ (Hz)} \times Pr. 22 \text{ (\%)}}{400 \text{Hz}}$ 

•By setting "9999" (initial value) in *Pr. 23 Stall prevention operation level compensation factor at double speed*, the stall prevention operation level is constant at the *Pr. 22* setting up to 400Hz.

#### (6) Set two types stall prevention operation levels (Pr. 48)

- •Turning RT signal on makes Pr. 48 Second stall prevention operation current valid.
- •For the terminal used for RT signal input, set "3" in any of *Pr. 178 to Pr. 184 (input terminal function selection)* to assign the function.



#### **NOTE**

- Changing the terminal assignment using *Pr. 178 to Pr. 184 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.
- The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 131)



# (7) Limit the stall prevention operation and fast-response current limit operation according to the operating status (Pr. 156)

•Refer to the following table and select whether fast-response current limit operation will be performed or not and the operation to be performed at OL signal output.

Pr. 1	156	Fast-Response Current Limit	Opera	reventio tion Sele tivated activate	ection	OL Signal Output O:Operation	Pr. 156	Fast-Response Pr. 156 Current Limit				ection	Output O:Operation
Sett		O: Activated ●: Not activated	Acceleration	Constant	Deceleration	continued •: Operation not continued *1	Setting	O: Activated •: Not activated	Acceleration	Constant	Deceleration	continued •: Operation not continued *1	
0 (init valu	ial	0	0	0	0	0	16	0	0	0	0	•	
1	,	•	0	0	0	0	17	•	0	0	0	•	
2		0	•	0	0	0	18	0	•	0	0	•	
3		•	•	0	0	0	19	•	•	0	0	•	
4		0	0	•	0	0	20	0	0	•	0	•	
5		•	0	•	0	0	21	•	0	•	0	•	
6		0	•	•	0	0	22	0	•	•	0	•	
7		•	•	•	0	0	23	•	•	•	0	•	
8		0	0	0	•	0	24	0	0	0	•	•	
9		•	0	0	•	0	25	•	0	0	•	•	
10		0	•	0	•	0	26	0	•	0	•	•	
11		•	•	0	•	0	27	•	•	0	•	•	
12		0	0	•	•	0	28	0	0	•	•	•	
13		•	0	•	•	0	29	•	0	•	•	•	
14		0	•	•	•	— *2	30	0	•	•	•	— *2	
15	)	•	•	•	•	— *2	31	•	•	•	•	— *2	
100	Power driving	0	0	0	0	0	Power driving	•	0	0	0	0	
*3	Regeneration	•	•	•	•	—*2	Regeneration	• opped by stall prevention	•	•	•	—*2	

- \*1 When "Operation not continued for OL signal output" is selected, the Lill fault (stopped by stall prevention) is displayed and operation stopped.
- Since stall prevention is not activated, OL signal and E.OLT are not output.

  The settings "100" and "101" allow operations to be performed in the driving and regeneration modes, respectively. The setting "101" disables the fastresponse current limit in the driving mode.



#### NOTE

- When the load is heavy or the acceleration/deceleration time is short, stall prevention is activated and acceleration/ deceleration may not be made according to the preset acceleration/deceleration time. Set Pr. 156 and stall prevention operation level to the optimum values.
- In vertical lift applications, make setting so that the fast-response current limit is not activated. Torque may not be produced, causing a load drop due to gravity.



No not set a small value as the stall prevention operation current. Otherwise, torque generated will reduce.

Test operation must be performed.

Stall prevention operation during acceleration may increase the acceleration time.

Stall prevention operation performed during constant speed may cause sudden speed changes.

Stall prevention operation during deceleration may increase the deceleration time, increasing the deceleration distance.



# Parameters referred to

- Pr. 3 Base frequency Refer to page 88
  Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 128
- Pr. 190 to Pr. 192 (output terminal function selection) The Refer to page 134

#### 4.5 Limit the output frequency

Purpose	Parameter	Refer to Page	
Set upper limit and lower limit of output frequency	Maximum/minimum frequency	Pr. 1, Pr. 2, Pr. 18	86
Perform operation by avoiding mechanical resonance points	Frequency jump	Pr. 31 to Pr. 36	87


#### 4.5.1 Maximum/minimum frequency (Pr. 1, Pr. 2, Pr. 18)

Motor speed can be limited.

Clamp the upper and lower limits of the output frequency.

Parameter Number	Name	Initial Value	Setting Range	Description
1	Maximum frequency	120Hz	0 to 120Hz	Upper limit of the output frequency.
2	Minimum frequency	0Hz	0 to 120Hz	Lower limit of the output frequency.
10 *	High speed maximum	120Hz	120 to 1001 la	Set when performing the operation at 120Hz
18 *	frequency	120HZ	120 to 400Hz	or more.

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)



#### (1) Set maximum frequency

- Use Pr. 1 Maximum frequency to set the maximum frequency. If the frequency of the frequency command entered is higher than the setting, the output frequency is clamped at the maximum frequency.
- When you want to perform operation above 120Hz, set the upper limit of the output frequency to Pr. 18 High speed maximum frequency. (When Pr. 18 is set, Pr. 1 automatically switches to the frequency of Pr. 18. Also, when Pr. 1 is set, Pr. 18 is automatically changed to the frequency set in Pr. 1.

# REMARKS

When performing operation above 50Hz using the frequency setting analog signal, change Pr. 125 (Pr. 126) (frequency setting

### (2) Set minimum frequency

- Use Pr. 2 Minimum frequency to set the minimum frequency.
- If the set frequency is less than Pr. 2, the output frequency is clamped at Pr. 2 (will not fall below Pr. 2).



# > REMARKS

- When Pr. 15 Jog frequency is equal to or less than Pr. 2, the Pr. 15 setting has precedence over the Pr. 2 setting.
- When stall prevention is activated to decrease the output frequency, the output frequency may drop to Pr. 2 or below.



Note that when Pr. 2 is set to any value equal to or more than Pr. 13 Starting frequency, simply turning on the start signal will run the motor at the preset frequency according to the set acceleration time even if the command frequency is not input.



# Parameters referred to

Pr. 13 Starting frequency Refer to page 102 Pr. 15 Jog frequency The Refer to page 94




# 4.5.2 Avoid mechanical resonance points (frequency jumps) (Pr. 31 to Pr. 36)


When it is desired to avoid resonance attributable to the natural frequency of a mechanical system, these parameters allow resonant frequencies to be jumped.

Parameter Number	Name	Initial Value Setting Range		Description
31	Frequency jump 1A	9999	0 to 400Hz, 9999	
32	Frequency jump 1B	9999	0 to 400Hz, 9999	44. 45.04. 05.04. 05. (
33	Frequency jump 2A	9999	0 to 400Hz, 9999	1A to 1B, 2A to 2B, 3A to 3B is frequency
34	Frequency jump 2B	9999	0 to 400Hz, 9999	9999: Function invalid
35	Frequency jump 3A	9999	0 to 400Hz, 9999	Joseph Milandi III Mand
36	Frequency jump 3B	9999	0 to 400Hz, 9999	

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)



- Up to three areas may be set, with the jump frequencies set to either the top or bottom point of each area.
- The value set to 1A, 2A or 3A is a jump point and operation in the jump zone is performed at these frequencies.



Example 1

Example 2

To fix the frequency to 30Hz in the range 30Hz to 35Hz, set 35Hz in Pr. 34 and 30Hz in Pr. 33.

To jump the frequency to 35Hz in the range 30Hz to 35Hz, set 35Hz in Pr. 33 and 30Hz in Pr. 34.



#### NOTE

During acceleration/deceleration, the running frequency within the set area is valid.

# 4.6 Set V/F pattern


Purpose	Parameter	Refer to Page	
Set motor ratings	Base frequency, Base frequency voltage	Pr. 3, Pr. 19, Pr. 47	88
Select a V/F pattern according to applications.	Load pattern selection	Pr. 14	90

# 4.6.1 Base frequency, voltage (Pr. 3, Pr. 19, Pr. 47)

Used to adjust the inverter outputs (voltage, frequency) to the motor rating.

Parameter Number	Name	Name Initial Value Setting F		Description
3	Base frequency	50Hz	0 to 400Hz	Rated motor frequency. (50Hz/60Hz)
			0 to 1000V	Base voltage.
19 *	Base frequency voltage	8888	8888	95% of power supply voltage
			9999	Same as power supply voltage
47 .	Second V/F (base	0000	0 to 400Hz	Base frequency when the RT signal is on.
47 *	frequency)	9999	9999	Second V/F invalid

<sup>\*</sup> The above parameters can be set when *Pr. 160 User group read selection* = "0". (*Refer to page 177*)



## (1) Base frequency setting (Pr. 3)

- When operating a standard motor, generally set the rated frequency of the motor to *Pr. 3 Base frequency*. When running the motor using commercial power supply-inverter switch-over operation, set *Pr. 3* to the same value as the power supply frequency.
- If the frequency given on the motor rating plate is "60Hz" only, always set to "60Hz". It may result in an inverter trip due to overload.

Special care must be taken when "1" (variable torque load) is set in  $Pr.\ 14\ Load\ pattern\ selection$  .

• When using the Mitsubishi constant-torque motor, set *Pr. 3* to 60Hz.

#### (2) Set two kinds of base frequencies (Pr. 47)

- When you want to change the base frequency when switching two types of motors with one inverter, use the *Pr. 47 Second V/F* (base frequency).
- *Pr. 47 Second V/F (base frequency)* is valid when the RT signal is on. Set "3" in any of *Pr. 178 to Pr. 184 (input terminal function selection)* and assign the RT signal.

# • REMARKS

• The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 131)



- •Use Pr. 19 Base frequency voltage to set the base voltage (e.g. rated motor voltage).
- •If the setting is less than the power supply voltage, the maximum output voltage of the inverter is as set in Pr. 19.
- •Pr. 19 can be utilized in the following cases.
  - (a) When regeneration is high (e.g. continuous regeneration) During regeneration, the output voltage becomes higher than the reference and may cause an overcurrent trip (E.OC□) due to an increased motor current.
  - (b) When power supply voltage variation is large When the power supply voltage exceeds the rated voltage of the motor, speed variation or motor overheat may be caused by excessive torque or increased motor current.



• When advanced magnetic flux vector control or general-purpose magnetic flux vector control is selected, Pr. 3, Pr. 47 and Pr. 19 are invalid and Pr. 83 and Pr. 84 are valid.

Note that Pr. 3 or Pr. 47 value is made valid as inflection points of S-pattern when Pr. 29 Acceleration/deceleration pattern selection = "1" (S-pattern acceleration/deceleration A).

· Changing the terminal assignment using Pr. 178 to Pr. 184 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.



# Parameters referred to


Pr. 14 Load pattern selection Refer to page 90 Pr. 29 Acceleration/deceleration pattern selection Refer to page 103 Pr. 83 Motor rated voltage, Pr. 84 Rated motor frequency Refer to page 110 Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 128 General-purpose magnetic flux vector control Refer to page 79 Advanced magnetic flux vector control Refer to page 76

# 4.6.2 Load pattern selection (Pr. 14)

You can select the optimum output characteristic (V/F characteristic) for the application and load characteristics.

Parameter Number	Name	Initial Value	Setting Range	Description
			0	For constant torque load
			1	For variable torque load
14	Load pattern selection	0	2	For constant torque elevators
14			2	(at reverse rotation boost of 0%)
			2	For constant torque elevators
			3	(at reverse rotation boost of 0%)

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)




#### (1) Constant-torque load application (setting "0", initial value)

- At or less than the base frequency, the output voltage varies linearly with the output frequency.
- Set this value when driving the load whose load torque is constant even if the speed varies, e.g. conveyor, cart or roll drive.

### **POINT**


If the load is a fan or pump, select for constant-torque load (setting "0") in any of the following cases.


- · When a blower of large inertia moment (J) is accelerated in a short time
- For constant-torque load such as rotary pump or gear pump
- · When load torque increases at low speed, e.g. screw pump



#### (2) Variable-torque load application (setting "1")

- At or less than the base frequency, the output voltage varies with the output frequency in a square curve.
- Set this value when driving the load whose load torque varies in proportion to the square of the speed, e.g. fan or pump.





#### (3) Constant-torque load application (setting "2, 3")

- Set "2" when a vertical lift load is fixed as power forward rotation driving load at regenerative load at reverse rotation.
- Pr. 0 Torque boost is valid during forward rotation and torque boost is automatically changed to "0%" during reverse rotation. Pr. 46 Second torque boost is made valid when the RT signal turns on.
- Set "3" for an elevated load that is in the driving mode during reverse rotation and in the regenerative load mode during forward rotation according to the load weight, e.g. counterweight system.
- For the RT signal, set "3" in any of Pr. 178 to Pr. 184 (input terminal function selection) to assign the function.



# • REMARKS

- · When torque is continuously regenerated as vertical lift load, it is effective to set the rated voltage in Pr. 19 Base frequency voltage to prevent trip due to current at regeneration.
- In addition, when the RT signal is on, the other second functions are also valid.



- Load pattern selection does not function under advanced magnetic flux vector control and general-purpose magnetic flux vector control.
- Changing the terminal assignment using Pr. 178 to Pr. 184 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.



#### Parameters referred to

Pr. 0, Pr. 46 (Torque boost) Refer to page 75 Pr. 3 Base frequency Refer to page 88 Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 128 General-purpose magnetic flux vector control Refer to page 76 Advanced magnetic flux vector control Refer to page 76

# 4.7 Frequency setting by external terminals

Purpose	Parameter	Refer to Page	
Make frequency setting by	Multi apped appretion	Pr. 4 to Pr. 6, Pr. 24 to Pr. 27,	92
combination of terminals	Multi-speed operation	Pr. 232 to Pr. 239	92
Perform jog operation	Jog operation	Pr. 15, Pr. 16	94
Infinitely variable speed setting by	Pameta satting function	Pr. 59	06
terminals	Remote setting function	F1. 59	96

# 4.7.1 Operation by multi-speed operation (Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239)


Can be used to change the preset speed in the parameter with the contact signals.

Any speed can be selected by merely turning on-off the contact signals (RH, RM, RL, REX signals).

Parameter	Name	Initial Value	Setting Range	Description	
Number	Name	miliai vaiue	Setting Range	Description	
4	Multi-speed setting (high	50Hz	0 to 400Hz	Frequency when RH turns on	
7	speed)	30112	0 10 400112	Trequency when it it turns on	
5	Multi-speed setting (middle	30Hz	0 to 400Hz	Frequency when RM turns on.	
	speed)	30112	0 10 400112	Trequency when two turns on.	
6	Multi-speed setting (low	10Hz	0 to 400Hz	Frequency when RL turns on.	
	speed)	10112	0 10 400112	riequency when RL turns on.	
24 *	Multi-speed setting (speed 4)	9999	0 to 400Hz, 9999		
25 *	Multi-speed setting (speed 5)	9999	0 to 400Hz, 9999		
26 *	Multi-speed setting (speed 6)	9999	0 to 400Hz, 9999		
27 *	Multi-speed setting (speed 7)	9999	0 to 400Hz, 9999		
232 *	Multi-speed setting (speed 8)	9999	0 to 400Hz, 9999	Frequency from 4 speed to 15 speed can	
233 *	Multi-speed setting (speed 9)	9999	0 to 400Hz, 9999	be set according to the combination of	
234 *	Multi-speed setting (speed 10)	9999	0 to 400Hz, 9999	the RH, RM, RL and REX signals.	
235 *	Multi-speed setting (speed 11)	9999	0 to 400Hz, 9999	9999: not selected	
236 *	Multi-speed setting (speed 12)	9999	0 to 400Hz, 9999		
237 *	Multi-speed setting (speed 13)	9999	0 to 400Hz, 9999		
238 *	Multi-speed setting (speed 14)	9999	0 to 400Hz, 9999		
239 *	Multi-speed setting (speed 15)	9999	0 to 400Hz, 9999		

The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.

<sup>\*</sup> The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)



#### (1) 3-speed setting (*Pr. 4 to Pr. 6*)

•The inverter operates at frequencies set in Pr. 4 when RH signal is on, Pr. 5 when RM signal is on and Pr. 6 when RL signal is on.


# • REMARKS


- For multi-speed setting, if two or three speeds are simultaneously selected, priority is given to the set frequency of the lower signal.
  - For example, when the RH and RM signals turn on, the RM signal (Pr. 5) has a higher priority.
- The RH, RM, RL signals are assigned to the terminal RH, RM, RL in the initial setting. By setting "0 (RL)", "1 (RM)", "2 (RH)" in any of *Pr. 178 to Pr. 184 (input terminal function selection)*, you can assign the signals to other terminals.



## (2) Multi-speed setting for 4 or more speeds (Pr. 24 to Pr. 27, Pr. 232 to Pr. 239)

- •Frequency from 4 speed to 15 speed can be set according to the combination of the RH, RM, RL and REX signals. Set the running frequencies in Pr. 24 to Pr. 27, Pr. 232 to Pr. 239 (In the initial value setting, speed 4 to speed 15 are unavailable).
- •For the terminal used for REX signal input, set "8" in any of Pr. 178 to Pr. 184 (input terminal function selection) to assign the function.





Multi-speed operation connection example

When "9999" is set in Pr. 232 Multi-speed setting (speed 8), the frequency changes to 0Hz when RH, RM and RL are turned off and REX is turned on.



# (I) REMARKS

The priorities of the frequency commands by the external signals are "jog operation > multi-speed operation > terminal 4 analog input > terminal 2 analog input".

(Refer to page 168 for the frequency command by analog input)

- Valid in the external operation mode or PU/external combined operation mode (Pr. 79 = "3" or "4").
- Multi-speed parameters can also be set in the PU or external operation mode.
- Pr. 24 to Pr. 27 and Pr. 232 to Pr. 239 settings have no priority between them.
- When Pr. 59 Remote function selection ≠ "0", multi-speed setting is invalid as RH, RM and RL signals are remote setting signals.



• Changing the terminal assignment using Pr. 178 to Pr. 184 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.



#### Parameters referred to

Pr. 15 Jog frequency Refer to page 94

Pr. 59 Remote function selection Refer to page 96 Pr. 79 Operation mode selection Refer to page 180

Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 128

# 4.7.2 Jog operation (Pr. 15, Pr. 16)

You can set the frequency and acceleration/deceleration time for jog operation. Jog operation can be performed in either of the external and the PU operation mode.

This operation can be used for conveyor positioning, test operation, etc.


Parameter Number	Name	Initial Value	Setting Range	Description
15	Jog frequency	5Hz	0 to 400Hz	Frequency for jog operation.
16	Jog acceleration/ deceleration time	0.5s	0 to 3600/ 360s *	Acceleration/deceleration time for jog operation. As the acceleration/deceleration time, set the time taken to reach the frequency (initial value is 50Hz) set in <i>Pr. 20 Acceleration/deceleration reference frequency</i> . Acceleration/deceleration time can not be set separately.

These parameters are displayed as simple mode parameter only when the parameter unit (FR-PU04/FR-PU07) is connected. When the parameter unit is not connected, the above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

\* When the Pr. 21 Acceleration/deceleration time increments setting is "0" (initial value), the setting range is "0 to 3600s" and setting increments is "0.1s". When the setting is "1", the setting range is "0 to 360s" and the setting increments is "0.01s".

#### (1) Jog operation from outside


- •When the jog signal is on, a start and stop can be made by the start signal (STF, STR).
- •For the terminal used for Jog operation selection, set "5" in any of *Pr.178 to Pr.184 (input terminal function selection)* to assign the function.



If not displayed, press  $\frac{PU}{EXT}$  to change to the external (EXT) operation mode. If the operation mode still does not change, set Pr. 79 to change to the external operation mode.

2. Turn on the JOG switch.

- 3. Turn the start switch (STF or STR) on.
  - The motor runs while the start switch (STF or STR) is on.
  - The motor runs at 5Hz. (initial value of Pr. 15)
- 4. Turn the start switch (STF or STR) off.




# REMARKS

- When you want to change the running frequency, change Pr. 15 Jog frequency. (initial value "5Hz")
- When you want to change the acceleration/deceleration time, change Pr. 16 Jog acceleration/deceleration time. (initial value "0.5s") The acceleration time and deceleration time cannot be set separately for jog operation.



# (2) Jog operation from PU

•Selects Jog operation mode from the operation panel and PU (FR-PU04/FR-PU07). Operation is performed only while the start button is pressed.



# Operation

— Display ————

- Confirmation of the RUN indication and operation mode indication
  - The monitor mode should have been selected.
  - The inverter should be at a stop.
- 2. Press  $\frac{PU}{EXT}$  to choose the PU Jog operation mode.
- 3. Press (RUN)
  - While (RUN) is pressed, the motor rotates.
  - The motor runs at 5Hz. (Pr. 15 initial value)
- 4. Release (RUN)
















# [When changing the frequency of PU Jog operation]

5. Press (MODE) to choose the parameter setting mode.






(The parameter number read previously appears.)



- 7. Press  $(\overline{\text{SET}})$  to show the currently set value. (5Hz)
- 8. Turn to set the value to " !!!!!". (10Hz)
- 9. Press (SET) to set.











Flicker...Parameter setting complete!!



#### NOTE

- When Pr. 29 Acceleration/deceleration pattern selection = "1" (S-pattern acceleration/deceleration A), the acceleration/deceleration time is the period of time required to reach Pr. 3 Base frequency.
- The Pr. 15 setting should be equal to or higher than the Pr. 13 Starting frequency. Starting frequency
- The JOG signal can be assigned to the input terminal using any of *Pr. 178 to Pr. 184 (input terminal function selection)*. When terminal assignment is changed, the other functions may be affected. Please make setting after confirming the function of each terminal.
- During jog operation, the second acceleration/deceleration via the RT signal cannot be selected. (The other second functions are valid. (Refer to page 227))
- When *Pr. 79 Operation mode selection* = "4", pressing RUN of the operation panel and FWD / REV of the parameter unit (FR-PU04/FR-PU07) starts the inverter and pressing RESET stops the inverter.
- This function is invalid when Pr. 79 = "3" or "6".



#### Parameters referred to


- Pr. 13 Starting frequency Starting frequency Refer to page 102
- Pr. 29 Acceleration/deceleration pattern selection TE Refer to page 103
- Pr. 20 Acceleration/deceleration reference frequency, Pr. 21 Acceleration/deceleration time increments 👺 Refer to page 99
- Pr. 79 Operation mode selection Refer to page 180
- Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 128

# 4.7.3 Remote setting function (Pr. 59)

•Even if the operation panel is located away from the enclosure, you can use contact signals to perform continuous variable-speed operation, without using analog signals.

Parameter			Setting	Description		
Number	Name	Initial Value	Range	RH, RM, RL signal function	Frequency setting storage function	
			0	Multi-speed setting		
			1	Remote setting	With	
			2	Remote setting	Frequency setting storage function	
59	Remote function selection	0			Not used	
		ļ	3	Remote setting	(Turning STF/STR off	
			3	Remote setting	With Not used Not used (Turning STF/STR off clears remotely-set	
					frequency.)	

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 156)



<sup>\*</sup> External running frequency (other than multi-speed) or PU running frequency



#### (1) Remote setting function

•Use *Pr. 59* to select whether the remote setting function is used or not and whether the frequency setting storage function in the remote setting mode is used or not.

When *Pr.* 59 is set to any of "1 to 3" (remote setting function valid), the functions of the RH, RM and RL signals are changed to acceleration (RH), deceleration (RM) and clear (RL).

•When using the remote setting function, following frequencies can be compensated to the frequency set by RH and RM operation according to the operation mode.

During external operation (including Pr. 79 = "4") ...... external frequency command other than multi-speed settings

#### (2) Frequency setting storage

• The frequency setting storage function stores the remotely-set frequency (frequency set by RH/RM operation) into the memory (EEPROM). When power is switched off once, then on, operation is resumed with that output frequency value. (Pr. 59 = 1)


<Frequency setting storage conditions>

- · Frequency at the point when the start signal (STF or STR) turns off
- The remotely-set frequency is stored every one minute after one minute has elapsed since turn off (on) of both the RH (acceleration) and RM (deceleration) signals. (The frequency is written if the present frequency setting compared with the past frequency setting every one minute is different. The state of the RL signal does not affect writing.)



#### NOTE

The range of frequency changeable by RH (acceleration) and RM (deceleration) is 0 to maximum frequency (Pr. 1 or Pr. 18 setting).
 Note that the maximum value of set frequency is (main speed + maximum frequency).



- When the acceleration or deceleration signal switches on, acceleration/deceleration time is as set in *Pr. 44 Second acceleration/deceleration time* and *Pr. 45 Second deceleration time*. Note that when long time has been set in *Pr. 7* or *Pr. 8*, the acceleration/deceleration time is as set in *Pr. 7* or *Pr. 8*. (when RT signal is off)
  - When the RT signal is on, acceleration/deceleration is made in the time set in *Pr. 44* and *Pr. 45*, regardless of the *Pr. 7* or *Pr. 8* setting.
- Even if the start signal (STF or STR) is off, turning on the acceleration (RH) or deceleration (RM) signal varies the preset frequency.
- When switching the start signal from ON to OFF, or changing frequency by the RH or RM signal frequently, set the frequency setting value storage function (write to EEPROM) invalid (Pr. 59 = "2, 3"). If set valid (Pr. 59 = "1"), frequency is written to EEPROM frequently, this will shorten the life of the EEPROM.
- The RH, RM, RL signals can be assigned to the input terminal using any *Pr. 178 to Pr. 184 (input terminal function selection)*. When terminal assignment is changed, the other functions may be affected. Please make setting after confirming the function of each terminal.
- · Also available for the network operation mode.







# > REMARKS

During jog operation or PID control operation, the remote setting function is invalid.

#### Setting frequency is "0"

- Even when the remotely-set frequency is cleared by turning on the RL (clear) signal after turn off (on) of both the RH and RM signals, the inverter operates at the remotely-set frequency stored in the last operation if power is reapplied before one minute has elapsed since turn off (on) of both the RH and RM signals
- When the remotely-set frequency is cleared by turning on the RL (clear) signal after turn off (on) of both the RH and RM signals, the inverter operates at the frequency in the remotely-set frequency cleared state if power is reapplied after one minute has elapsed since turn off (on) of both the RH and RM signals.







 $lap{N}$  When selecting this function, re-set the maximum frequency according to the machine.



#### Parameters referred to

Pr. 1 Maximum frequency, Maximum frequency, Pr. 18 High speed maximum frequency Refer to page 86

Pr. 7 Acceleration time, Pr. 8 Deceleration time, Pr. 44 Second acceleration/deceleration time, Pr. 45 Second deceleration time 👺 Refer to page 99

Pr. 178 to Pr. 184 (input terminal function selection) Terminal Function Refer to page 128



# 4.8 Setting of acceleration/deceleration time and acceleration/ deceleration pattern

Purpose	Parameter t	Parameter that should be Set		
Motor acceleration/deceleration	Acceleration/deceleration	Pr. 7, Pr. 8, Pr. 20, Pr. 21, Pr. 44,	00	
time setting	times	Pr. 45, Pr. 147	99	
Starting frequency	Starting frequency and start-time hold	Pr. 13, Pr. 571	102	
Set acceleration/deceleration pattern suitable for application	Acceleration/deceleration pattern	Pr. 29	103	
Automatically set optimum acceleration/deceleration time.	Automatic acceleration/ deceleration	Pr. 61 to Pr. 63, Pr. 292	104	

# 4.8.1 Setting of the acceleration and deceleration time (Pr. 7, Pr. 8, Pr. 20, Pr. 21, Pr. 44, Pr. 45, Pr. 147)


Used to set motor acceleration/deceleration time.


Set a larger value for a slower speed increase/decrease or a smaller value for a faster speed increase/decrease. For the acceleration time at automatic restart after instantaneous power failure, refer to *Pr. 611 Acceleration time at a restart (page 151)*.

Parameter Number	Name	Initial Value		Setting Range	Description	
		FR-E740-095 or less	5s	0 to 3600/	Motor acceleration time.	
7	Acceleration time	FR-E740-120 and 170	10s	360s *2		
		FR-E740-230 and 300	15s	3005 *2		
		FR-E740-095 or less	5s	0 to 3600/		
8	Deceleration time	FR-E740-120 and 170	10s	360s *2	Motor deceleration t	ime.
		FR-E740-230 and 300	15s	3608 *2		
	Acceleration/				F	and the bearing
<b>20</b> *1	deceleration	50Hz		1 to 400Hz	Frequency that will be the basis of acceleration/deceleration time. <i>Pr. 20</i>	
	reference frequency					
	Acceleration/			0	Increments: 0.1s	Increments and setting
<b>21</b> *1		_	0	0	Range: 0 to 3600s	range of acceleration/
21 *1	deceleration time	0		1	Increments: 0.01s	deceleration time
	increments				Range: 0 to 360s	setting can be changed.
	Second acceleration/	FR-E740-095 or less	5s	0 to 3600/	Acceleration/deceleration time when the RT	
<b>44</b> *1	deceleration time	FR-E740-120 and 170	10s	360s *2		
	deceleration time	FR-E740-230 and 300	15s	3005 *2	signal is on.	
	Second deceleration	9999		0 to 3600/	Deceleration time when the RT signal is on.	
<b>45</b> *1	time			360s *2		
	time			9999	Acceleration time = deceleration time	
	Acceleration/				Frequency when au	tomatically switching to
	deceleration time	0000		0 to 400Hz	the acceleration/deceleration time of Pr. 44	
		9999		ı	and Pr. 45.	
	switching frequency			9999	No function	

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

Depends on the Pr. 21 Acceleration/deceleration time increments setting. The initial value for the setting range is "0 to 3600s" and the setting increments is "0.1s".





# (1) Acceleration time setting (Pr. 7, Pr. 20)

- •Use Pr. 7 Acceleration time to set the acceleration time required to reach Pr. 20 Acceleration/deceleration reference frequency from 0Hz.
- •Set the acceleration time according to the following formula.

Example) When Pr. 20 = 50Hz (initial value), Pr. 13 = 0.5Hz, and acceleration can be made up to the maximum operating frequency of 40Hz in 10s

$$Pr. 7 = \frac{50 \text{Hz}}{40 \text{Hz} - 0.5 \text{Hz}} \times 10 \text{s} = 12.7 \text{s}$$

# (2) Deceleration time setting (Pr. 8, Pr. 20)

- •Use Pr. 8 Deceleration time to set the deceleration time required to reach 0Hz from Pr. 20 Acceleration/deceleration reference frequency.
- •Set the deceleration time according to the following expression.

$$\frac{\text{Deceleration}}{\text{time setting}} = \frac{Pr. 20}{\text{Maximum operating frequency - } Pr. 10} \times \text{Deceleration time from maximum operating frequency to stop}$$

Example) When the frequency can be decelerated down to the maximum operating frequency of 40Hz in 10s with 120Hz set in Pr. 20 and 3Hz set in Pr. 10

$$Pr. 8 = \frac{120 \text{Hz}}{40 \text{Hz} - 3 \text{Hz}} \times 10 \text{s} = 32.4 \text{s}$$

# (3) Change the setting range and increments of the acceleration/deceleration time (Pr. 21)

•Use Pr. 21 to set the acceleration/deceleration time and minimum setting range.

Value "1" ......0 to 360s (minimum setting increments: 0.01s)



#### NOTE

Changing the Pr. 21 setting changes the acceleration/deceleration time setting (Pr. 7, Pr. 8, Pr. 16, Pr. 44, Pr. 45). (It does not influence the setting of Pr. 611 Acceleration time at a restart.)

When Pr. 7 is set to "5.0s" at Pr. 21 setting of "0", and then Pr. 21 is changed to "1", the Pr. 7 setting automatically changes to "0.5s".




#### (4) Set two kinds of acceleration/deceleration times (RT signal, Pr. 44, Pr. 45, Pr. 147)

- Pr. 44 and Pr. 45 are valid when the RT signal is on, or the output frequency reaches or exceeds the setting of Pr. 147.
- •When "9999" is set to Pr. 45, the deceleration time becomes equal to the acceleration time (Pr. 44).
- •For the RT signal, set "3" in any of Pr. 178 to Pr. 184 (input terminal function selection) to assign the function.
- •When RT signal is off, automatic switching of the acceleration/deceleration time is available with Pr. 147.

Pr. 147 Setting	Acceleration/Deceleration Time	Description	
9999 (initial value)	Pr. 7. Pr. 8	No automatic switching of the acceleration/deceleration	
9999 (Illitial value)	F1. 7, F1. 0	time	
0.00Hz	Pr. 44, Pr. 45	Second acceleration/deceleration time from a start	
$0.00$ Hz $\leq Pr. 147 \leq$ Set frequency	Output frequency < Pr. 147: Pr. 7, Pr. 8	Acceleration/deceleration time automatic switching *	
0.00Hz ≤ <i>Pr. 147</i> ≤ Set frequency	Pr. 147 ≤ Output frequency: Pr. 44, Pr. 45	Acceleration/deceleration time automatic switching *	
Set frequency < Pr. 147	Pr. 7. Pr. 8	No automatic switching, since output frequency will not	
Set frequency < Pr. 147	Pr. 7, Pr. 0	reach the switching frequency	

When the RT signal turns on, the acceleration/deceleration time switches to the second acceleration/deceleration time even when the output frequency is not reached to Pr. 147 setting.





#### NOTE

- When the acceleration/deceleration pattern is S-pattern acceleration/deceleration A (refer to page 103), the acceleration/ deceleration time is the time required to reach Pr. 3 Base frequency .
- Acceleration/deceleration time formula when the set frequency is the base frequency or higher

$$t = \frac{4}{9} \times \frac{T}{(Pr. 3)^2} \times f^2 + \frac{5}{9} T$$

- T: Acceleration/deceleration time setting (s)
- Guideline for acceleration/deceleration time at the Pr. 3 Base frequency of 50Hz (0Hz to set frequency)

Frequency setting (Hz) Acceleration/ deceleration time (s)	50	120	200	400
5	5	16	38	145
15	15	47	115	429

Changing terminal assignment may affect the other functions. Make setting after confirming the function of each terminal.



# • REMARKS

- The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 131)
  - If the Pr. 20 setting is changed, the Pr. 125 and Pr. 126 (frequency setting signal gain frequency) settings do not change. Set Pr. 125 and Pr. 126 to adjust the gains.
- When the Pr. 7, Pr. 8, Pr. 44 and Pr. 45 settings are 0.03s or less, the acceleration/deceleration time is 0.04s. At that time, set Pr. 20 to "120Hz" or less.
- Any value can be set to the acceleration/deceleration time but the actual motor acceleration/deceleration time cannot be made shorter than the shortest acceleration/deceleration time determined by the mecanical system J (moment of inertia) and motor torque.



#### Parameters referred to

Pr. 3 Base frequency Refer to page 88

Pr. 10 DC injection brake operation frequency Refer to page 118

Pr. 29 Acceleration/deceleration pattern selection Refer to page 103

Pr. 125, Pr. 126 (frequency setting gain frequency) Refer to page 168


Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 128

# 4.8.2 Starting frequency and start-time hold function (Pr. 13, Pr. 571)

You can set the starting frequency and hold the set starting frequency for a certain period of time. Set these functions when you need the starting torque or want to smooth motor drive at a start.

Parameter Number	Name	Initial Value	Setting Range	Description
13	Starting frequency	0.5Hz	0 to 60Hz	Frequency at start can be set in the range 0 to 60Hz.  Starting frequency at which the start signal is turned on.
571	Restart coasting time	9999	0.0 to 10.0s 9999	Holding time of <i>Pr. 13 Starting frequency</i> .  Holding function at a start is invalid

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)




## (1) Starting frequency setting (Pr. 13)

- •Frequency at start can be set in the range 0 to 60Hz.
- You can set the starting frequency at which the start signal is turned on.



#### **NOTE**

The inverter will not start if the frequency setting signal is less than the value set in Pr. 13. For example, when 5Hz is set in Pr. 13, the motor will not start running until the frequency setting signal reaches 5Hz.



#### (2) Start-time hold function (Pr. 571)

- •This function holds during the period set in *Pr. 571* and the output frequency set in *Pr. 13 Starting frequency*.
- •This fnction performs initial excitation to smooth the motor drive at a start.



# REMARKS

When Pr. 13 = "OHz", the starting frequency is held at 0.01Hz.



#### **NOTE**

- When the start signal was turned off during start-time hold, deceleration is started at that point.
- At switching between forward rotation and reverse rotation, the starting frequency is valid but the start-time hold function is invalid.



Note that when *Pr. 13* is set to any value equal to or lower than *Pr. 2 Minimum frequency*, simply turning on the start signal will run the motor at the preset frequency even if the command frequency is not input.



## Parameters referred to

Pr. 2 Minimum frequency Refer to page 86




# 4.8.3 Acceleration/deceleration pattern (Pr. 29)

You can set the acceleration/deceleration pattern suitable for application.


Parameter Number	Name	Initial Value	Setting Range	Description
	Acceleration/deceleration		0	Linear acceleration/ deceleration
29		0	1	S-pattern acceleration/deceleration A
pattern selecti	pattern selection		2	S-pattern acceleration/deceleration B

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)



# (1) Linear acceleration/deceleration (Pr. 29 setting "0", initial value)

•For the inverter operation, the output frequency is made to change linearly (linear acceleration/deceleration) to prevent the motor and inverter from excessive stress to reach the set frequency during acceleration, deceleration, etc. when frequency changes. Linear acceleration/deceleration has a uniform frequency/time slope.



#### (2) S-pattern acceleration/deceleration A (Pr. 29 = "1")

•For machine tool spindle applications, etc.


Used when acceleration/deceleration must be made in a short time to a high-speed range of not lower than the base frequency.

In this acceleration/deceleration pattern, *Pr. 3 Base frequency* (fb) is the inflection point of the S pattern and you can set the acceleration/deceleration time appropriate for motor torque reduction in a constant-power operation range of base frequency (fb) or higher.



#### **NOTE**

As the acceleration/deceleration time of S-pattern acceleration/deceleration A, set the time taken until Pr. 3 Base frequency is reached, not Pr. 20 Acceleration/deceleration reference frequency.



#### (3) S-pattern acceleration/deceleration B (Pr. 29 = "2")

•For prevention of load shifting in conveyor and other applications.

Since acceleration/deceleration is always made in an S shape from current frequency (f2) to target frequency (f1), this function eases shock produced at acceleration/deceleration and is effective for load collapse prevention, etc.



## Parameters referred to

Pr. 3 Base frequency Refer to page 88

Pr. 7 Acceleration time, Pr. 8 Deceleration time, Pr. 20 Acceleration/deceleration reference frequency Refer to page 99

# 4.8.4 Shortest acceleration/deceleration (automatic acceleration/deceleration) (Pr. 61 to Pr. 63, Pr. 292, Pr. 293)

The inverter operates in the same conditions as when appropriate values are set in each parameter even if acceleration/deceleration time and V/F pattern are not set. This function is useful when you just want to operate, etc. without fine parameter setting.

Parameter	Name	Initial	Setting	Description
Number	Name	Value	Range	Description
		9999	0 to 500A	Set the reference current during shortest
61	Reference current			acceleration/deceleration.
			9999	Rated inverter output current value is reference
62	Reference value at	9999	0 to 200%	Set the limit value during shortest acceleration.
02	acceleration	9999	9999	150% is a limit value
63	Reference value at	9999	0 to 200%	Set the limit value during shortest deceleration.
03	deceleration	9999	9999	150% is a limit value
	Automatic acceleration/ deceleration	0	0	Normal mode
			1	Shortest acceleration/deceleration (without brake)
292			11	Shortest acceleration/deceleration (with brake)
			7, 8	Brake sequence mode 1, 2
				(Refer to page 124)
			0	Both acceleration and deceleration are made in the
				shortest acceleration/deceleration mode
293	Acceleration/deceleration separate selection	0	1	Only acceleration is made in the shortest
			'	acceleration/deceleration mode
			2	Only deceleration is made in the shortest
				acceleration/deceleration mode

#### (1) Shortest acceleration/deceleration mode (Pr. 292 = "1, 11", Pr. 293)

- •Set when you want to accelerate/decelerate the motor for the shortest time. It is desired to make acceleration/deceleration in a shorter time for a machine tool etc. but the design values of machine constants are unknown.
- •Acceleration/deceleration speed is automatically adjusted at a start of acceleration/deceleration from the value of the setting value of *Pr. 7 Acceleration time* and *Pr. 8 Deceleration time* so that acceleration/deceleration is made with the maximum torque the inverter can output. (The setting values of *Pr. 7* and *Pr. 8* are not changed.)
- •Either acceleration or deceleration can be made in the shortest time using *Pr. 293Acceleration/deceleration separate selection*. When the setting value is "0" (initial value), both acceleration and deceleration can be made in the shortest time.
- •Set "11" when an optional high-duty brake resistor or brake unit is connected. Deceleration time can be further shortened.
- •When the shortest/acceleration mode is selected, the stall prevention operation level during acceleration/deceleration from the value of becomes 150% (adjustable using *Pr. 61* to *Pr. 63* ). Setting of *Pr. 22 Stall prevention operation level* is used only during a constant speed operation.
- •It is inappropriate to use for the following applications.
  - a) Machine with a large inertia such as a fan (more than 10 times). Since stall prevention operation will be activated for a long time, this type of machine may be brought to an alarm stop due to motor overloading, etc.
  - b) It is desired to always perform operation with a constant acceleration/deceleration time.
  - c) It is desired to perform operation making sure the inverter and motor have enough capability.

# REMARKS

- Even if automatic acceleration/deceleration mode has been selected, inputting the jog signal (jog operation) or RT signal (second function selection) during an inverter stop will switch to the normal operation and give priority to jog operation or second function selection. Note that JOG and RT signal input is invalid even if JOG signal and RT signal are input during operation in automatic acceleration/deceleration mode.
- Since acceleration/deceleration is made with the stall prevention operation being activated, the acceleration/deceleration speed always varies according to the load conditions.
- Note that when proper values are set in Pr. 7 and Pr. 8, acceleration/deceleration time may be shorter than selecting shortest
  acceleration/deceleration mode.



# (2) Adjustment of shortest acceleration/deceleration mode (Pr. 61 to Pr. 63)

•By setting the adjustment parameters Pr. 61 and Pr. 63, the application range can be made wider.

Parameter Number	Name	Setting Range	Description
61	Reference current	0 to 500A	For example, when the motor and inverter are different in capacity, set the rated motor current value.  Set reference current (A) of the stall prevention operation level during acceleration/deceleration.
	9999 (initial value)		The rated inverter current is defined as reference.
62	Reference value at acceleration	0 to 200%	Set when it is desired to change the reference level of acceleration and deceleration.  Set the stall prevention operation level (ratio to the current value of <i>Pr. 61</i> ) during acceleration/deceleration.
63	Reference value at deceleration	9999 (initial value)	The 150% value during shortest acceleration/deceleration is judged as the stall prevention operation level.

# • REMARKS

Since the Pr. 61 to Pr. 63 settings automatically return to the initial value (9999) if the Pr. 292 setting is changed, set Pr. 292 first when you need to set Pr. 61 to Pr. 63.

# Parameters referred to

Pr. 0 Torque boost Refer to page 75
Pr. 7 Acceleration time, Pr. 8 Deceleration time Refer to page 99
Pr. 22 Stall prevention operation level Refer to page 82

# 4.9 Selection and protection of a motor

Purpose	Parameter that	should be Set	Refer to Page
Motor protection from overheat	Electronic thermal O/L relay	Pr. 9, Pr. 51	106
Use the constant torque motor	Applied motor	Pr. 71	108
The motor performance can be maximized for operation in magnetic flux vector control method.	Offline auto tuning	Pr. 71, Pr. 80 to Pr. 84, Pr. 90 to Pr. 94, Pr. 96, Pr. 859	110

# 4.9.1 Motor overheat protection (Electronic thermal O/L relay) (Pr. 9, Pr. 51)


Set the current of the electronic thermal relay function to protect the motor from overheat. This feature provides the optimum protective characteristics, including reduced motor cooling capability, at low speed.

Parameter Number	Name	Initial Value	Setting Range	Description
9	Electronic thermal O/L relay	Inverter rated current *1	0 to 500A	Set the rated motor current.
<b>51</b> *2	Second electronic thermal O/L relay *3	9999	0 to 500A 9999	Valid when the RT signal is on. Set the rated motor current. Second electronic thermal O/L relay invalid

- \*1 The initial value of the FR-E740-026 or less is set to 85% of the rated inverter current.
- \*2 The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)
- \*3 When parameter is read using the FR-PU04, a parameter name different from an actual parameter is displayed.

### (1) Electronic thermal O/L relay (Pr. 9)

#### Electronic thermal O/L relay operation characteristic



This function detects the overload (overheat) of the motor and trips. (The operation characteristic is shown on the left)

- Set the rated current (A) of the motor in Pr. 9.
   (If the motor has both 50Hz and 60Hz rating and the Pr. 3 Base frequency is set to 60Hz, set the 1.1 times of the 60Hz rated motor current.)
- Set "0" in Pr. 9 when you do not want to operate the electronic thermal O/L relay, e.g. when using an external thermal relay with the motor. (Note that the output transistor protection of the inverter functions (E.THT).)
- When using a Mitsubishi constant-torque motor
  - 1) Set "1" or "13 to 16", "50", "53", "54" in any of *Pr.* 71. (This provides a 100% continuous torque characteristic in the low-speed range.
  - 2) Set the rated current of the motor in Pr. 9.
- \*1 When a value 50% of the inverter rated output current (current value) is set to *Pr. 9*
- \*2 The % value denotes the percentage to the inverter rated output current. It is not the percentage to the motor rated current.
- \*3 When you set the electronic thermal O/L relay dedicated to the Mitsubishi constant-torque motor, this characteristic curve applies to operation at 6Hz or higher.

# **NOTE**


- Fault by electronic thermal relay function is reset by inverter power reset and reset signal input. Avoid unnecessary reset and power-off.
- When multiple motors are operated by a single inverter, protection cannot be provided by the electronic thermal function. Install an external thermal relay to each motor.
- When the difference between the inverter and motor capacities is large and the setting is small, the protective characteristics of the electronic thermal relay function will be deteriorated. In this case, use an external thermal relay.
- A special motor cannot be protected by the electronic thermal relay function.
- The operation time of the transistor protection thermal shortens when the Pr. 72 PWM frequency selection setting increases.



## (2) Set two different electronic thermal O/L relays (Pr. 51)

Use this function when running two motors of different rated currents individually by a single inverter. (When running two motors together, use external thermal relays.)

- •Set the rated current of the second motor to Pr. 51.
- •When the RT signal is on, thermal protection is provided based on the Pr. 51 setting.
- •For the terminal used for RT signal input, set "3" in any of Pr. 178 to Pr. 184 (input terminal function selection) to assign the function.



Pr. 450	Pr. 9	Pr.51	RT = OFF		RT :	= ON
Second applied motor	Electronic thermal O/L relay	Second electronic thermal O/L relay	First motor	Second motor	First motor	Second motor
		9999	×	×	×	×
9999	0	0	×	×	×	×
		0.01 to 500	×	Δ	×	0
	Other than 0	9999	0	×	0	×
9999		0	0	×	Δ	×
		0.01 to 500	0	Δ	Δ	0
		9999	×	×	×	×
Other than 9999	0	0	×	×	×	×
		0.01 to 500	×	Δ	×	0
		9999	0	Δ	Δ	0
Other than 9999	Other than 0	0	0	×	Δ	×
		0.01 to 500	0	Δ	Δ	0


- O... Output current value is used to perform integration processing.
- Δ... Output current is assumed as 0A to perform integration processing. (cooling processing)
- x... Electronic thermal relay function is not activated.



• The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 131)

## (3) Electronic thermal relay function prealarm (TH) and alarm signal (THP signal)

100%: Electronic thermal O/L relay alarm operation value




- The alarm signal (THP) is output and electronic thermal relay function prealarm (TH) is displayed when the electronic thermal O/L relay cumulative value reaches 85% of the level set in Pr. 9 or Pr. 51. If it reaches 100% of the Pr. 9 Electronic thermal O/L relay setting, a motor overload trip (E.THM/E.THT) occurs.
- The inverter does not trip even when the alarm signal (THP) is output.
- For the terminal used for the THP signal output, assign the function by setting "8 (positive logic) or 108 (negative logic)" in any of *Pr. 190 to Pr. 192 (output terminal function selection)*.



## NOTE

• Changing the terminal assignment using *Pr.190 to Pr.192* (output terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.

## (4) External thermal relay input (OH signal)



- To protect the motor against overheat, use the OH signal when using an external thermal relay or the built-in thermal protector of the motor.
- When the thermal relay operates, the inverter trips and outputs the fault signal (E.OHT).
- For the terminal used for OH signal input, assign the function by setting "7" to any of *Pr. 178 to Pr. 184 (input terminal function selection)*.



## **NOTE**

• Changing the terminal assignment using Pr. 178 to Pr. 184 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.



## Parameters referred to

Pr. 71 Applied motor Refer to page 108

Pr. 72 PWM frequency selection Refer to page 163

Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 128

Pr. 190 to Pr. 192 (output terminal function selection) Refer to page 134

## 4.9.2 Applied motor (Pr. 71, Pr. 450)

Setting of the used motor selects the thermal characteristic appropriate for the motor.

Setting is required to use a constant-torque motor. Thermal characteristic of the electronic thermal relay function suitable for the motor is set.

When general-purpose magnetic flux vector or advanced magnetic flux vector control is selected, the motor constants (SF-JR, SF-HR, SF-JRCA, SF-HRCA, etc.) necessary for control are selected as well.

Parameter Number	Name	Initial Value	Setting Range	Description
71	Applied motor	0	0, 1, 3 to 6, 13 to 16, 23, 24, 40, 43, 44, 50, 53, 54	Selecting the standard motor or constant-torque motor sets the corresponding motor thermal characteristic.
450	Second applied motor	9999	0, 1 9999	Set when using the second motor.  Second motor is invalid  (thermal characteristic of the first motor  (Pr. 71))

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

## (1) Set the motor to be used

Refer to the following list and set this parameter according to the motor used.

Pr. 71 (Pr. 450)					Motor (O	: Used motor)
Set	ting	Thermal Characteristic of the Electi	onic Thorms	I Polay Function	Wiotor (O	. Oseu motor)
Pr. 71	Pr. 450	Thermal Characteristic of the Liecti	Onic mema	i Kelay i dilodon	Standard	Constant torque
17.71	17. 450		(SF-JR, etc.)	(SF-JRCA, etc.)		
,	(Pr. 71 initial value) Thermal characteristics of a standard motor		0			
1	1	Thermal characteristics of the Mitsubishi co				0
40	_	Thermal characteristic of Mitsubishi high ef			O *1	
50	1	Thermal characteristic of Mitsubishi consta	nt torque moto	r (SF-HRCA)		O *2
3	_	Standard motor			0	
13	_	Constant-torque motor				0
23	_	Mitsubishi standard motor (SF-JR 4P 1.5kW or less)	Select "Offlin	e auto tuning setting"	0	
43	_	Mitsubishi high efficiency motor (SF-HR)	1		O *1	
53	_	Mitsubishi constant-torque motor (SF-HRCA)				O *2
4	_	Standard motor			0	
14	_	Constant-torque motor				0
24	_	Mitsubishi standard motor (SF-JR 4P 1.5kW or less)	1	g data can be read,	0	
44	_	Mitsubishi high efficiency motor (SF-HR)	cnan	ged, and set.	0*1	
54	_	Mitsubishi constant-torque motor (SF-HRCA)				O *2
5	_	Standard motor	Star	Direct input of	0	
15	_	Constant-torque motor	connection	motor constants is		0
6		Standard motor	Delta		0	
16		Constant-torque motor	connection	enabled		0
_	9999 (initial value)	Without second applied motor				

<sup>\*1</sup> Motor constants of Mitsubishi high efficiency motor SF-HR.

## • REMARKS

- When performing offline auto tuning, set any of "3, 13, 23, 43, 53" in *Pr. 71*. (Refer to *page 110* for offline auto tuning.)
- For the FR-E740-120 and 170, the *Pr. 0 Torque boost* and *Pr. 12 DC injection brake operation voltage* settings are automatically changed according to the *Pr. 71* setting as follows.

Automatic Change	Standard Motor	Constant-torque Motor
Parameter	Setting *1	Setting *2
Pr. 0	3%	2%
Pr. 12	4%	2%

<sup>\*1</sup> Pr. 71 setting: 0, 3 to 6, 23, 24,40, 43, 44

<sup>\*2</sup> Motor constants of Mitsubishi constant-torque motor SF-HRCA.

<sup>\*2</sup> Pr. 71 setting: 1, 13 to 16, 50, 53, 54



## (2) Use two motors (*Pr. 450*)

- Set Pr. 450 Second applied motor to use two different motors with one inverter.
- When "9999" (initial value) is set, no function is selected.
- When a value other than 9999 is set in Pr. 450, the second motor is valid when the RT signal turns on.
- For the RT signal, set "3" in any of Pr. 178 to Pr. 184 (input terminal function selection) to assign the function.



## • REMARKS

• The RT signal acts as the second function selection signal and makes the other second functions valid. (Refer to page 131)



ullet Changing the terminal assignment using  $Pr.\ 178\ to\ Pr.\ 184\ (input\ terminal\ function\ selection)$  may affect other functions. Make setting after confirming the function of each terminal.



Net this parameter correctly according to the motor used.

Incorrect setting may cause the motor to overheat and burn.

Set the electronic thermal relay function to the thermal characteristic for the constant-torque motor when using a geared motor (GM-G, GM-D, GM-SY, GM-HY2 series) to perform advanced magnetic flux vector control or general-purpose magnetic-flux vector control.



## **Parameters referred to**

Pr. 0 Torque boost Refer to page 75

Pr. 12 DC injection brake operation voltage Refer to page 118

Pr. 80 Motor capacity, Pr. 81 Number of motor poles Refer to page 110

Pr. 82 to Pr. 84, Pr. 90 to Pr. 94 (motor constants), Pr. 96 Auto tuning setting/status 🖼 Refer to page 110

Pr. 800 Control method selection Refer to page 74

# 4.9.3 To exhibit the best performance of the motor performance (offline auto tuning) (Pr. 71, Pr. 80 to Pr. 84, Pr. 90 to Pr. 94, Pr. 96, Pr. 859)

The motor performance can be maximized with offline auto tuning.

•What is offline auto tuning?

When performing advanced magnetic flux vector control or general-purpose magnetic flux vector control, the motor can be run with the optimum operating characteristics by automatically measuring the motor constants (offline auto tuning) even when each motor constants differs, other manufacturer's motor is used, or the wiring length is long.

Parameter Number	Name	Initial Value		Setting Range	Description
71	Applied motor	0		0, 1, 3 to 6, 13 to 16, 23, 24, 40,	By selecting a standard motor or constant- torque motor, thermal characteristic and motor
80	Motor capacity	9999		43, 44, 50, 53, 54 0.1 to 15kW	constants of each motor are set.  Applied motor capacity.
81	Number of motor poles	9999		9999 2, 4, 6, 8, 10	V/F control Number of motor poles.
0.	Trained of motor poles	3333		9999	V/F control Tuning data
82	Motor excitation current	9999		0 to 500A	(The value measured by offline auto tuning is automatically set.)
				9999	Uses the Mitsubishi motor (SF-JR, SF-HR, SF-JRCA, SF-HRCA) constants.
83	Motor rated voltage	400V class	400V	0 to 1000V	Rated motor voltage (V).
84	Rated motor frequency	50Hz		10 to 120Hz	Rated motor frequency (Hz).
90	Motor constant (R1)	9999		0 to 50Ω, 9999	Tuning data
91	Motor constant (R2)	9999		0 to 50Ω, 9999	(The value measured by offline auto tuning is
92	Motor constant (L1)	9999		0 to 1000mH, 9999	automatically set.)
93	Motor constant (L2)	9999		0 to 1000mH, 9999	9999: Uses the Mitsubishi motor (SF-JR, SF-
94	Motor constant (X)	9999		0 to 100%, 9999	HR, SF-JRCA, SF-HRCA) constants.
				0	Offline auto tuning is not performed
		o <b>g/</b>		1	For advanced magnetic flux vector control Offline auto tuning is performed without motor running (all motor constants).
96	Auto tuning setting/ status			11	For general-purpose magnetic flux vector control Offline auto tuning is performed without motor running. (motor constant (R1) only)
				21	Offline auto tuning for V/F control (automatic restart after instantaneous power failure (with frequency search)) ( <i>Refer to page 154</i> )
859	Torque current	9999		0 to 500A	Tuning data (The value measured by offline auto tuning is automatically set.)
				9999	Uses the Mitsubishi motor (SF-JR, SF-HR, SF-JRCA, SF-HRCA) constants.



• The setting range and increments of *Pr.* 82, *Pr.* 90 to *Pr.* 94 and *Pr.* 859 changes according to the setting value of *Pr.* 71 and *Pr.* 96.

Applied Motor		Internal Stored Value *1		Direct Input Value *2		Auto Tuning Measured Value *3	
Parameter Number	Function Name	Setting Range	Setting Increments	Setting Range	Setting Increments	Setting Range	Setting Increments
82	Motor excitation current	0 to 500A, 9999	0.01A	0 to 500A, 9999	0.01A	0 to ****, 9999	1
90	Motor constant (R1)	0 to 50Ω, 9999	0.001Ω	0 to 50Ω, 9999	0.001Ω	0 to ****, 9999	1
91	Motor constant (R2)	0 to 50Ω, 9999	0.001Ω	0 to 50Ω, 9999	0.001Ω	0 to ****, 9999	1
92	Motor constant (L1)	0 to 1000mH, 9999	0.1mH	0 to 50Ω, 9999	0.001Ω	0 to ****, 9999	1
93	Motor constant (L2)	0 to 1000mH, 9999	0.1mH	0 to 50Ω, 9999	0.001Ω	0 to ****, 9999	1
94	Motor constant (X)	0 to 100%, 9999	0.1%	0 to 500Ω, 9999	0.01Ω	0 to ****, 9999	1
859	Torque current	0 to 500A, 9999	0.01A	0 to 500A, 9999	0.01A	0 to ****, 9999	1

- When Pr. 71 = "0, 1, 40 or 50", or setting value of Pr. 96 after performing offline auto tuning is read "3, 13, 23".
- \*2 When Pr. 71 = "5. 6. 15. or 16"
- \*3 When Pr. 71 = "3, 13, 23, 43 or 53" and setting value of Pr. 96 after performing offline auto tuning is read "3, 13, 23". Or when Pr. 71 = "4, 14, 24, 44 or 54".



### POINT

- This function is made valid only when a value other than "9999" is set in *Pr. 80 and Pr. 81* and advanced magnetic flux vector control or general-purpose magnetic flux vector control is selected.
- · You can copy the offline auto tuning data (motor constants) to another inverter with the PU (FR-PU07).
- Even when motors (other manufacturer's motor, SF-JRC, etc.) other than Mitsubishi standard motor, high
  efficiency motor (SF-JR, SF-HR 0.2kW or more), and Mitsubishi constant-torque motor (SF-JRCA SF-HRCA
  four-pole 0.4kW to 15kW) are used or the wiring length is long, using the offline auto tuning function runs the
  motor with the optimum operating characteristics.
- Tuning is enabled even when a load is connected to the motor.
   As the motor may run slightly, fix the motor securely with a mechanical brake or make sure that there will be no problem in safety if the motor runs (caution is required especially in elevator). Note that tuning performance is unaffected even if the motor runs slightly.
- Reading/writing/copy of motor constants tuned by offline auto tuning are enabled.
- The offline auto tuning status can be monitored with the operation panel and PU (FR-PU04/FR-PU07).
- Do not connect a surge voltage suppression filter (FR-ASF-H/FR-BMF-H) between the inverter and motor.

## (1) Before performing offline auto tuning

Check the following before performing offline auto tuning.

- Make sure advanced magnetic flux vector control or general-purpose magnetic flux vector control (*Pr.* 80, *Pr.* 81) is selected. (Tuning can be performed even under V/F control selected by turning on X18.)
- A motor should be connected. Note that the motor should be at a stop at a tuning start.
- The motor capacity should be equal to or one rank lower than the inverter capacity.
- The maximum frequency is 120Hz.
- A high-slip motor, high-speed motor and special motor cannot be tuned.
- As the motor may run slightly, fix the motor securely with a mechanical brake or make sure that there will be no problem
  in safety if the motor runs (caution is required especially in elevator). Note that tuning performance is unaffected even if
  the motor runs slightly.
- Offline auto tuning will not be performed properly if it is performed with a surge voltage suppression filter (FR-ASFH/FR-BMF-H) connected between the inverter and motor. Remove it before starting tuning.

# (2) Setting

- 1) Select advanced magnetic flux vector control (*Refer to page 76*) or general-purpose magnetic flux vector control (*Refer to page 79*).
- 2) Set "1" or "11" in Pr. 96Auto tuning setting/status.
  - When the setting is "1" ...... Tune all motor constants without running the motor.

When performing advanced magnetic flux vector control, set "1" to perform tuning.

(Excitation noise is produced during tuning.)

\*Tuning time differs according to the inverter capacity and motor type.

• When the setting is "11"...... Tune motor constants (R1) only without running the motor.

When performing general-purpose magnetic flux vector control, set "11" to perform tuning. It takes approximately 9s until tuning is completed.

- 3) Set the rated motor current (initial value is rated inverter current) in Pr. 9 Electronic thermal O/L relay. (Refer to page 106)
- 4) Set the rated voltage of motor (initial value is 400V) in *Pr. 83 Motor rated voltage* and rated motor frequency (initial value is 50Hz) in *Pr. 84 Rated motor frequency*.

(For a Japanese standard motor, etc. which has both 50Hz and 60Hz rated values, use it with an initial value(400V/60Hz).

5) Set Pr. 71 Applied motor according to the motor used.

Motor	Pr. 71 Setting *1	
	SF-JR	3
Mitsubishi standard motor	SF-JR 4P 1.5kW or less	23
Mitsubishi high efficiency motor	SF-HR	43
	Others	3
	SF-JRCA 4P	13
Mitsubishi constant-torque motor	SF-HRCA	53
	Others (SF-JRC, etc.)	13
Other manufacturer's standard motor	_	3
Other manufacturer's constant-torque motor	_	13

<sup>\*1</sup> Refer to page 108, for other settings of Pr. 71.

## (3) Execution of tuning



## **POINT**

Before performing tuning, check the monitor display of the operation panel or parameter unit (FR-PU04/FR-PU07) if the inverter is in the status for tuning. (Refer to 2) below) When the start command is turned on under V/F control, the motor starts.

1) When performing tuning or PU operation, press (RUN) of the operation panel or FWD or REV of the parameter unit (FR-PU04/FR-PU07).

For external operation, turn on the run command (STF signal or STR signal). Tuning starts.



- To force tuning to end, use the MRS or RES signal or press (STOP) of the operation panel. (Turning the start signal (STF signal or STR signal) off also ends tuning.)
- During offline auto tuning, only the following I/O signals are valid: (initial value)
  - Input terminal <valid signal> MRS, RES, STF, STR
  - · Output terminal RUN, AM, A, B, C

Note that the progress status of offline auto tuning is output in eight steps from AM when speed and output frequency are selected.

- Since the RUN signal turns on when tuning is started, caution is required especially when a sequerence which releases a mechanical brake by the RUN signal has been designed.
- When executing offline auto tuning, input the run command after switching on the main circuit power (R/L1, S/L2, T/ L3) of the inverter.
- Do not perform ON/OFF switching of the second function selection signal (RT) during execution of offline auto tuning. Auto tuning is not excecuted properly.
- 2) Monitor is displayed on the operation panel and parameter unit (FR-PU04/FR-PU07) during tuning as below.

	Parameter Unit (FR-PU04/FR-PU07) Display		Operation Panel Indication	
Pr. 96 setting	1	11	1	11
(1) Setting	READ:List 1 STOP PU	READ:List 11 STOP PU	I SET SET	;; SE
(2)Tuning in progress	TUNE 2	TUNE 12		; S
(3)Normal end	TUNE 3 COMPLETION STF STOP PU	TUNE 13 COMPETION STF STOP PU	Flickering	Flickering
(4)Error end (when inverter protective function operation is activated)			3	RUM MON BXT



## • REMARKS

Reference: Offline auto tuning time (when the initial value is set)

Offline Auto Tuning Setting	Time	
Tune all motor constants (Pr. 96 = "1")	Approximately 25 to 75s	
Tune all motor constants (Fr. 90 = 1)	(Tuning time differs according to the inverter capacity and motor type.)	
Tune motor constants (R1) only ( $Pr. 96 = "11"$ )	Approximately 9s	

The set frequency monitor displayed during the offline auto tuning is 0Hz.



3) When offline auto tuning ends, press (STOP) of the operation panel during PU operation. For external operation, turn off the start signal (STF signal or STR signal) once.

This operation resets the offline auto tuning and the PU's monitor display returns to the normal indication. (Without this operation, next operation cannot be started.)



## • REMARKS

- Do not change the Pr. 96 setting after completion of tuning (3 or 13). If the Pr. 96 setting is changed, tuning data is made invalid. If the Pr. 96 setting is changed, tuning must be performed again.
- 4) If offline auto tuning ended in error (see the table below), motor constants are not set. Perform an inverter reset and restart tuning.

Error	Error Cause	Domody
Display	Error Cause	Remedy
8	Forced end	Set "1" or "11" in Pr. 96 and perform tuning again.
9	Inverter protective function operation	Make setting again.
91	Current limit (stall prevention) function was activated.	Set "1" in <i>Pr. 156</i> .
92	Converter output voltage reached 75% of rated value.	Check for fluctuation of power supply voltage.
02	Calculation error	Check the motor wiring and make setting again.
93	A motor is not connected.	Set the rated current of the motor in Pr. 9.

5) When tuning is ended forcibly by pressing (STOP) or turning off the start signal (STF or STR) during tuning, offline auto tuning does not end normally. (The motor constants have not been set.) Perform an inverter reset and restart tuning.



## NOTE

- . The motor constants measured once in the offline auto tuning are stored as parameters and their data are held until the offline auto tuning is performed again.
- An instantaneous power failure occurring during tuning will result in a tuning error. After power is restored, the inverter goes into the normal operation mode. Therefore, when STF (STR) signal is on, the motor runs in the forward (reverse) rotation.
- Any alarm occurring during tuning is handled as in the ordinary mode. Note that if a fault retry has been set, retry is



As the motor may run slightly during offline auto tuning, fix the motor securely with a mechanical brake or make sure that there will be no problem in safety if the motor runs. Note that if the motor runs slightly, tuning performance is unaffected.



## (4) Utilizing or changing offline auto tuning data for use

The data measured in the offline auto tuning can be read and utilized or changed.

<Operating procedure>

1) Set Pr. 71 according to the motor used.

Motor	Pr. 71 Setting *1	
	SF-JR	4
Mitsubishi standard motor	SF-JR 4P 1.5kW or less	24
Mitsubishi high efficiency motor	SF-HR	44
	Others	4
	SF-JRCA 4P	14
Mitsubishi constant-torque motor	SF-HRCA	54
	Others (SF-JRC, etc.)	14
Other manufacturer's		4
standard motor	-	4
Other manufacturer's		14
constant-torque motor	-	14

<sup>\*1</sup> For other settings of Pr.71, refer to page 108.

2) In the parameter setting mode, read the following parameters and set desired values.

Parameter Number	Name	Setting Range	Setting Increments	Initial Value
82	Motor excitation current	0 to ****, 9999	1	9999
90	Motor constant (R1)	0 to ****, 9999	1	9999
91	Motor constant (R2)	0 to ****, 9999	1	9999
92	Motor constant (L1)	0 to ****, 9999	1	9999
93	Motor constant (L2)	0 to ****, 9999	1	9999
94	Motor constant (X)	0 to ****, 9999	1	9999
859	Torque current	0 to ****, 9999	1	9999



## • REMARKS

- When "9999" is set in Pr. 82, Pr. 90 to Pr. 94, Pr. 859, Mitsubishi motor (SF-JR, SF-HR, SF-JRCA, SF-HRCA) constants are used.
- As the motor constants measured in the offline auto tuning have been converted into internal data (\*\*\*\*), refer to the following setting example when making setting:

Setting example To slightly increase Pr. 90 value (5%)

When Pr. 90 is displayed as "2516",

set 2642, i.e. 2516 x 1.05=2641.8, in Pr. 90.

(The value displayed has been converted into a value for internal use. Hence, simple addition of a given value to the displayed value has no significance.)

# 7/

## (5) Method to set the motor constants without using the offline auto tuning data

The Pr. 90 and Pr. 94 motor constants may either be entered in  $[\Omega]$  or in [mH]. Before starting operation, confirm which motor constant unit is used.

- To enter the Pr. 90 to Pr. 94 motor constants in  $[\Omega]$
- <Operating procedure>

1)Set Pr. 71 according to the motor used.

		Star Connection Motor	Delta Connection Motor
Setting	Standard motor	5	6
Octung	Constant-torque motor	15	16

2)In the parameter setting mode, read the following parameters and set desired values.

Iq =torque current, I100 =rated current, I0 =no load current

$$Iq = \sqrt{1100^2 - 10^2}$$

Parameter Number	Name	Setting Range	Setting Increments	Initial Value
82	Motor excitation current (no load current)	0 to 500A, 9999	0.01A	9999
90	Motor constant (r1)	0 to 50Ω, 9999	0.001Ω	9999
91	Motor constant (r2)	0 to 50Ω, 9999	0.001Ω	9999
92	Motor constant (x1)	0 to 50Ω, 9999	0.001Ω	9999
93	Motor constant (x2)	0 to 50Ω, 9999	0.001Ω	9999
94	Motor constant (xm)	0 to 500Ω, 9999	0.01Ω	9999
859	Torque current	0 to 500A, 9999	0.01A	9999

3) Refer to the following table and set Pr. 83 and Pr. 84.

Parameter Number	Name	Setting Range	Setting Increments	Initial	Value
83	Motor rated voltage	0 to 1000V	0.1V	400V class	400V
84	Rated motor frequency	10 to 120Hz	0.01Hz	50	Hz



## > REMARKS

• When "9999" is set in Pr. 82, Pr. 90 to Pr. 94, Pr. 859, Mitsubishi motor (SF-JR, SF-HR, SF-JRCA, SF-HRCA) constants are used.



## **NOTE**

• If "star connection" is mistaken for "delta connection" or vice versa during setting of Pr. 71, advanced magnetic flux vector control and general-purpose magnetic flux vector control cannot be exercised properly.



●To enter the Pr. 90 and Pr. 94 motor constants in [mH]

<Operating procedure>


1) Set Pr. 71 according to the motor used.

Motor	Pr.71 Setting *1	
Mitsubishi standard motor	SF-JR	0
Mitsubishi high efficiency motor	SF-HR	40
Mitsubishi constant-torque motor	SF-JRCA 4P	1
Witsubishi constant torque motor	SF-HRCA	50

<sup>\*1</sup> For other settings of Pr. 71, refer to page 108.

2) In the parameter setting mode, read the following parameters and set desired values. Calculate the *Pr. 94* value from the following formula.

$$Pr. 94 \text{ setting} = (1 - \frac{M^2}{L1 \times L2}) \times 100 \text{ (%)}$$



R1: Primary resistance

R2: Secondary resistanceI1: Primary leakage inductanceI2: Secondary leakage inductance

M: Excitation inductance

S: Slip

L1 = I1 + M: Primary inductance L2 = I2 + M: Secondary inductance

## Motor equivalent circuit diagram

Parameter Number	Name	Setting Range	Setting Increments	Initial Value
82	Motor excitation current (no load current)	0 to 500A, 9999	0.01A	9999
90	Motor constant (R1)	0 to 50Ω, 9999	0.001Ω	9999
91	Motor constant (R2)	0 to 50Ω, 9999	0.001Ω	9999
92	Motor constant (L1)	0 to 1000mH, 9999	0.1mH	9999
93	Motor constant (L2)	0 to 1000mH, 9999	0.1mH	9999
94	Motor constant (X)	0 to 100%, 9999	0.1%	9999
859	Torque current	0 to 500A, 9999	0.01A	9999

3) Refer to the following table and set Pr. 83 and Pr. 84.

Parameter Number	Name	Setting Range	Setting Increments	Initial	Value
83	Motor rated voltage	0 to 1000V	0.1V	400V class	400V
84	Rated Motor Frequency	10 to 120Hz	0.01Hz	50	Hz



## > REMARKS

• When "9999" is set in Pr. 82, Pr. 90 to Pr. 94, Pr. 859, Mitsubishi motor (SF-JR, SF-HR, SF-JRCA, SF-HRCA) constants are used.



## Parameters referred to

Pr. 7 Acceleration time, Pr. 8 Deceleration time Refer to page 99

Pr. 9 Electronic thermal O/L relay Refer to page 106

Pr. 71 Applied motor Refer to page 108

Pr. 80 Motor capacity, Pr. 81 Number of motor poles Refer to page 74

Pr. 156 Stall prevention operation selection Refer to page 82

Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 128

Pr. 190 to Pr. 192 (output terminal function selection) Refer to page 134

Pr. 800 Control method selection Refer to page 74

## 4.10 Motor brake and stop operation


Purpose	Parameter th	at should be Set	Refer to Page
Motor braking torque adjustment	DC Injection brake	Pr. 10 to Pr. 12	118
Improve the motor braking torque with	Selection of a	Pr. 30, Pr. 70	119
an option	regenerative brake	P1. 30, P1. 70	119
Coast the motor to a stop	Selection of motor	Pr. 250	121
Coast the motor to a stop	stopping method	F1. 230	121
Used to stop the motor with a		Pr. 6, Pr. 48, Pr. 270, Pr. 275,	
mechanical brake	Stop-on-contact control		122
(vibration restraint at stop-on-contact)		Pr. 276	
Used to stop the motor with a			
mechanical brake (operation timing of a	Brake sequence function	Pr. 278 to Pr. 283, Pr. 292	124
mechanical brake)			

## 4.10.1 DC injection brake (Pr. 10 to Pr. 12)

The DC injection brake can be operated at a motor stop to adjust the stop timing and braking torque. In DC injection brake operation, DC voltage is directly applied to the motor to prevent the motor shaft from rotating. The motor will not return to the original position if the motor shaft rotates due to external force.

Parameter Number	Name	Initial Value		Setting Range	Description
10	DC injection brake	3Hz		0 to	Operation frequency of the DC injection brake.
10	operation frequency	3112		120Hz	Operation frequency of the DC injection brake.
11	DC injection brake	0.5-		0	DC injection brake disabled
- ''	operation time	0.5s		0.1 to 10s	Operation time of the DC injection brake.
12	DC injection brake	FR-E740-016 to 170	4%	0 to 30%	DC injection brake voltage (torque). When "0" is
12	operation voltage	tion voltage FR-E740-230 and 300		0 10 30%	set, DC injection brake is disabled.

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)



## (1) Operation frequency setting (Pr. 10)

• After the frequency at which the DC injection brake will be operated is set to *Pr. 10*, the DC voltage is applied to the motor when this frequency is reached during deceleration.

## Operation frequency (2) Operation time setting (*Pr. 11*)

- •In Pr. 11, set the time of the DC injection brake.
- •When the motor does not stop due to large load moment (J), increasing the setting produces an effect.
- •When *Pr. 11* = "0s", the DC injection brake is disabled. (At a stop, the motor coasts.)

## (3) Operation voltage (torque) setting (Pr. 12)

- Use Pr. 12 to set the percentage to the power supply voltage.
- When Pr. 12 = "0%", the DC injection brake is disabled. (At a stop, the motor coasts.)
- •When using the constant-torque motor (SF-JRCA) and energy saving motor (SF-HR, SF-HRCA), change the *Pr. 12* setting as follows:

SF-JRCA:

FR-E740-095 or less...4%

FR-E740-120 or more...2%

SF-HR, SF-HRCA:

FR-E740-095 or less...4%

FR-E740-120 and 170...3%

FR-E740-230 and 300...2%





## • REMARKS

- For the FR-E740-120 and 170, when the Pr. 12 setting is the following, changing the Pr. 71 Applied motor setting automatically changes the Pr. 12 setting. Therefore, it is not necessary to change the Pr. 12 setting.
  - (a) When 4% (initial value) is set in Pr. 12
    - The Pr. 12 setting is automatically changed to 2% if the Pr. 71 value is changed from the value selecting the standard motor (0, 3 to 6, 23, 24, 40, 43, 44) to the value selecting the constant torque motor (1, 13 to 16, 50, 53, 54).
  - (b) When 2% is set in Pr. 12
    - The Pr. 12 setting is automatically changed to 4% (initial value) if the Pr. 71 value is changed from the value selecting the constant torque motor (1, 13 to 16, 50, 53, 54) to the value selecting the standard motor (0, 3 to 6, 23, 24, 40, 43, 44).
- Even if the Pr. 12 setting is increased, braking torque is limited so that the output current is within the rated inverter current.



As stop holding torque is not produced, install a mechanical brake.



## Parameters referred to

Pr. 13 Starting frequency Refer to page 102 Pr. 71 Applied motor Refer to page 108

## 4.10.2 Selection of a regenerative brake (Pr. 30, Pr. 70)

- When making frequent starts/stops, use the optional high-duty brake resistor (FR-ABR) and brake unit (FR-BU2) to increase the regenerative brake duty.
- Use a power regeneration common converter (FR-CV) for continuous operation in regeneration status. Use the high power factor converter (FR-HC) to reduce harmonics, improve the power factor, or continuously use the regenerative status.

Parameter	Name	Initial	Setting	Description
Number	Name	Value	Range	Description
				Without regenerative function,
			0	Brake unit (FR-BU2)
	Regenerative function		0	Power regeneration common converter (FR-CV)
30	selection	0		High power factor converter (FR-HC)
	Selection		1	High-duty brake resistor (FR-ABR)
			2	High power factor converter (FR-HC) when automatic
			2	restart after instantaneous power failure is selected
70	Special regenerative	00/	0 to 200/	Brake duty when using the high-duty brake resistor
70	brake duty	0%	0 to 30%	(FR-ABR)

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

## (1) When using the brake unit (FR-BU2), power regeneration common converter (FR-CV), and high power factor converter (FR-HC).

•Set Pr. 30 to "0" (initial value). The Pr. 70 setting is made invalid.

At this time, the regenerative brake duty is as follows.

- •Assign the inverter operation enable signal (X10) to the contact input terminal. To make protective coordination with the FR-HC and FR-CV, use the inverter operation enable signal to shut off the inverter output. Input the RDY signal of the FR-HC (RDYB signal of the FR-CV).
- •For the terminal used for X10 signal input, assign its function by setting "10" (X10) to any of Pr. 178 to Pr. 184.

## (2) When using the high-duty brake resistor (FR-ABR)


- •Set "1" in Pr. 30.
- •Set Pr. 70 as follows.

# When a high power factor converter (FR-HC) is used and automatic restart after instantaneous power failure function is made valid.

- •When automatic restart after instantaneous power failure function of both the FR-HC and inverter is made valid (when a value other than "9999" is set in Pr. 57 Restart coasting time), set "2" in Pr. 30.
- •Set Pr. 70 to "0%" (initial value).
- •When the FR-HC detects power failure during inverter operation, the RDY signal turns on, resulting in the motor coasting. Turning the RDY signal off after power restoration, the inverter detects the motor speed (depends on the Pr.162 Automatic restart after instantaneous power failure selection) and restarts automatically after instantaneous power failure.

## (4) Regenerative brake duty alarm output and alarm signal (RBP signal)

100%: regenerative overvoltage protection operation value



- •[RB] appears on the operation panel and an alarm signal (RBP) is output when 85% of the regenerative brake duty set in Pr. 70 is reached. If the regenerative brake duty reaches 100% of the Pr. 70 setting, a regenerative overvoltage (E.OV1 to E.OV3) occurs. Note that [RB] is not displayed when Pr. 30 = "0".
- •The inverter does not trip even when the alarm (RBP) signal is output.
- •For the terminal used for the RBP signal output, assign the function by setting "7 (positive logic) or 107 (negative logic)" in any of Pr. 190 to Pr. 192 (output terminal function selection).



## REMARKS

- The MRS signal can also be used instead of the X10 signal. (Refer to page 130)
- Refer to page 28 to 32 for connecting the high-duty brake resistor (FR-ABR), brake unit (FR-BU2), high power factor converter (FR-HC), and power regeneration common converter (FR-CV).



When terminal assignment is changed using Pr. 178 to Pr. 184 (input terminal function selection) and Pr. 190 to Pr. 192 (output terminal function selection), the other functions may be affected. Make setting after confirming the function of each terminal. (Refer to page 128)





The value set in Pr. 70 must not exceed the setting of the brake resistor used. Otherwise, the resistor can overheat.



## Parameters referred to

Pr. 57 Restart coasting time Refer to page 151 Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 128 Pr. 190 to Pr. 192 (output terminal function selection) Refer to page 134





## 4.10.3 Stop selection (Pr. 250)

Used to select the stopping method (deceleration to a stop or coasting) when the start signal turns off.
Used to stop the motor with a mechanical brake, etc. together with switching off of the start signal.
You can also select the operations of the start signals (STF/STR). (Refer to *page 132* for start signal selection)

				De	scription
Parameter	Nama	Initial Value	Cotting Dongs	Start signal (STF/	
Number	Name	illitiai value	Setting Range	STR)	Stop operation
				(Refer to page 132)	
				STF signal:	The motor is coasted to a stop
			0 to 100a	Forward rotation start	when the preset time elapses
			0 to 100s	STR signal:	after the start signal is turned
		9999		Reverse rotation start	off.
			1000s to 1100s	STF signal: Start signal	The motor is coasted to a stop
				STR signal:	(Pr. 250 - 1000)s after the start
250	Ston coloction			Forward/reverse signal	signal is turned off.
250	Stop selection		0000	STF signal:	
				Forward rotation start	
			9999	STR signal:	When the start signal is turned
				Reverse rotation start	off, the motor decelerates to
				STF signal: Start signal	stop.
			8888	STR signal:	
				Forward/reverse signal	

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)





## (1) Decelerate the motor to a stop

- •Set Pr. 250 to "9999" (initial value) or "8888".
- •The motor decelerates to a stop when the start signal (STF/STR) turns off.

## (2) Coast the motor to a stop

- •Use *Pr. 250* to set the time from when the start signal turns off until the output is shut off. When any of "1000 to 1100" is set, the output is shut off in (*Pr. 250* 1000)s.
- •The output is shut off when the time set in *Pr. 250* has elapsed after the start signal had turned off. The motor coasts to a stop.
- •The RUN signal turns off when the output stops.

## REMARKS

Stop selection is invalid when the following functions are activated.

- Power failure stop function (Pr. 261)
- PU stop (Pr. 75)
- Deceleration stop because of communication error (Pr. 502)
- Emergency stop by LonWorks communication



## NOTE

•When the start signal is turned on again during motor coasting, the motor starts at Pr. 13 Starting frequency.




## Parameters referred to

Pr.7 Acceleration time, Pr. 8 Deceleration time Refer to page 99 Pr. 13 Starting frequency Refer to page 102

## 4.10.4 Stop-on contact control function (Pr. 6, Pr. 48, Pr. 270, Pr. 275, Pr. 276)


AD MFVC GP MFVC

To ensure accurate positioning at the upper limit etc. of a lift, stop-on-contact control causes a mechanical brake to be closed while the motor is developing a holding torque to keep the load in contact with a mechanical stopper etc. This function suppresses vibration which is liable to occur when the load is stopped upon contact in vertical motion applications, ensuring steady precise positioning.



Parameter Number	Name	Initial Value	Setting Range	Description
6	Multi-speed setting (low speed)	10Hz	0 to 400Hz	Sets the output frequency for stop-on-contact control.
48	Second stall prevention operation current	9999	0 to 200%	Sets the stall prevention operation level for stall prevention operation level.
	operation current		9999	Pr. 22 setting
270	Stop-on contact control	0	0	Normal operation
270	selection	0	1	Stop-on-contact control
275	Stop-on contact excitation current low-speed multiplying factor	excitation current low- 9999		Set the force (holding torque) for stop-on-contact control.  Normally set 130% to 180%.  Valid only during advanced magnetic flux vector control
	speed multiplying factor		9999	Without compensation
276	PWM carrier frequency at stop-on contact	9999	0 to 9	Sets a PWM carrier frequency for stop-on-contact control.
270		9999	9999	As set in Pr. 72 PWM frequency selection.

## (1) Connection and operation example



- \* The input signal terminal used differs according to the Pr. 180 to Pr. 184 settings.
- \* Goes into stop-on-contact control when both RL and RT switch on. RL and RT may be switched on in any order with any time difference.
  - (a) Acceleration time (Pr. 7) (b) Deceleration time (Pr. 8)
  - (c) Second deceleration time (*Pr. 44/Pr. 45*)

## (2) Set stop-on-contact control

- Make sure that the inverter is in external operation mode. (Refer to page 180)
- Select advanced magnetic flux vector control or general-purpose magnetic flux vector control.
- Set "1" in Pr. 270 Stop-on contact control selection.
- Set output frequency during stop-on-contact control in *Pr.* 6 *Multi-speed setting (low speed)*.

  The frequency should be as low as possible (about 2Hz). If it is set to more than 30Hz, the operating frequency will be 30Hz.
- When both the RT and RL signals are switched on, the inverter enters the stop-on-contact mode, in which operation is performed at the frequency set in *Pr.* 6 independently of the preceding speed.
- For the terminal used for X18 signal input, set "3" in any of *Pr. 178 to Pr. 184 (input terminal function selection)* and "0" in *Pr. 178 to Pr. 184 (input terminal function selection)* to assign the function.



## NOTE

- By increasing the Pr. 275 setting, the low-speed (stop-on-contact) torque increases, but overcurrent fault (E.OCT) may
  occur or the machine may oscillate in a stop-on-contact state.
- The stop-on-contact function is diferent from servo-lock function, and if used to stop or hold a load for an extended period, this function can cause the motor to overheat.
   After a stop, immediately change to a mechanical brake to hold the load.
- Under the following operating conditions, the stop-on-contact functionis made invalid:
   PU operation (Pr. 79), Jog operation (JOG signal), PU+external operation (Pr. 79), PID control function operation (Pr. 128), remote setting function operation (Pr. 59), automatic acceleration/deceleration operation (Pr. 292)



## (3) Function switching of stop-on-contact control selection

Main Functions	Normal Operation	With stop-on-contact Control
Main Functions	(either RL or RT is off or both are off)	(both RL and RT are on)
	Multi-speed	
Output frequency	0 to 5V, 0 to 10V	Pr. 6 setting
	4 to 20mA etc.	
Stall prevention operation	Pr. 22 setting	Pr. 48 setting
level	Fr. 22 Setting	(Pr. 22 when Pr. 48 = "9999")
Excitation current low		Only Pr. 275 (0 to 300%) is compensated
speed scaling factor	_	before both RL and RT turn on.
		Output frequency is 3Hz or less
Carrier frequency	Pr. 72 setting	When <i>Pr. 276</i> setting ( <i>Pr. 72</i> when <i>Pr. 276</i> =
		"9999")
Fast-response current	Valid	Invalid
limit	valiu	invaliu

## (4) Set frequency when stop-on-contact control (Pr. 270 = 1) is selected

- The following table lists the frequencies set when the input terminals (RH, RM, RL, RT, JOG) are selected together. Bold frame indicates stop-on-contact control is valid.
- Stop-on-contact control is invalid when remote setting function is selected (Pr. 59 = 1 to 3).

In	Input Signal (○ = on)		n)	Sat Eraguanay	
RH	RM	RL	RT	JOG	Set Frequency
0					Pr. 4 Multi-speed setting (high speed)
	0				Pr. 5 Multi-speed setting (middle speed)
		0			Pr. 6 Multi-speed setting (low speed)
			0		By 0 to 5V(0 to 10V), 4 to 20mA input
				0	Pr. 15 Jog frequency
0	0				Pr. 26 Multi-speed setting (speed 6)
0		0			Pr. 25Multi-speed setting (speed 5)
0			0		Pr. 4 Multi-speed setting (high speed)
0				0	Pr. 15 Jog frequency
	0	0			Pr. 24 Multi-speed setting (speed 4)
	0		0		Pr. 5 Multi-speed setting (middle speed)
	0			0	Pr. 15 Jog frequency
		0	0		Pr. 6 Multi-speed setting (low speed)
		0		0	Pr. 15 Jog frequency
			0	0	Pr. 15 Jog frequency
		0	0	0	Pr. 15 Jog frequency

In	Input Signal (○ = on)		n)	Set Frequency	
RH	RM	RL	RT	JOG	Set Frequency
	0		0	0	Pr. 15 Jog frequency
	0	0		0	Pr. 15 Jog frequency
	0	0	0		Pr. 6 Multi-speed setting (low speed)
0			0	0	Pr. 15 Jog frequency
0		0		0	Pr. 15 Jog frequency
0		0	0		Pr. 6 Multi-speed setting (low speed)
0	0			0	Pr. 15 Jog frequency
0	0		0		Pr. 26 Multi-speed setting (speed 6)
0	0	0			Pr. 27 Multi-speed setting (speed 7)
	0	0	0	0	Pr. 15 Jog frequency
0		0	0	0	Pr. 15 Jog frequency
0	0		0	0	Pr. 15 Jog frequency
0	0	0		0	Pr. 15 Jog frequency
0	0	0	0		Pr. 6 Multi-speed setting (low speed)
0	0	0	0	0	Pr. 15 Jog frequency
					By 0 to 5V(0 to 10V), 4 to 20mA
					input



Changing the terminal function using any of Pr. 178 to Pr. 184 may affect the other functions. Make setting after confirming the function of each terminal.



## Parameters referred to

Pr. 4 to Pr. 6, Pr. 24 to Pr. 27 (multi-speed setting) Refer to page 92

Pr. 15 Jog frequency Refer to page 94

Pr. 48 Second stall prevention operation current Refer to page 82

Pr. 59 Remote function selection Refer to page 96

Pr. 72PWM frequency selection Refer to page 163

Pr. 79 Operation mode selection Refer to page 180

Pr. 128 PID action selection Refer to page 231 Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 128

Pr. 292 Automatic acceleration/deceleration Terr Refer to page 104


## 4.10.5 Brake sequence function (Pr. 278 to Pr. 283, Pr. 292) ADMEVIC GP. MEVIC GP. MEV

This function is used to output from the inverter the mechanical brake operation timing signal in vertical lift and other applications.

This function prevents the load from dropping with gravity at a start due to the operation timing error of the mechanical brake or an overcurrent alarm from occurring at a stop, ensuring secure operation.

Parameter Number	Name	Initial Value	Setting Range	Description
278	Brake opening frequency	3Hz	0 to 30Hz	Set to the rated slip frequency of the motor + about 1.0Hz. This parameter may be set only if $Pr. 278 \le Pr. 282$ .
279	Brake opening current	130%	0 to 200%	Generally, set this parameter to about 50 to 90%. If the setting is too low, the load is liable to drop due to gravity at start. Suppose that the rated inverter current is 100%.
280	Brake opening current detection time	0.3s	0 to 2s	Generally, set this parameter to about 0.1 to 0.3s.
281	Brake operation time at start	0.3s	0 to 5s	When $Pr. 292 =$ "7", set the mechanical delay time until the brake is loosened.  Set the mechanical delay time until the brake is loosened + about 0.1 to 0.2s when $Pr. 292 =$ "8".
282	Brake operation frequency	6Hz	0 to 30Hz	Set the frequency to activate the mechanical brake by turning off the brake opening request signal (BOF). Generally, set this parameter to the $Pr.\ 278$ setting + 3 to 4Hz. This parameter may be set only if $Pr.\ 278 \le Pr.\ 282$ .
283	Brake operation time at stop	0.3s	0 to 5s	Set the mechanical delay time until the brake is closed + 0.1s when $Pr.\ 292 = 7$ . Sets the mechanical delay time until the brake is closed + 0.2 to 0.3s when $Pr.\ 292 = 8$ .
292	Automatic acceleration/ deceleration	0	0 1, 11 7 8	Normal operation mode Shortest acceleration/deceleration mode (Refer to page 104) Brake sequence mode 1 Brake sequence mode 2

## <Connection diagram>



- \*1 The input signal terminal used differs according to the Pr. 178 to Pr. 184 settings.
- \*2 The output signal terminal used differs according to the Pr. 190 to Pr. 192 settings.
- \*3 The current should be within the permissible current of transistor in the inverter. (24V 0.1ADC)



## NOTE

- When brake sequence mode is selected, automatic restart after instantaneous power failure is invalid.
- When using this function, set the acceleration time to 1s or longer.
- Changing the terminal function using any of *Pr. 178 to Pr. 184* and *Pr. 190 to Pr. 192* may affect the other functions. Make setting after confirming the function of each terminal.




## (1) Set the brake sequence mode

- Select advanced magnetic flux vector control or general-purpose magnetic flux vector control.
   The brake sequence function is valid only when the external operation mode, external/PU combined operation mode 1 or network operation mode is selected.
- Set "7 or 8" (brake sequence mode) in *Pr. 292*.

  To ensure more complete sequence control, it is recommended to set "7" (brake opening completion signal input) in *Pr. 292*.
- Set "15" in any of *Pr. 178 to Pr. 184 (input terminal function selection)* and assign the brake opening completion signal (BRI) to the input terminal.
- Set "20 (positive logic)" or "120 (negative logic)" in any of *Pr. 190 to Pr. 192 (output terminal function selection)* and assign the brake opening request signal (BOF) to the output terminal.

## (2) With brake opening completion signal input (Pr. 292 = "7")


- When the start signal is input to the inverter, the inverter starts running. When the internal speed command reaches the value set in *Pr.* 278 and the output current is not less than the value set in *Pr.* 279, the inverter outputs the brake opening request signal (BOF) after the time set in *Pr.* 280 has elapsed.
  - When the time set in *Pr. 281* elapses after the brake opening completion signal (BRI) was activated, the inverter increases the output frequency to the set speed.
- When the speed has decreased to the frequency set in *Pr. 282* during deceleration, the BOF signal is turned off. When the time set in *Pr. 283* elapses after the electromagnetic brake operation was completed and the BRI signal was turned off, the inverter output is switched off.



# $\overline{\gamma}$

## (3) With brake opening completion signal input (Pr.292 = "8")

- When the start signal is input to the inverter, the inverter starts running. When the internal speed command reaches the value set in *Pr.* 278 and the output current is not less than the value set in *Pr.* 279, the inverter outputs the brake opening request signal (BOF) after the time set in *Pr.* 280 has elapsed.
  - When the time set in Pr. 281 elapses after the BOF signal is output, the inverter increases the output frequency to the set speed.
- When the speed has decreased to the frequency set in *Pr. 282* during deceleration, the brake opening request signal (BOF) is turned off. When the time set in *Pr. 283* has elapsed after the BOF signal is turned off, the inverter output is switched off.



## REMARKS

If brake sequence mode has been selected, inputting the jog signal (jog operation) or RT signal (second function selection)
during an inverter stop will make brake sequence mode invalid and give priority to jog operation or second function selection.
Note that JOG and RT signal input is invalid even if JOG signal and RT signal are input during operation in brake sequence
mode.



## (4) Protective functions


If any of the following errors occurs in the brake sequence mode, the inverter results in a fault, trips, and turns off the brake opening request signal (BOF).

Fault Display	Description
E.MB4	Although more than 2s have elapsed after the start command (forward or reverse rotation) is input, the brake opening request signal (BOF) does not turn on.
E.MB5	Although more than 2s have elapsed after the brake opening request signal (BOF) turned on, the brake opening completion signal (BRI) does not turn on.
E.MB6	Though the inverter had turned on the brake opening request signal (BOF), the brake opening completion signal (BRI) turned off midway.
E.MB7	Although more than 2s have elapsed after the brake opening request signal (BOF) turned off at a stop, the brake opening completion signal (BRI) does not turn off.



## **NOTE**

- A too large setting of Pr. 278 Brake opening frequency activates stall prevention operation and may cause E.MB4.
- If the sum of the time between Pr. 13 Starting frequency and Pr. 278 Brake opening frequency + Pr. 280 Brake opening current detection time is more than 2s, E.MB4 occurs.





## Parameters referred to

Pr. 80 Motor capacity, Pr. 81 Number of motor poles Refer to page 74
Pr. 180 to Pr. 184 (input terminal function selection) Refer to page 128
Pr. 190 to Pr. 192 (output terminal function selection) Refer to page 134
Pr. 800 Control method selection Refer to page 74

## 4.11 Function assignment of external terminal and control

Purpose	Parameter	that should be Set	Refer to Page
Assign function to input terminal	Input terminal function selection	Pr. 178 to Pr. 184	128
Set MRS signal (output shutoff) to NC contact specification	MRS input selection	Pr. 17	130
Assign start signal and forward/ reverse command to other signals	Start signal (STF/STR) operation selection	Pr. 250	132
Assign function to output terminal	Output terminal function assignment	Pr. 190 to Pr. 192	134
Detect output frequency	Up-to-frequency sensitivity Output frequency detection	Pr. 41 to Pr. 43	138
Detect output current	Output current detection Zero current detection	Pr. 150 to Pr. 153	139
Remote output function	Remote output	Pr. 495 to Pr. 497	141

## 4.11.1 Input terminal function selection (Pr. 178 to Pr. 184)

Use these parameters to select/change the input terminal functions.

Parameter Number	Name	Initial Value	Initial Signal	Setting Range
178	STF terminal function selection	60	STF (forward rotation command)	0 to 5, 7, 8, 10, 12, 14 to 16, 18, 24, 25, 60, 62, 65 to 67, 9999
179	STR terminal function selection	61	STR (reverse rotation command)	0 to 5, 7, 8, 10, 12, 14 to 16, 18, 24, 25, 61, 62, 65 to 67, 9999
180	RL terminal function selection	0	RL (low-speed operation command)	
181	RM terminal function selection	1	RM (middle speed operation command)	
182	RH terminal function selection	2	RH (high-speed operation command)	0 to 5, 7, 8, 10, 12, 14 to 16, 18, 24, 25, 62, 65 to 67, 9999
183	MRS terminal function selection	24	MRS (output stop)	
184	RES terminal function selection	62	RES (inverter reset)	

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

## (1) Input terminal function assignment

- •Using Pr. 178 to Pr. 184, set the functions of the input terminals.
- •Refer to the following table and set the parameters:

Setting	Signal		Function	Related Parameters	Refer to Page
	DI	Pr. 59 = 0 (initial value)	Low-speed operation command	Pr. 4 to Pr. 6, Pr. 24 to Pr. 27 Pr.232 to Pr.239	92
0	Pr. 59 = 1, 2 *1 Pr. 270 = 1 *2		Remote setting (setting clear)	Pr. 59	96
			Stop-on contact selection 0	Pr. 270, Pr. 275, Pr. 276	122
1	RM	Pr. 59 = 0 (initial value)	Middle-speed operation command	Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239	92
		<i>Pr.</i> 59 = 1, 2 *1	Remote setting (deceleration)	Pr. 59	96
2 RH		Pr. 59 = 0 (initial value)	High-speed operation command	Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239	92
		<i>Pr.</i> 59 = 1, 2 *1	Remote setting (acceleration)	Pr. 59	96



Setting	Signal	Function	Related Parameters	Refer to
		Second function selection	Pr. 44 to Pr. 51	Page
3 RT		Pr. 270 = 1 *2 Stop-on contact selection	** **	122
4	AU	Terminal 4 input selection	Pr. 267	165
5	JOG	Jog operation selection	Pr. 15, Pr. 16	94
7	OH	<u> </u>	Pr. 9	106
- /	OH	External thermal relay input *3	1 11 7	100
8	REX	15-speed selection (combination with three spee RH)	Pr. 4 to Pr. 6, Pr. 24 to Pr. 27, Pr. 232 to Pr. 239	92
10	X10	Inverter run enable signal (FR-HC, FR-CV conne	ection) Pr. 30, Pr. 70	119
12	X12	PU operation external interlock	Pr. 79	180
14	X14	PID control valid terminal	Pr. 127 to Pr. 134	231
15	BRI	Brake opening completion signal	Pr. 278 to Pr. 283	124
16	X16	PU-external operation switchover (turning on X1 external operation)	6 selects Pr. 79, Pr. 340	187
18	X18	V/F switchover (V/F control is exercised when X	18 is on) Pr. 80, Pr. 81, Pr. 800	74, 76, 79, 110
24	MRS	Output stop	Pr. 17	130
25	STOP	Start self-holding selection	_	132
60	STF	Forward rotation (assigned to STF terminal (Pr.	(78) only) —	132
61	STR	Reverse rotation command (assigned to STR ter only)		132
62	RES	Inverter reset	_	_
65	X65	PU/NET operation switchover (turning on X65 se operation)	Pr. 79, Pr. 340	188
66	X66	External/NET operation switchover (turning on X NET operation)	66 selects Pr. 79, Pr. 340	188
67	X67	Command source switchover (turning on X67 mand Pr. 339 commands valid)	akes <i>Pr. 338</i> Pr. 338, Pr. 339	191
9999	_	No function	_	_

- \*1 When Pr. 59 Remote function selection = "1" or "2", the functions of the RL, RM and RH signals are changed as given in the table.
- \*2 When Pr. 270 Stop-on contact control selection = "1", functions of RL and RT signals are changed as in the table.
- \*3 The OH signal turns on when the relay contact "opens".



## NOTE

- Changing the terminal assignment using *Pr.178 to Pr.184 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.
- · One function can be assigned to two or more terminals. In this case, the terminal inputs are ORed.
- The priorities of the speed commands are in order of jog, multi-speed setting (RH, RM, RL, REX) and PID (X14).
- When the X10 signal (FR-HC, FR-CV connection-inverter operation enable signal) is not set or when the PU operation external interlock (X12) signal is not assigned with *Pr.79 Operation mode selection* set to "7", the MRS signal shares this function.
- Use common terminals to assign multi-speeds (7 speeds) and remote setting. They cannot be set individually.
   (Common terminals are used since these functions are designed for speed setting and need not be set at the same time.)
- When V/F control is selected by V/F switchover (X18 signal), second function is also selected at the same time.
   Control between V/F and advanced (general-purpose) magnetic flux can not be switched during operation. In case control is switched between V/F and advanced (general-purpose) magnetic flux, only second function is selected.
- Turning the AU signal on makes terminal 2 (voltage input) invalid.

## (2) Response time of each signal


• The response time of the X10 signal and MRS signal is within 2ms. The response time of other signals is within 20ms.


## 4.11.2 Inverter output shutoff signal (MRS signal, Pr. 17)

The inverter output can be shut off by the MRS signal. Also, logic for the MRS signal can be selected.

Parameter Number	Name	Initial Value	Setting Range	Description
			0	Normally open input
	MRS input selection		2	Normally closed input
17		0	2	(NC contact input specifications)
17		U		External terminal: Normally closed input
			4	(NC contact input specifications)
				Communication: Normally open input

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)





## (1) Output shutoff signal (MRS signal)

- Turning on the output shutoff signal (MRS) during inverter running shuts off the output immediately.
- •MRS signal may be used as described below.
- (a) When mechanical brake (e.g. electromagnetic brake) is used to stop motor

The inverter output is shut off when the mechanical brake operates.

- (b) To provide interlock to disable operation by the inverter With the MRS signal on, the inverter cannot be operated if the start signal is entered into the inverter.
- (c) Coast the motor to a stop. When the start signal is turned off, the inverter decelerates the motor to a stop in the preset deceleration time, but when the MRS signal is turned on, the motor coasts to a stop.

## (2) MRS signal logic inversion (Pr. 17)

• When Pr. 17 is set to "2", the MRS signal (output stop) can be changed to the normally closed (NC contact) input specification. When the MRS signal turns on (opens), the inverter shuts off the output.

## (3) Assign a different action for each MRS signal input from communication and external terminal (Pr. 17 = "4")

•When Pr. 17 is set to "4", the MRS signal from external terminal (output stop) can be changed to the normally closed (NC contact) input, and the MRS signal from communication can be changed to the normally open (NO contact) input. This function is useful to perform operation by communication with MRS signal from external terminal remained on.

External MRS	Communication MRS	Pr. 17 Setting				
LATERIIAI WING	Communication wiks	0	2	4		
OFF	OFF	Operation enabled	Output shutoff	Output shutoff		
OFF	ON	Output shutoff	Output shutoff	Output shutoff		
ON	OFF	Output shutoff	Output shutoff	Operation enabled		
ON	ON	Output shutoff	Operation enabled	Output shutoff		

## • REMARKS

- The MRS signal is assigned to the terminal MRS in the initial setting. By setting "24" in any of Pr.178 to Pr.184 (input terminal function selection), you can assign the RT signal to the other terminal.
- The MRS signal can shut off the output, independently of the PU, external or network operation mode.



• Changing the terminal assignment using Pr. 178 to Pr. 184 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.



## Parameters referred to

Pr. 178 to Pr. 184 (input terminal function selection) TF Refer to page 128




## 4.11.3 Condition selection of function validity by second function selection signal (RT)

- You can select the second function using the RT signal.
- When the RT signal turns on, the second function becomes valid.
- For the RT signal, set "3" in any of Pr. 178 to Pr. 184 (input terminal function selection) to assign the function.
- The second function has the following applications.
- (a) Switching between normal use and emergency use
- (b) Switching between heavy load and light load
- (c) Changing of acceleration/deceleration time by broken line acceleration/deceleration
- (d) Switching of characteristic between the main motor and sub motor

## Second function connection diagram

# Start Second function selection High speed Middle speed RM PC

## Second acceleration/deceleration time



Function	First Function	Second Function	Refer to
Function	Parameter Number	Parameter Number	Page
Torque boost	Pr. 0	Pr. 46	75
Base frequency	Pr. 3	Pr. 47	88
Acceleration time	Pr. 7	Pr. 44	99
Deceleration time	Pr. 8	Pr. 44, Pr. 45	99
Electronic thermal O/L relay	Pr. 9	Pr. 51	106
Stall prevention	Pr. 22	Pr. 48	82
Applied motor	Pr. 71	Pr. 450	108



## NOTE

- When the RT signal is on, the above second function is selected at the same time.
- Changing the terminal assignment using *Pr. 178 to Pr. 184 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.



## Parameters referred to

Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 128

## 4.11.4 Start signal operation selection (STF, STR, STOP signal, Pr. 250)

You can select the operation of the start signal (STF/STR).

Used to select the stopping method (deceleration to a stop or coasting) when the start signal turns off.


Used to stop the motor with a mechanical brake, etc. together with switching off of the start signal. (Refer to page 121 for stop selection)

Parameter		Initial		Description		
Number	Name	Value	Setting Range	Start signal	Stop operation	
Number		value		(STF/STR)	Refer to page 121	
				STF signal: Forward rotation start	The motor is coasted to a stop	
			0 to 100s	STR signal: Reverse rotation start	when the preset time elapses	
				31K signal. Reverse rotation start	after the start signal is turned off.	
			1000s to 1100s	STF signal: Start signal	When the setting is any of 1000s to	
250	Stop	9999		STR signal: Forward/reverse signal	1100s, the inverter coasts to a stop	
230	selection				in (Pr. 250 - 1000)s.	
			9999	STF signal: Forward rotation start	When the start signal is turned	
			9999	STR signal: Reverse rotation start	off, the motor decelerates to	
			8888	STF signal: Start signal	,	
			0000	STR signal: Forward/reverse signal	stop.	

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

## (1) Two-wire type connection (STF, STR signal)

- •The two-wire connection is shown below.
- •In the default setting, the forward/reverse rotation signals (STF/STR) are used as start and stop signals. Turn on either of the forward and reverse rotation signals to start the motor in the corresponding direction. Switch on both or switch off (or both on) the start signal during operation to decelerate the inverter to a stop.
- •The speed setting signal may either be given by entering 0 to 10VDC across the speed setting input terminal 2-5, by setting the required values in *Pr. 4 to Pr. 6 Multi-speed setting (high, middle, low speeds)*, etc. (For multi-speed operation, refer to *page 92.*)
- •When *Pr. 250* is set to any of "1000 to 1100, 8888", the STF signal becomes a start command and the STR signal a forward/reverse command.



## REMARKS

• When Pr. 250 is set to any of "0 to 100, 1000 to 1100", turning off the start command coasts the inverter to a stop. (Refer to page 121)


Time

• The STF and STR signals are assigned to the STF and STR terminals in the default setting. The STF signal can be assigned to *Pr. 178 STF terminal function selection*, and the STR signal to *Pr. 179 STR terminal function selection* only.



## (2) Three-wire type (STF, STR, STOP signal)

- •The three-wire connection is shown below.
- •Turning the STOP signal on makes start self-holding function valid. In this case, the forward/reverse rotation signal functions only as a start signal.
- If the start signal (STF or STR) is turned on and then off, the start signal is held and makes a start. When changing the direction of rotation, turn STR (STF) on once and then off.
- •To stop the inverter, turning off the STOP signal once decelerates it to a stop.
- When using the STOP signal, set "25" in Pr. 178 to Pr. 184 to assign function.



## REMARKS

- When the JOG signal is turned on to enable jog operation, the STOP signal becomes invalid.
- If the MRS signal is turned on to stop the output, the self-holding function is not canceled.

## (3) Start signal selection

STF	STR	Pr. 250 Setting Inverter Status					
317	SIK	0 to 100s, 9999	1000s to 1100s 8888				
OFF	OFF	Stop	Stop				
OFF	ON	Reverse rotation	σιορ				
ON	OFF	Forward rotation	Forward rotation				
ON	ON	Stop	Reverse rotation				



## Parameters referred to

Pr. 4 to Pr. 6 (multi-speed setting) Refer to page 92
Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 128

## 4.11.5 Output terminal function selection (Pr. 190 to Pr. 192)

You can change the functions of the open collector output terminal and relay output terminal.

Parameter Number	Nai	me	Initial Value	Initial Signal	Setting Range
190	RUN terminal function selection	Open collector	0	RUN (inverter running)	0, 1, 3, 4, 7, 8, 11 to 16, 20, 25, 26, 46, 47, 64, 90, 91, 93, 95, 96, 98, 99, 100, 101, 103, 104,
191	FU terminal function selection	output terminal	4	FU (output frequency detection)	107, 108, 111 to 116, 120, 125, 126, 146, 147, 164, 190, 191, 193, 195, 196, 198, 199, 9999
192	A,B,C terminal function selection	Relay output terminal	99	ALM (fault output)	0, 1, 3, 4, 7, 8, 11 to 16, 20, 25, 26, 46, 47, 64, 90, 91, 95, 96, 98, 99, 100, 101, 103, 104, 107, 108, 111 to 116, 120, 125, 126, 146, 147, 164, 190, 191, 195, 196, 198, 199, 9999

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

## (1) Output signal list

- •You can set the functions of the output terminals.
- •Refer to the following table and set the parameters: (0 to 99: positive logic, 100 to 199: negative logic)

Setting					Related	Refer	
Positive logic	Negative logic	Signal	Function	n Operation		to Page	
0	100	RUN	Inverter running	Output during operation when the inverter output frequency rises to or above <i>Pr. 13 Starting frequency</i> .	_	136	
1	101	SU	Up to frequency *1	Output when the output frequency is reached to the set frequency.	Pr. 41	138	
3	103	OL	Overload alarm	Output while stall prevention function is activated.	Pr. 22, Pr. 23, Pr. 66	82	
4	104	FU	Output frequency detection	Output when the output frequency reaches the frequency set in <i>Pr. 42</i> ( <i>Pr. 43</i> for reverse rotation).	Pr. 42, Pr. 43	138	
7	107	RBP	Regenerative brake pre-alarm	Output when 85% of the regenerative brake duty set in $Pr$ . $70$ is reached.	Pr. 70	119	
8	108	THP	Electronic thermal O/L relay pre-alarm	Output when the electronic thermal value reaches 85% of the trip level. (Electronic thermal relay function protection (E.THT/E.THM) activates, when the value reached 100%.	Pr. 9, Pr. 51	106	
11	111	RY	Inverter operation ready	Output when reset process is completed (when the inverter can be started by switching the start signal on or while it is running) after powering on inverter.	_	136	
12	112	Y12	Output current detection	Output when the output current is higher than the $Pr. 150$ setting for longer than the time set in $Pr. 151$ .	Pr. 150, Pr. 151	139	
13	113	Y13	Zero current detection	Output when the output power is lower than the $Pr. 152$ setting for longer than the time set in $Pr. 153$ .	Pr. 152, Pr. 153	139	
14	114	FDN	PID lower limit	Output when the feedback value falls below the lower limit of PID control.			
15	115	FUP	PID upper limit	Output when the feedback value rises above the upper limit of PID control	Pr. 127 to Pr. 134	231	
16	116	RL	PID forward/reverse rotation output	Output when forward rotation is performed in PID control.			
20	120	BOF	Brake opening request	Output to open the brake when the brake sequence function is selected.	Pr. 278 to Pr. 283, Pr. 292	124	
25	125	FAN	Fan fault output	Output at the time of a fan fault.	Pr. 244	247	
26	126	FIN	Heatsink overheat pre-alarm	Output when the heatsink temperature reaches about 85% of the heatsink overheat protection providing temperature.	_	273	
46	146	Y46	During deceleration at occurrence of power failure (retained until release)  Output when the power failure-time deceleration function is executed.		Pr. 261	157	
47	147	PID	During PID control activated	Output during PID control.	Pr. 127 to Pr. 134	231	
64	164	Y64	During retry	Output during retry processing.	Pr. 65 to Pr. 69	159	

Set	ting				Related	Refer		
Positive logic	Negative logic	Signal	Function	Operation	Parameter	to Page		
90	190	Y90 Life alarm		Y90 Life alarm  Output when any of the control circuit capacitor, main circuit capacitor and inrush current limit circuit or the cooling fan approaches the end of its service life.				
91	191	Y91	Fault output 3 (power-off signal)	·		137		
93	193	Current average value		Average current value and maintenance timer value are output as pulses.  The signal can not be set in <i>Pr. 192 A,B,C terminal function selection</i> .	Pr. 555 to Pr. 557	253		
95	195	Y95	Maintenance timer signal	Output when Pr. 503 rises to or above the Pr. 504 setting.	Pr. 503, Pr. 504	252		
96	196	REM	Remote output	Output to the terminal when a value is set to the parameter.	Pr. 495 to Pr. 497	141		
98	198	LF	Alarm output	Output when an alarm (fan failure or communication error warning) occurs.	Pr. 121, Pr. 244	200, 247		
99	199	ALM Fault output		Output when the fault occurs. The signal output is stopped when the fault is reset.	_	137		
9999 —		_	No function	_	_	_		

Note that when the frequency setting is varied using an analog signal or of the operation panel, the output of the SU (up to frequency) signal may alternate on and off depending on that varying speed and the timing of the varying speed due to acceleration/deceleration time setting. (The output will not alternate on and off when the acceleration/deceleration time setting is "0s".)



## • REMARKS


- The same function may be set to more than one terminal.
- When the function is executed, the terminal conducts at the setting of any of "0 to 99", and does not conduct at the setting of any of "100 to 199".



## NOTE

- Changing the terminal assignment using Pr.190 to Pr.192 (output terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.
   Do not assign signals which repeat frequent ON/OFF to A, B, and C. Otherwise, the life of the relay contact decreases.

## (2) Inverter operation ready signal (RY signal) and inverter running signal (RUN signal)



- When the inverter is ready to operate, the output of the operation ready signal (RY) is on. (It is also on during inverter running.)
- When the output frequency of the inverter rises to or above *Pr. 13 Starting frequency*, the output of the inverter running signal (RUN) is turned on. During an inverter stop or DC injection brake operation, the output is off.
- When using the RY and RUN signals, assign functions to *Pr.190 to Pr.192 (output terminal selection function)* referring to the table below.

Output	Pr. 190 to Pr. 192 Setting						
Signal	Positive logic	Negative logic					
RY	11	111					
RUN	0	100					

Inverter Status	Start Signal	Start	Start		at Alarm		atic Restar eous Powe	
	OFF	Signal ON	Signal ON	Under DC	Occurrence	Coas	sting	
Output	(during	(during	(during	Injection Brake	or MRS Signal ON	Start	Start	Restarting
signal	stop)	stop)	operation)		(output shutoff)	signal	signal	Restarting
Signal	stop)					ON	OFF	
RY	ON	ON	ON	ON	OFF	ON *1		ON
RUN	OFF	OFF	ON	OFF	OFF	OFF		ON


<sup>\*1</sup> This signal turns OFF during power failure or undervoltage.

## • REMARKS

• The RUN signal (positive logic) is assigned to the terminal RUN in the initial setting.

# Function assignment of external terminal and control

## (3) Fault output signal (ALM signal)



• If the inverter comes to trip, the ALM signal is output.

## • REMARKS

- · The ALM signal is assigned to the ABC contact in the default setting. By setting "99 (positive logic) or 199 (negative logic) in Pr.190 to Pr.192 (output terminal function selection), the ALM signal can be assigned to the other signal.
- Refer to page 268 for the inverter fault description.

## (4) Fault output 3 (power-off signal) (Y91 signal)

- The Y91 signal is output at occurrence of a fault attributable to the failure of the inverter circuit or a fault caused by a wiring mistake.
- When using the Y91 signal, set "91 (positive logic)" or "191 (negative logic)" to any of Pr.190 to Pr.192 (output terminal function selection) to assign the function to the output terminal.
- The following table indicates the faults that will output the Y91 signal. (Refer to page 267 for the fault description.)

Operation Panel Indication		Name	
Е. ЬЕ	E. BE	Brake transistor alarm detection	
E. GF	E.GF	Output side earth(ground) fault overcurrent	
E. LF	E.LF	Output phase loss	
E. PE	E.PE	Parameter storage device fault	
8.28	E.PE2	Internal board fault	
E. 6/ E. 7, E.C.P.U	E. 6/ E. 7/ E.CPU	CPU fault	
нов.а <i>НО 1,</i> 3		Inrush current limit circuit fault	

# • REMARKS

At occurrence of output side earth (ground) fault overcurrent (E.GF), overcurrent trip during acceleration(E.OC1) may be displayed. At this time, the Y91 signal is output.



## Parameters referred to


Pr. 13 Starting frequency 🖫 Refer to page 102


## 4.11.6 Detection of output frequency (SU, FU signal, Pr. 41 to Pr. 43)

The inverter output frequency is detected and output at the output signals.

Parameter Number	Name	Initial Value	Setting Range	Description
41	Up-to-frequency sensitivity	10%	0 to 100%	Level where the SU signal turns on.
42	Output frequency detection	6Hz	6Hz 0 to 400Hz Frequency where the FU signs	
43	Output frequency detection for reverse	9999	0 to 400Hz	Frequency where the FU signal turns on in reverse rotation.
	rotation		9999	Same as Pr. 42 setting

The above parameters can be set when *Pr. 160 User group read selection* = "0". (*Refer to page 177*)





## (1) Up-to-frequency sensitivity (SU signal, Pr. 41)

- When the output frequency reaches the set frequency, the up-to-frequency signal (SU) is output.
- The Pr.~41 value can be adjusted within the range 0% to  $\pm 100\%$  on the assumption that the set frequency is 100%.
- •This parameter can be used to ensure that the running frequency has been reached to provide the operation start signal etc. for related equipment.
- •When using the SU signal, set "1 (positive logic) or 101 (negative logic)" in *Pr. 190 to Pr. 192 (output terminal function selection*) to assign function to the output terminal.

# (2) Output frequency detection (FU signal, *Pr. 42*, *Pr. 43*)

- •The output frequency detection signal (FU) is output when the output frequency reaches or exceeds the *Pr. 42* setting.
- •This function can be used for electromagnetic brake operation, open signal, etc.
- •When the detection frequency is set to *Pr. 43*, frequency detection for reverse operation use only can also be set. This function is effective for switching the timing of electromagnetic brake operation between forward rotation (rise) and reverse rotation (fall) during vertical lift operation, etc.
- •When  $Pr. 43 \neq$  "9999", the Pr. 42 setting is used for forward rotation and the Pr. 43 setting is used for reverse rotation.

# **●** REMARKS

- The FU signal is assigned to the terminal FU in the initial setting. The FU signal can also be assigned to the other terminal by setting "4 (positive logic) or 104 (negative logic)" in any of *Pr. 190 to Pr. 192*.
- All signals are off during DC injection brake.
- The output frequency to be compared with the set frequency is the output frequency before slip compensation is performed.



## NOTE

• Changing the terminal assignment using *Pr.190 to Pr.192 (output terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.



## Parameters referred to

Pr. 190 to Pr. 192 (output terminal function selection) 🖫 (Refer to page 134)





## 4.11.7 Output current detection function (Y12 signal, Y13 signal, Pr. 150 to Pr. 153)

The output current during inverter running can be detected and output to the output terminal.

Parameter Number	Name	Initial Value	Setting Range	Description
150	Output current detection level	150%	0 to 200%	Output current detection level. 100% is the rated inverter current.
151	Output current detection signal delay time	0s	0 to 10s	Output current detection period.  The time from when the output current has risen above the setting until the output current detection signal (Y12) is output.
152	Zero current detection level	5%	0 to 200%	Zero current detection level. The rated inverter current is assumed to be 100%.
153	Zero current detection time	0.5s	0 to 1s	Period from when the output current drops below the <i>Pr. 152</i> value until the zero current detection signal (Y13) is output.

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)





The zero current detection signal (Y13) holds the signal for approximately 100ms once turned on.

## (1) Output current detection (Y12 signal, Pr. 150, Pr. 151)

- •The output current detection function can be used for excessive torque detection, etc.
- •If the output current remains higher than the Pr. 150 setting during inverter operation for longer than the time set in Pr. 151, the output current detection signal (Y12) is output from the inverter's open collector or relay output terminal.
- •When the Y12 signal turns on, the ON state is held for approximately 100ms.
- •For the Y12 signal, set "12 (positive logic) or 112 (negative logic)" in Pr. 190 to Pr. 192 (output terminal function selection) and assign functions to the output terminal.

## Zero current detection (Y13 signal, Pr. 152, Pr. 153)

- •If the output current remains lower than the Pr. 152 setting during inverter operation for longer than the time set in Pr. 153, the zero current detection (Y13) signal is output from the inverter's open collector or relay output terminal.
- •When the inverter's output current falls to "0", torque will not be generated. This may cause a drop due to gravity when the inverter is used in vertical lift application.
- To prevent this, the Y13 signal can be output from the inverter to close the mechanical brake when the output current has fallen to "zero".
- •For the Y13 signal, set "13 (positive logic) or 113 (negative logic)" in Pr. 190 to Pr. 192 (output terminal function selection) and assign functions to the output terminal.

## • REMARKS

- This function is also valid during execution of the online auto tuning.
- The response time of Y12 and Y13 signals is approximately 0.1s. Note that the response time changes according to the load condition.

When Pr. 152 = "0", detection is disabled.



Changing the terminal assignment using Pr. 190 to Pr. 192 (output terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.



# **!** CAUTION

The zero current detection level setting should not be too high, and the zero current detection time setting not too long. Otherwise, the detection signal may not be output when torque is not generated at a low output current.

To prevent the machine and equipment from resulting in hazardous conditions detection signal, install a safety backup such as an emergency brake even the zero current detection function is set valid.



## **Parameters referred to**

Offline auto tuning F Refer to page 110
Pr. 190 to Pr. 192 (output terminal function selection) F Refer to page 134



## 4.11.8 Remote output selection (REM signal, Pr. 495 to Pr. 497)


You can utilize the on/off of the inverter's output signals instead of the remote output terminal of the programmable logic controller.

Parameter	Name	Initial	Setting	Description		
Number	Name	Value	Range	Description		
			0	Remote output data clear at powering off	Remote output data	
			1	Remote output data retention at	clear at inverter reset	
495	Remote output	0	'	powering off	clear at inverter reset	
493	selection	U	10	Remote output data clear at powering off	Remote output data	
			11	Remote output data retention at	retention at inverter	
			111	powering off	reset	
496*	Remote output data 1	0	0 to 4095	Refer to the following diagram.		
497*	Remote output data 2	0	0 to 4095	A Kelel to the following diagram.		

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

## <Remote output data>

Pr. 496



Pr. 497


b11											b0	
*1	*1	RA3*3	RA2*3	RA1*3	Y6*2	Y5*2	Y4*2	Y3*2	Y2*2	Y1*2	Y0*2	

- Any
- \*2 Y0 to Y6 are available only when the extension output option (FR-A7AY E
- RA1 to RA3 are available only when the relay output option (FR-A7AR E

- · The output terminal can be turned on/off depending on the Pr. 496 or Pr. 497 setting. The remote output selection can be controlled on/off by computer link communication from the PU connector or RS-485 port or by communication from the communication option.
- · Set "96 (positive logic) or 196 (negative logic)" to any of Pr. 190 to Pr. 192 (output terminal function selection), and assign the remote output (REM) signal to the terminal used for remote output,
- · When you refer to the diagram on the left and set 1 to the terminal bit (terminal where the REM signal has been assigned) of Pr. 496 or Pr. 497, the output terminal turns on (off for negative logic). By setting 0, the output terminal turns off (on for negative logic).

Example: When "96 (positive logic)" is set in Pr. 190 RUN terminal function selection and "1" (H01) is set in Pr. 496, the terminal RUN turns on.

## ON/OFF example for positive logic



- When Pr. 495 = "0" (initial value), performing a power on reset (including a power failure) clears the REM signal output. (The ON/OFF status of the terminals are as set in Pr. 190 to Pr. 192.) The Pr. 496 and Pr. 497 settings are also "0". When Pr. 495 = "1, 11", the remote output data before power off is stored into the EEPROM, so the signal output at power recovery is the same as before power off. However, it is not stored when the inverter is reset (terminal reset, reset request through communication).
  - (See the chart on the left)
- When Pr. 495 = "10, 11", signal before rest is saved even at inverter reset.

# • REMARKS

- The output terminal where the REM signal is not assigned using any of Pr. 190 to Pr. 192 does not turn on/off if 0/1 is set to the terminal bit of Pr. 496 or Pr. 497. (It turns on/off with the assigned function.)
- When the inverter is reset (terminal reset, reset request through communication), Pr. 496 and Pr. 497 values turn to "0". When Pr. 495 = "1, 11", however, they are the settings at power off. (The settings are stored at power off.) When Pr. 495 = 10, 11", they are the same as before an inverter reset is made.



## Parameters referred to

Pr. 190 to Pr. 192 (output terminal function selection) T Refer to page 134

<sup>\*</sup> The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.

## 4.12 Monitor display and monitor output signal

Purpose	Parameter that	Parameter that should be Set				
Display motor speed Set speed	Speed display and speed setting	Pr. 37	142			
Change PU monitor display data	DU/PU main display data selection Cumulative monitor clear	Pr. 52, Pr. 54, Pr. 170, Pr. 171, Pr. 268, Pr. 563, Pr. 564	143			
Change the monitor output from terminal AM	Terminal AM function selection	Pr. 158	143			
Set the reference of the monitor output from terminal AM	Terminal AM standard setting	Pr. 55, Pr. 56	148			
Adjust terminal AM outputs	Terminal AM calibration	Pr. 645, Pr. 901	149			

## 4.12.1 Speed display and speed setting (Pr. 37)

The monitor display and frequency setting of the PU (FR-PU04/FR-PU07) can be changed to the machine speed.

Parameter Number	Name	Initial Value	Setting Range	Description
37	Speed display	0	0	Frequency display, setting
31			0.01 to 9998*	Machine speed at 60Hz.

The above parameters can be set when Pr. 160User group read selection = "0". (Refer to page 177)

Maximum setting value of  $Pr. 37 < \frac{16777.215 \times 60 \text{ (Hz)}}{\text{Setting value of } Pr. 1 \text{ (Hz)}}$ 

Note that the maximum setting value of Pr. 37 is 9998 if the result of the above formula exceeds 9998.

• To display the machine speed, set in Pr. 37 the machine speed for 60Hz operation.

For example, when Pr 37 = "1000", "1000" is displayed on the output frequency and set frequency monitor when the running frequency is 60Hz. When running frequency is 30Hz, "500" is displayed.

Pr. 37 Setting	Output Frequency Monitor	Set Frequency Monitor	Frequency Setting Parameter Setting
0 (initial value)	Hz	Hz	Hz
0.01 to 9998	Machine speed *1	Machine speed *1	

<sup>\*1</sup> Machine speed conversion formula .......Pr. 37 × frequency/60Hz

<sup>\*2</sup> Hz is displayed in 0.01Hz increments and machine speed is in 0.001.



## NOTE

- Under V/F control, the output frequency of the inverter is displayed in terms of synchronous speed, and therefore, displayed value = actual speed + motor slip. The display changes to the actual speed (estimated value calculated based on the motor slip) when advanced magnetic flux vector control was selected or slip compensation was made valid.
- Refer to Pr. 52 when you want to change the PU main monitor (PU main display).
- · Since the panel display of the operation panel is 4 digits in length, the monitor value of more than "9999" is displayed "----".
- When the machine speed is displayed on the FR-PU04/FR-PU07, do not change the speed by using an up/down key in the state where the set speed exceeding 65535 is displayed. The set speed may become arbitrary value.
- While the machine speed is displayed on the monitor, values of other parameters related to speed (Pr. 1, etc.) are in frequency increments.
- Due to the limitations on the resolution of the set frequency, the indication in the second decimal place may differ from the setting.
- When frequency or set frequency is monitored from network option card except for FR-A7NC E kit, frequency is displayed for monitor description regardless of Pr. 37 setting.



Make sure that the running speed setting is correct.

Otherwise, the motor might run at extremely high speed, damaging the machine.



## Parameters referred to

Pr. 1 Maximum frequency Refer to page 86

Pr. 52 DU/PU main display data selection Refer to page 143

Pr. 800 Control method selection Te Refer to page 74

<sup>\*</sup> The maximum value of the setting range differs according to the Pr. 1 Maximum frequency and it can be calculated from the following formula.



# 4.12.2 Monitor display selection of DU/PU and terminal AM (Pr. 52, Pr.158, Pr. 170, Pr. 171, Pr. 268, Pr. 563, Pr. 564)

The monitor to be displayed on the main screen of the control panel and parameter unit (FR-PU04/FR-PU07) can be selected.

In addition, signal to be output from the terminal AM (analog voltage output) can be selected.

Parameter Number	Name	Initial Value	Setting Range	Description
52 *	DU/PU main display data selection	0 (output frequency)	0, 5, 7 to 12, 14, 20, 23 to 25, 52 to 57, 61, 62, 100	Select the monitor to be displayed on the operation panel and parameter unit.  Refer to the following table for monitor description.
158 *	AM terminal function selection	1 (output frequency)	1 to 3, 5, 7 to 12, 14, 21, 24, 52, 53, 61, 62	Select the monitor output to terminal AM.
			0	Set "0" to clear the watt-hour meter monitor.
170	Watt-hour meter clear	9999	10	Set the maximum value when monitoring from communication to 0 to 9999kWh.
			9999	Set the maximum value when monitoring from communication to 0 to 65535kWh.
171	Operation hour meter clear	9999	0, 9999	Set "0" in the parameter to clear the operation time monitor.  Setting 9999 does not clear.
	Monitor decimal digits		0	Displayed as integral value
268 *	selection	9999	1	Displayed in 0.1 increments.
	Selection		9999	No function
563	Energization time carrying- over times		0 to 65535 (reading only)	The numbers of cumulative energization time monitor exceeded 65535h is displayed. (Reading only)
564	Operating time carrying- over times	0	0 to 65535 (reading only)	The numbers of operation time monitor exceeded 65535h is displayed. (Reading only)

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

#### (1) Monitor description list (Pr. 52)

- •Set the monitor to be displayed on the operation panel and parameter unit (FR-PU04/FR-PU07) in *Pr. 52 DU/PU main display data selection* .
- •Set the monitor to be output to the terminal AM (analog voltage output) in Pr. 158 AM terminal function selection .
- •Refer to the following table and set the monitor to be displayed. (The monitor marked cannot be selected.)

		Pr. 52 \$	Setting				
Types of Monitor	Unit	Operation panel LED	PU main monitor	Pr.158 (AM) Setting	Terminal AM Full Scale Value		Description
Output frequency	0.01Hz	0/1	00	1	Pr. 55		Displays the inverter output frequency.
Output current	0.01A	0/1	100	2	Pr. 56		Displays the inverter output current effective value.
Output voltage	0.1V	0/1	100	3	400V class	800V	Displays the inverter output voltage.
Fault display	_	0/1	100	×	_		Displays 8 past faults individually.
Frequency setting value	0.01Hz	5	*1	5	Pr. 55		Displays the set frequency.
Motor torque	0.1%	7	*1	7	Rated torque		Displays the motor torque in % on the assumption that the rated motor torque is 100%. (Displays 0% during V/F control)
Converter output voltage	0.1V	8	*1	8	400V class 800V		Displays the DC bus voltage value.
Regenerative brake duty	0.1%	9	*1	9	Pr. 70	•	Brake duty set in Pr. 30, Pr. 70

<sup>\*</sup> The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.

		Pr. 52 S	Setting			
		Operation	PU	Pr.158 (AM)	Terminal AM	
Types of Monitor	Unit	panel LED	main monitor	Setting	Full Scale Valu	Description
Electronic thermal relay function load factor	0.1%	10	*1	10	100%	Displays the thermal cumulative value on the assumption that the thermal operation level is 100% (Larger thermal between the motor thermal and transistor thermal).
Output current peak value	0.01A	11	*1	11	Pr. 56	Holds and displays the peak value of the output power monitor. (Cleared at every start)
Converter output voltage peak value	0.1V	12	*1	12	400V class 800	Holds and displays the peak value of the V DC bus voltage value. (Cleared at every start)
Output power	0.01kW	14	*1	14	Rated inverter power × 2	Displays the power on the inverter output side
Input terminal status	_	_	*1	×	_	Displays the input terminal ON/OFF status on the PU. (Refer to page 146 for DU display)
Output terminal status	_		*1	×	_	Displays the output terminal ON/OFF status on the PU. (Refer to page 146 for DU display)
Cumulative energization time *2, *5	1h	2	20	×	_	Adds up and displays the energization time after inverter shipment. You can check the numbers of the monitor value exceeded 65535h with <i>Pr. 563</i> .
Reference voltage output	_	-	_	21	_	Terminal AM: Output 10V
Actual operation time *2, *3, *5	1h	2	23	×	_	Adds up and displays the inverter operation time.  You can check the numbers of the monitor value exceeded 65535h with <i>Pr. 564</i> .  Can be cleared by <i>Pr. 171</i> . ( <i>Refer to page 147</i> )
Motor load factor	0.1%	2	24	24	200%	Displays the output current value on the assumption that the inverter rated current value is 100%.  Monitor value = output power monitor value/rated inverter current 100 [%]
Cumulative power *5	0.01kWh *4	2	25	×	_	Adds up and displays the power amount based on the output power monitor.  Can be cleared by <i>Pr. 170</i> . ( <i>Refer to page 147</i> )
PID set point	0.1%	5	52	52	100%	Displays the set point, measured value and
PID measured value	0.1%	5	53	53	100%	deviation during PID control (Refer to page
PID deviation	0.1%	5	54	×	_	235 for details)
Inverter I/O terminal monitor	_	55	×	×	_	Displays the ON/OFF status of the inverter input terminal and output terminal on the operation panel ( <i>Refer to page 146</i> for details)
Option input terminal status	_	56	×	×	_	Displays the input terminal ON/OFF status of the digital input option (FR-A7AX E Kit) on the operation panel. ( <i>Refer to page 146</i> for details)
Option output terminal status	_	57	×	×	_	Displays the output terminal ON/OFF status of the digital output option (FR-A7AY E kit) or relay output option (FR-A7AR E Kit) on the operation panel ( <i>Refer to page 146</i> for details).
Motor thermal load factor	0.1%	6	61	61	Thermal relay operation level (100%)	Motor thermal heat cumulative value is displayed. (Motor overload trip (E.THM) at 100%)
Inverter thermal load factor	0.1%	6	52	62	Thermal relay operation level (100%)	Transistor thermal heat cumulative value is displayed. (Inverter overload trip (E.THT) at 100%)



- \*1 Frequency setting to output terminal status on the PU main monitor are selected by "other monitor selection" of the parameter unit (FR-PU04V/FR-PU07).
- \*2 The cumulative energization time and actual operation time are accumulated from 0 to 65535 hours, then cleared, and accumulated again from 0.

  When the operation panel is used, the time is displayed up to 65.53 (65530h) on the assumption that 1h = 0.001, and thereafter, it is added up from 0.
- \*3 Actual operation time is not accumulated when the cumulative operation time is less than 1h until turning off of the power supply.
- \*4 When using the parameter unit (FR-PU04/FR-PU07), "kW" is displayed.
- \*5 Since the panel display of the operation panel is 4 digits in length, the monitor value of more than "9999" is displayed "----".
- \*6 Larger thermal value between the motor thermal and transistor thermal is displayed.


  A value other than 0% is displayed if the ambient temperature (heatsink temperature) is high even when the inverter is at a stop.

## • REMARKS


- By setting "0" in Pr. 52, the monitoring of output speed to fault display can be selected in sequence by (SET)
- When the operation panel is used, the displayed units are Hz and A only and the others are not displayed.
- The monitor set in *Pr. 52* is displayed in the third monitor position. However, change the output current monitor for the motor load factor.

#### Initial Value

\*The monitor displayed at powering on is the first monitor. Display the monitor you want to display on the first monitor and hold down (SET) for 1s. (To return to the output frequency monitor, hold down (SET) for 1s after displaying the output frequency monitor.)



Example) When *Pr.* 52 is set to "20" (cumulative energization time), the monitor is displayed on the operation panel as described below.



#### (2) Display set frequency during stop (Pr. 52)

• When "100" is set in *Pr. 52*, the set frequency and output frequency are displayed during stop and operation respectively. (LED of Hz flickers during stop and is lit during operation.)

	Pr. 52					
	0	100				
	During	During stop	During			
	running/stop	During stop	running			
Output	Output	Set	Output			
frequency	frequency	frequency*	frequency			
Output		Output current				
current		Output current				
Output	Output voltage					
voltage	Output voltage					
Fault	Fault display					
display		i auit uispiay				

<sup>\*</sup> The set frequency displayed indicates the frequency to be output when the start command is on. Different from the frequency setting displayed when Pr. 52 = "5", the value based on maximum/minimum frequency and frequency jump is displayed.

## D R

#### REMARKS

- During an error, the output frequency at error occurrence appears.
- During MRS signal is on, the values displayed are the same as during a stop.
- During offline auto tuning, the tuning status monitor has priority.


#### (3) Operation panel I/O terminal monitor (Pr. 52)

- •When Pr. 52 is set to any of "55 to 57", the I/O terminal status can be monitored on the operation panel.
- •The I/O terminal monitor is displayed on the third monitor.
- •The LED is on when the terminal is on, and the LED is on when the terminal is off. The center line of LED is always on.


Pr. 52 Setting	Monitor Description					
55	Displays the I/O and output terminal ON/OFF status of the inverter unit.					
56 *	Displays the input terminal ON/OFF status of the digital input option (FR-A7AX E kit).					
57 *	Displays the output terminal ON/OFF status of the digital output option (FR-A7AY E kit) or relay output option (FR-A7AR E kit).					

You can set "56" or "57" if the option is not fitted. When the option is not fitted, the monitor displays are all off.


•On the unit I/O terminal monitor (Pr. 52 = "55"), the upper LEDs denote the input terminal status and the lower the output terminal status.



•On the input option terminal monitor (Pr. 52 = "56"), the decimal point LED of the first digit LED is on.



•On the output option terminal monitor (Pr. 52 = "57"), the decimal point LED of the second digit LED is on.





#### (4) Cumulative power monitor and clear (Pr. 170)

- •On the cumulative power monitor (Pr. 52 = "25"), the output power monitor value is added up and is updated in 1h increments.
- •The operation panel, parameter unit (FR-PU04/FR-PU07) and communication (RS-485 communication, communication option) display increments and display ranges are as indicated below.

Operation Panel *1		Parameter Unit	*2	Communication		
Range	Unit Range		Unit	R	Unit	
Nallye	Oilit	Kalige	Oliit	<i>Pr. 170</i> = 10	<i>Pr. 170</i> = 9999	Oilit
0 to 99.99kWh	0.01kWh	0 to 999.99kWh	0.01kWh		0 to 65535kWh	
100.0 to 999.9kWh	0.1kWh	1000.0 to 9999.9kWh 0.1kWh		0 to 9999kWh	(initial value)	1kWh
1000 to 9999kWh	1kWh	10000 to 99999kWh	1kWh		(iiiiiai value)	

Power is measured in the range 0 to 9999.99kWh, and displayed in 4 digits.

When the monitor value exceeds "99.99", a carry occurs, e.g. "100.0", so the value is displayed in 0.1kWh increments.

When the monitor value exceeds "999.99", a carry occurs, e.g. "1000.0", so the value is displayed in 0.1kWh increments.

•Writing "0" to Pr. 170 clears the cumulative power monitor.



#### • REMARKS

• If "0" is written to Pr. 170 and Pr. 170 is read again, "9999" or "10" is displayed.

#### (5) Cumulative energization time and actual operation time monitor (Pr. 171, Pr. 563, Pr. 564)

- •Cumulative energization time monitor (Pr. 52 = "20") accumulates energization time from shipment of the inverter every one hour.
- •On the actual operation time monitor (Pr. 52 = "23"), the inverter running time is added up every hour. (Time is not added up during a stop.)
- •If the monitored value exceeds 65535, it is added up from 0. You can check the numbers of cumulative energization time monitor exceeded 65535h with Pr. 563 and the numbers of actual operation time monitor exceeded 65535h with Pr. 564.
- •Writing "0" to Pr. 171 clears the cumulative energization power monitor. (The cumulative time monitor can not be cleared.)



#### • REMARKS

- · The actual operation time is not added up unless the inverter is operated one or more hours continuously.
- If "0" is written to Pr. 171 and Pr. 171 is read again, "9999" is always displayed. Setting "9999" does not clear the actual operation

#### (6) You can select the decimal digits of the monitor (Pr. 268)

•As the operation panel display is 4 digits long, the decimal places may vary at analog input, etc. The decimal places can be hidden by selecting the decimal digits.

In such a case, the decimal digits can be selected by Pr. 268.

Pr. 268 Setting	Description
9999 (initial value)	No function
	For the first or second decimal places (0.1 increments or 0.01 increments) of the monitor, numbers in the first
0	decimal place and smaller are rounded to display an integral value (1 increments). The monitor value smaller than
	0.99 is displayed as 0.
1	When 2 decimal places (0.01 increments) are monitored, the 0.01 decimal place is dropped and the monitor
ı	displays the first decimal place (0.1 increments). The monitored digits in 1 increments are displayed as they are.



## • REMARKS

The number of display digits on the cumulative energization time (Pr. 52 = "20") and actual operation time (Pr. 52 = "23") does not change.



#### Parameters referred to

Pr. 30 Regenerative function selection, Pr. 70 Special regenerative brake duty Refer to page 119 Pr. 37 Speed display Refer to page 142

Pr. 55 Frequency monitoring reference, Pr. 56 Current monitoring reference Refer to page 148

Power is measured in the range 0 to 99999.99kWh, and displayed in 5 digits.


## 4.12.3 Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)

Analog voltage output from the terminal AM is available. Set the reference of the signal output from terminal AM.

Parameter Number	Name	Initial Value	Setting Range	Description
55*	Frequency monitoring reference	50Hz	0 to 400Hz	Full-scale value to output the output frequency monitor value to terminal AM.
56*	Current monitoring reference	Inverter rated current	0 to 500A	Full-scale value to output the output current monitor value to terminal AM.


The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

#### (1) Frequency monitoring reference (Pr. 55)



- Set the frequency to be referenced when the frequency monitor (output frequency/set frequency) is selected for the terminal AM display.
- Set the frequency (output frequency/set frequency) when the voltage output at terminal AM is 10VDC.
- The analog voltage output and frequency at terminal AM are proportional. (The maximum output voltage is 10VDC.)

#### (2) Current monitoring reference (Pr. 56)



- Set the current to be referenced when the current monitor (inverter output current, etc.) is selected for terminal AM display.
- Set the current value when the voltage output at terminal AM is 10VDC.
- The analog voltage output and current value at terminal AM are proportional. (The maximum output voltage is 10VDC.)

<sup>\*</sup> The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.




### 4.12.4 Terminal AM calibration (calibration parameter Pr. 645, C1 (Pr.901))

By using the operation panel or parameter unit, you can calibrate terminal AM to full scale deflection.

Parameter Number	Name	Initial Value	Setting Range	Description
645	AM 0V adjustment	1000	970 to 1200	Calibrates the scale of the meter when analog output is 0.
C1(901)	AM terminal calibration	_	_	Calibrates the scale of the meter connected to terminal AM.

- The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)
- The parameter number in parentheses is the one for use with the operation panel (PA02) for the FR-E500 series or parameter unit (FR-PU04/FR-PU07). \*2
- The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write

#### Terminal AM bias calibration



- Use Pr. 645 AM OV adjustment to calibrate the bias side output signal from terminal AM.
- If the meter needle does not point to 0 when the analog output from terminal AM is 0, add or decrease the Pr. 645 setting to adjust the meter needle points to 0.
- When changing  $\pm 1$  in Pr. 645, the analog output changes about ±5mV.

(Analog output will not become lower than about -100mV even when setting the Pr. 645 lower.)





#### NOTE

- Calibration bias and gain changes when changing the control circuit terminal block. Use Pr. 645 and CI(Pr. 901) to
- If bias calibration (Pr. 645) is performed, make sure to perform gain calibration (C1(Pr. 901)) too.

#### (2) Terminal AM gain calibration (C1 (Pr. 901))

Terminal AM is factory-set to provide a 10VDC output in the full-scale status of the corresponding monitor item. Calibration parameter C1 (Pr. 901) allows the output voltage ratios (gains) to be adjusted according to the meter scale. Note that the maximum output voltage is 10VDC.





- · Calibrate the terminal AM gain in the following procedure.
  - 1) Connect a 0-10VDC meter (frequency meter) to across inverter terminals AM-5. (Note the polarity. The terminal AM is positive.)
  - 2) Refer to the monitor description list (page 143) and set Pr. 158. When you selected the running frequency, inverter output current, etc. as monitor, preset in Pr. 55 or Pr. 56 the running frequency or current value at which the output signal will be 10V.
  - 3) When outputting the item that cannot achieve a 100% value easily by operation, e.g. output current, set "21" (reference voltage output) in Pr. 158 and perform the following operation. After that, set "2" (output current, for example) in Pr. 158.



#### (I) REMARKS

When outputting such an item as the output current, which cannot reach a 100% value easily by operation, set Pr. 158 to "21" (reference voltage output) and make calibration. 10VDC is output from the terminal AM.

#### (3) How to calibrate the terminal AM when using the operation panel

Confirmation of the RUN indication and operation mode indication

Press (MODE) to choose the parameter setting mode.

Operation -

3. Turn until [. . . appears

4. Turn (SET) until [ - - - appears.

5. Turn until [ | appears.

Set to C1 AM terminal calibration.

6. Press (SET) to enable setting.

7. If the inverter is at a stop, press the RUN key to start the inverter.

(Motor needs not be connected.)

8. Turn to adjust the indicator needle to the desired position.

9. Press (SET).
Setting is complete.

(When *Pr. 158* = 1)

Hz MON PU

PRM indication is lit.

 $\Rightarrow$  P. B

(The parameter number read previously appears.)

C1 to C7 setting is enabled.

SET) ⇒ [ - - -

SET 

The monitor set to Pr. 158

AM terminal function selection is displayed.



SET SCOO HZ

Flicker...Parameter setting complete!!

•Turn to read another parameter.

•Press (SET) to return to the [ - - - indication (step 4).

•Press (SET) twice to show the next parameter ( Pr.[].

## • REMARKS

- Calibration can also be made for external operation. Set the frequency in the external operation mode, and make calibration in the above procedure.
- Calibration can be made even during operation.
- For operation from the parameter unit (FR-PU04/FR-PU07), refer to the instruction manual of the parameter unit.

## Parameters referred to

Pr. 55 Frequency monitoring reference Refer to page 148
Pr. 56 Current monitoring reference Refer to page 148

Pr. 158 AM terminal function selection Refer to page 143



# 4.13 Operation selection at power failure and instantaneous power failure

Purpose	Parameter tl	Refer to Page	
At instantaneous power failure	Automatic restart operation	Pr. 30, Pr. 57, Pr. 58, Pr. 96,	
occurrence, restart inverter without	after instantaneous power	Pr. 162, Pr. 165, Pr. 298, Pr. 299,	151
stopping motor	failure/flying start	Pr. 611	
When undervoltage or a power	Power failure-time		
failure occurs, the inverter can be	deceleration-to-stop	Pr. 261	157
decelerated to a stop.	function		

# 4.13.1 Automatic restart after instantaneous power failure/flying start (Pr. 30, Pr. 57, Pr. 58, Pr. 96, Pr. 162, Pr. 165, Pr. 298, Pr. 299, Pr. 611)


You can restart the inverter without stopping the motor in the following cases:

- When power comes back on after an instantaneous power failure
- When motor is coasting at start

Parameter Number	Name	Initial Value	Setting Range	Description
20	Regenerative function		0, 1	The motor starts at the starting frequency when MRS (X10) turns on then off
30	selection	0	2	Restart operation is performed when MRS (X10) turns on then off
57	Restart coasting time	9999	0	FR-E740-040 or less1s FR-E740-060 to 1702s FR-E740-230 and 3003s The above times are coasting time.
	, and the second		0.1 to 5s	Waiting time for inverter-triggered restart after an instantaneous power failure.
			9999	No restart
58	Restart cushion time	1s	0 to 60s	Voltage starting time at restart.
			0	Offline auto tuning is not performed
			1	Advanced magnetic flux vector control  Offline auto tuning is performed without motor running (all motor constants) (Refer to page 76)
96	Auto tuning setting/status	0	11	For general-purpose magnetic flux vector control  Offline auto tuning is performed without motor running (motor constants (R1) only) (Refer to page 79)
			21	Offline auto tuning (tuning performed without motor running) for V/F control and automatic restart after instantaneous power failure (with frequency search)
	Automatic restart after		0	With frequency search
162		_	1	Without frequency search (reduced voltage system)
162	instantaneous power	1	10	Frequency search at every start
	failure selection		11	Reduced voltage at every start
4.CE	Stall prevention operation	4500/	0.1- 0000/	Considers the rated inverter current as 100% and sets the
165	level for restart	150%	0 to 200%	stall prevention operation level during restart operation.
298	Frequency search gain	9999	0 to 32767	When offline auto tuning is performed under V/F control, frequency search gain necessary for frequency search for automatic restart after instantaneous power failure is set as
			9999	well as the motor constants (R1). Uses the Mitsubishi motor (SF-JR, SF-HR, SF-JRCA, SF-HRCA) constants
			0	Without rotation direction detection
	Rotation direction		1	With rotation direction detection
299	detection selection at restarting	0	9999	When <i>Pr.</i> 78 = 0, With rotation direction detection When <i>Pr.</i> 78 = 1, 2
644	Acceleration time at a		0 to 3600s	Without rotation direction detection  Acceleration time to reach the acceleration time reference frequency at a restart.
611	restart  arameters can be set when Pr. 160 U	5s	9999	Acceleration time for restart is the normal acceleration time (e.g. <i>Pr. 7</i> )


The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

## When Pr. 162 = 1, 11 (without frequency search)



\* The output shut off timing differs according to the load condition.

#### When Pr. 162 = 0, 10 (with frequency search)



#### (1) Automatic restart operation selection

(Pr. 30, Pr. 162, Pr. 299)

#### Without frequency search

When *Pr.* 162 = "1" or "11", automatic restart operation is performed in a reduced voltage system, where the voltage is gradually risen with the output frequency unchanged from prior to an instantaneous power failure independently of the coasting speed of the motor.

#### > REMARKS

• This system stores the output frequency and rotation direction prior to an instantaneous power failure and restart using the stored value. Therefore, if the instantaneous power failure time exceeds 0.2s and the stored value cannot be retained, the inverter starts at *Pr. 13 Starting frequency* (initial value = 0.5Hz) in the starting direction upon power restoration.

#### With frequency search

When "0 (initial value) or 10" is set in *Pr. 162*, the inverter smoothly starts after detecting the motor speed upon power restoration. (The motor capacity should be equal to or one rank lower than the inverter capacity)

When using the frequency search, perform offline auto tuning.

(Refer to page 110 for advanced magnetic flux vector, general-purpose magnetic flux vector control and page 154 for V/F control.)

- During reverse rotation, the inverter can be restarted smoothly as the direction of rotation is detected.
- •You can select whether to make rotation direction detection or not with *Pr. 299 Rotation direction detection selection at restarting*.

When capacities of the motor and inverter differ, set "0" (without rotation direction detection) in *Pr. 299*.

Pr. 299 Setting	Pr. 78 Setting				
17. 299 Setting	0	1	2		
9999	0	×	×		
0 (initial value)	×	×	×		
1	0	0	0		

O: the rotation direction is detected.

x: the rotation direction is not detected.



#### > REMARKS

- · Speed detection time (frequency search) changes according to the motor speed. (maximum 100ms)
- When the inverter capacity is two rank or more larger than the motor capacity, the inverter may not start due to overcurrent trip (E.OC□).
- If two or more motors are connected to one inverter, the inverter functions abnormally. (The inverter does not start smoothly.)
- When reverse rotation is detected when *Pr.* 78 = "1" (reverse rotation disabled), the rotation direction is changed to forward rotation after decelerates in reverse rotation when the start command is forward rotation. The inverter will not start when the start command is reverse rotation.



#### NOTE

- When automatic restart operation after instantaneous power failure is activated while the motor is running at a low speed (less than 10Hz), the motor restarts in the direction prior to instantaneous power failure without detecting the rotation direction (*Pr. 299 Rotation direction detection selection at restarting* = "1").
- If the frequency search result exceeds the set frequency, the output frequency is limited at the set frequency.
- When the wiring length exceeds than 100m, select without frequency search (Pr. 162 = "1, 11").



#### Restart operation at every start

When Pr. 162 = "10" or "11", automatic restart operation is also performed every start, in addition to the automatic restart after instantaneous power failure. When Pr. 162 = "0", automatic restart operation is performed at the first start after power supply-on, but not performed at the second time or later.

#### • Automatic restart operation selection of MRS (X10) signal

Restart operation after turning MRS (X10) signal on then off using Pr. 30 can be selected as in the table below. When automatic restart after instantaneous power failure is selected when using the high power factor converter (FR-HC), noramally set "2" in Pr. 30.

Pr. 30 Setting	Operation after MRS and X10 Signal Turns off, on, then off.
0, 1	Start at the Pr. 13 Starting frequency.
2	Frequency search is made and starts at the coasting speed.

#### (2) Restart coasting time (Pr. 57)

- •Coasting time is the time from when the motor speed is detected until automatic restart control is started.
- •Set Pr. 57 to "0" to perform automatic restart operation.


The coasting time is automatically set to the value below. Generally this setting will pose no problems.

FR-E740-040 or less	ls
FR-E740-060 to 1702	2s
FR-E740-230 and 300	3s

•Operation may not be performed well depending on the magnitude of the moment of inertia (J) of the load or running frequency. Adjust the coasting time between 0.1s and 5s according to the load specifications.

#### (3) Restart cushion time (Pr. 58)

- •Cushion time is the length of time when the voltage appropriate to the voltage at the detected motor speed (output frequency prior to instantaneous power failure when Pr. 162 = "1, 11") from 0V.
- •Normally the initial value need not be changed for operation, but adjust it according to the magnitude of the moment of inertia (J) of the load or torque.



#### (4) Automatic restart operation adjustment (Pr. 165, Pr. 611)

- •Using Pr. 165, you can set the stall prevention operation level at a restart.
- •Using *Pr.* 611, you can set the acceleration time to the acceleration time reference frequency when automatic restart operation is performed besides the normal acceleration time.



#### ▶ REMARKS

• If the Pr. 21 Acceleration/deceleration time increments is changed, the setting increments of Pr. 611 remain unchanged.

#### (5) Frequency search gain (Pr. 298), offline auto tuning (Pr. 96)

- •When automatic restart after instantaneous power failure operation (with frequency search) is valid at V/F control, perform offline auto tuning.
- •Perform offline auto tuning during V/F control in the following order to set *Pr. 298 Frequency search gain* automatically. (Refer to *page 110* during advanced magnetic flux vector control and general-purpose magnetic flux vector control.)

#### Before performing offline auto tuning

Check the following before performing offline auto tuning.

- •The inverter is under V/F control
- •A motor should be connected. Note that the motor should be at a stop at a tuning start.
- •The motor capacity should be equal to or one rank lower than the inverter capacity.
- •The maximum frequency is 120Hz.
- •A high-slip motor, high-speed motor and special motor cannot be tuned.
- •Even if tuning is performed without motor running (*Pr. 96 Auto tuning setting/status* = "21"), the motor may run slightly. Therefore, fix the motor securely with a mechanical brake, or before tuning, make sure that there will be no problem in safety if the motor runs (caution is required especially in vertical lift applications). Note that tuning performance is unaffected even if the motor runs slightly.
- •Offline auto tuning will not be performed properly if it is performed with a surge voltage suppression filter (FR-ASFH, FR-BMF-H) connected between the inverter and motor. Remove it before starting tuning.

#### Setting

1) Set "21" in Pr. 96 Auto tuning setting/status.

Tuning is performed without motor running.

It takes approximately 9s \* until tuning is completed.

(Excitation noise is produced during tuning.)

- \*Tuning time differs according to the inverter capacity and motor type.
- 2) Set the rated motor current (initial value is rated inverter current) in Pr. 9 Electronic thermal O/L relay. (Refer to page 106)
- 3) Set Pr. 71 Applied motor according to the motor used.

Motor	Pr.71 Setting *1	
	SF-JR	3
Mitsubishi standard motor	SF-JR 4P 1.5kW or less	23
Mitsubishi high efficiency motor	SF-HR	43
	Others	3
Mitaulaialai aayatayt tayayya	SF-JRCA 4P	13
Mitsubishi constant-torque motor	SF-HRCA	53
motor	Others (SF-JRC, etc.)	13
Other manufacturer's standard motor		3
Other manufacturer's constant torque motor	_	13

<sup>\*1</sup>Refer to page 108, for other settings of Pr. 71.

#### Execution of tuning



#### POINT

Before performing tuning, check the monitor display of the operation panel or parameter unit (FR-PU04/FR-PU07) if the inverter is in the status for tuning. (Refer to 2) below)

1) When performing PU operation, press (RUN) of the operation panel. For external operation, turn on the start command (STF signal or STR signal). Tuning starts.



#### NOTE

- To force tuning to end, use the MRS or RES signal or press (STOP) of the operation panel. (Turning the start signal (STF signal or STR signal) off also ends tuning.)
- During offline auto tuning, only the following I/O signals are valid: (initial value)
  - •Input terminal <Valid signal> MRS, RES, STF, STR
  - Output terminal RUN, AM, A, B, C

Note that the progress status of offline auto tuning is output in eight steps from AM when speed and output frequency are selected.

- Since the RUN signal turns on when tuning is started, caution is required especially when a sequerence which releases a mechanical brake by the RUN signal has been designed.
- When executing offline auto tuning, input the run command after switching on the main circuit power (R/L1, S/L2, T/ L3) of the inverter.
- · Do not perform ON/OFF switching of the second function selection signal (RT) during execution of offline auto tuning. Auto tuning is not excecuted properly.
- 2) Monitor is displayed on the operation panel and parameter unit (FR-PU04, FR-PU07) during tuning as below.

	Parameter Unit (FR-PU04, FR-PU07)	Operation Panel Indication
Pr. 96 setting	21	21
(1) Setting	READ:List 21 STOP PU	2 1 _ MON _
(2) Tuning in progress	TUNE 22 STF FWD PU	22 RUN MON BAT
(3) Normal end	TUNE 23 COMPLETION STF STOP PU	Flickering
(4) Error end (when inverter protective function operation is activated)	TUNE 9 ERROR STF STOP PU	<b>3</b> Ext Ext =

•Reference: Offline auto tuning time (when the initial value is set)

Offline Auto Tuning Setting	Time
Tune motor constants (R1) only	Approx. 9s (Tuning time differs according to the inverter capacity
( <i>Pr.</i> 96 = "21")	and motor type.)

3) When offline auto tuning ends, press (STOP) of the operation panel during PU operation. For external operation, turn off the start signal (STF signal or STR signal) once.

This operation resets the offline auto tuning and the PU's monitor display returns to the normal indication. (Without this operation, next operation cannot be started.)



#### • REMARKS

• Do not change the Pr. 96 setting after completion of tuning (23). If the Pr. 96 setting is changed, tuning data is made invalid. If the  ${\it Pr.\,96}$  setting is changed, tuning must be performed again.

4) If offline auto tuning ended in error (see the table below), motor constants are not set. Perform an inverter reset and restart tuning.

Error Display	Error Cause	Remedy
8	Forced end	Set "21" in Pr. 96 and perform tuning again.
9	Inverter protective function operation	Make setting again.
91	Current limit (stall prevention) function was activated.	Set "1" in <i>Pr. 156</i> .
92	Converter output voltage reached 75% of rated value.	Check for fluctuation of power supply voltage.
93	Calculation error	Check the motor wiring and make setting again.
33	A motor is not connected.	Set the rated current of the motor in Pr. 9.


5) When tuning is ended forcibly by pressing (STOP) or turning off the start signal (STF or STR) during tuning, offline auto tuning does not end normally. (The motor constants have not been set.) Perform an inverter reset and restart tuning.



#### NOTE


- · The motor constants measured once in the offline auto tuning are stored as parameters and their data are held until the offline auto tuning is performed again.
- An instantaneous power failure occurring during tuning will result in a tuning error. After power is restored, the inverter goes into the normal operation mode. Therefore, when STF (STR) signal is on, the motor runs in the forward (reverse) rotation.
- Any alarm occurring during tuning is handled as in the ordinary mode. Note that if a fault retry has been set, retry is ianored.
- The set frequency monitor displayed during the offline auto tuning is 0Hz.
- Changing the terminal assignment using Pr.178 to Pr.184 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.
- The SU and FU signals are not output during a restart. They are output after the restart cushion time has elapsed.
- · Automatic restart operation will also be performed after a reset or when a retry is made by the retry function.





When you have selected automatic restart after instantaneous power failure function, apply in easily visible places the CAUTION stickers supplied to the Installation guideline.







## Parameters referred to

Pr. 7 Acceleration time, Pr. 21 Acceleration/deceleration time increments Refer to page 99

Pr. 13 Starting frequency Refer to page 102

Pr. 65, Pr. 67 to Pr. 69 Retry function Refer to page 159

Pr. 71 Applied motor Refer to page 108

Pr. 78 Reverse rotation prevention selection Refer to page 177

Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 128




### 4.13.2 Power-failure deceleration stop function (Pr. 261)

When a power failure or undervoltage occurs, the inverter can be decelerated to a stop or can be decelerated and reaccelerated to the set frequency.

Parameter	Nome	Name Initial Setting Value Range		Description
Number	Name			Description
		0	0	Coasts to stop.  When undervoltage or power failure occurs, the inverter output is shut off.
261	Power failure stop		1	When undervoltage or a power failure occurs, the inverter can be decelerated to a stop.
	selection	2		When undervoltage or a power failure occurs, the inverter can be decelerated to a stop.  If power is restored during a power failure, the inverter accelerates again.

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)



#### *Pr.* 261 = 1 Power During deceleration Output frequency at occurrence of power failure During stop at occurrence of power failure Time STF Y46

Turn off STF once to make acceleration again

#### (1) Parameter setting

•When Pr. 261 is set to "1" or "2", the inverter decelerates to a stop if an undervoltage or power failure occurs.

#### (2) Operation outline of deceleration to stop at power


•When undervoltage or power failure has occurred, the output frequency is decreased and controled so that the converter circuit (DC bus) voltage is constant and decreased to 0Hz to stop.

#### (3) Power failure stop function (Pr. 261 = "1")

•If power is restored during power failure deceleration, deceleration to a stop is continued and the inverter remains stopped. To restart, turn off the start signal once, then turn it on again.

## • REMARKS


- When automatic restart after instantaneous power failure is selected (Pr. 57 ≠ "9999"), power failure stop function is made invalid and automatic restart operation after instantaneous power failure is made valid.
  - After a power failure stop, the inverter will not start even if the power is restored with the start signal (STF/STR) input. After switching on the power, turn off the start signal once and then on again to make a start.




## 7/

#### (4) Operation continuation at instantaneous power failure function (Pr. 261 = "2")

- •When power is restored during deceleration after a power failure, acceleration is made again up to the set frequency.
- •When this function is used in combination with the automatic restart after instantaneous power failure function( $Pr.57 \neq$  "9999"), deceleration can be made at a power failure and acceleration can be made again after power restoration.







#### NOTE

When operation continuation at instantaneous power failure function is used, keep the starting signal (STF/STR) on
even during instantaneous power failure. If the starting signal turns off during instantaneous power failure, the
inverter decelerates according to the deceleration time setting, causing the motor to coast if enough regenerative
energy is not obtained.

#### (5) Power failure deceleration signal (Y46 signal)

- •The Y46 signal is on during deceleration at an instantaneous power failure or during a stop after deceleration at an instantaneous power failure.
- •After a power failure stop, the inverter can not start even if power is restored the start command is given. In this case, check the power failure deceleration signal (Y46 signal). (at occurrence of input phase loss (E.ILF), etc.)
- •For the Y46 signal, set "46 (forward operation)" or "146 (reverse operation)" to any of *Pr. 190 to Pr. 192 (output terminal function selection)* to assign the function.



#### > REMARKS

During a stop or trip, the power failure stop selection is not performed.



#### **NOTE**

• Changing the terminal assignment using *Pr. 190 to Pr. 192 (output terminal function selection)* may affect the other functions. Please make setting after confirming the function of each terminal.



Even if the power failure stop function is valid, some loads may cause the inverter to trip and the motor to coast.

The motor will coast if enough regenerative energy is not given from the motor to the inverter.



#### Parameters referred to

Pr. 57 Restart coasting time Refer to page 151
Pr. 190 to Pr. 192 (output terminal function selection) Refer to page 134



## 4.14 Operation setting at fault occurrence


Purpose	Parameter th	Refer to Page	
Recover by retry operation at fault occurrence	Retry operation	Pr. 65, Pr. 67 to Pr. 69	159
Do not output input/output phase failure alarm	Input/output phase failure protection selection	Pr. 251, Pr. 872	161

#### 4.14.1 Retry function (Pr. 65, Pr. 67 to Pr. 69)


If a fault occurs, the inverter resets itself automatically to restart. You can also select the fault for a retry. When you have selected automatic restart after instantaneous power failure ( $Pr. 57 Restart coasting time \neq 9999$ ), restart operation is performed at the retry operation time which is the same of that of a power failure. (Refer to page 151 for the restart function.)

Parameter	Name Initial Setting		Description	
Number	Name	Value Range		Description
65	Retry selection	0	0 to 5	A fault for retry can be selected. (Refer to the next page)
			0	No retry function
			1 to 10	Set the number of retries at fault occurrence.
67	Number of retries at fault occurrence	0		A fault output is provided during retry operation.
67				Set the number of retries at fault occurrence. (The setting
				value of minus 100 is the number of retries.)
				A fault output is provided during retry operation.
68	20 Between elimentine		0.1 to 360s	Set the waiting time from when an inverter fault occurs
00	Retry waiting time	1s	0.1 10 3608	until a retry is made.
69	Retry count display erase	0	0	Clear the number of restarts succeeded by retry.

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)



## Retry failure example



- Retry operation automatically resets a fault and restarts the inverter at the starting frequency when the time set in Pr. 68 elapses after the inverter is tripped.
- Retry operation is performed by setting *Pr.67* to any value other than "0". Set the number of retries at fault occurrence in *Pr. 67*.
- When retries fail consecutively more than the number of times set in Pr. 67, a retry count excess fault (E.RET) occurs, resulting in inverter trip. (Refer to retry failure example)
- Use Pr. 68 to set the waiting time from when the inverter trips until a retry is made in the range 0 to 360s. (When the setting value is "0s", the actual time is 0.1s.)
- Reading the *Pr.* 69 value provides the cumulative number of successful restart times made by retry.
  - The cumulative count in Pr. 69 is increased by 1 when a retry is regarded as successful after normal operation continues without faults occurring for more than four times longer than the time set in Pr. 68 after a retry start.
  - (When retry is successful, cumulative number of retry failure is cleared.)
- Writing "0" to Pr. 69 clears the cumulative count.
- During a retry, the Y64 signal is on. For the Y64 signal, assign the function by setting "64 (positive operation)" or "164 (negative operation)" to any of *Pr. 190 to Pr. 192* (output terminal faction selection).

- Using Pr. 65, you can select the fault that will cause a retry to be executed. No retry will be made for the fault not indicated. (Refer to page 268 for the fault description.)
  - indicates the faults selected for retry.

Fault for	Pr. 65 Setting					
Retry	0	1	2	3	4	5
E.OC1	•	•		•	•	•
E.OC2	•	•		•	•	
E.OC3	•	•		•	•	•
E.OV1	•		•	•	•	
E.OV2	•		•	•	•	
E.OV3	•		•	•	•	
E.THM	•					
E.THT	•					
E. BE	•				•	
E. GF	•				•	

Fault for	Pr. 65 Setting					
Retry	0	1	2	3	4	5
E.USB	•				•	
E.OHT	•					
E.OLT	•				•	
E.OP1	•				•	
E. PE	•				•	
E.MB4	•				•	
E.MB5	•				•	
E.MB6	•				•	
E.MB7	•				•	
E.ILF	•				•	



#### **NOTE**

- When terminal assignment is changed using Pr.190 to Pr.192, the other functions may be affected. Make setting after confirming the function of each terminal.
- · The data stored as the error reset for retry is only that of the fault which occurred the first time.
- When an inverter fault is reset by the retry function at the retry time, the accumulated data of the electronic thermal relay function, regeneration brake duty etc. are not cleared. (Different from the power-on reset.)
- · Retry is not performed if E.PE (Parameter storage device fault) occurred at power on.



Mhen you have selected the retry function, stay away from the motor and machine when the inverter is tripped. They will start suddenly (after the reset time has elapsed) after the inverter trip. When you have selected the retry function, apply in easily visible places the CAUTION stickers supplied.



#### Parameters referred to

Pr. 57 Restart coasting time (Refer to page 151)



### 4.14.2 Input/output phase loss protection selection (Pr. 251, Pr. 872)

You can disable the output phase loss protection function that trips the inverter if one phase of the inverter output side (load side) three phases (U, V, W) is lost.

The input phase loss protection function of the inverter input side (R/L1, S/L2, T/L3) can be made valid.

Parameter Number	Name	Initial Value	Setting Range	Description
254	Output phase loss	4	0	Without output phase loss protection
251	protection selection	1	1	With output phase loss protection
070	Input phase loss protection	4	0	Without input phase loss protection
872	selection	1	1	With input phase loss protection

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

#### (1) Output phase loss protection selection (Pr. 251)

• When Pr. 251 is set to "0", output phase loss protection (E.LF) becomes invalid.

#### (2) Input phase loss protection selection (Pr. 872)

• When *Pr.* 872 is set to "1", input phase loss protection (E.ILF) is provided if a phase loss of one phase among the three phases is detected for 1s continuously.



#### NOTE

- If an input phase loss continues for a long time, the converter section and capacitor lives of the inverter will be shorter.
- As phase loss is detected according to the bus voltage change, it can not be detected if the load is light. Also, if the power supply voltage is imbalanced, phase loss is less likely detected.
- Phase loss can not be detected during regeneration load operation.

### 4.14.3 Earth (ground) fault detection at start (Pr. 249)

You can choose whether to make earth (ground) fault detection at start valid or invalid. Earth (Ground) fault detection is executed only right after the start signal is input to the inverter.

Protective function will not activate if an earth (ground) fault occurs during operation.

Parameter Number	Name	Initial Value	Setting Range	Description
0.40	Earth (ground) fault	1	0	Without earth (ground) fault detection
249	detection at start		1	With earth (ground) fault detection

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)



#### NOTE

- As detection is executed at starting, output is delayed for approx. 20ms every starting.
- If an earth (ground) fault is detected with "1" set in *Pr. 249*, output side earth (ground) fault overcurrent (E.GF) is detected and the inverter trips. (*Refer to page 273*)
- If the motor capacity is smaller than the inverter capacity for the FR-E740-120 or more, earth (ground) fault detection may not be provided.

## 4.15 Energy saving operation

Purpose	Parameter that should be Set		Refer to Page
Energy saving operation	Optimum excitation control	Pr. 60	162

## 4.15.1 Optimum excitation control (Pr. 60)

Without a fine parameter setting, the inverter automatically performs energy saving operation. This inverter is optimum for fan and pump applications

Parameter Number	Name	Initial Value	Setting Range	Description
60	Energy saving control	0	0	Normal operation mode
60	selection *	0	9	Optimum excitation control mode

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

#### (1) Optimum excitation control mode (setting "9")

- •When "9" is set in *Pr.* 60, the inverter operates in the optimum excitation control mode.
- •The optimum excitation control mode is a control system which controls excitation current to improve the motor efficiency to maximum and determines output voltage as an energy saving method.



• When the motor capacity is too small as compared to the inverter capacity or two or more motors are connected to one inverter, the energy saving effect is not expected.



#### **NOTE**

- When the optimum excitation control mode is selected, deceleration time may be longer than the setting value. Since overvoltage alarm tends to occur as compared to the constant torque load characteristics, set a longer deceleration time
- Optimum excitation control functions only under V/F control. Optimum excitation control does not function under advanced magnetic flux vector control and general-purpose magnetic flux vector control.
- · Optimum excitation control will not be performed during an automatic restart after instantaneous power failure.
- · Since output voltage is controlled by optimum excitation control, output current may slightly increase.



#### Parameters referred to

Advanced magnetic flux vector control Refer to page 76

General-purpose magnetic flux vector control Refer to page 79

Pr. 57 Restart coasting time Refer to page 151

<sup>\*</sup> When parameter is read using the FR-PU04, a parameter name different from an actual parameter is displayed.



## 4.16 Motor noise, EMI measures, mechanical resonance

Purpose of Use	Parameter that	should be Set	Refer to Page
Reduction of the motor noise Measures against EMI and leakage currents	Carrier frequency and Soft-PWM selection	Pr. 72, Pr. 240	163
Reduce mechanical resonance	Speed smoothing control	Pr. 653	164

#### 4.16.1 PWM carrier frequency and soft-PWM control (Pr. 72, Pr. 240)

You can change the motor sound.

Parameter Number	Name	Initial Value	Setting Range	Description
72 *	PWM frequency selection	1	0 to 15	You can change the PWM carrier frequency. The setting is in [kHz]. Note that 0 indicates 0.7kHz and 15 indicates 14.5kHz.
240 *	Soft-PWM operation	4	0	Soft-PWM is invalid
240	selection	1	1	When $Pr. 72 = 0$ to 5, soft-PWM is valid.

The above parameters can be set when Pr.160 User group read selection = "0". (Refer to page 177)

#### (1) PWM carrier frequency changing (Pr. 72)

- •You can change the PWM carrier frequency of the inverter.
- •Changing the PWM carrier frequency produces an effect on avoiding the resonance frequency of a mechanical system or motor or on EMI measures or on leakage current reduction caused by the PWM switching.

#### (2) Soft-PWM control (Pr. 240)

•Soft-PWM control is a control method that changes the motor noise from a metallic tone into an unoffending complex tone.



#### NOTE

- Decreasing the PWM carrier frequency effect on EMI measures and on leakage current reduction, but increases motor noise.
- When PWM carrier frequency is set to 1kHz or less  $(Pr.72 \le 1)$ , fast response current limit may function prior to stall prevention operation due to increase in ripple currents, resulting in insufficient torque. In such case, set fast-response current limit operation invalid using  $Pr. 156 \, Stall \, prevention \, operation \, selection$ .
- When setting 2kHz or more in *Pr. 72* to perform operation in the place where the ambient temperature exceeding 40°C , caution should be taken as the rated inverter current should be reduced. (*Refer to page 296*)



#### Parameters referred to

Pr. 156 Stall prevention operation selection TF Refer to page 82

<sup>\*</sup> The parameters in the table allow its setting to be changed during operation even if "0" (initial value) is set in Pr. 77 Parameter write selection.


## 7/

### 4.16.2 Speed smoothing control (Pr. 653)

Vibration due to mechanical resonance influences the inverter control, causing the output current (torque) unstable. In this case, the output current (torque) fluctuation can be reduced to ease vibration by changing the output frequency.

Parameter Number	Name	Initial Value	Setting Range	Description
653	Speed smoothing control	0	0 to 200%	Increase or decrease the value using 100% as reference to check an effect.

#### (1) Control block diagram



#### (2) Setting method

If vibration due to mechanical resonance occurs, set 100% in *Pr.* 653, run the inverter at the frequency which generates maximum vibration and check if the vibration will be reduced or not after several seconds.

If effect is not produced, gradually increase the Pr. 653 setting and check the effect repeatedly until the most effective value is set in Pr. 653.

If vibration becomes large by increasing the Pr. 653 setting, gradually decrease the Pr. 653 setting than 100% to check the effect in a similar manner.



#### **NOTE**

Depending on the machine, vibration may not be reduced enough or an effect may not be produced.



## 4.17 Frequency setting by analog input (terminal 2, 4)

Purpose	Parameter that	t should be Set	Refer to Page
Selection of voltage/current input (terminal 2, 4) Perform forward/reverse rotation by analog input.	Analog input selection	Pr. 73, Pr. 267	165
Adjustment (calibration) of analog input frequency and voltage (current)	Bias and gain of frequency setting voltage (current)	Pr. 125, Pr. 126, Pr. 241, C2 to C7 (Pr. 902 to Pr. 905)	168

## 4.17.1 Analog input selection (Pr. 73, Pr. 267)

You can select the function that switches between forward rotation and reverse rotation according to the analog input terminal specifications and input signal.

Parameter Number	Name	Initial Value	Setting Range	Description	
			0	Terminal 2 input 0 to 10V	Without reversible operation
73	Analog input selection	1	1	Terminal 2 input 0 to 5V	Without reversible operation
/3	Analog input selection	'	10	Terminal 2 input 0 to 10V	With reversible operation
			11	Terminal 2 input 0 to 5V	Willi reversible operation
				Voltage/current input switch	Description
267	Terminal 4 input	0	0	I	Terminal 4 input 4 to 20mA
			1		Terminal 4 input 0 to 5V
			2		Terminal 4 input 0 to 10V

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

#### (1) Selection of analog input specifications

- •For the terminal 2 for analog voltage input, 0 to 5V (initial value) or 0 to 10V can be selected.
- Either voltage input (0 to 5V, 0 to 10V) or current input (4 to 20mA initial value) can be selected for terminal 4 used for analog input.

Change the input specifications to change Pr. 267 and voltage/current input switch.


• Rated specifications of terminal 4 change according to the voltage/current input switch setting.

Voltage input: Input resistance  $10k\Omega \pm 1k\Omega$ ,

Maximum permissible input voltage 20VDC

Current input: Input resistance  $233\Omega \pm 5\Omega$ ,

Maximum permissible input voltage 30mA







#### NOTE

Set *Pr. 267* and a voltage/current input switch correctly, then input an analog signal in accordance with the setting. Incorrect setting as in the table below could cause component damage. Incorrect settings other than below can cause abnormal operation.

Setting Causing Component Damage Switch setting Terminal input		Operation
		Operation
I (current input)	Voltage input	This could cause component damage to the analog signal output circuit of signal output devices.  (electrical load in the analog signal output circuit of signal output devices increases)
V (voltage input)	Current input	This could cause component damage of the inverter signal input circuit. (output power in the analog signal output circuit of signal output devices increases)

•Refer to the following table and set Pr. 73 and Pr. 267.

indicates main speed setting)

Pr.73	Terminal 2	Terminal 4 Input		Reversible
Setting	Input	AU signal		Operation
0	0 to 10V			
1	0 to 5V			Not function
(initial value)	0 10 3 V	OFF	_	
10	0 to 10V			Yes
11	0 to 5V			103
0			According to the Pr. 267 setting	
1	_		0:4 to 20mA (initial value)	Not function
(initial value)		ON	1:0 to 5V	
10				Yes
11			2:0 to 10V	162


- : invalid

•The terminal used for the AU signal input, set "4" in Pr. 178 to Pr. 184 (input terminal function selection) to assign functions.




#### NOTE

- · Turn the AU signal on to make terminal 4 valid.
- Make sure that the parameter and switch settings are the same. Different setting may cause a fault, failure or malfunction.
- Use *Pr. 125 (Pr. 126) (frequency setting gain)* to change the maximum output frequency at input of the maximum output frequency command voltage (current). At this time, the command voltage (current) need not be input.
- Also, the acceleration/deceleration time, which is a slope up/down to the acceleration/deceleration reference frequency, is not affected by the change in Pr. 73 setting.
- Changing the terminal assignment using *Pr. 178 to Pr. 184 (input terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.



#### Connection diagram using terminal 2 (0 to 5VDC)



Connection diagram using terminal 2 (0 to 10VDC)

#### (2) Perform operation by analog input selection.

- •The frequency setting signal inputs 0 to 5VDC (or 0 to 10VDC) to across the terminals 2-5. The 5V (10V) input is the maximum output.
- •The power supply 5V can be input by either using the internal power supply or preparing an external power supply. Prepare an external power supply to input the power supply 10V. For the built-in power supply, terminals 10-5 provide 5VDC output.

	Inverter Built-in	Frequency	Pr.73	
Terminal	Power Supply	Setting	(terminal 2 input	
	Voltage	Resolution	power)	


- •When inputting 10VDC to the terminal 2, set "0" or "10" in *Pr. 73*. (The initial value is 0 to 5V)
- Setting "1 (0 to 5VDC)" or "2 (0 to 10VDC)" in *Pr. 267* and a voltage/current input switch in the OFF position changes the terminal 4 to the voltage input specification. When the AU signal turns on, the terminal 4 input becomes valid.



#### > REMARKS

The wiring length of the terminal 10, 2, 5 should be 30m maximum.






#### (3) Perform operation by analog input selection.

- •When the pressure or temperature is controlled constant by a fan, pump, etc., automatic operation can be performed by inputting the output signal 4 to 20mADC of the adjuster to across the terminals 4-5.
- •The AU signal must be turned on to use the terminal 4.

#### Connection diagram using terminal 4 (4 to 20mADC)



Reversible operation example

## (4) Perform forward/reverse rotation by analog input (polarity reversible operation)

•Setting "10" or "11" in *Pr. 73* and adjusting *Pr. 125* (*Pr. 126*) *Terminal 2* frequency setting gain frequency (Terminal 4 frequency setting gain frequency) and *C2* (*Pr. 902*) *Terminal 2 frequency setting bias frequency* to *C7* (*Pr.905*) *Terminal 4 frequency setting gain* makes reverse operation by terminal 2 (terminal 4) valid.

Example)When performing reversible operation by terminal 2 (0 to 5V) input

- 1) Set "11" in *Pr. 73* to make reversible operation valid. Set frequency at maximum analog input in *Pr. 125 (Pr. 903)*
- 2) Set 1/2 of the value set in C4 (Pr. 903) in C3 (Pr. 902).
- 3) Reversible operation is performed when 0 to 2.5VDC is input and forward rotation when 2.5 to 5VDC.



#### NOTE

- When reversible operation is set, be aware of reverse rotation operation when analog input stops (only the start signal is input).
- When reversible operation is valid, reversible operation (0 to 4mA: reverse operation, 4mA to 20mA: forward operation) is performed by terminal 4 in the initial setting.



#### **Parameters referred to**

## 4.17.2 Response level of analog input and noise elimination (Pr. 74)

The time constant of the primary delay filter can be set for the external frequency command (analog input (terminal 2, 4) signal).

Parameter Number	Name	Initial Value	Setting Range	Description
74	Input filter time constant	1	0 to 8	Primary delay filter time constant for the analog input.
				A larger setting results in a larger filter.

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

- · Valid for eliminating noise of the frequency setting circuit.
- Increase the filter time constant if steady operation cannot be performed due to noise.
   A larger setting results in slower response. (The time constant can be set between approximately 1ms to 1s with the setting of 0 to 8.)

# 4.17.3 Bias and gain of frequency setting voltage (current) (Pr. 125, Pr. 126, Pr. 241, C2 (Pr. 902) to C7 (Pr. 905))

You can set the magnitude (slope) of the output frequency as desired in relation to the frequency setting signal (0 to 5V, 0 to 10V or 4 to 20mADC).

Set *Pr.* 267 and voltage/current input switch to switch between 0 to 5VDC, 0 to 10VDC, 0 to 20mADC using terminal 4. (*Refer to page 165*)


#### [Frequency setting bias/gain parameter]


Parameter Number	Name	Initial Value	Setting Range		Description
125	Terminal 2 frequency setting gain frequency	50Hz	0 to 400Hz	Frequency of termina	ıl 2 input gain (maximum).
126	Terminal 4 frequency setting gain frequency	50Hz	0 to 400Hz	Frequency of termina	ıl 4 input gain (maximum).
244 +1 +2	Analog input display unit	0	0	Displayed in %	Heit for one less innert display.
<b>241</b> *1, *3	switchover	0	1	Displayed in V/mA	Unit for analog input display.
C2 (902)	Terminal 2 frequency setting	0Hz	0 to 400Hz	Fraguanay on the hi	as side of terminal 2 input
*1, *2	bias frequency	UHZ	0 to 400HZ	Frequency on the bias side of terminal 2 input.	
C3 (902)	Terminal 2 frequency setting	0%	0 to 2009/	Converted % of the	bias side voltage (current) of
*1, *2	bias	0%	0 to 300%	terminal 2 input.	
C4 (903)	Terminal 2 frequency setting	100%	0 to 300%	Converted % of the	gain side voltage of terminal 2
*1, *2	gain	100%	0 10 300%	input.	
C5 (904)	Terminal 4 frequency setting	0Hz	0 to 400Hz	Fraguanay on the hi	as side of terminal 4 input.
*1, *2	bias frequency	UHZ	0 to 400H2	Frequency on the bid	as side of terminal 4 input.
C6 (904)	Terminal 4 frequency setting	20%	0 to 300%	Converted % of the	bias side current (voltage) of
*1, *2	bias	20%	0 10 300%	terminal 4 input.	
C7 (905)	Terminal 4 frequency setting	100%	0 to 300%	Converted % of the	gain side current (voltage) of
*1, *2	gain	100%	0 10 300%	terminal 4 input.	


<sup>\*1</sup> The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

<sup>\*2</sup> The parameter number in parentheses is the one for use with the operation panel (PA02) for the FR-E500 series or parameter unit (FR-PU04/FR-PU07).

<sup>\*3</sup> The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.







## (1) Change the frequency at maximum analog input (Pr. 125, Pr. 126)

•Set Pr. 125 (Pr. 126) when changing frequency setting (gain) of the maximum analog input voltage (current) only. (C2 (Pr. 902) to C7 (Pr.905) setting need not be changed)

### (2) Analog input bias/gain calibration

(C2 (Pr. 902) to C7 (Pr. 905))

- •The "bias" and "gain" functions are used to adjust the relationship between the input signal entered from outside the inverter to set the output frequency, e.g. 0 to 5V, 0 to 10V or 4 to 20mADC, and the output frequency.
- •Set the bias frequency of the terminal 2 input using C2 (Pr. 902).

(It is initially-set to the frequency at 0V)

- •Set the output frequency in Pr. 125 for the frequency command voltage set with Pr. 73 Analog input
- •Set the bias frequency of the terminal 4 input using C5 (Pr. 904).

(It is initially-set to the frequency at 4mA)

- •Using Pr. 126, set the output frequency relative to 20mA of the frequency command current (4 to 20mA).
- •There are three methods to adjust the frequency setting voltage (current) bias/gain.
  - a) Method to adjust any point without application of a voltage (current) to across terminals 2-5 (4-5) **P** page 170
  - b) Method to adjust any point without application of a voltage (current) to across terminals 2-5 (4-5)



#### NOTE

When voltage/current input signal for terminal 4 was switched using Pr. 267 and voltage/current input switch, perform calibration without fail.

#### (3) Analog input display unit changing (Pr. 241)

- You can change the analog input display unit (%/V/mA) for analog input bias/gain calibration.
- Depending on the terminal input specification set to Pr. 73, Pr. 267, and voltage/current switch, the display units of C3 (Pr. 902), C4 (Pr. 903), C6 (Pr. 904), C7 (Pr. 905) change as shown below.

Analog Command (terminal 2, 4) (depending on <i>Pr. 73, Pr. 267</i> , and voltage/current input switch)	<i>Pr. 241</i> = <b>0</b> (initial value)	<i>Pr. 241</i> = 1
0 to 5V input	0 to 5V → 0 to 100% (0.1%) display	0 to 100% → 0 to 5V (0.01V) display
0 to 10V input	0 to 10V → 0 to 100% (0.1%) display	0 to 100% → 0 to 10V (0.01V) display
0 to 20mA input	0 to 20mA → 0 to 100%(0.1%) display	0 to 100% → 0 to 20mA (0.01mA) display

#### (4) Frequency setting signal (current) bias/gain adjustment method


#### (a) Method to adjust any point without application of a voltage (current) to across terminals 2-5 (4-5). Operation Display -1. Confirmation of the RUN indication and operation mode indication The inverter should be at a stop. The inverter should be in the PU operation mode (Using (PU PRM indication is lit. 2. Press (MODE) to choose the parameter setting mode. (MODE) (The parameter number read previously àppears.)

- 3. Turn ( until [ . . .
- 4. Turn (SET) until [ - appears.
- 5. Turn until [ 4 (<u>[</u> \rceil ) appears. Set to C4 Terminal 2 frequency setting gain.
- **6.** Press (SET) to display the analog voltage (current) value (%).
- 7. Apply a 5V (20mA) voltage (current). (Turn the external potentiometer connected across terminals 2-5 (across terminals 4-5) to maximum (any position).)









Terminal 4 input is



The value is nearly 100 (%) in the maximum position of the potentiometer.




#### **NOTE**

After performing operation in step 6, do not touch until completion of calibration.

8. Press (SET) to set.





Terminal 4 input is selected

#### Flicker...Parameter setting complete!!

- The value is nearly 100 (%) in the maximum position of the potentiometer.
- Turn to read another parameter.
- •Press (SET) to return to the [ - indication (step 4).
- •Press (SET) twice to show the next parameter ( [ ] . [ ] ).

## > REMARKS

- · If the frequency meter (display meter) connected across the terminals AM-5 does not indicate just 50Hz, set the calibration  $parameter\ C1\ AM\ terminal\ calibration.\ (Refer\ to\ page\ 149)$
- If the gain and bias frequency settings are too close, an error (  $\xi \in \Im$  ) may be displayed at the time of write.



(b) Method to adjust any point without application of a voltage (current) to across terminals 2-5 (4-5) (To change from 4V (80%) to 5V (100%))

#### Operation —

- 1. Confirmation of the RUN indication and operation mode indication
  - The inverter should be at a stop.
  - The inverter should be in the PU operation mode.
- 2. Press (MODE) to choose the parameter setting mode.
- 3. Turn until [ appears.
- 4. Turn (SET) until [ - appears.
- 5. Turn until [ 4 (<u>[</u> 7) appears. Set to C4 Terminal 2 frequency setting gain.
- **6.** Press (SET) to display the analog voltage (current) value (%).
- 7. Turn to set gain voltage (%). "0V(0mA) is 0%, 10V(5V, 20mA) is 100%"









(The parameter number read previously appears.)









Analog voltage (current) value (%) across terminals 2-5 (across terminals 4-5)

The gain frequency is reached when the analog voltage (current) value across terminals 2-5 (across terminals 4-5) is 100%.



### **REMARKS**

The current setting at the instant of turning



You can not check after performing operation in step 7.



100

8. Press (SET) to set.







Terminal 4 input is selected



## Flicker...Parameter setting complete!!

(Adjustment completed)

- to read another parameter.
- •Press (SET) to return to the [ - indication (step 4).
- •Press (SET) twice to show the next parameter ( Pr.[].

## • REMARKS

after step 6, you can confirm the current frequency setting bias/gain setting. You can not check after performing operation in step 7.

 $\mathbb{Z}$ 

(c) Adjusting only the frequency without adjusting the gain voltage (current). (When changing the gain frequency from 50Hz to 40Hz)

#### Operation –

1. Turn until P. 125 (Pr. 125) or

P. 126 (Pr. 126) appears

2. Press (SET) to show the currently set value. (50.00Hz)

3. Turn to change the set value to

" \\ [] [] [] ". (40.00Hz)

4. Press (SET) to set.

#### Display











Terminal 2 input is selected Terminal 4 input is selected



## Flicker...Parameter setting complete!!

5. Mode/monitor check

Press (MODE) twice to choose the monitor/frequency monitor.

Apply a voltage across the inverter terminals 2-5 (across 4-5) and turn on the start command (STF, STR).

Operation starts at 40Hz.







#### > REMARKS

- Changing C4 (Pr. 903) or C7 (Pr. 905) (gain adjustment) value will not change the Pr. 20 value.
- For operation from the parameter unit (FR-PU04/FR-PU07), refer to the instruction manual of the FR-PU04/FR-PU07.
- When setting the value to 120Hz or more, it is necessary to set *Pr. 18 High speed maximum frequency* to 120Hz or more. (*Refer to page 86*)
- Make the bias frequency setting using the calibration parameter C2 (Pr. 902) or C5 (Pr. 904). (Refer to page 169)

## **⚠** CAUTION

Take care when setting any value other than "0" as the bias frequency at 0V (0mA). Even if a speed command is not given, merely turning on the start signal will start the motor at the preset frequency.



#### Parameters referred to

Pr. 20 Acceleration/deceleration reference frequency Refer to page 99

Pr. 73 Analog input selection, Pr. 267 Terminal 4 input selection Refer to page 165

Pr. 79 Operation mode selection Refer to page 180

Bias and gain of built-in frequency setting potentiometer Refer to page 262



## 4.18 Misoperation prevention and parameter setting restriction

Purpose	Parameter that should	l be Set	Refer to Page
Limits reset function Trips stop when PU is disconnected Stops from PU	Reset selection/disconnected PU detection/PU stop selection	Pr. 75	173
Prevention of parameter rewrite	Parameter write disable selection	Pr. 77	176
Prevention of reverse rotation of the motor	Reverse rotation prevention selection	Pr. 78	177
Displays pages any parameters	Display of applied parameters and	Pr. 160,	177
Displays necessary parameters	user group function	Pr. 172 to Pr. 174	1//
Control of parameter write by communication	EEPROM write selection	Pr. 342	204

#### 4.18.1 Reset selection/disconnected PU detection/PU stop selection (Pr. 75)

You can select the reset input acceptance, disconnected PU (FR-PU04/FR-PU07) connector detection function and PU stop function.

Parameter Number	Name	Initial Value	Setting Range	Description
75	Reset selection/ disconnected PU detection/ PU stop selection	14	0 to 3, 14 to 17	For the initial value, reset always enabled, without disconnected PU detection, and with PU stop function are set.

<sup>•</sup>The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

<sup>•</sup>The Pr. 75 value can be set any time. Also, if parameter (all) clear is executed, this setting will not return to the initial value.

Pr. 75 Setting	Reset Selection	Disconnected PU Detection	PU Stop Selection
0	Reset input normally enabled	If the PU is disconnected, operation	
1	Reset input is enabled only when the fault occurs.	will be continued.	Pressing (STOP) decelerates the motor
2	Reset input normally enabled	When the PU is disconnected, the	to a stop only in the PU operation
3	Reset input is enabled only when the fault occurs.	inverter trips.	mode.
14 (initial value)	Reset input normally enabled	If the PU is disconnected, operation	
15	Reset input is enabled only when the fault occurs.	will be continued.	Pressing (STOP) decelerates the motor to a stop in any of the PU, externa
16	Reset input normally enabled	When the PU is disconnected, the	and communication operation modes.
17	Reset input is enabled only when the fault occurs.	inverter trips.	and communication operation modes.

#### (1) Reset selection

- •You can select the enable condition of reset function (RES signal, reset command through communication) input.
- •When Pr. 75 is set to any of "1, 3, 15, 17", a reset can be input only when the inverter is tripped.



#### NOTE

- When the reset signal (RES) is input during operation, the motor coasts since the inverter being reset shuts off the output.
- When reset is performed, cumulative values of electronic thermal O/L relay, regenerative brake duty are cleared.
- The reset key of the PU is only valid when the inverter is tripped, independently of the Pr. 75 setting.

#### (2) Disconnected PU detection

- •This function detects that the PU (FR-PU04/FR-PU07) has been disconnected from the inverter for longer than 1s and causes the inverter to provide a fault output (E.PUE) and come to trip.
- •When Pr. 75 is set to any of "0, 1, 14, 15", operation is continued if the PU is disconnected.



#### REMARKS

- · When the PU has been disconnected since before power-on, it is not judged as a fault.
- To make a restart, confirm that the PU is connected and then reset the inverter.
- The motor decelerates to a stop when the PU is disconnected during PU jog operation with Pr. 75 set to any of "0, 1, 14, 15" (which selects operation is continued if the PU is disconnected).
- When RS-485 communication operation is performed through the PU connector, the reset selection/PU stop selection function is valid but the disconnected PU detection function is invalid.

#### PU stop selection

- •In any of the PU operation, external operation and network operation modes, the motor can be stopped by pressing STOP key of the operation panel or parameter unit (FR-PU04/FR-PU07, operation panel for FR-E500 (PA02)).
- •When the inverter is stopped by the PU stop function, " 🗗 💆 " (PS) is displayed. A fault output is not provided.
- •After the motor is stopped from the PU, it is necessary to perform PU stop (PS) reset to restart. PS reset can be made from the unit from which PU stop is made (operation panel, parameter unit (FR-PU04/PU07, operation panel for FR-E500
- •The motor can be restarted by making PS cancel using a power supply reset or RES signal.
- •When Pr. 75 is set to any of "0 to 3", PU stop (PS display) is invalid, deceleration to a stop by (RESET) is valid only in the PU operation mode.




#### > REMARKS

During operation in the PU operation mode through USB communication or RS-485 communication from the PU connector, the motor decelerates to stop (PU stop) when entered from the operation panel (STOP)

# (PS) reset method)



## (4) How to restart the motor stopped by (SPGF) input from the PU in external operation mode (PU stop



#### a) Operation panel

- 1)After completion of deceleration to a stop, switch off the STF or STR signal.
- 2)Press  $\frac{PU}{EXT}$  to display PU ....................... (  $\ref{FS}$  reset)
- 3)Press  $\frac{PU}{FXT}$  to return to  $\frac{FXT}{FXT}$ .
- 4) Switch on the STF or STR signal.

#### b) Parameter unit (FR-PU04/FR-PU07)

- 1)After completion of deceleration to a stop, switch off the STF or STR signal.
- 2)Press EXT ...... ( **P** 5 reset)
- 3)Switch on the STF or STR signal.
- •The motor can be restarted by making a reset using a power supply reset or RES signal.



#### > REMARKS

If Pr. 250 Stop selection is set to other than "9999" to select coasting to a stop, the motor will not be coasted to a stop but decelerated to a stop by the PU stop function during external operation.



#### (5) Restart (PS reset) method when PU stop (PS display) is made during PU operation

•PU stop (PS display) is made when the motor is stopped from the unit where control command source is not selected (operation panel, parameter unit (FR-PU04/FR-PU07, operation panel for FR-E500 (PA02)) in the PU operation mode. For example, when *Pr. 551 PU mode operation command source selection* = "9999" (initial value), the motor is stopped from

the PU (PS display) if entered from the operation panel (RESET) in PU operation mode with the parameter unit mounted.

## When the motor is stopped from the PU when the parameter unit (FR-PU04/FR-PU07) is selected as control command source.

- 1) After the motor has decelerated to a stop, press (STOP) of the parameter unit (FR-PU04/FR-PU07).
- 2) Press  $\frac{PU}{EXT}$  to display  $\boxed{EXT}$  .(  $\begin{cases} \begin{cases} \begin{case$
- 3) Press PU of the parameter unit (FR-PU04/FR-PU07) to select the PU operation mode.
- 4) Press FWD or REV of the parameter unit (FR-PU04/FR-PU07).

### • REMARKS

• When *Pr.* 551 = "9999", the priorities of the PU control source is USB connector > parameter unit (FR-PU04/FR-PU07) > operation panel.



 $\hat{\mathbb{N}}$  Do not reset the inverter while the start signal is being input.

Otherwise, the motor will start instantly after resetting, leading to potentially hazardous conditions.



#### Parameters referred to

Pr. 250 Stop selection \*\* Refer to page 121
Pr. 551 PU mode operation command source selection \*\* Refer to page 191

### 4.18.2 Parameter write disable selection (Pr. 77)

You can select whether write to various parameters can be performed or not. Use this function to prevent parameter values from being rewritten by misoperation.

Parameter Number	Name	Initial Value	Setting Range	Description
	Parameter write selection		0 Write is enabled only during	
77		0	1	Parameter can not be written.
			2	Parameter write is enabled in any operation
		2		mode regardless of operation status.

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

#### (1) Write parameters only during stop (setting "0" initial value)

- •Parameters can be written only during a stop in the PU operation mode.
- •The shaded parameters in the parameter list (page 52) can always be written regardless of the operation mode and operating status. However, Pr. 72 PWM frequency selection and Pr. 240 Soft-PWM operation selection can be written when the inverter is running in the PU operation mode, but cannot be written in the external operation mode.

#### (2) Inhibit parameter write (setting "1")

- Parameter write is not enabled. (Read is enabled.)
- Parameter clear and all parameter clear cannot be performed, either.
- •The parameters given on the right can be written if Pr. 77 ="1".

	Parameter Number	Name	
22		Stall prevention operation level	
	75	Reset selection/disconnected PU detection/	
	75	PU stop selection	
	77	Parameter write selection	
=	79	Operation mode selection	
	160	User group read selection	

#### (3) Write parameters during operation (setting "2")

- •Parameters can always be written.
- •The following prameters cannot be written when the inverter is running if *Pr.* 77 = "2". Stop the inverter when changing their parameter settings.

Parameter	Nama	
Number	Name	
19	Base frequency voltage	
23	Stall prevention operation level compensation	
23	factor at double speed	
40	RUN key rotation direction selection	
48	Second stall prevention operation current	
60	Energy saving control selection	
61	Reference current	
66	Stall prevention operation reduction starting	
00	frequency	
71	Applied motor	
79	Operation mode selection	
80	Motor capacity	
81	Number of motor poles	
82	Motor excitation current	
83	Motor rated voltage	
84	Rated motor frequency	
90 to 94	(Motor constants)	
96	Auto tuning setting/status	
178 to 184	(input terminal function selection)	
190 to 192	(output terminal function selection)	

Parameter	Name	
Number	Name	
255	Life alarm status display	
256	Inrush current limit circuit life display	
257	Control circuit capacitor life display	
258	Main circuit capacitor life display	
277	Stall prevention operation current switchover	
292	Automatic acceleration/deceleration	
293	Acceleration/deceleration separate selection	
298	Frequency search gain	
329	Digital input unit selection	
329	(Parameter for the plug-in option FR-A7AX E kit)	
343	Communication error count	
450	Second applied motor	
541	Frequency command sign selection (CC-Link)	
541	(Parameter for the plug-in option FR-A7NC E kit)	
563	Energization time carrying-over times	
564	Operating time carrying-over times	
800	Control method selection	
859	Torque current	



#### **Parameters referred to**

Pr. 79 Operation mode selection 👺 Refer to page 180

Pr. 77 can be always set independently of the operation mode and operation status.



#### 4.18.3 Reverse rotation prevention selection (Pr. 78)

This function can prevent reverse rotation fault resulting from the incorrect input of the start signal.

Parameter Number	Name	Initial Value	Setting Range	Description
	Reverse rotation prevention		0	Both forward and reverse rotations allowed
78	•	0	1	Reverse rotation disabled
	selection		2	Forward rotation disabled

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

- Set this parameter when you want to limit the motor rotation to only one direction.
- This parameter is valid for all of the reverse rotation and forward rotation keys of the operation panel and parameter unit(FR-PU04/FR-PU07), the start signals (STF, STR signals) via external terminals, and the forward and reverse rotation commands through communication.

## 4.18.4 Extended parameter display and user group function (Pr. 160, Pr. 172 to Pr. 174)

Parameter which can be read from the operation panel and parameter unit can be restricted.

Parameter Number	Name	Initial Value	Setting Range	Description
			9999	Displays only the simple mode parameters
160	User group read selection	0	1, 3, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1,	Displays simple mode + extended parameters
100	osci group read selection			Displays the parameters registered in the user group.
<b>172</b> *1	User group registered	0	(0 to 16)	Displays the number of cases registered as a user group (reading only)
	display/batch clear		9999	Batch clear the user group registration
<b>173</b> *1, *2	User group registration	9999	0 to 999, 9999	Sets the parameter numbers to be registered to the user group
<b>174</b> *1, *2	User group clear	9999	0 to 999, 9999	Sets the parameter numbers to be cleared from the user group

- \*1 The above parameters can be set when Pr. 160 User group read selection = "0".
- \*2 The values read from Pr. 173 and Pr. 174 are always "9999".

#### (1) Display of simple mode parameters and extended parameters (Pr. 160)

- •When Pr. 160 = "9999", only the simple mode parameters can be displayed on the operation panel and parameter unit (FR-PU04/FR-PU07). (Refer to the parameter list, page 52, for the simple mode parameters.)
- •In the initial setting (Pr. 160 = "0") status, simple mode parameters and extended parameters can be displayed.

## • REMARKS

- When a plug-in option is fitted to the inverter, the option parameters can also be read.
- When communication is used to read the parameters, all parameters can be read, regardless of the Pr. 160 setting.
- When RS-485 communication is used to read the parameters, all parameters can be read, regardless of the Pr. 550 NET mode operation command source selection, Pr. 551 PU mode operation command source selection, regardless of Pr. 160 setting.

Pr. 551	Pr. 550	Pr. 160 Valid/Invalid
2 (PU)	-	Valid
	0 (OP)	Valid
3 (USB)	2 (PU)	Invalid (all parameters
9999	2 (FU)	can be read)
(auto detect initial	9999 (auto detect initial value)	With OP: valid
value)		Without OP: invalid
value)		(all parameters can be
	,	read)

<sup>\*</sup> OP indicates a communication option.


• Pr. 15 Jog frequency, Pr. 16 Jog acceleration/deceleration time, and Pr. 991 PU contrast adjustment are displayed as simple mode parameter when the parameter unit (FR-PU04/FR-PU07) is fitted.

#### (2) User group function (Pr. 160, Pr. 172 to Pr. 174)

- •The user group function is designed to display only the parameters necessary for setting.
- •From among all parameters, 16 parameters maximum can be registered in the user group. When *Pr. 160* is set to "1", only the parameters registered to the user group can be accessed. (The parameters not registered in the user group can not be read.)
- •To set a parameter in the user group, set its parameter number in *Pr. 173*.
- •To delete a parameter from the user group, set its parameter number to *Pr. 174*. Set "9999" in *Pr. 172* to batch delete parameters registered.

#### (3) Registration of parameter to user group (Pr. 173)

When registering Pr. 3 to user group





#### (4) Deletion of parameter from user group (Pr. 174)

When deleting Pr. 3 from user group

#### Operation –

- 1. Confirm the operation display and operation mode display.
  - The inverter should be at a stop.
  - The inverter should be in the PU operation mode.


(Press  $\left(\frac{PU}{FXT}\right)$  in the external operation mode.)

- 2. Press (MODE) to choose the parameter setting mode.
- 3. Turn until P 174 appears.
- **4.** Press (SET) to display " **9399**"
- 5. Turn until Pr. 3 appears.
- 6. Press (SET) to set.

" P | T I I and " are displayed alternately. To continue parameter clear, repeat steps 3 to











Flicker...Clear of Pr. 3 to user group completed!!

# • REMARKS

- Pr. 77, Pr. 160 and Pr. 991 can always be read, independently of the user group setting.
- Pr. 77, Pr. 160 and Pr. 172 to Pr. 174 cannot be registered to the user group.
- When Pr. 174 is read, "9999" is always displayed. Although "9999" can be written, no function is available.
- When any value other than "9999" is set to Pr. 172, no function is available.



#### **Parameters referred to**

Pr. 550 NET mode operation command source selection Refer to page 191 Pr. 551 PU mode operation command source selection Refer to page 191

# 4.19 Selection of operation mode and operation location

Purpose	Parameter that should	Refer to Page	
Operation mode selection	Operation mode selection	Pr. 79	180
Started in network operation mode	Operation mode at power-on	Pr. 79, Pr. 340	190
	Operation command source and		
Salastian of anaratian lagation	speed command source during	Pr. 338, Pr. 339	101
Selection of operation location	communication operation, selection	Pr. 550, Pr. 551	191
	of operation location		

# 4.19.1 Operation mode selection (Pr. 79)

Used to select the operation mode of the inverter.

Mode can be changed as desired between operation using external command signals (external operation), operation from the operation panel and PU (FR-PU07/FR-PU04) (PU operation), combined operation of PU operation and external operation (external/PU combined operation), and network operation (when RS-485 communication or a communication option is used).


Dovemeter		luitial	Catting			LED Indication
Parameter Number	Name	Initial Value	Setting Range	Descr	:Off	
Number		value	Kange			□:On
			0	Use external/PU switchover mod PU and external operation mode At power on, the inverter is in the	External operation mode  EXT  PU operation mode  PU	
			1	Fixed to PU operation mode		PU
			2	Fixed to external operation mode Operation can be performed by and Net operation mode.		External operation mode  EXT  NET operation mode
				External/PU combined operation	mode 1	
				Frequency command	Start command	
	Operation		3	Operation panel and PU (FR-PU04/FR-PU07) setting or external signal input (multi-speed setting, across terminals 4-5 (valid when AU signal turns on)).	External signal input (terminal STF, STR)	
79	mode	0	4	External/PU combined operation	PU EXT	
	selection			Frequency command	Start command	
				External signal input (terminal 2, 4, JOG, multi-speed selection, etc.)	Enter from RUN of the operation panel and FWD and REV of the PU (FR-PU04/FR-PU07)	
			6	Switchover mode Switchover between PU operation, external operation, and NET operation is available while keeping the same operation status.		PU operation mode  External operation mode  EXT  NET operation mode
			7	External operation mode (PU operation Mode (PU operation Mode can be switch (output stop during external operation Mode can not be switch operation mode can not be switch (PU operation Mode can not be switch Mode (PU operation Mode (PU opera	PU operation mode  PU  External operation mode  EXT	

The above parameters can be changed during a stop in any operation mode.



#### (1) Operation mode basics


- The operation mode specifies the souce of the start command and the frequency command for the inverter.
- Select the "external operation mode" when the start command and the frequency command are applied from a potentiometer, switches, etc. which are provided externally and connecting them to the control terminals. Select "PU operation mode" when the commands are applied using the operation panel or parameter unit (FR-PU04/FR-PU07). Select the "network operation mode (NET operation mode)" when the commands are applied from the RS-485 communication with the PU connector or the network to the communication option card.
- The operation mode can be selected from the operation panel or with the communication instruction code.



# **REMARKS**

- Either "3" or "4" may be set to select the PU/external combined mode. Refer to page 180 for details.
- The stop function (PU stop selection) activated by pressing (STOP) of the operation panel and parameter unit (FR-PU04/FR-PU07) is valid even in other than the PU operation mode in the initial setting. (Refer to Pr. 75 Reset selection/disconnected PU detection/PU stop selection (page 173))

# (2) Operation mode switching method



# • REMARKS

• Refer to the flow chart on the next page for switching by the external terminal.

\*PU operation external interlock signal (X12) \*\* Refer to page 186

PU-external operation switch-over signal (X16) Refer to page 187


External-NET operation switchover signal (X65), NET-PU operation switchover signal (X66) Refer to page 188

Pr. 340 Communication startup mode selection \*\*Refer to page 190




#### (3) Operation mode selection flow

In the following flowchart, select the basic parameter setting and terminal connection related to the operation mode.



### (4) External operation mode (setting "0" (initial value), "2")




- •Select the extenal operation mode when the start command and the frequency command are applied from a frequency setting potentiometer, start switch, etc. which are provided externally and connecting them to the control circuit terminals of the inverter.
- •Basically, parameter changing is disabled in the external operation mode. (Some parameters can be changed. Refer to *page 52* for the parameter list.)
- When "0" or "2" is selected for *Pr. 79*, the inverter enters the external operation mode at power-on. (When using the network operation mode, refer to *page 190*.)
- When parameter changing is seldom necessary, setting
   "2" fixes the operation mode to the external operation mode.

When frequent parameter changing is necessary, setting "0" (initial value) allows the operation mode to be changed easily to the PU operation mode by pressing

(PU EXT) of the operation panel. When you switched to the PU operation mode, always return to the external operation mode.


 The STF and STR signal are used as a start command, and the voltage or current signal to terminal 2, 4, multispeed signal, JOG signal, etc. are used as a frequency command.


#### (5) PU operation mode (setting "1")



- •Select the PU operation mode when applying start and speed command by only the key operation of the operation panel (FR-PU04/FR-PU07). Also select the PU operation mode when making communication using the PU connector.
- •When "1" is selected for *Pr. 79*, the inverter enters the PU operation mode at power on. You cannot change to the other operation mode.
- •The setting dial of the operation panel can be used for setting like a potentiometer. (Refer to Pr. 161 Frequency setting/key lock operation selection (page 257))


### (6) PU/external combined operation mode 1 (setting "3")






- •Select the PU/external combined operation mode 1 when applying frequency command from the operation panel or parameter unit (FR-PU04/FR-PU07) and inputting the start command with the external start switch.
- •Select "3" for *Pr. 79*. You cannot change to the other operation mode.
- •When a frequency is applied from the external signal by multi-speed setting, it has a higher priority than the frequency command from the PU. When AU is on, the command signal to terminal 4 is used.

## (7) PU/external combined operation mode 2 (setting "4")





- •Select the PU/external combined operation mode 2 when applying frequency command from the external potentiometer, multi-speed or JOG signal and inputting the start command by key operation of the operation panel (FR-PU04/FR-PU07).
- •Select "4" for Pr: 79. You cannot change to the other operation mode.

# 7

#### (8) Switch-over mode (setting "6")

•While continuing operation, you can switch between the PU operation, external operation and network operation (when RS-485 communication with the PU connector or communication option is used).

Operation Mode Switching	Switching Operation/Operating Status
External operation → PU operation	Select the PU operation mode with the operation panel or parameter unit.  •Rotation direction is the same as that of external operation.  •The frequency set with the potentiometer (frequency command) or like is used unchanged. (Note that the setting will disappear when power is switched off or the inverter is reset.)
External operation → NET operation	Send the mode change command to the network operation mode through communication.  •Rotation direction is the same as that of external operation.  •The value set with the setting potentiometer (frequency command) or like is used unchanged. (Note that the setting will disappear when power is switched off or the inverter is reset.)
PU operation → external operation	Press the external operation key of the parameter unit.  •The rotation direction is determined by the input signal of the external operation.  •The set frequency is determined by the external frequency command signal.
PU operation → NET operation	Send the mode change command to the network operation mode through communication.  •Rotation direction and set frequency are the same as those of PU operation.
NET operation → external operation	Command to change to external mode is transmitted by communication.  •Rotation direction is determined by the external operation input signal.  •The set frequency is determined by the external frequency command signal.
NET operation → PU operation	Select the PU operation mode with the operation panel or parameter unit.  •The rotation direction and frequency command in the network operation mode are used unchanged.

#### (9) PU operation interlock (setting "7")

•The PU operation interlock function is designed to forcibly change the operation mode to the external operation mode when the PU operation interlock signal (X12) input turns off.

This function prevents the inverter from being inoperative by the external command if the mode is accidentally left unswitched from PU operation mode.

- •Set "7" (PU operation interlock) in Pr. 79.
- •For the terminal used for X12 signal (PU operation interlock signal) input, set "12" to any of *Pr. 178 to Pr. 184 (input terminal function selection)* to assign the function. (Refer to *page 128* for *Pr.178 to Pr.184*.)
- •When the X12 signal is not assigned, function of the MRS signal switches from MRS (output stop) to PU operation interlock signal.

X12 (MRS)	Function/Operation							
Signal	Operation mode	Parameter write						
	Operation mode (external, PU, NET) switching	Parameter write enabled (depending on Pr. 77Parameter						
ON	enabled	write selection and each parameter write conditions						
	Output stop during external operation	(Refer to page 52 for the parameter list))						
	Forcibly switched to external operation mode							
OFF	External operation allowed	Parameter write disabled with exception of <i>Pr. 79</i>						
OFF	Switching between the PU and Net operation mode	Parameter write disabled with exception of Pr. 79						
	is enabled							

# <Function/operation changed by switching on-off the X12 (MRS) signal>

Operating Condition			Operation		Switching to PU,
Operation	Status	X12 (MRS) Signal	Mode	Operating Status	
mode	Status		wode		Mode
	During	ON → OFF *1		If external operation frequency setting and	Disallowed
PU/NET	stop	ON 7 OFF *1	External *2	start signal are entered, operation is	Disallowed
	Running	ON → OFF *1		performed in that status.	Disallowed
	During	OFF → ON		During stop	Allowed
External	stop	ON → OFF	External *2	During stop	Disallowed
LAternal	Running	OFF → ON	External *2	During operation → output stop	Disallowed
	Ruilling	ON → OFF		Output stop → operation	Disallowed

<sup>\*</sup>I The operation mode switches to the external operation mode independently of whether the start signal (STF, STR) is on or off. Therefore, the motor is run in external operation mode when the X12 (MRS) signal is turned off with either of STF and STR on.

<sup>\*2</sup> At fault occurrence, pressing  $(\overline{\text{RESET}})$  of the operation panel resets the inverter.



- If the X12 (MRS) signal is on, the operation mode cannot be switched to the PU operation mode when the start signal
- When the MRS signal is used as the PU interlock signal, the MRS signal serves as the normal MRS function (output stop) by turning on the MRS signal and then changing the Pr. 79 value to other than "7" in the PU operation mode. As soon as "7" is set to Pr.79, the MRS signal acts as the PU interlock signal.
- When the MRS signal is used as the PU interlock signal, the logic of the signal is as set in Pr. 17. When Pr. 17 = "2", read ON as OFF and OFF as ON in the above explanation.
- Changing the terminal assignment using Pr. 178 to Pr. 184 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.

#### (10) Switching of operation mode by external signal (X16 signal)

- •When external operation and operation from the operation panel are used togheter, use of the PU-external operation switching signal (X16) allows switching betwen the PU operation mode and external operation mode during a stop (during a motor stop, start command off).
- •When Pr. 79 = any of "0, 6, 7", the operation mode can be switched between the PU operation mode and external operation mode. (Pr. 79 = "6" Switch-over mode can be changed during operation)
- •For the terminal used for X16 signal input, set "16" to any of Pr. 178 to Pr. 184 (input terminal function selection) to assign the function.

	Pr. 79	X16 Signal State	Operation Mode	Remarks		
	Setting	ON (external)	OFF (PU)	Kellidi k5		
0 (	initial value)	External operation mode	PU operation mode	Can be switched to external, PU or NET operation mode		
	1	PU opera	tion mode	Fixed to PU operation mode		
	2 External operation mode		eration mode	Fixed to external operation mode (can be switched to NET operation mode)		
	3, 4	External/PU combin	ned operation mode	External/PU combined mode fixed		
	6 Externa		PU operation mode	Switching among the external, PU, and NET operation mode is enabled while running.		
7	X12 (MRS) ON	External operation mode	PU operation mode	Can be switched to external, PU or NET operation mode (output stop in external operation mode)		
X12 (MRS) OFF		External operation mode		Fixed to external operation mode (forcibly switched to external operation mode)		



#### • REMARKS

- · The operation mode status changes depending on the setting of Pr. 340 Communication startup mode selection and the ON/OFF status of the X65 and X66 signals. (For details, refer to page 188)
- The priorities of Pr. 79, Pr. 340 and signals are Pr. 79 > X12 > X66 > X65 > X16 > Pr. 340.



#### **NOTE**

• Changing the terminal assignment using Pr. 178 to Pr. 184 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.

# 7/

#### (11) Switching of operation mode by external signals (X65, X66 signals)

- •When *Pr.* 79 = any of "0, 2, 6, 7", the operation mode switching signals (X65, X66) can be used to change the PU or external operation mode to the network operation mode during a stop (during a motor stop or start command off). (*Pr.* 79 = "6" Switch-over mode can be changed during operation)
- When switching between the network operation mode and PU operation mode
  - 1)Set *Pr.* 79 to "0" (initial value), "6" or "7".(At the *Pr.* 79 setting of "7", the operation mode can be switched when the X12 (MRS) signal turns on.)
  - 2)Set "10" in Pr. 340 Communication startup mode selection.
  - 3)Set "65" in any of Pr. 178 to Pr. 184 to assign the NET-PU operation switching signal (X65) to the terminal.
  - 4)The operation mode changes to the PU operation mode when the X65 signal turns on, or to the network operation mode when the X65 signal turns off.

Pr. 340		Pr. 79	X65 Sig	nal State	Remarks	
Setting	ng Setting		ON (PU) OFF (NET)		Remarks	
	0 (	(initial value)	PU operation mode *1	NET operation mode *2	Cannot be switched to external operation mode	
		1	PU opera	ation mode	Fixed to PU operation mode	
	2		NET oper	ation mode	Fixed to NET operation mode	
		3, 4	External/PU combi	ned operation mode	External/PU combined mode fixed	
10		6	PU operation mode *1	NET operation mode	Operation mode can be switched with operation continued	
		b	Po operation mode *1	*2	Cannot be switched to external operation mode	
	X12 (MRS)		PU operation mode *1	NET operation mode	Output stop in external operation mode	
	7	ON	Po operation mode *1	*2, *3	Output Stop in external operation mode	
	′	X12 (MRS)	External operation mode		Forcibly switched to external operation mode	
		OFF	External op	ciation mode	Profession switched to external operation mode	

- \*1 NET operation mode when the X66 signal is on.
- \*2 PU operation mode is selected when the X16 signal is off. PU operation mode also when *Pr. 550 NET mode operation command source selection=* "0" (communication option control source) and the communication option is not fitted.
- \*3 External operation mode when the X16 signal is on.
  - •When switching between the network operation mode and external operation mode
    - 1) Set *Pr.* 79 to "0 (initial value), 2, 6 or 7". (At the *Pr.* 79 setting of "7", the operation mode can be switched when the X12 (MRS) signal turns on.)
    - 2) Set "0 (initial value) or 1" in Pr. 340 Communication startup mode selection.
    - 3) Set "66" in any of Pr. 178 to Pr. 184 to assign the NET-PU operation switching signal (X66) to the terminal.
    - 4) The operation mode changes to the network operation mode when the X66 signal turns on, or to the external operation mode when the X66 signal turns off.

Pr. 340		Pr. 79	X66 Sigr	nal State	Remarks	
Setting	Setting		ON (NET)	OFF (external)	Remarks	
	0	(initial value)	NET operation mode *1	External operation mode *2		
		1	PU operat	tion mode	Fixed to PU operation mode	
	2		NET operation mode *1	External operation mode	Cannot be switched to PU operation mode	
0 (initial		3, 4	External/PU combin	ed operation mode	External/PU combined mode fixed	
value)		6	NET operation mode	External operation	Operation mode can be switched with	
		O	*1	mode *2	operation continued	
	7	X12 (MRS) ON	NET operation mode *1 External operation mode *2		Output stop in external operation mode	
	,	X12 (MRS) OFF	External ope	ration mode	Forcibly switched to external operation mode	

<sup>\*1</sup> PU operation mode is selected when Pr. 550 NET mode operation command source selection = "0" (communication option control source) and the communication option is not fitted.

<sup>\*2</sup> PU operation mode is selected when the X16 signal is off. When the X65 signal has been assigned, the operation mode changes with the ON/OFF state of the X65 signal.





# • REMARKS

• The priorities of Pr. 79, Pr. 340 and signals are Pr. 79 > X12 > X66 > X65 > X16 > Pr. 340.



#### **NOTE**

• Changing the terminal assignment using Pr. 178 to Pr. 184 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.



#### Parameters referred to

Pr. 15 Jog frequency Refer to page 94

Pr. 4 to 6, Pr. 24 to 27, Pr. 232 to Pr. 239 Multi-speed operation Refer to page 92

Pr. 75 Reset selection/disconnected PU detection/PU stop selection Refer to page 173

Pr. 161 Frequency setting/key lock operation selection Refer to page 257

Pr. 178 to Pr. 184 (input terminal function selection) 👺 Refer to page 128

Pr. 190 to Pr. 192 (output terminal function selection) 👺 Refer to page 134

Pr. 340 Communication startup mode selection Refer to page 190

Pr. 550 NET mode operation command source selection Refer to page 191

# 4.19.2 Operation mode at power-on (Pr. 79, Pr. 340)

When power is switched on or when power comes back on after instantaneous power failure, the inverter can be started up in the network operation mode.

After the inverter has started up in the network operation mode, parameter write and operation can be performed from a program.

Set this mode for communication operation using PU connector or communication option.

Parameter Number	Name	Initial Value	Setting Range	Description
79	Operation mode selection	0	0 to 4, 6, 7	Operation mode selection
7.5	Operation mode selection		0 10 4, 0, 7	(Refer to page 183)
	Communication startup mode selection		0	As set in <i>Pr. 79</i> .
		0	1	Network operation mode
340 *			40	Network operation mode
340 *				Operation mode can be changed between
			10	the PU operation mode and network
				operation mode from the operation panel.

The above parameters can be changed during a stop in any operation mode.

#### (1) Specify operation mode at power-on (Pr. 340)

•Depending on the Pr. 79 and Pr. 340 settings, the operation mode at power-on (reset) changes as described below.

Pr. 340 Setting	Pr. 79 Setting	Operation Mode at Power-on, Power Restoration, Reset	Operation Mode Switching		
	0 (initial value)	External operation mode	Switching among the external, PU and Net operation mode is enabled *1		
	1	PU operation mode	Fixed to PU operation mode		
0	2	External operation mode	Switching between the external and NET operation mode is enabled Switching to PU operation mode disabled		
(initial	3, 4	External/PU combined mode	Operation mode switching disabled		
value)	6	External operation mode	Switching among the external, PU, and NET operation mode is enabled while running.		
	7	X12 (MRS) signal ONExternal operation mode	Switching among the external, PU and Net operation mode is enabled *1		
	/	X12 (MRS) signal offExternal operation mode	Fixed to external operation mode (Forcibly switched to external operation mode.)		
	0	NET operation mode			
	1	PU operation mode			
	2	NET operation mode			
	3, 4	External/PU combined mode			
1	6	NET operation mode	Same as when <i>Pr. 340</i> = "0"		
	7	X12 (MRS) signal ON NET operation mode  X12(MRS) signal off External operation mode			
	0	NET operation mode	Switching between the PU and Net operation mode is enabled *2		
	1	PU operation mode	Same as when <i>Pr. 340</i> = "0"		
	2	NET operation mode	Fixed to NET operation mode		
10	3, 4	External/PU combined mode	Same as when <i>Pr. 340</i> = "0"		
	6	NET operation mode	Switching between the PU and NET operation mode is enabled while running *2		
	7	External operation mode	Same as when <i>Pr. 340</i> = "0"		

<sup>\*1</sup> Operation mode can not be directly changed between the PU operation mode and network operation mode

<sup>\*2</sup> Operation mode can be changed between the PU operation mode and network operation mode with  $\frac{PU}{EXT}$  key of the operation panel and X65 signal.



## **Parameters referred to**

Pr. 79 Operation mode selection 👺 Refer to page 180

<sup>\*</sup> The above parameters can be set when *Pr. 160 User group read selection* = "0". However, the parameters can be set whenever the communication option is connected. (*Refer to page 177*)



# 4.19.3 Start command source and frequency command source during communication operation (Pr. 338, Pr. 339, Pr. 550, Pr. 551)

When the RS-485 communication with the PU connector or communication option is used, the external start command and frequency command can be made valid. Command source in the PU operation mode can be selected. From the communication device, parameter unit, etc. which have command source, parameter write or start command can be executed. Parameter read or monitoring can be executed in any operation mode.

Parameter	Maria	Initial	Setting	December 201	
Number	Name	Value	Range	Description	
220	Communication operation		0	Start command source communication	
338	command source	0	1	Start command source external	
			0	Frequency command source communication	
				Frequency command source external (Frequency command from	
339	Communication speed	0	1	communication is invalid, frequency command from terminal 2 is valid)	
	command source			Frequency command source external (Frequency command from	
			2	communication is valid, frequency command from terminal 2 is invalid)	
	NET mode operation	9999	0	The communication option is the command source when NET operation mode.	
			2	PU connector is the command source when NET operation mode.	
550 <b>*</b>	command source			Automatic communication option recognition	
	selection		9999	Normally, PU connector is the command source. When a	
				communication option is mounted, the communication option is the	
				command source.	
			2	PU connector is the command source when PU operation mode.	
			3	USB connector is the command source when PU operation mode.	
	PU mode operation		4	Operation panel is the command source when PU operation mode.	
551 *	command source	9999		USB automatic recognition	
	selection	0000		Normally, operation panel is the command source. When the	
			9999	parameter unit is connected to the PU connector, PU is the	
				command source. When USB is connected, USB connector is the	
	remeters can be get when B. 160 H.		"0"	command source.	

The above parameters can be set when *Pr. 160 User group read selection* = "0". However, the parameters can be set whenever the communication option is connected. (*Refer to page 177*)

#### (1) Select the command source of the network operation mode (Pr. 550)

- •Either the RS-485 communication with the PU connector or communication option can be specified as the command source in the network operation mode.
- •For example, set *Pr. 550* to "2" when executing parameter write, start command or frequency command from the unit RS-485 terminals in the network operation mode independently of whether the communication option is connected or not.



#### NOTE

• Since *Pr.* 550 = "9999" (automatic communication option recognition) in the initial setting, parameter write, start command and frequency command cannot be executed by communication using the unit RS-485 terminals when the communication option is fitted.

<sup>\*</sup> Pr. 550 and Pr. 551 are always write-enabled.

# 7/

#### (2) Selects the command source of the PU operation mode (Pr. 551)

- •Any of the operation panel, PU connector, or USB connector can be specified as the command source in the PU operation mode.
- •In the PU operation mode, set *Pr. 551* to "2" when executing parameter write, start command or frequency command during the RS-485 communication with PU communication.



#### **NOTE**

- When performing the RS-485 communication with the PU connector when *Pr.* 551 = "9999", PU mode command source does not automatically change to the PU connector. Change to the network operation mode to change the command source.
- When "2" (NET mode PU connector) is set in *Pr. 550* and "2" (PU mode PU connector) is set in *Pr. 551*, PU operation mode has priority. When the communication option is not fitted, therefore, the operation mode cannot be switched to the network operation mode.
- Changed setting value is made valid when powering on or resetting the inverter.
- The Modbus-RTU protocol cannot be used in the PU operation mode. Select network operation mode (NET mode command source).

PU...PU operation mode, NET...network operation mode, —....without command source

Pr. 550	Pr. 551	Operation	USB	PU co	nnector	Communication	Damania.
Setting	Setting	Operation panel	connector	Parameter unit	RS-485 communication	option	Remarks
	2		_	PU	PU *1	NET *2	
	3		PU	_	_	NET *2	
0	4	PU	_	_	_	NET *2	
	9999 (initial value)	PU *3	PU *3	PU *3	PU *1	NET *2	
	2	_	_	PU	PU *1	_	Switching to NET operation mode disabled
	3	_	PU	_	NET	_	
2	4	PU	_	_	NET	_	
	9999 (initial value)	PU *3	PU *3	PU *3	NET	NET	
	2	_	_	PU	PU *1	NET *2	
	3	_	PU	_	_	NET *2	Communication option fitted
				_	NET	_	Communication option not fitted
9999 (initial	4	PU	_	_	_	NET *2	Communication option fitted
value)	4	PU		_	NET	_	Communication option not fitted
	9999 (initial	9999 (initial PU *3 value)	DII *3	PU *3	_	NET *2	Communication option fitted
	,		PU *3	_	NET	_	Communication option not fitted

<sup>\*1</sup> The Modbus-RTU protocol cannot be used in the PU operation mode. When using the Modbus-RTU protocol, set Pr. 550 to "2".

<sup>\*2</sup> When the communication option is not fitted, the operation mode cannot be switched to the network operation mode.

<sup>\*3</sup> When Pr. 551 = "9999", the priorities of the PU control source is USB connector > parameter unit (FR-PU04/FR-PU07) > operation panel.



# (3) Controllability through communication

- •Controllability through communcation in each operation mode is shown below.
- •Monitoring and parameter read can be performed from any operation regardless of operation mode.

Control by RS-485   Control by RS-485   Control by RS-485   Run command (start)   O	Operation Location	Condition (Pr. 551 Setting)	Operation Mode Item	PU Operation	External Operation	External/PU Combined Operation Mode 1 (Pr. 79 = 3)	External/PU Combined Operation Mode 2 (Pr. 79 = 4)	NET Operation (when using PU connector) *6	NET Operation (when using communication option) *7
Control by RS-485   Communication from PU connector PU			Run command (start)	0	×	×	0		×
Control by RS-485   Communication from the labove   Control by RS-485   Communication from the labove   Control by communication from communicat				0	Δ *3	$\Delta*3$	0		\ *3
Inverter reset	Control by		•	0	×	0	×		×
Control by communication from be above   Control by communication from the above   Control by communication from the above   Control by communication option   Control circuit external   Control circuit extern	RS-485		Parameter write	O*4	× *5	O*4	O *4	>	< *5
PU   Connector   Other than the above   Run command (stop)   x   x   x   x   x   x   x   x   x	communica		Inverter reset	0	0	0	0		0
Connector         Other than the above         Running frequency setting         x         x         x         x         x*5	tion from		Run command (start)	×	×	×	×	O *1	×
Above	PU		Run command (stop)	×	×	×	×	O *1	×
Inverter reset	connector			×	×	×	×	O *1	×
A			Parameter write	× *5	× *5	× *5	× *5	O *4	×*5
Control by communication from tom communication option   Control by communication option   Co			Inverter reset	×	×	×	×	O *2	×
Operation from the cognition   Operation from the usb		_		0	×	×	0		×
Parameter write   C **4		9999		0	×	0	×		×
Control by communication from communication option   Control by communication option   Control circuit external   Control circuit external   Control communication from communication from communication from circuit external   Control circuit external   Control communication from communication from circuit external   Control circuit external	Operation	· '	Parameter write	O *4	× *5	× *5	× *5	>	< <b>*</b> 5
Connector         Other than the above         (start, stop)         X	from the		Inverter reset	0	0	0	0		0
Above   Setting   X				×	×	×	×		×
Inverter reset			0 ,	×	×	×	×		×
Run command (start, stop)			Parameter write	× *5	×*5	× *5	× *5	>	< *5
Control by communication from communication option			Inverter reset	0	0	0	0		0
tion from communica tion option         —         Running frequency setting         ×         ×         ×         ×         ×         ×         0 *1           Parameter write tion option         1         ×         ×         ×         ×         ×         ×         ×         ×         ×         ×         ×         ×         0 *2         × <td< td=""><td>,</td><td></td><td></td><td>×</td><td>х</td><td>×</td><td>×</td><td>×</td><td>O *1</td></td<>	,			×	х	×	×	×	O *1
tion option   Parameter write   x*3   x*3   x*3   x*3   x*3   x*3   0*4	tion from	_		×	×	×	×	×	O *1
Control   Inverter reset			Parameter write	× *5	× *5	× *5	× *5	× *5	O *4
circuit external  Run command (start, stop)  Run command × O × **1	tion option		Inverter reset	×	×	×	×	×	O *2
external (start, stop) × O O × ×*1	Control		Inverter reset	0	0	0	0		0
terminals Frequency setting × O × O ×*1		_		×	0	0	×	×*1	
	terminals		Frequency setting	×	0	×	0	>	< *1

O: Enabled,  $\times$ : Disabled,  $\Delta$ : Some are enabled

- \*1 As set in Pr.338 Communication operation command source and Pr. 339 Communication speed command source (Refer to page 191)
- \*2 At occurrence of RS-485 communication error, the inverter cannot be reset from the computer.
- \*3 Enabled only when stopped by the PU. At a PU stop, PS is displayed on the operation panel. As set in Pr. 75 PU stop selection. (Refer to page 173)
- \*4 Some parameters may be write-disabled according to the Pr. 77 Parameter write selection setting and operating status. (Refer to page 176)
- \*5 Some parameters are write-enabled independently of the operation mode and command source presence/absence. When *Pr.* 77 = 2, write is enabled. (Refer to the parameter list on *page 52*) Parameter clear is disabled.
  - When Pr. 550 NET mode operation command source selection = "2" (PU connector valid) or Pr. 550 NET mode operation command source selection = "9999" and the communication option is not fitted.
- When Pr. 550 NET mode operation command source selection= "0" (communication option valid) or Pr. 550 NET mode operation command source selection= "9999" and the communication option is fitted.

# 7

# (4) Operation at error occurrence

Error Definition	Operation Mode Condition (Pr. 551 setting)		External Operation	External/PU Combined Operation Mode 1 (Pr. 79 = 3)	External/PU Combined Operation Mode 2 (Pr. 79 = 4)	NET Operation (when used with PU connector) *5	NET Operation (when used with communication option) *6	
Inverter fault	_	Stop						
PU disconnection of	2 (PU connector) 9999 (automatic recognition)	Stop/continued *	1, *4					
the PU	Other than the above	Stop/continued*1	Stop/continued*1					
RS-485 communication	2 (PU connector)	Stop/ continued*2	Continued		Stop/ continued*2	_	Continued	
error of the PU connector	Other than the above	Continued				Stop/ continued*3	Continued	
Communication error of USB	3 (USB connector) 9999 (automatic recognition)	Stop/ continued*2	Continued		Stop/ continued*2	Continued		
connector	Other than the above	Continued						
Communication error of communication option	_	Continued				Stop/ continued*3	Continued	

<sup>\*1</sup> Can be selected using Pr. 75 Reset selection/disconnected PU detection/PU stop selection.

<sup>\*2</sup> Can be selected using Pr. 122 PU communication check time interval, Pr. 336 RS-485 communication check time interval, Pr. 548 USB communication check time interval.

<sup>\*3</sup> As controlled by the communication option.

<sup>\*4</sup> In the PU JOG operation mode, operation is always stopped when the PU is disconnected. Whether fault (E.PUE) occurrence is allowed or not is as set in Pr. 75 Reset selection/disconnected PU detection/PU stop selection.

<sup>\*5</sup> When Pr. 550 NET mode operation command source selection = "2" (PU connector valid) or Pr. 550 NET mode operation command source selection = "9999" and the communication option is not fitted.

<sup>\*6</sup> When Pr. 550 NET mode operation command source selection = "0" (communication option valid) or Pr. 550 NET mode operation command source selection = "9999" and the communication option is fitted.



# (5) Selection of control source in network operation mode (Pr. 338, Pr. 339)

- •As control sources, there are the operation command source that controls the signals related to the inverter start command and function selection and the speed command source that controls the signals related to frequency setting.
- •In network operation mode, the commands from the external terminals and communication (PU connector or communication option) are as listed below.

-	perat		Pr. 3	338 Communication operation command source		0: NET			1: Externa	al	Domesko
	Location - Selection		Pr. 339 Communication speed command source		0: NET	1: External	2: External	0: NET	1: External	2: External	Remarks
Fix	ed		Runn	ing frequency from	NET		NICT	NET		NICT	
fun	ctio	n	comn	nunication	NET	_	NET	NET		NET	
(ter	min	al-	Termi	nal 2	_	External			External	_	
	ıival ctio		Termi	nal 4	_	Exte	ernal	_	Exte	ernal	
		0	RL	Low speed operation command/remote setting clear/stop-on contact selection 0	NET	Exte	ernal	NET	Exte	ernal	Pr. 59 = "0" (multi-speed)
		1	RM	Middle speed operation command/remote setting function	NET	Exte	ernal	NET	Exte	ernal	Pr. 59 = "1, 2" (remote) Pr. 270 = "1"
		2	RH	High speed operation command/remote setting function	NET	Exte	ernal	NET	Exte	ernal	(stop-on-contact)
		3	RT	Second function selection/ stop-on contact selection 1		NET			External		Pr. 270 = "1" (stop-on-contact)
		4	ΑU	Current input selection	_	Com	bined			bined	
		5		Jog operation selection					External		
		7	ОН	External thermal relay input			Exte	ernal	1		"0"
	6	8	REX	Fifteen speed selection	NET	Exte	ernal	NET	Exte	ernal	Pr. 59 = "0" (multi-speed)
tion	ettin	10	X10	Inverter operation enable signal			Exte	ernal			
func	<i>184</i> s	12	X12	PU operation external interlock			Exte	ernal			
<u>×</u>	Pr.	14	X14	PID control valid terminal	NET	Exte	ernal	NET	Exte	ernal	
Selective function	Pr. 178 to Pr. 184 setting	15	BRI	Brake opening completion signal		NET			External		
S	Pr. 1	16	X16	PU-external operation switchover			Exte	ernal			
		18	X18	V/F switching		NET			External		
				Output stop		Combined			External		Pr. 79 ≠ " <b>7</b> "
		24	MRS	PU operation interlock	External			Pr. 79 = "7" When the X12 signal is not assigned			
		25		Start self-holding selection	_			External			
		60		Forward rotation command	NET			External			
		61		Reverse rotation command	NET			External			
		62	RES	Reset	External						
		65	X65	PU/NET operation switchover	External						
		66	X66	NET-external operation switching	External						
		67	X67	Command source switchover		_	Exte	ernal	_		
ĪΕχ	nlaı	natio	ation of table]								

## [Explanation of table]

External : Command is valid only from control terminal.

NET : Command only from communication is valid

Combined: Command from both control terminal and communication is valid.

Command from either of control terminal and communication is invalid.

# • REMARKS

- The command source of communication is as set in Pr. 550 and Pr. 551.
- The *Pr. 338* and *Pr. 339* settings can be changed while the inverter is running when *Pr. 77* = "2". Note that the setting change is reflected after the inverter has stopped. Until the inverter has stopped, communication operation command source and communication speed command source before the setting change are valid.



# Switching of command source by external terminal (X67)

- •In the network operation mode, the command source switching signal (X67) can be used to switch the start command source and speed command source.
- Set "67" to any of Pr. 178 to Pr. 184 (input terminal function selection) to assign the X67 signal to the control terminal.
- •When the X67 signal is off, the start command source and speed command source are control terminal.

X67 Signal State	Start Command Source	Speed Command Source		
No signal assignment	According to Pr. 338	According to Pr. 339		
ON				
OFF	Command is valid only from control terminal.			



# • REMARKS

- The ON/OFF state of the X67 signal is reflected only during a stop. It is reflected after a stop when the terminal is switched while the inverter is running.
- When the X67 signal is off, a reset via communication is disabled.



• Changing the terminal assignment using Pr. 178 to Pr. 184 (input terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.



#### Parameters referred to

Pr. 59 Remote function selection Refer to page 96
Pr. 79 Operation mode selection Refer to page 180
Pr. 270 Stop-on contact control selection Refer to page 122



# 4.20 Communication operation and setting


Purpose	Parameter that s	Parameter that should be Set		
Communication operation from PU	Initial setting of computer link communication (PU connector)	Pr. 117 to Pr. 124	200	
connector	Modbus-RTU communication specifications	Pr. 117, Pr. 118, Pr. 120, Pr. 122, Pr. 343, Pr. 502, Pr. 549	217	
Restrictions on parameter write through communication	Communication EEPROM write selection	Pr. 342	204	
Communication using USB (FR Configurator)	USB communication	Pr. 547, Pr. 548	230	

# 4.20.1 Wiring and configuration of PU connector

Using the PU connector, you can perform communication operation from a personal computer etc.

When the PU connector is connected with a personal, FA or other computer by a communication cable, a user program can run and monitor the inverter or read and write to parameters.

#### (1) PU connector pin-outs



Pin Number	Name	Description
1)	SG	Earth (ground)
''	30	(connected to terminal 5)
2)	_	Parameter unit power supply
3)	RDA	Inverter receive+
4)	SDB	Inverter send-
5)	SDA	Inverter send+
6)	RDB	Inverter receive-
7)	SG	Earth (ground)
, , , , , , , , , , , , , , , , , , ,	36	(connected to terminal 5)
8)		Parameter unit power supply


# •

#### **NOTE**

- Pins No. 2 and 8 provide power to the operation panel or parameter unit. Do not use these pins for RS-485 communication.
- When making RS-485 communication between the FR-E700 series, FR-E500 series and FR-S500 series, Incorrect connection of pins No.2 and No.8 (parameter unit power supply) of the above PU connector may result in the inverter malfunction or failure.


When multiple inverters are connected using pins No.2 and No.8, power is provided from the inverter which is powered on to the inverters which are powered off in case inverters which are powered on and off are mixed. In such a case, a protective circuit of the inverter, which is on, functions to stop communication.

When connecting multiple inverters for RS-485



communication, make sure to disconnect cables from No.2 and No.8 so that pins No.2 and No.8 are not connected


When using the RS-485 converter which receives power from the inverter, make sure that power is provided from one inverter only. (*Refer to the figure below.*)




Do not connect the PU connector to the computer's LAN board, FAX modem socket or telephone modular connector.
 The product could be damaged due to differences in electrical specifications.

# (2) PU connector communication system configuration

Connection of a computer to the inverter (1:1 connection)



#### Combination of computer and multiple inverters (1:n connection)



# REMARKS

Computer-inverter connection cable

Refer to the following for the cable (RS-232C ↔ RS-485 converter) for connection of the computer having the RS-232C interface with the inverter. Examples of product available on the market (as of September, 2006)

Туре	Maker		
FA-T-RS40 series *1	Mitsubishi Electric Engineering Co., Ltd.		

- \*1 The converter cable cannot connect two or more inverters (the computer and inverter are connected on a 1:1 basis). Since the product is packed with the RS-232C cable and RS-485 cable (10BASE-T cable + RJ-45 connector), the cable and connector need not be prepared separately. Contact a maker for details of the product.
- Refer to the following when fabricating the cable on the user side.
   Examples of product available on the market (as of September, 2006)


	<u> </u>	\ \	,
	Product	Туре	Maker
1)	10BASE-T cable	SGLPEV-T 0.5mm × 4P *2	Mitsubishi Cable Industries, Ltd.

<sup>\*2</sup> Do not use pins No. 2, 8 of the 10BASE-T cable. (Refer to page 197)




#### (3) Connection with RS-485 computer

#### Wiring of one RS-485 computer and one inverter



#### Wiring of one RS-485 computer and "n" (multiple) inverters




- Make connection in accordance with the instruction manual of the computer to be used with. Fully check the terminal numbers of the computer since they vary with the model.
- The inverters may be affected by reflection depending on the transmission speed or transmission distance. If this reflection hinders communication, provide a terminating resistor. If the PU connector is used to make a connection, use a distributor since a terminating resistor cannot be fitted. Connect the terminating resistor to only the inverter remotest from the computer. (Terminating resistor:  $100\Omega$ )



- Do not use pins No. 2, 8 of the 10BASE-T cable. (Refer to page 197)
- When making RS-485 communication between the FR-E700 series, FR-E500 series and FR-S500 series, incorrect connection of pins No.2 and 8 (parameter unit power supply) of the above PU connector may result in the inverter malfunction or failure. (Refer to page 197)

#### (4) Two-wire type connection

If the computer is 2-wire type, a connection from the inverter can be changed to 2-wire type by passing wires across reception terminals and transmission terminals of the PU connector pin.



# • REMARKS

- A program should be created so that transmission is disabled (receiving state) when the computer is not sending and reception is disabled (sending state) during sending to prevent the computer from receiving its own data.
- The passed wiring length should be as short as possible.

# 4.20.2 Initial settings and specifications of RS-485 communication (Pr. 117 to Pr. 120, Pr. 123, Pr. 124, Pr. 549)

Used to perform required settings for RS-485 communication between the inverter and personal computer.

- Use PU connector of the inverter for communication.
- You can perform parameter setting, monitoring, etc. using Mitsubishi inverter protocol or Modbus-RTU protocol.
- To make communication between the personal computer and inverter, initialization of the communication specifications must be made to the inverter.

Data communication cannot be made if the initial settings are not made or there is any setting error.

Parameter Number	Name	Initial Value	Setting Range	Desc	cription	
117	PU communication station number	0	0 to 31 (0 to 247) *1	Inverter station number specification Set the inverter station numbers when two or more		
118	PU communication speed	192	48, 96, 192, 384	inverters are connected to one personal computer.  Communication speed The setting value X 100 equals the communication speed.  Example)19200bps if 192		
	PU communication stop		0	Stop bit length 1bit	Data length  8bit	
119	bit length	1	1 10 11	2bit 1bit 2bit	7bit	
120	PU communication parity check	2	0 1 2	Without parity check With odd parity check With even parity check		
123	PU communication waiting time setting	9999	0 to 150ms	Set the waiting time between data transmission to the inverter and response.  Set with communication data.		
124	PU communication CR/LF selection	1	0 1 2	Without CR/LF With CR With CR/LF		
549	Protocol selection	0	0 1	Mitsubishi inverter (comp Modbus-RTU protocol	outer link operation) protocol	

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

<sup>\*1</sup> When "1" (Modbus-RTU protocol) is set in Pr. 549, the setting range within parenthesis is applied.



#### NOTE

 Always reset the inverter after making the initial settings of the parameters. After you have changed the communication-related parameters, communication cannot be made until the inverter is reset.



## 4.20.3 Operation selection at communication error occurrence (Pr. 121, Pr. 122, Pr. 502)

You can select the inverter operation when a communication line error occurs during RS-485 communication from the PU connector.


Parameter	Name	Initial	Setting	Description					
Number	- Name	Value	Range						
121	Number of PU communication retries  Number of retries at data receive error occurs, the inverter (computer line)  Number of retries at data receive error occurs, the inverter occurs, the inverted occurs of the permission occurs of the permission occurs occurs, the inverted occurs occurs occurs, the inverted occurs o					permissible value, . nputer link operat	e value, the inverter will coperation) protocol		
							switched to the		
122	PU communication check time interval	0	0.1 to 999.8s	Communication check (signal loss detection) time interval If a no-communication state persists for longer than the permistime, the inverter will come to trip (depends on <i>Pr. 502</i> ).					
			9999	No communicat	No communication check (signal loss detection)				
				At fault occurrence	Indication	Fault output	At fault removal		
	Stop mode selection		0, 3	Coasts to stop	E.PUE	Output	Stop (E.PUE)		
502	at communication error	0	1	Decelerates to stop	After stop E.PUE	Output after stop	Stop (E.PUE)		
			2	Decelerates to stop	After stop E.PUE	Without output	Automatic restart functions		

The above parameters can be set when *Pr. 160 User group read selection* = "0". However, it can be set any time when the communication option is connected. (*Refer to page 177*)


### (1) Retry count setting (Pr.121)

- •Set the permissible number of retries at data receive error occurrence. (Refer to page 209 for data receive error for retry)
- •When data receive errors occur consecutively and exceed the permissible number of retries set, an inverter trips (E.PUE) and a motor stops (as set in *Pr. 502*).
- •When "9999" is set, an inverter fault is not provided even if data receive error occurs but an alarm signal (LF) is output. For the terminal used for the LF signal output, assign the function by setting "98 (positive logic) or 198 (negative logic)" in any of *Pr. 190 to Pr. 192 (output terminal function selection)*.

#### Example: PU connector communication, Pr. 121 = "1" (initial value)



## Example: PU connector communication, *Pr. 121* = "9999"




# • REMARKS

 Pr. 121 is valid only when Mitsubishi inverter (computer link operation) protocol is selected. Pr. 121 is not valid when Modbus-RTU communication protocol is selected.

### (2) Signal loss detection (Pr.122)

- •If a signal loss (communication stop) is detected between the inverter and master as a result of a signal loss detection, a communication fault (E.PUE) occurs and the inverter trips. (as set in *Pr. 502*).
- •When the setting is "9999", communication check (signal loss detection) is not made.
- •When the setting value is "0" (initial value), RS-485 communication can be made. However, a communication fault (E.PUE) occurrs as soon as the inverter is switched to the operation mode (network operation mode in the initial setting) with the control.
- •A signal loss detection is made when the setting is any of "0.1s to 999.8s". To make a signal loss detection, it is necessary to send data (refer to Mitsubishi inverter protool control code (page 208), Modbus-RTU comunciation protocol (page 218)) from the computer within the communication check time interval. (The inverter makes communication check (clearing of communication check counter) regardless of the station number setting of the data sent from the master).
- •Communication check is made from the first communication in the operation mode with control source valid (network operation mode in the initial setting).

Example: PU connector communication, Pr. 122 = "0.1 to 999.8s"



# **CAUTION**

Always set the communication check time interval before starting operation to prevent hazardous conditions. Data communication is not started automatically but is made only once when the computer provides a communication request. If communication is disabled during operation due to signal cable breakage etc., the inverter cannot be stopped. When the communication check time interval has elapsed, the inverter trips (E.PUE).

The inverter can be coasted to a stop by turning on its RES signal or by switching power off.

If communication is broken due to signal cable breakage, computer fault, etc. the inverter does not detect such a fault. This should be fully noted.



# (3) Stop operation selection at occurrence of communication fault (Pr. 502)

•Stop operation when retry count excess (Mitsubishi inverter protocol only) or signal loss detection error occurs can be selected.


Operation at fault occurrence


Pr. 502 Setting	Operation	Indication	Fault Output				
0 (initial value)	Coasts to stop.	E. PUE lit	Provided				
1	Decelerates to stop	E. PUE lit after stop	Provided after stop				
2	Decelerates to stop	L. FOL III alter stop	Not provided				
3	Same as the setting "0"						


#### Operation at fault removal

Pr.502 Setting	Operation	Indication	Fault Output			
0 (initial value)	Kept stopped	E. PUE	Kept provided			
1	Кері зіоррец	L.1 0L	Rept provided			
2	Automatic restart functions	Normal display	Not provided			
3	Same as the setting "0"					


#### ● Pr. 502 setting "0 (initial value), 3"







● Pr. 502 setting "2"



# • REMARKS

- The fault output indicates fault output signal (ALM signal) or alarm bit output.
  - When the setting was made to provide a fault output, the fault description is stored into the faults history. (The fault description is written to the faults history when a fault output is provided.)

When no fault output is provided, the fault definition overwrites the fault indication of the faults history temporarily, but is not stored.

After the fault is removed, the fault indication returns to the ordinary monitor, and the faults history returns to the preceding fault indication

- When the *Pr.* 502 setting is "1 or 2", the deceleration time is the ordinary deceleration time setting (e.g. *Pr.* 8, *Pr.* 44, *Pr.* 45). In addition, acceleration time for restart is the normal acceleration time (e.g. *Pr.* 7, *Pr.* 44).
- When "2" is set in Pr. 502, run command/speed command at restarting follows the command before an fault occurrence.
- When "2" is set in Pr. 502 at occurrence of a communication error and the error is removed during deceleration, the inverter accelerates again at that point.



#### Parameters referred to

Pr. 7 Acceleration time, Pr. 8 Deceleration time Refer to page 99
Pr. 190 to Pr. 192 (output terminal function selection) Refer to page 134

# 4.20.4 Communication EEPROM write selection (Pr. 342)

When parameter write is performed from the inverter PU connector, USB communication, and communication option, parameters storage device can be changed from EEPROM + RAM to RAM only. Set when a frequent parameter change is necessary.

Parameter Number	Name	Initial Value	Setting Range	Description
342	Communication EEPROM	0	0	Parameter values written by communication are written to the EEPROM and RAM.
342	write selection	U	1	Parameter values written by communication are written to RAM.

The above parameters can be set when Pr. 160 User group read selection = "0". However, it can be set any time when the communication option is connected. (Refer to page 177)

• When changing the parameter values frequently, set "1" in Pr. 342 to write them to the RAM only. The life of the EEPROM will be shorter if parameter write is performed frequently with the setting unchanged from "0 (initial value)" (EEPROM write).



# • REMARKS

• When "1" (write to RAM only) is set in Pr. 342, powering off the inverter will erase the changed parameter values. Therefore, the parameter values available when power is switched on again are the values stored in EEPROM previously.



# 4.20.5 Mitsubishi inverter protocol (computer link communication)


You can perform parameter setting, monitor, etc. from the PU connector of the inverter using the Mitsubishi inverter protocol (computer link communication).

#### (1) Communication

•The communication specifications are given below.

Item		Description	Related
	em	Description	Parameter
Communication	orotocol	Mitsubishi protocol (computer link)	Pr. 549
Conforming stan	dard	EIA-485 (RS-485)	_
Number of conne	ctable devices	1:N (maximum 32 units), setting is 0 to 31 stations	Pr. 117
Communication speed PU connector		Selected from among 4800/9600/19200 and 38400bps	Pr. 118
Control procedur	е	Asynchronous	_
Communication r	nethod	Half-duplex	_
	Character system	ASCII (7 bits or 8 bits can be selected)	Pr. 119
	Start bit	1bit	_
Communication	Stop bit length	1 bit or 2 bits can be selected	Pr. 119
Communication	Parity check	Check (even, odd) or no check can be selected	Pr. 120
	Error check	Sum code check	_
	Terminator	CR/LF (presence/absence selectable)	Pr. 124
Waiting time setting		Selectable between presence and absence	Pr. 123

#### (2) Communication procedure



- Data communication between the computer and inverter is made in the following procedure.
  - Request data is sent from the computer to the inverter. (The inverter will not send data unless requested.)
  - 2) After waiting for the waiting time
  - The inverter sends return data to the computer in response to the computer request.
  - After waiting for the inverter data processing time
  - Answer from the computer in response to reply data 3) of the inverter is transmitted. (Even if 5) is not sent, subsequent communication is made properly.)
- If a data error is detected and a retry must be made, execute retry operation with the user program. The inverter comes to trip if the number of consecutive retries exceeds the parameter setting.
- \*2 On receipt of a data error occurrence, the inverter returns retry data 3) to the computer again. The inverter comes to trip if the number of consecutive data errors reaches or exceeds the parameter setting.

# (3) Communication operation presence/absence and data format types

- •Data communication between the computer and inverter is made in ASCII code (hexadecimal code).
- •Communication operation presence/absence and data format types are as follows:

No.	Operati	on	Run	Operation	Parameter	Inverter	Monitor	Parameter
NO.	Operati	operation -			Write	Reset	Wichitto	Read
1)	Communication request is accordance with the us computer.		A'	A, A" *3	A, A" *3	А	В	В
2)	Inverter data processing tir	me	Present	Present	Present	Absent	Present	Present
3)	Reply data from the inverter (Data 1) is	No error *1 (Request accepted)	С	С	С	C *2	E, E', E" *3	E, E" *3
	checked for error)	With error. (Request rejected)	D	D	D	D *2	D	D
4)	Computer processing dela	y time	Absent	Absent	Absent	Absent	Absent	Absent
5)	Answer from computer in response to reply data 3).	No error *1 (No inverter processing)	Absent	Absent	Absent	Absent	Absent (C)	Absent (C)
3)	(Data 3) is checked for error)	With error. (Inverter outputs 3) again.)	Absent	Absent	Absent	Absent	F	F

- \*1 In the communication request data from the computer to the inverter, 10ms or more is also required after "no data error (ACK)". (Refer to page 208)
- \*2 Reply from the inverter to the inverter reset request can be selected. (Refer to page 212)
- \*3 When any of "0.01 to 9998" is set in *Pr. 37* and "01" in instruction code HFF sets data format to "A" or "E". In addition, data format is always A" and E" for read or write of *Pr. 37*.
- 1) Communication request data from the computer to the inverter

Format						١	lumbe	of Cha	aracters	3					
Format	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
A (Data write)	ENQ *1	Inverter station number *2		Instruction		Waiting Time *3	Data					um eck	*4		
A' (Data write)	ENQ *1	Inverter station number *2		Waiting Time *3	Da	ata		ım eck	*4						
A" (Data write)	ENQ *1	I Istation number! I Time I Data		ata			Su che		*4						
<b>B</b> (Data read)	ENQ *1	Investation :			ıction de	Waiting Time *3	Su che		*4						

# 3) Reply data from the inverter to the computer

•When data is written

Format	Number of Characters							
Format	1	2 3		4	5			
<b>C</b> (Without data error)	ACK *1	station	erter number 2	*4				
<b>D</b> (With data error)	NAK *1	station	erter number 2	Error	*4			

#### •When data is read

Format		Number of Characters											
Format	1	2	3	4	5	6	7	8	9	10	11	12	13
<b>E</b> (Without data error)	STX *1	station number		Read data			ETX *1	Sum check		*4			
E' (Without data error)	STX *1	station	erter number 2	Read data		ETX *1	Sum check		*4				
E" (Without data error)	STX *1	station	erter number 2			Read	l data			ETX *1	Su che		*4
<b>D</b> (With data error)	NAK *1	station	erter number 2	Error	*4								



#### 5) Send data from computer to inverter during data read

Format	Number of Characters						
Format	1	2 3		4			
C (Without data error)	ACK *1	station	erter number 2	*4			
<b>F</b> (With data error)	NAK *1	Investation *		*4			

- Indicate a control code
- \*1 \*2
- Specify the inverter station numbers between H00 and H1F (stations 0 to 31) in hexadecimal.

  When the *Pr. 123 (waiting time setting)* is other than 9999, create the communication request data without "waiting time" in the data format. (The number \*3 of characters decreases by 1.) CR, LF code

When data is transmitted from the computer to the inverter, codes CR (carriage return) and LF (line feed) are automatically set at the end of a data group on some computers. In this case, setting must also be made on the inverter according to the computer. Whether the CR and LF codes will be present or absent can be selected using Pr. 124 (CR, LF selection).

#### **Data definitions**

#### 1) Control code

Signal	ASCII Code	Description
STX	H02	Start of Text (Start of data)
ETX	H03	End of Text (End of data)
ENQ	H05	Enquiry (Communication request)
ACK	H06	Acknowledge (No data error detected)
LF	H0A	Line Feed
CR	H0D	Carriage Return
NAK	H15	Negative Acknowledge (Data error detected)

#### 2) Inverter station number

Specify the station number of the inverter which communicates with the computer.


#### 3) Instruction code

Specify the processing request, e.g. operation or monitoring, given by the computer to the inverter. Hence, the inverter can be run and monitored in various ways by specifying the instruction code as appropriate. (Refer to page 52)

Indicates the data such as frequency and parameters transferred to and from the inverter. The definitions and ranges of set data are determined in accordance with the instruction codes. (Refer to page 52)

#### 5) Waiting time

Specify the waiting time between the receipt of data at the inverter from the computer and the transmission of reply data. Set the waiting time in accordance with the response time of the computer between 0 and 150ms in 10ms increments. (e.g. 1 = 10ms, 2 = 20ms).




# • REMARKS


- · When the Pr. 123, Pr. 337 (waiting time setting) setting is other than 9999, create the communication request data without "waiting time" in the data format. (The number of characters decreases by 1.)
- The data check time changes depending on the instruction code. (Refer to page 209)

#### 6) Sum check code

The sum check code is 2-digit ASCII (hexadecimal) representing the lower 1 byte (8 bits) of the sum (binary) derived from the checked ASCII data.



When the Pr. 123 Waiting time setting ≠ "9999", create the communication request data without "waiting time" in the data format. (The number of characters decreases by 1.)






#### 7) Error code


If any error is found in the data received by the inverter, its definition is sent back to the computer together with the NAK code.

Error	Error Item	Error Description	Inverter Operation
Code	Lifoi itelli	Error Description	inverter operation
HO	Computer NAK error	The number of errors consecutively detected in communication request	
110	Computer NAR error	data from the computer is greater than allowed number of retries.	
H1	Parity error	The parity check result does not match the specified parity	
H2	Sum check error	The sum check code in the computer does not match that of the data	Brought to trip (E. PUE)
112	Sum check end	received by the inverter.	if error occurs
		The data received by the inverter has a grammatical mistake.	continuously more than
H3	Protocol error	Alternatively, data receive is not completed within the predetermined	the allowable number of
		time. CR or LF is not as set in the parameter.	retry times.
H4	Framing error	The stop bit length differs from the initial setting.	
H5	Overrun error	New data has been sent by the computer before the inverter completes	
ПЭ	Overrun error	receiving the preceding data.	
H6	_	_	_
			Does not accept
H7	Character error	cter error The character received is invalid (other than 0 to 9, A to F, control code	received data but is not
			brought to trip.
H8		_	_
H9	_	_	_
		Parameter write was attempted in other than the computer link operation	
HA	Mode error	mode, when operation command source is not selected or during inverter	
		operation.	Does not accept
НВ	Instruction code	The specified command does not exist.	received data but is not
TID	error	The specified command does not exist.	brought to trip.
НС	Data range error	Invalid data has been specified for parameter write, frequency setting,	
	Data lalige ellol	etc.	
HD	_	_	_
HE		_	
HF		_	_

## (5) Response time



# [Formula for data sending time]



# Communication specifications

Name	Number of Bits		
Stop bit length	1 bits		
Stop bit length	2 bits		
Data langth		7 bits	
Data length		8 bits	
Parity check	Present	1 bits	
Failty Check	Absent	0	

#### ●Data check time

Item	Check Time
Various monitors, operation command,	< 12ms
frequency setting (RAM)	< 121115
Parameter read/write, frequency setting	< 30ms
(EEPROM)	< 301118
Parameter clear/all clear	< 5s
Reset command	No answer

#### (6) Instructions for the program


- 1) When data from the computer has any error, the inverter does not accept that data. Hence, in the user program, always insert a retry program for data error.
- 2) All data communication, e.g. run command or monitoring, are started when the computer gives a communication request. The inverter does not return any data without the computer's request. Hence, design the program so that the computer gives a data read request for monitoring, etc. as required.
- 3) Program example

To change the operation mode to computer link operation

# Programming example of Microsoft® Visual C++® (Ver.6.0)

```
#include <stdio.h>
#include <windows.h>
void main(void){
     HANDLÉ
                       hCom:
                                        //Communication handle
     DCB
                       hDcb:
                                        //Structure for communication setting
     COMMTIMEOUTS
                                hTim:
                                        // Structure for time out setting
                                                 // Send buffer
     char
                       szTx[0x10];
     char
                       szRx[0x10]:
                                                 // Receive buffer
     char
                       szCommand[0x10];// Command
                                                 // For buffer size storing
     int
                       nTx,nRx;
     int
                       nSum;
                                                 // For sum code calculation
     BOOL
                       bRet;
     int
                       nRet;
     int
                       i;
     //**** Opens COM1 port****
     hCom = CreateFile ("COM1", (GENERIC_READ | GENERIC_WRITE), 0, NULL, OPEN_EXISTING, FILE_ATTRIBUTE_NORMAL, NULL);
              //**** Makes a communication setting of COM1 port****
              GetCommState(hCom,&hDcb);
                                                                                     // Retrieves current communication information
              hDcb.DCBlength = sizeof(DCB);
                                                                                     // Structure size setting
              hDcb.BaudRate = 19200;
                                                                                     // Communication speed=19200bps
              hDcb.ByteSize = 8;
                                                                                     // Data length=8bit
              hDcb.Parity = 2;
                                                                                     // Even parity
              hDcb.StopBits = 2;
                                                                                     // Stop bit=2bit
              bRet = SetCommState(hCom,&hDcb);
                                                                                     // Sets the changed communication data
              if (bRet == TRUE) {
                       //**** Makes a time out setting of COM1 port****
                       Get CommTimeouts(hCom,&hTim);
                                                                                     // Obtains the current time out value
                       hTim.WriteTotalTimeoutConstant = 1000;
                                                                                     // Write time out 1s
                       hTim.ReadTotalTimeoutConstant = 1000;
                                                                                     // Read time out 1s
                       SetCommTimeouts(hCom,&hTim);
                                                                                     // Changed time out value setting
                       //**** Sets the command to switch the operation mode of the station 1 inverter to the network operation mode ****
                       sprintf(szCommand,"01FB10000");
                                                                                     // Send data (NET operation write)
                       nTx = strlen(szCommand):
                                                                                     //Send data size
                       //**** Generates sum code****
                                                                                     // Initialization of sum data
                       nSum = 0:
                       for (i = 0; i < nTx; i++) {
                                nSum += szCommand[i]:
                                                                                     // Calculates sum code
                                nSum \&= (0xff);
                                                                                     // Masks data
                       }
                       //**** Generates send data****
                                                                                     // Initialization of send buffer
                       memset(szTx,0,sizeof(szTx));
                       memset(szRx,0,sizeof(szRx)):
                                                                                     // Initialization of receive buffer
                       sprintf(szTx,"\5%s%02X",szCommand,nSum);// ENQ code+send data+sum code
                       nTx = 1 + nTx + 2;
                                                                                     // Number of ENQ code+number of send data+number of sum code
                       nRet = WriteFile(hCom,szTx,nTx,&nTx,NULL);
                       //**** Sending >
                       if(nRet != 0) {
                                nRet = ReadFile(hCom,szRx,sizeof(szRx),&nRx,NULL);\\
                       //**** Receiving ****
                                if(nRet != 0) {
                                         //**** Displays the receive data ****
                                        for(i = 0; i < nRx; i++) {
                                                 printf("%02X ",(BYTE)szRx[i]);// Consol output of receive data
                                                  // Displays ASCII coder in hexadecimal. Displays 30 when "0"
                                        printf("\n\r");
              CloseHandle(hCom);
                                                                                     // Close communication port
     }
```





# **!** CAUTION

Always set the communication check time interval before starting operation to prevent hazardous conditions. Data communication is not started automatically but is made only once when the computer provides a communication request. If communication is disabled during operation due to signal loss etc., the inverter cannot be stopped. When the communication check time interval has elapsed, the inverter will come to trip (E.PUE, E.SER).

The inverter can be coasted to a stop by switching on its RES signal or by switching power off.

If communication is broken due to signal cable breakage, computer fault etc., the inverter does not detect such a fault. This should be fully noted.

# (7) Setting items and set data

After completion of parameter settings, set the instruction codes and data then start communication from the computer to allow various types of operation control and monitoring.

No.		Item	Read/ Write	Instruction Code	Data Definition	Number of Data Digits (Format)
1	Оре	eration mode	Read Write	H7B HFB	H0000: Network operation H0001: External operation H0002: PU operation	4 digits (B, E/D) 4 digits (A, C/D)
		Output frequency /speed	Read	H6F	H0000 to HFFFF: Output frequency in 0.01Hz increments Speed increments 0.001 (when $Pr. 37 = 0.01$ to 9998) When "0.01 to 9998" is set in $Pr. 37$ and "01" in instruction code HFF, the data format is E". When "100" is set in $Pr. 52$ , the monitor value is different depending on whether the inverter is at a stop or running. ( <i>Refer to page 143</i> )	4 digits, 6 digits (B, E, E"/D)
		Output current	Read	H70	H0000 to HFFFF: Output current (hexadecimal) in 0.01A increments	4 digits (B, E/D)
	Output voltage		Read	H71	H0000 to HFFFF: Output voltage (hexadecimal) in 0.1V increments	4 digits (B, E/D)
2	Monitor	Special monitor	Read	H72	H0000 to HFFFF: Monitor data selected in instruction code HF3	4 digits, 6 digits (B, E, E"/D)
	Mo	Special monitor	Read	H73	H01 to H3C: Monitor selection data  Refer to the special monitor No. table (page 214)	2 digits (B, E'/D) 2 digits
		Selection No.	Write	HF3		(A', C/D)
		Fault description Read H74 to H77 H76 H77	H75 Third fault in past Second fault in past H76 Fifth fault in past Fourth fault in past	4 digits (B, E/D)		
3	-	Run command Write expansion)		HF9	Control input commands such as the forward rotation signal (STF)	4 digits (A, C/D)
, j	Run	command	Write	HFA	and reverse rotation signal (STR). (For details, refer to page 216)	2 digits (A', C/D)
4	moni	rter status itor ansion)	Read	H79	Monitor the states of the output signals such as forward rotation, reverse rotation and inverter running (RUN). (For details, refer to	4 digits (B, E/D)
	Inver moni	ter status tor	Read	H7A	page 216)	2 digits (B, E'/D)
	Set f	requency //)	Read	H6D	Read set frequency/speed from RAM or EEPROM.  H0000 to HFFFF: Set frequency in 0.01Hz increments	4 digits, 6
		Set frequency (EEPROM) Set frequency (RAM)		H6E	Speed increments 0.001 (when $Pr. 37 = 0.01$ to 9998) When "0.01 to 9998" is set in $Pr. 37$ and "01" in instruction code HFF, the data format is E".	digits (B, E, E"/D)
5				· · ·		HED
	Set frequency (RAM, EEPROM)		Write	HEE	<ul> <li>When "0.01 to 9998" is set in <i>Pr. 37</i> and "01" in instruction code</li> <li>HFF, the data format is A".</li> <li>To change the set frequency consecutively, write data to the inverter RAM. (instruction code: HED)</li> </ul>	digits (A, A", C/D)

Refer to page 206 for data format (A, A', A", B, B', C, D, E, E', E")



No.	ltem	Read/ Write	Instruction Code	Data Definition	Number of Data Digits (Format)		
6	Inverter reset	Write	HFD	H9696: Inverter reset     As the inverter is reset at start of communication by the computer, the inverter cannot send reply data back to the computer.  H9666: Inverter reset     When data is sent normally, ACK is returned to the computer and then the inverter is reset.	4 digits (A, C/D)  4 digits (A, D)		
7	Fault definition all clear	Write	HF4	H9696: Faults history batch clear	4 digits (A, C/D)		
8	Parameter all clear	Write	HFC	All parameters return to the initial values.  Any of four different all clear operations are performed according to the data.  Pr. Communication Pr. Pr. Communication Pr. Pr. 2  HEC HF3 HFF  H9696  H9966  H9966  H5A5A  H5FAA  When all parameter clear is executed for H9696 or H9966, communication-related parameter settings also return to the initial values. When resuming operation, set the parameters again.  *1 Refer to page 200.  *2 Refer to the list of calibration parameters below for calibration parameters.  *3 Pr. 75 is not cleared.	4 digits (A, C/D)		
9	Doromotor	Read	H00 to H63	Refer to the instruction code ( <i>Refer to page 52</i> ) and write and/or read parameter values as required.	4 digits, 6 digits (B, E, E"/D)		
10	Parameter	Write	H80 to HE3	When setting <i>Pr. 100</i> and later, link parameter extended setting must be set.  Data format of <i>Pr. 37</i> read and write is E" and A"	4 digits, 6 digits (A, A", C/D)		
44	Link parameter expansion setting	Read	H7F	Parameter description is changed according to the H00 to H09 setting.	2 digits (B, E'/D)		
11		Write	HFF	For details of the settings, refer to the parameter instruction code ( <i>Refer to page 52</i> ).	2 digits (A', C/D)		
45	Second parameter changing (instruction code HFF = 1, 9)	Read	Setting calibration parameter *1  d H6C H00: Frequency *2 H01: Parameter-set analog value				
12		Write	HEC	<ul> <li>H02: Analog value input from terminal</li> <li>*1 Refer to the list of calibration parameters on the next page for calibration parameters.</li> <li>*2 The gain frequency can also be written using <i>Pr. 125</i> (instruction code: H99) or <i>Pr. 126</i> (instruction code: H9A).</li> </ul>	2 digits (A', C/D)		

Refer to page 206 for data format (A, A', A", B, B', C, D, E, E', E")

# • REMARKS

- Set 65520 (HFFF0) as a parameter value "8888" and 65535 (HFFFF) as "9999".
- For the instruction codes HFF, HEC and HF3, their values are held once written but cleared to zero when an inverter reset or all clear is performed.

Example) When reading the C3 (Pr. 902) and C6 (Pr. 904) settings from the inverter of station 0

	Computer Send Data	Inverter Send Data	Description
1)	ENQ 00 FF 0 01 82	ACK 00	Set "H01" to the expansion link parameter.
2)	ENQ 00 EC 0 01 7E	ACK 00	Set "H01" to second parameter changing.
3)	ENQ 00 5E 0 0F	STX 00 0000 ETX 25	C3 (Pr. 902) is read. 0% is read.
4)	ENQ 00 60 0 FB	STX 00 0000 ETX 25	C6 (Pr. 904) is read. 0% is read.

To read/write C3 (Pr. 902) and C6 (Pr. 904) after inverter reset or parameter clear, execute from 1) again.

# • List of calibration parameters

Damamatan	Name	Instruction Code			
Parameter	Name	Read	Write	Extended	
C2 (902)	Terminal 2 frequency setting bias frequency	5E	DE	1	
C3 (902)	Terminal 2 frequency setting bias	5E	DE	1	
125 (903)	Terminal 2 frequency setting gain frequency	5F	DF	1	
C4 (903)	Terminal 2 frequency setting gain	5F	DF	1	
C5 (904)	Terminal 4 frequency setting bias frequency	60	E0	1	
C6 (904)	Terminal 4 frequency setting bias	60	E0	1	
126 (905)	Terminal 4 frequency setting gain frequency	61	E1	1	
C7 (905)	Terminal 4 frequency setting gain	61	E1	1	

# [Special monitor selection No.]

Refer to page 143 for details of the monitor description.

Data	Description	Unit		
H01	Output frequency/speed *1	0.01Hz/		
1101	Output frequency/speed *1	0.001		
H02	Output current	0.01A		
H03	Output voltage	0.1V		
H05	Frequency setting/speed setting *1	0.01Hz/		
1103	riequency setting/speed setting *1	0.001		
H07	Motor torque	0.1%		
H08	Converter output voltage	0.1V		
H09	Regenerative brake duty	0.1%		
HOA	Electronic thermal relay function	0.1%		
TIOA	load factor	0.176		
H0B	Output current peak value	0.01A		
H0C	Converter output voltage peak value	0.1V		
H0E	Output power	0.01kW		

Data	Description	Unit
H0F	Input terminal status *2	_
H10	Output terminal status *3	_
H14	Cumulative energization time	1h
H17	Actual operation time	1h
H18	Motor load factor	0.1%
H19	Cumulative power	1kWh
H34	PID set point	0.1%
H35	PID measured value	0.1%
H36	PID deviation	0.1%
НЗА	Option input terminal status 1*4	_
H3B	Option input terminal status 2*5	_
H3C	Option output terminal status *6	_
H3D	Motor thermal load factor	0.1%
H3E	Inverter thermal load factor	0.1%

\*1 When "0.01 to 9998" is set in Pr. 37 and "01" in instruction code HFF, the data format is 6 digits (E").

										• .	,					
	out term b15	inal moni	tor details													b0
	_	_	_	_		RES	_	MRS	_	RH	RM	RL	_	_	STR	STF
	utput ter b15	minal mo	nitor detai	ls												b0
	_	_	_	_	_	_	_	_	_	_	ABC	FU	_	_	_	RUN
	etails of b15	option inp	out termina	al monitor	1 (input to	erminal st	atus of FR	R-A7AX E	kit)—all te	erminals a	re off whe	n an optio	n is not fit	ted.		b0
	X15	X14	X13	X12	X11	X10	Х9	X8	X7	X6	X5	X4	Х3	X2	X1	X0
	Details of option input terminal monitor 2 (input terminal status of FR-A7AX E kit)—all terminals are off when an option is not fitted. b15												b0			
	_		_		_	_		_		_	_	_	_			DY
	Details of option output terminal monitor (output terminal status of FR-A7AX E kit/A7AR E kit)—all terminals are off when an option is not fitted.															
_	b15															b0
	—	_	_	_	_	_	RA3	RA2	RA1	Y6	Y5	Y4	Y3	Y2	Y1	Y0




### [Fault data]

Refer to page 267 for details of fault description

Data	Definition
H00	No fault
1100	present
H10	E.OC1
H11	E.OC2
H12	E.OC3
H20	E.OV1
H21	E.OV2
H22	E.OV3
H30	E.THT
H31	E.THM
H40	E.FIN
H52	E.ILF

Data	Definition
H60	E.OLT
H70	E.BE
H80	E.GF
H81	E.LF
H90	E.OHT
HA1	E.OP1
HB0	E.PE
HB1	E.PUE
HB2	E.RET
HB3	E.PE2
HC0	E.CPU
HC5	E.IOH

Data	Definition
HC7	E.AIE
HC8	E.USB
HD8	E.MB4
HD9	E.MB5
HDA	E.MB6
HDB	E.MB7
HF1	E.1
HF6	E.6
HF7	E.7
HFD	E.13



# [Run command]

H	Instruction	Bit	B	F			
Item	Code	Length	Description	Example			
Run command	HFA	8bit	b0: AU (current input selection) *3 b1: forward rotation command b2: reverse rotation command b3: RL (low speed operation command) *1*3 b4: RM (middle speed operation command) *1*3 b5: RH (high speed operation command) *1*3 b6: RT (second function selection)*3 b7: MRS (output stop) *1*3	[Example 1] H02 Forward rotation b7			
Run command (expansion)	HF9	16bit	b0: AU (current input selection) *3 b1: forward rotation command b2: reverse rotation command b3: RL (low speed operation command) *1*3 b4: RM (middle speed operation command) *1*3 b5: RH (high speed operation command) *1*3 b6: RT (second function selection)*3 b7: MRS (output stop) *1*3 b8: — b9: — b10: — b11: RES (reset) *2*3 b12: — b13: — b14: — b15: —	[Example 1] H0002 Forward rotation  b15			

<sup>\*1</sup> The signal within parentheses is the default setting. The description changes depending on the setting of Pr. 180 to Pr .184 (input terminal function selection) (page 128).

#### [Inverter status monitor]

	Bit			
Item	Item Instruction		Description	Example
item	Code	Length	Description	Example
Inverter status monitor	Н7А	8bit	b0: RUN (inverter running) * b1: Forward rotation b2: Reverse rotation b3: SU (up-to-frequency) b4: OL (overload) b5: — b6: FU (frequency detection) * b7: ABC (fault) *	[Example 1] H02 During forward rotation b7
Inverter status monitor (expansion)	H79	16bit	b0: RUN (inverter running) * b1: Forward rotation b2: Reverse rotation b3: SU (up-to-frequency) b4: OL (overload) b5: — b6: FU (frequency detection) * b7: ABC (fault) * b8: — b9: — b10: — b11: — b12: — b13: — b14: — b15: Fault occurrence	[Example 1] H0002 During forward rotation b15  0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0

<sup>\*</sup> The signal within parentheses is the default setting. Definitions change according to the Pr.190 to Pr. 192 (output terminal function selection).

<sup>\*2</sup> The signal within parentheses is the default setting. Reset cannot be controlled by the network, bit 11 is invalid in the initial status. When using bit 11, change the signal with Pr. 184 RES terminal function selection (page128) (Reset can be executed with the instruction code HFD)

<sup>\*3</sup> When Pr. 551 = "2" (PU Mode control source is PU connector), only forward rotation and reverse rotation can be used.



## 4.20.6 Modbus RTU communication specifications (Pr. 117, Pr. 118, Pr. 120, Pr. 122, Pr. 343, Pr. 502, Pr. 549)

Using the Modbus RTU communication protocol, communication operation or parameter setting can be performed from the PU connector of the inverter.

Parameter	Name	Initial Value	Setting		Desci	ription			
Number	Name	initial value	Range		Desci	приоп			
	PU communication		0	Broadcast comm	Broadcast communication				
117	station number	0		Inverter station r	number specificati	ion			
	Station number		1 to 247	Set the inverter s	station numbers v	vhen two or more	inverters are		
					e personal compu	uter.			
	PU communication		48, 96, 192,	Communication	•				
118	speed	96	384	_		e communication	speed.		
	opoou.			Example) 9600b					
			0	Without parity ch					
	DU			Stop bit length 2					
120	PU communication	2	1	With odd parity of					
	parity check			Stop bit length 1					
			2	With even parity					
				Stop bit length 1bit					
			0	RS-485 communication can be made. Note that a communication					
	PU communication	0		fault (E.PUE) occurs as soon as the inverter is switched to the operation mode with command source.					
122			999 88	Communication check (signal loss detection) time interval					
122	check time interval			If a no-communication state persists for longer than the permissible					
				time, the inverter will come to trip (depends on <i>Pr. 502</i> ).					
			9999	No communication check (signal loss detection)					
	Communication error				, ,	ication errors duri	ing Modbus-RTH		
343	count	0	_	communication (		iodilon onoro dan	ing would refer		
	Count			At Fault	I		At Fault		
				Occurrence	Indication	Fault Output	Removal		
	Stop mode selection		0, 3	Coasts to stop.	E.PUE	Output	Stop (E.PUE)		
502	at communication	0		Decelerates to	After stop	Output after	Stop		
	error		1	stop	E.PUE	stop	(E.PUE)		
			2	Decelerates to stop	After stop E.PUE	Without output	Automatic restart functions		
549	Protocol selection	0	0		, ,	operation) protoc	ol		
J-13	i i otocoi acicctioni		1	Modbus-RTU pro	otocol				
<b>-</b>									

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)



- When Modbus-RTU communication is performed from the master with address 0 (station number 0) set, broadcast communication is selected and the inverter does not send a response message. When response from the inverter is necessary, set a value other than "0" (initial value is 0) in Pr. 117 PU communication station number. Some functions are invalid for broadcast communication. (Refer to page 220)
- When "1" (Modbus-RTU protocol) is set in Pr. 549 and "384" (38400bps) in Pr. 118, parameter unit (FR-PU04/FR-PU07) is disabled. When using the parameter unit (FR-PU04/FR-PU07), change parameter using the operation panel.



## • REMARKS

- Set Pr. 549 Protocol selection to "1" to use the Modbus RTU protocol.
- When PU connector is selected as NET mode operation source (when Pr. 550 NET mode operation command source selection = "2" or "9999" (initial value) without communication option), Modbus RTU communication operation can be performed. (Refer to page

#### (1) Communication

•The communication specifications are given below.

Item		Description	Related Parameter
Communication protocol		Modbus-RTU protocol	Pr. 549
Conforming	standard	EIA-485(RS-485)	_
Number of o	connectable	1:N (maximum 32 units), setting is 0 to 247 stations	Pr. 117
Communication speed		Selected from among 4800/9600/19200 and 38400bps	Pr. 118
Control procedure		Asynchronous	_
Communication method		Half-duplex	_
	Character system	Binary (always 8 bits)	_
	Start bit	1bit	_
	Cton hit langth	Select from the following three types	
Communi	Stop bit length	•No parity, stop bit length 2 bits	Pr. 120
cation	Parity check	No odd parity, stop bit length 1 bits	PI. 120
	Failty Clieck	<ul><li>Even parity, stop bit length 1 bit</li></ul>	
	Error check	CRC code check	_
	Terminator	Not used	_
Waiting time	e setting	Not used	_

#### (2) Outline

The Modbus protocol is the communication protocol developed by Modicon for PLC.

The Modbus protocol performs serial communication between the master and slave using the dedicated message frame. The dedicated message frame has the functions that can perform data read and write. Using the functions, you can read and write the parameter values from the inverter, write the input command of the inverter, and check the operating status. In this product, the inverter data are classified in the holding register area (register addresses 40001 to 49999). By accessing the assigned holding register address, the master can communicate with the inverter which is a slave.




## • REMARKS

There are two different serial transmission modes: ASCII (American Standard Code for Information Interchange) mode and RTU (Remote Terminal Unit) mode. This product supports only the RTU mode in which 1-byte (8-bit) data is transmitted as-is. Only the communication protocol is defined by the Modbus protocol, and the physical layer is not stipulated.

## Communication operation and setting

### (3) Message format



#### Data check time

Item	Check Time
Various monitors, operation command,	<12ms
frequency setting (RAM)	< 121115
Parameter read/write, frequency setting	<30ms
(EEPROM)	<301118
Parameter clear/all clear	<5s
Reset command	No answer

#### 1) Query

The master sends a message to the slave (= inverter) at the specified address.

#### 2) Normal Response

After receiving the query from the master, the slave executes the requested function and returns the corresponding normal response to the master.

#### 3) Error Response

If an invalid function code, address or data is received, the slave returns it to the master.

When a response description is returned, the error code indicating that the request from the master cannot be executed is

No response is returned for the hardware-detected error, frame error and CRC check error.

#### 4) Broadcast

By specifying address 0, the master can send a message to all slaves. All slaves that received the message from the master execute the requested function. In this communication, the slaves do not return a response to the master.




The slave executes the function independently of the inverter station number setting (Pr. 117) during broadcast communication.

## (4) Message frame (protocol)

#### Communication method

Basically, the master sends a query message (question) and the slave returns a response message (response). When communication is normal, Device Address and Function Code are copied as they are, and when communication is abnormal (function code or data code is illegal), bit 7 (= 80h) of Function Code is turned on and the error code is set to Data Bytes.

Query message from Master



The message frame consists of the four message fields as shown above.

By adding the no-data time (T1: Start, End) of 3.5 characters to the beginning and end of the message data, the slave recognizes it as one message.

#### Protocol details

The four message fields will be explained below.

Start	1) ADDRESS	2) FUNCTION	3) DATA	4) CRC	CHECK	End
T1	8bit	8bit	n×8bit	L	Н	T1
	0.0.1	02.1		8bit	8bit	

Message Field	Description					
	The address code is 1 byte long (8 bits) and any of 0 to 247 can be set. Set 0 to send a broadcast					
1) ADDRESS field	message (a	Il-address instruction) or any	of 1 to 247 to send a message to eac	ch slave.		
1) ADDRESS field	When the slave responds, it returns the address set from the master.					
	The value set to Pr. 117 PU communication station number is the slave address.					
	The function	n code is 1 byte long (8 bits) a	nd any of 1 to 255 can be set. The m	aster sets the function		
	that it wants	to request from the slave, and	d the slave performs the requested or	peration. The following		
	table gives	the supported function codes.	An error response is returned if the	set function code is		
		hose in the following table.				
	When the s	lave returns a normal respons	e, it returns the function code set by	the master. When the		
	slave return	s an error response, it returns	H80 + function code.			
	0-4-	Franctica Nome	Outline.	Broadcast		
	Code	Function Name	Outline	Communication		
	H03	Read Holding Register	Reads the holding register data.	Disallowed		
2) FUNCTION	H06	Preset Single Register	Writes data to the holding	Allowed		
field	1100	1 reset Single Register	register.	Allowed		
	H08	Diagnostics	Function diagnosis	Disallowed		
		g	(communication check only)			
	H10	Preset Multiple Registers	Writes data to multiple	Allowed		
			consecutive holding registers.			
	H46	Read Holding Register	Reads the number of registers that succeeded in communication	Disallowed		
	1140	Access Log	last time.	Disallowed		
		Table				
	Table 1:Function code list					
	The format	changes depending on the fur	action code (Refer to page 221). Data in	icludes the byte count		
3) DATA field				iciaco ine byte count,		
	number of bytes, description of access to the holding register, etc.  The received message frame is checked for error. CRC check is performed, and 2 byte long data is					
		•	•	, ,		
	added to the end of the message. When CRC is added to the message, the low-order byte is added first and is followed by the high-order byte.					
4) CRC CHECK		, , ,	ing side that adds CRC to the messa	ge. The receiving side		
field		•	ing, and compares the result of that of	0		
		•	field. If these two values do not mate			
	as error.	TOOUTEUN THE ONE OF ILON	noid. Il triese two values de flot flate	ii, iiio rosuit is doillied		
	as enoi.					



### (5) Message format types

The message formats corresponding to the function codes in Table 1 on  $page\ 220$  will be explained.

#### •Read holding register data (H03 or 03)

Can read the description of **1)** system environment variables, **2)** real-time monitor, **3)** faults history, and **4)** inverter parameters assigned to the holding register area (refer to the register list (page 226))

#### Query message

1) Slave Address	2) Function	Starting Address		No. of Points		CRC Check	
(Ohit)	H03	Н	L	Н	L	L	Н
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

#### Normal response (Response message)

1) Slave Address	2) Function	Byte Count		Data			CRC Check	
(8bit)	H03 (8bit)	(8bit)	H (8bit)	L (8bit)	 (n × 16bit)	L (8bit)	H (8bit)	

#### Query message setting

Message	Setting Description						
1) Slave Address	Address to which the message will be sent						
1) Slave Address	Broadcast communication cannot be made (0 is invalid).						
2) Function	Set H03.						
	Set the address at which holding register data read will be started.						
2) Starting Address	Starting address = Starting register address (decimal)-40001						
3) Starting Address	For example, setting of the starting address 0001 reads the data of the holding						
	register 40002.						
4) No. of Points	Number of holding registers from which data will be read						
4) No. of Points	The number of registers from which data can be read is a maximum of 125.						

#### Description of normal response

Message	Setting Description						
5) Byte Count	The setting range is H02 to H14 (2 to 20).						
5) Byte Count	Twice greater than the No. of Point specified at 4) is set.						
	The number of data specified at 4) is set. Data are read in order of Hi byte and Lo						
6) Data: Read data	byte, and set in order of starting address data, starting address + 1 data, starting						
	address + 2 data,						

Example: To read the register values of 41004 (Pr. 4) to 41006 (Pr. 6) from the slave address 17 (H11)

#### Query message

Slave Address	Function	Starting A	No. of F	Points	CRC (	Check	
H11	H11 H03 H03		HEB	H00	H03	H77	H2B
(8bit)			(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

#### Normal response (Response message)

Slave Address	Function	Byte Count		Data						Check
H11	H03	H06	H17	H70	H0B	HB8	H03	HE8	H2C	HE6
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

#### Read value

Register 41004(*Pr. 4*): H1770 (60.00Hz) Register 41005(*Pr. 5*): H0BB8 (30.00Hz) Register 41006(*Pr. 6*): H03E8 (10.00Hz)



#### • Write holding register data (H06 or 06)

Can write the description of 1) system environment variables and 4) inverter parameters assigned to the holding register area (refer to the register list ( page 226)).

#### Query message

1) Slave Address	2) Function	3) Registe	r Address	4) Pres	et Data	CRC Check		
(8bit)	H06	Н	L	Н	L	L	Н	
	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	

Normal response (Response message)

1) Slave Address	2) Function	3) Registe	r Address	4) Pres	et Data	CRC Check		
(Ohit)	H06	Н	L	Н	L	L	Н	
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	

#### Query message setting

Message	Setting Description					
1) Slave Address	Address to which the message will be sent					
1) Slave Address	Setting of address 0 enables broadcast communication					
2) Function	Set H06.					
	Address of the holding register to which data will be written					
2) Desigter Address	Register address = Holding register address (decimal)-40001					
3) Register Address	For example, setting of register address 0001 writes data to the holding register					
	address 40002.					
4) Propet Date	Data that will be written to the holding register					
4) Preset Data	The written data is always 2 bytes.					

#### Description of normal response

1) to 4) (including CRC check) of the normal response are the same as those of the query message. No response is made for broadcast communication.

Example: To write 60Hz (H1770) to 40014 (running frequency RAM) at slave address 5 (H05).

#### Query message

Slave Address	Function	Register A	Preset	Data	CRC (	Check	
H05	H06	H00	H0D	H17	H70	H17	H99
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

Normal response (Response message)

Same data as the query message



#### NOTE

For broadcast communication, no response is returned in reply to a query. Therefore, the next query must be made when the inverter processing time has elapsed after the previous query.



#### •Function diagnosis (H08 or 08)

A communication check can be made since the query message sent is returned unchanged as a response message (function of sub function code H00).

Sub function code H00 (Return Query Data)

Query message

1) Slave Address	2) Function	3) Subf	unction	4) [	Date	CRC Check		
(8bit)	H08	H00	H00	Н	L	L	Н	
(ODIL)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	

Normal response (Response message)

1) Slave Address 2) Function		3) Subf	unction	4) C	ate	CRC Check		
(8bit)	H08	H00	H00	Н	L	L	Н	
	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	

#### Query message setting

Message	Setting Description				
1) Slave Address	Address to which the message will be sent				
1) Slave Address	Broadcast communication cannot be made (0 is invalid).				
2) Function	Set H08.				
3) Subfunction	Set H0000.				
4) Data	Any data can be set if it is 2 bytes long. The setting range is H0000 to HFFFF				

#### • Description of normal response

1) to 4) (including CRC check) of the normal response are the same as those of the query message.



#### **NOTE**

For broadcast communication, no response is returned in reply to a query. Therefore, the next query must be made when the inverter processing time has elapsed after the previous query.

#### • Write multiple holding register data (H10 or 16)

You can write data to multiple holding registers.

Query message

1)Slave Address	2) Function		ting ress	4) No. of Registers		5) ByteCount		6) Data			CRC Check	
(8bit)	H10 (8bit)	H (8bit)	L (8bit)	H (8bit)	L (8bit)	(8bit)	H (8bit)	L (8bit)	 (n×2×8bit)	L (8bit)	H (8bit)	

Normal response (Response message)

1)Slave Address	2)Function	3)Starting Address		4)No. of Registers		CRC Check	
(8bit)	H10	H	L	H	L	L	H
	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

#### · Query message setting

Message	Setting Description		
1) Clave Address	Address to which the message will be sent		
1) Slave Address	Setting of address 0 enables broadcast communication		
2) Function	Set H10.		
	Address where holding register data write will be started		
2) Starting Address	Starting address = Starting register address (decimal)-40001		
3) Starting Address	For example, setting of the starting address 0001 reads the data of the holding		
	register 40002.		
4) No. of Dointo	Number of holding registers where data will be written		
4) No. of Points	The number of registers where data can be written is a maximum of 125.		
5) Puto Count	The setting range is H02 to HFA (0 to 250).		
5) Byte Count	Set a value twice greater than the value specified at 4).		
	Set the data specified by the number specified at 4). The written data are set in		
6) Data	order of Hi byte and Lo byte, and arranged in order of the starting address data,		
	starting address + 1 data, starting address + 2 data		



#### • Description of normal response

1) to 4) (including CRC check) of the normal response are the same as those of the query message.

Example: To write 0.5s (H05) to 41007 (Pr. 7) at the slave address 25 (H19) and 1s (H0A) to 41008 (Pr. 8).

#### Query message

Slave Address	Function		ting ress	No. of Points		Byte Count	Data			CRC Check		
H19	H10	H03	HEE	H00	H02	H04	H00	H05	H00	H0A	H86	H3D
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

#### Normal response (Response message)

Slave Address	Function	Star Add	ting ress	No. of Points		CRC Check	
H19	H10	H03	HEE	H00	H02	H22	H61
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

#### • Read holding register access log (H46 or 70)

A response can be made to a query made by the function code H03 or H10.

The starting address of the holding registers that succeeded in access during previous communication and the number of successful registers are returned.

In response to the query for other than the above function code, 0 is returned for the address and number of registers.

#### Query message

1) Slave Address	2) Function	CRC Check		
(8bit)	H46	L	Н	
(obit)	(8bit)	(8bit)	(8bit)	

#### Normal response (Response message)

1) Slave Address	2) Function	3) Starting Address		4) No. of Points		CRC Check	
(8bit)	H46	H	L	H	L	L	H
	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

#### Query message setting

Message	Setting Description
1) Slave Address	Address to which the message will be sent
1) Slave Address	Broadcast communication cannot be made (0 is invalid).
2) Function	Set H46.

#### • Description of normal response

Message	Setting Description
	The starting address of the holding registers that succeeded in access is returned.
2) Ctarting Address	Starting address = Starting register address (decimal)-40001
3) Starting Address	For example, when the starting address 0001 is returned, the address of the
	holding register that succeeded in access is 40002.
4) No. of Points	The number of holding registers that succeeded in access is returned.

Example: To read the successful register starting address and successful count from the slave address 25 (H19).

#### Query message

Slave Address Function		CRC Check		
H19	H46	H8B	HD2	
(8bit)	(8bit)	(8bit)	(8bit)	

#### Normal response (Response message)

Slave Address	Function	Starting Address		No. of Points		CRC Check	
H19	H10	H03	HEE	H00	H02	H22	H61
(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)	(8bit)

Success of two registers at starting address 41007 (Pr. 7) is returned.



#### • Error response

An error response is returned if the query message received from the master has an illegal function, address or data. No response is returned for a parity, CRC, overrun, framing or busy error.



No response message is sent in the case of broadcast communication also.

Error response (Response message)

1) Slave Address 2) Function		3) Exception Code	CRC (	Check
(8bit)	H80 + Function	(8bit)	L	Н
(onit)	(8bit)	(obit)	(8bit)	(8bit)

Message	Setting Description
1) Slave Address	Address received from the master
2) Function	Master-requested function code + H80
3) Exception Code	Code in the following table

#### **Error code list**

Code	Error Item	Error Description
01	ILLEGAL FUNCTION	The set function code in the query message from the master cannot be
01	(Function code illegal)	handled by the slave.
ILLEGAL DATA ADDRESS *1		The set register address in the query message from the master cannot be
02	(Address illegal)	handled by the inverter.
		(No parameter, parameter read disabled, parameter write disabled)
	ILLEGAL DATA VALUE	The set data in the query message from the master cannot be handled by the
03	(Data illegal)	inverter.
		(Out of parameter write range, mode specified, other error)

- \*1 An error will not occur in the following cases.
  - 1) Function code H03 (Read holding register data)
    - When the No. of Points is 1 or more and there is one or more holding registers from which data can be read
  - 2) Function code H10 (Write multiple holding register data)
    - When the No. of Points is 1 or more and there is 1 or more holding registers to which data can be written

Namely, when the function code H03 or H10 is used to access multiple holding registers, an error will not occur if a non-existing holding register or read disabled or write disabled holding register is accessed.



#### REMARKS

An error will occur if all accessed holding registers do not exist.

Data read from a non-existing holding register is 0, and data written there is invalid.

#### · Message data mistake detection

To detect the mistakes of message data from the master, they are checked for the following errors. If an error is detected, a trip will not occur.

#### Error check item

Error Item	Error Description	Inverter Operation
Dority orror	The data received by the inverter differs from the	
Parity error	specified parity (Pr. 334 setting).	
Framing array	The data received by the inverter differs from the	
Framing error	specified stop bit length (Pr. 333).	
Overrun error	The following data was sent from the master before	1) Pr.343 is increased by 1 at error
Overruit error	the inverter completes data receiving.	occurrence.
	The message frame data length is checked, and the	2)The terminal LF is output at error
Message frame error	received data length of less than 4 bytes is regarded	occurrence.
	as an error.	
	A mismatch found by CRC check between the	
CRC check error	message frame data and calculation result is	
	regarded as an error.	

# 6) Modbus registers

#### System environment variable

Register	Definition	Read/write	Remarks
40002	Inverter reset	Write	Any value can be written
40003	Parameter clear	Write	Set H965A as a written value.
40004	All Parameter clear	Write	Set H99AA as a written value.
40006	Parameter clear *1	Write	Set H5A96 as a written value.
40007	All parameter clear *1	Write	Set HAA99 as a written value.
40009	Inverter status/control input instruction*2	Read/write	See below.
40010	Operation mode/inverter setting *3	Read/write	See below.
40014	Running frequency (RAM value)	Read/write	According to the <i>Pr.37</i> settings, the frequency and selectable speed are in 1r/min
40015	Running frequency (EEPROM value)	Write	increments.

- \*1 The communication parameter values are not cleared.
- \*2 For write, set the data as a control input instruction. For read, data is read as an inverter operating status.
- \*3 For write, set data as the operation mode setting. For read, data is read as the operation mode status.

#### <Inverter status/control input instruction>

	Defir	nition	
Bit	Control input instruction	Inverter status	
0	Stop command	RUN (inverter running) *2	
1	Forward rotation command	Forward rotation	
2	Reverse rotation command	During reverse rotation	
3	RH (high-speed operation	CLL (up to fraguency)	
3	command)*1	SU (up-to-frequency)	
4	RM (middle-speed operation	Ol (cuarland)	
4	command)*1	OL (overload)	
5	RL (low-speed operation	0	
3	command)*1		
6	0	FU (frequency detection) *2	
7	RT (second function selection)	ABC (fault) *2	
8	AU (current input selection)	0	
9	0	0	
10	MRS (output stop) *1	0	
11	0	0	
12	RES (reset) *1	0	
13	0	0	
14	0	0	
15	0	Fault occurrence	

#### <Operation mode/inverter setting>

Mode	Read Value	Written
Wiode	Read value	Value
EXT	H0000	H0010
PU	H0001	_
EXT	H0002	
JOG	H0002	_
PU	H0003	
JOG	П0003	_
NET	H0004	H0014
PU+EXT	H0005	_

The restrictions depending on the operation mode changes according to the computer link specifications.


- \*1 The signal within parentheses is the default setting. The description changes depending on the setting of *Pr.180 to Pr.184* (input terminal function selection) (refer to page 128).
  - Each assigned signal is valid or invalid depending on NET. (Refer to page 191)
- \*2 The signal within parentheses is the default setting. Definitions change according to the Pr.190 to Pr.192 (output terminal function selection) (refer to page 134).

#### ●Real time monitor

Refer to page 143 for details of the monitor description.

Register	Description	Unit
40201	Output frequency/speed *1	0.01Hz/1
40202	Output current	0.01A
40203	Output voltage	0.1V
40205	Output frequency setting/speed	0.01Hz/
40203	setting *1	0.001
40207	Motor torque	0.1%
40208	Converter output voltage	0.1V
40209	Regenerative brake duty	0.1%
40210	Electronic thermal relay function	0.1%
40210	load factor	0.176
40211	Output current peak value	0.01A
40212	Converter output voltage peak value	0.1V
40214	Output power	0.01kW
40215	Input terminal status *2	_

Register	Description	Unit
40216	Output terminal status *3	_
40220	Cumulative energization time	1h
40223	Actual operation time	1h
40224	Motor load factor	0.1%
40225	Cumulative power	1kWh
40252	PID set point	0.1%
40253	PID measured value	0.1%
40254	PID deviation	0.1%
40258	Option input terminal status*4	_
40259	Option input terminal status 2*5	_
40260	Option output terminal status *6	_
40261	Motor thermal load factor	0.1%
40262	Inverter thermal load factor	0.1%



## $\overline{\gamma}$

#### Parameter

Parameter	Register	Parameter Name	Read/ Write	Remarks
0 to 999	41000 to 41999	Refer to the parameter list (page 52) for the parameter names.	Read/write	The parameter number + 41000 is the register number.
C2(902)	41902	Terminal 2 frequency setting bias frequency	Read/write	
C3(902)	42092	Terminal 2 frequency setting bias (Analog value)	Read/write	The analog value (%) set to C3 (902) is read.
C3(902)	43902	Terminal 2 frequency setting bias (Terminal analog value)	Read	The analog value (%) of the voltage (current) applied to the terminal 2 is read.
125(903)	41903	Terminal 2 frequency setting gain frequency	Read/write	
C4(003)	42093	Terminal 2 frequency setting gain (Analog value)	Read/write	The analog value (%) set to C4 (903) is read.
C4(903)	43903	Terminal 2 frequency setting gain (Terminal analog value)	Read	The analog value (%) of the voltage (current) applied to the terminal 2 is read.
C5(904)	41904	Terminal 4 frequency setting bias frequency	Read/write	
C6(004)	42094	Terminal 4 frequency setting bias (Analog value)	Read/write	The analog value (%) set to C6 (904) is read.
C6(904)	43904	Terminal 4 frequency setting bias (Terminal analog value)	Read	The analog value (%) of the current (voltage) applied to the terminal 4 is read.
126(905)	41905	Terminal 4 frequency setting gain frequency	Read/write	
C7(905)	42095	Terminal 4 frequency setting gain (Analog value)	Read/write	The analog value (%) set to C7 (905) is read.
C7(905)	43905	Terminal 4 frequency setting gain (Terminal analog value)	Read	The analog value (%) of the current (voltage) applied to the terminal 4 is read.

## • Faults history

Register	Definition	Read/write	Remarks
40501	Fault history 1	Read/write	Being 2 bytes in length, the data is stored as
40502	Fault history 2	Read	"H00OO".
40503	Fault history 3	Read	The error code can be referred to in the low-order 1
40504	Fault history 4	Read	byte.
40505	Fault history 5	Read	, ,
40506	Fault history 6	Read	Performing write using the register 40501 batch-
40507	Fault history 7	Read	clears the faults history.
40508	Fault history 8	Read	Set any value as data.

#### Fault code list

Data	Definition
H00	No fault
1100	present
H10	E.OC1
H11	E.OC2
H12	E.OC3
H20	E.OV1
H21	E.OV2
H22	E.OV3
H30	E.THT
H31	E.THM
H40	E.FIN
H52	E.ILF

Data	Definition
H60	E.OLT
H70	E.BE
H80	E.GF
H81	E.LF
H90	E.OHT
HA1	E.OP1
HB0	E.PE
HB1	E.PUE
HB2	E.RET
HB3	E.PE2
HC0	E.CPU
HC5	E.IOH

Data	Definition
HC7	E.AIE
HC8	E.USB
HD8	E.MB4
HD9	E.MB5
HDA	E.MB6
HDB	E.MB7
HF1	E.1
HF6	E.6
HF7	E.7
HFD	E.13

<sup>\*</sup> Refer to page 267 for details of fault definition.



#### (7) Pr. 343 Communication error count

You can check the cumulative number of communication errors.

Parameter	Setting Range	Minimum Setting Range	Initial Value
343	(Reading only)	1	0




#### NOTE

The number of communication errors is temporarily stored into the RAM. As it is not stored into the EEPROM performing a power supply reset or inverter reset clears the value to 0.

#### (8) Output terminal LF "alarm output (communication error warnings)"

During a communication error, the alarm signal (LF signal) is output by open collector output. Assign the used terminal using any of Pr. 190 to Pr. 192 (output terminal function selection).





The LF signal can be assigned to the output terminal using any of *Pr.190 to Pr.192*. Changing the terminal assignment may affect the other functions. Make setting after confirming the function of each terminal.

## 4.20.7 USB communication (Pr. 547, Pr. 548)

Inverter setup can be easily performed using the FR Configurator by connecting the inverter and personal computer with a USB cable.


• A personnel computer and inverter can be easily connected with one USB cable.

Parameter Number	Name	Initial Value	Setting Range	Description		
547*	USB communication station number	0	0 to 31	Inverter station number specification		
			0	USB communication is possible Trips in the PU operation mode (E.USB)		
548*	USB communication check time interval	9999	0.1 to 999.8s	Sets the interval of communication check time.  If a no-communication state persists for longer than the permissible time, the inverter will come to trip (E.USB).		
			9999	No communication check		

<sup>\*</sup> Changed setting value is made valid when powering on or resetting the inverter.

#### USB communication specifications

Interface	Conforms to USB1.1	
Transmission	12Mbps	
Speed:		
Wiring Length	Maximum 5m	
Connector	USB mini B connector (receptacle mini B type)	
Power supply	Self-power supply	



• You can perform parameter setting and monitoring with the FR Configurator. Refer to the instruction manual of the FR Configurator for details.



### • REMARKS

Information on USB cable

Name	Inverter Type	Application	on/Specifications
USB cable	MR-J3USBCBL3M Cable length 3m	Connector for amplifier mini-B connector (5 pin)	Connector for personal computer A connector



#### Parameters referred to

Pr. 551 PU mode operation command source selection Refer to page 191



## 4.21 Special operation and frequency control

Purpose	Parameter t	hat should be Set	Refer to Page
Perform process control such as pump and air volume.	PID control	Pr. 127 to Pr. 134	231
Dancer control	PID control (dancer control setting)	Pr. 44, Pr. 45, Pr. 128 to Pr. 134	238
Frequency control appropriate for load torque	Droop control	Pr. 286, Pr. 287	244
Avoid overvoltage alarm due to regeneration by automatic adjustment of output frequency	Regeneration avoidance function	Pr. 882, Pr. 883, Pr. 885, Pr. 886	245

## 4.21.1 PID control (Pr. 127 to Pr. 134)

The inverter can be used to exercise process control, e.g. flow rate, air volume or pressure.

The terminal 2 input signal or parameter setting is used as a set point and the terminal 4 input signal used as a feedback value to constitute a feedback system for PID control.


Parameter		Initial	Setting	ting Description					
Number	Name	Value	Range	Description					
4.5-	PID control automatic		0 to 400Hz	Frequency at which	the control is aut	omatically changed to PID control.			
127	switchover frequency	9999	9999	Without PID automa	tic switchover fur	nction			
			0	PID action is not per	formed				
			20	PID reverse action PID forward action PID reverse action PID reverse action PID forward action PID reverse action PID reverse action PID forward a					
			21	PID forward action	Set value (termi	nal 2 or <i>Pr. 133</i> )			
			40	PID reverse action	PID automatic switchover function  In is not performed In it i				
			41	PID forward action					
128	PID action selection	0	42	PID reverse action	Addition	` ′			
			43	PID forward action	method: ratio	of the operation mode)			
			50	PID reverse action	Deviation value	set point (Pr. 133), measured value (terminal 4) main speed (frequency command of the operation mode) alue signal input (LonWorks, CC-Link ation) value, set point input (LonWorks, CC- unication) r (parameter setting is small), the thy with a slight change of the proportional band narrows, the ves but the stability deteriorates, e.g. portional band required for only the integral (I) action variable as that for the proportional (P) the setting, the FUP signal is output. The			
			51	PID forward action	communication	)			
			60	PID reverse action	Measured value	Inication) (parameter setting is small), the ly with a slight change of the roportional band narrows, the res but the stability deteriorates, e.g.			
			61	PID forward action	Link communica	tion)			
				If the proportional ba	,				
			0.4.5	PID reverse action PID forward action Link communication  If the proportional band is narrow (parameter setting is small), the manipulated variable varies greatly with a slight change of the measured value. Hence, as the proportional band narrows, the response sensitivity (gain) improves but the stability deteriorates, e.g. hunting occurs. Gain Kp= 1/proportional band No proportional control For deviation step input, time (Ti) required for only the integral (I) action to provide the same manipulated variable as that for the proportional (Fig. 1) action action. As the integral time decreases, the set point is reached earlier					
400 . 1	DID was a settle well be and	4000/		9999 Without PID automatic switchover function  0 PID action is not performed 20 PID reverse action 21 PID forward action 22 PID reverse action 32 PID reverse action 33 PID forward action 44 PID forward action 45 PID reverse action 46 PID reverse action 47 PID forward action 48 PID forward action 49 PID reverse action 40 PID reverse action 41 PID forward action 42 PID reverse action 43 PID forward action 45 PID forward action 46 PID forward action 47 PID forward action 48 PID forward action 49 PID reverse action 40 PID reverse action 40 PID reverse action 41 PID forward action 42 PID forward action 43 PID forward action 44 PID forward action 45 PID forward action 46 PID reverse action 47 PID forward action 48 PID forward action 49 PID reverse action 40 PID reverse action 40 PID reverse action 41 PID forward action 42 PID forward action 43 PID forward action 44 PID forward action 45 PID forward action 46 PID reverse action 47 PID forward action 48 PID forward action 49 PID reverse action 40 PID reverse action 40 PID reverse action 41 PID forward action 42 PID forward action 43 PID forward action 44 PID forward action 45 PID forward action 46 PID reverse action 47 PID forward action 48 PID forward action 49 PID reverse action 40 PID reverse action 40 PID reverse action 40 PID reverse action 41 PID forward action 42 PID reverse action 43 PID forward action 44 PID reverse action 45 PID reverse action 46 PID reverse action 47 PID forward action 48 PID reverse action 49 PID reverse action 40 PID reverse action 40 PID reverse action 40 PID reverse action 40 PID reverse action 41 PID reverse action 40 PID reverse action 40 PID reverse action 41 PID reverse action 41 PID reverse action 42 PID reverse action 43 PID reverse action 44 PID reverse action 44 PID reverse action 44 PID reverse action 45 PID reverse action 46 PID reverse action 47 PID reverse action 48 PID reverse action 49 PID reverse action 40 PID reverse action 40 PID reverse action 40 Reversion 40 PID reverse action 40 Reversion 40 PID reverse action 40 Rev					
<b>129</b> *1	PID proportional band	100%	1000%	response sensitivity	(gain) improves I	ortional band narrows, the but the stability deteriorates, e.g.			
					, .	but the stability deteriorates, e.g. onal band			
			9999	1 1 1					
			0.1 to						
<b>130</b> *1	PID integral time	1s	3600s						
	3			but hunting occurs more easily.					
			9999						
			0 to	If the feedback value	tting, the FUP signal is output. The				
131	PID upper limit	9999	100%						
				. ,	, , ,	, , ,			
			9999						
			0 to		falls below the se	etting range, the FDN signal is			
132	PID lower limit	9999	100%	PID roward action  PID reverse action  PID forward action  PID forward action  PID forward action  PID reverse action  PID forward action  PID forward action  PID forward action  PID forward action  PID reverse action  PID forward action  If the proportional band is narrow (parameter setting is small), the manipulated variable varies greatly with a slight change of the measured value. Hence, as the proportional band narrows, the response sensitivity (gain) improves but the stability deteriorates, e.g. hunting occurs. Gain Kp= 1/proportional band  No proportional control  For deviation step input, time (Ti) required for only the integral (I) action to provide the same manipulated variable as that for the proportional (P action. As the integral time decreases, the set point is reached earlier but hunting occurs more easily.  No integral control.  Maximum value  If the feedback value exceeds the setting, the FUP signal is output. The maximum input (20mA/5V/10V) of the measured value (terminal 4) is equivalent to 100%.  No function  Minimum frequency  If the process value falls below the setting range, the FDN signal is output. The maximum input (20mA/5V/10V) of the measured value (terminal 4) is equivalent to 100%.  No function  Vised to set the set point for PID control.  Terminal 2 input is the set point.  For deviation ramp input, time (Td) required for providing only the manipulated variable for the proportional (P) action. As the differential time increases, greater response is made to a deviation change.					
			10070	. , ,					
			9999	' '					
400 1	DID antique to the		0 to 100%						
<b>133</b> *1	PID action set point	9999							
				·					
404 - 1	DID differential times	0000							
<b>134</b> *1	PID differential time	9999	10.00s						
			9999			Ü			
The above para	The above parameters can be set when Pr. 160 User group read selection ="0". (Refer to page 177)								

<sup>\*1</sup> Pr. 129, Pr. 130, Pr. 133 and Pr. 134 can be set during operation. They can also be set independently of the operation mode.

## //

#### (1) PID control basic configuration

•Pr. 128 = "20, 21" (measured value input)



Kp: Proportionality constant Ti: Integral time S: Operator Td: Differential time


#### (2) PID action overview

#### 1)PI action

A combination of proportional control action (P) and integral control action (I) for providing a manipulated variable in response to deviation and changes with time.

[Operation example for stepped changes of process value]

(Note) PI action is the sum of P and I actions.




#### 2)PD action

A combination of proportional control action (P) and differential control action (D) for providing a manipulated variable in response to deviation speed to improve the transient characteristic.

[Operation example for proportional changes of process value]


(Note) PD action is the sum of P and D actions.



#### 3)PID action

The PI action and PD action are combined to utilize the advantages of both actions for control.

(Note) PID action is the sum of P, I and D actions.






#### 4)Reverse operation

Increases the manipulated variable (output frequency) if deviation X = (set point - measured value) is positive, and decreases the manipulated variable if deviation is negative.



#### 5)Forward action

Increases the manipulated variable (output frequency) if deviation X = (set point - measured value) is negative, and decreases the manipulated variable if deviation is positive.




Relationships between deviation and manipulated variable (output frequency)

	Deviation			
	Positive	Negative		
Reverse action	71	K		
Forward action	R	71		

#### (3) Connection diagram

- Source logic
- Pr. 128 = 20
- •*Pr.* 183 = 14
- •Pr. 190 = 15•Pr. 191 = 14
- •Pr. 192 = 16



- \*1 The power supply must be selected in accordance with the power specifications of the detector used.
- \*2 The used output signal terminal changes depending on the Pr. 190 to Pr. 192 (output terminal selection) setting.
- \*3 The used input signal terminal changes depending on the Pr. 178 to Pr. 184 (input terminal selection) setting.

#### (4) I/O signals and parameter setting

- •Set "20, 21, 50, 51, 60 or 61" in Pr. 128 to perform PID operation.
- Set "14" in any of Pr. 178 to Pr. 184 (input terminal function selection) to assign PID control selection signal (X14) to turn the X14 signal on.

When the X14 signal is not assigned, only the Pr. 128 setting makes PID control valid.

• Enter the set point using the inverter terminal 2 or Pr. 133 and enter the measured value to terminal 4.



### • REMARKS

- When Pr. 128 = "0" or X14 signal is off, normal inverter operation is performed without PID action.
- Turning ON/OFF of bit of the terminal, to which X14 signal is assigned through network as RS-485 communication, enables PID control.

Signal		Terminal Used	Function	Description	Parameter Setting
	X14	Depending on	PID control	Turn on X14 signal to perform PID	Set 14 in any of <i>Pr. 178</i> to <i>Pr.</i>
	X14	Pr. 178 to Pr. 184	selection	control. *1	184.
				You can input the set point for PID	<i>Pr.</i> 128 = 20, 21,
	2	2	Cat paint input	control.	<i>Pr.</i> 133 = 9999
	2	2	Set point input	0 to 5V 0 to 100%	<i>Pr.</i> 73 = 1 *2, 11
				0 to 10V 0 to 100%	<i>Pr.</i> 73 = 0, 10
	PU		Set point input	Set the set point (Pr. 133) from the	<i>Pr.</i> 128 = 20, 21
	FU		Set point input	operation panel.	<i>Pr.</i> 133 = 0 to 100%
Input				Input the signal from the detector	<i>Pr.</i> 128 = 20, 21
<u>l</u>			Measured value	(measured value signal).	
	4	4	input	4 to 20mA 0 to 100%	<i>Pr.</i> 267 = 0 *2
			iliput	0 to 5V 0 to 100%	<i>Pr.</i> 267 = 1
				0 to 10V 0 to 100%	<i>Pr.</i> 267 = 2
	Communication *3		Deviation value	Inputs the deviation value from	Pr. 128 = 50, 51
			input	LonWorks, CC-Link communication.	17. 128 = 30, 31
			Set point, measured value input	Inputs the set point and deviation value	
				from LonWorks, CC-Link	<i>Pr.</i> 128 = 60, 61
				communication.	
		FUP	Upper limit output	Output to indicate that the process value	<i>Pr.</i> 128 = 20, 21, 60, 61
	FUP			signal exceeded the maximum value (Pr.	<i>Pr.</i> 131 ≠ 9999
	1 01			131).	Set 15 or 115 in any of Pr. 190
					to Pr. 192 *4
		FDN Depending on	Lower limit output		<i>Pr.</i> 128 = 20, 21, 60, 61
	FDN			Output when the process value signal	<i>Pr.</i> 132 ≠ 9999
				falls below the minimum value (Pr. 132).	Set 14 or 114 in any of Pr. 190
Output		Pr. 190 to Pr. 192		III I'II 's sector of the 's al' and a disast the sector of	to Pr. 192. *4
Out			<b>5</b>	"Hi" is output to indicate that the output	0-140 440 100
	Б.		Forward (reverse)	indication of the parameter unit is	Set 16 or 116 in any of <i>Pr. 190</i>
	RL		rotation direction	forward rotation (FWD) or "Low" to	to Pr. 192. *4
			output	indicate that it is reverse rotation (REV)	
			During DID control	or stop (STOP).	Cot 47 or 147 in any of B 100
	PID		During PID control	Turns on during PID control.	Set 47 or 147 in any of <i>Pr. 190</i>
			activated	Common terminal for terminals FUP,	to Pr. 192. *4
	SE	SE	Output terminal		
			common	FDN, RL, and PID	

- When the X14 signal is not assigned, only the Pr. 128 setting makes PID control valid.
- The shaded area indicates the parameter initial value.
- Refer to the CC-Link communication option (FR-A7NC E kit) instruction manual for the setting method from CC-Link communication. \*3
  - Refer to the LonWorks communication option (FR-A7NL E kit) instruction manual for the setting method from LonWorks communication.
- When 100 or larger value is set in any of Pr.190 to Pr.192 (output terminal function selection), the terminal output has negative logic. (For details, Refer to page 134)




- Changing the terminal function using any of Pr. 178 to Pr. 184 and Pr. 190 to Pr. 192 may affect the other functions. Make setting after confirming the function of each terminal.
- · When the Pr. 267 setting was changed, check the voltage/current input switch setting. Different setting may cause a fault, failure or malfunction. (Refer to page 165 for setting)



### (5) PID automatic switchover control (Pr. 127)

- •The system can be started up without PID control only at a start.
- •When the frequency is set to Pr. 127 PID control automatic switchover frequency within the range 0 to 400Hz, the inverter starts up without PID control from a start until output frequency is reached to the set frequency of Pr. 127, and then it shifts to PID control. Once the system has entered PID control operation, it continues PID control if the output ferquency falls to or below Pr.127.




#### (6) PID monitor function

- •The PID control set point, measured value and deviation value can be displayed on the operation panel and output from terminal AM.
- •The deviation monitor displays a negative value on the assumption that 1000 is 0%. (The deviation monitor cannot be output from the terminal AM.)
- •For each monitor, set the following value in Pr. 52 DU/PU main display data selection and Pr. 158 AM terminal function selection.


Setting	Monitor Description	Minimum Increments	Terminal AM Full Scale	Remarks
52	PID set point	0.1%	100%	
53	PID measured value	0.1%	100%	_
54	PID deviation value	0.1%	_	Value cannot be set to <i>Pr. 158</i> .  Displays 1000 when the PID deviation is 0%.

#### (7) Adjustment procedure



#### (8) Calibration example

(A detector of 4mA at 0°C and 20mA at 50°C is used to adjust the room temperature to 25°C under PID control. The set point is given to across inverter terminals 2-5 (0 to 5V).)





#### <Set point input calibration>

- 1. Apply the input voltage of 0% set point setting (e.g. 0V) across terminals 2-5.
- 2. Enter in C2 (Pr. 902) the frequency which should be output by the inverter at the deviation of 0% (e.g. 0Hz).
- 3. In C3 (Pr.902), set the voltage value at 0%.
- 4. Apply the voltage of 100% set point (e.g. 5V) to across terminals 2-5.
- 5. Enter in Pr.125 the frequency which should be output by the inverter at the deviation of 100% (e.g. 50Hz).
- 6. In *C4* (*Pr.903*), set the voltage value at 100%.

#### <Measured value calibration>


- 1. Apply the input current of 0% measured value (e.g. 4mA) across terminals 4-5.
- 2. Make calibration using C6 (Pr. 904.
- 3. Apply the input current of 100% measured value (e.g. 20mA) across terminals 4-5.
- 4. Make calibration using C7 (Pr. 905).



### • REMARKS

• The frequency set in C5 (Pr. 904) and Pr. 126 should be the same as set in C2 (Pr. 902) and Pr. 125.

The results of the above calibration are as shown below:





- If the multi-speed (RH, RM, RL signal) or jog operation (jog signal) is entered with the X14 signal on, PID control is stopped and multi-speed or jog operation started.
- If the setting is as follows, PID control becomes invalid.


Pr. 79 Operation mode selection ="6" (switchover mode)

When the inverter is at a stop with Pr. 261 Power failure stop selection selected.

- Changing the terminal function using any of Pr. 178 to Pr. 184, Pr. 190 to Pr. 192 may affect the other functions. Make setting after confirming the function of each terminal.
- When PID control is selected, the minimum frequency is the frequency set in Pr. 902 and the maximum frequency is the frequency set in Pr. 903.

Pr. 1 Maximum frequency and Pr. 2 Minimum frequency settings are also valid.

- The remote operation function is invalid during PID operation.
- When the control is switched to PID control during normal operation, the frequency command value calculated by PID operation using OHz as standard is used without the frequency during the operation.



Operation when control is switched to PID control during normal operation



#### Parameters referred to

Pr. 59 Remote function selection Refer to page 96 Pr. 73 Analog input selection Refer to page 165 Pr. 79 Operation mode selection Refer to page 180 Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 128 Pr. 190 to Pr. 192 (output terminal function selection) Refer to page 134 Pr. 261 Power failure stop selection Refer to page 157 C2 (Pr. 902) to C7 (Pr. 905) Frequency setting voltage (current) bias/gain 🖫 Refer to page 168

## 4.21.2 Dancer control (Pr. 44, Pr. 45, Pr. 128 to Pr. 134)

Performs PID control by feedbacking the position detection of the dancer roller, controlling the dancer roller is in the specified position.

Parameter	Name Initial Value		Setting		Description	on	
Number		<b>cond</b> FR-E740-095 or less 5s		Range			
	Second				This parameter is the acceleration time of the main		
44	acceleration/	FR-E740-120 and 170	10s	0 to 3600/360s	speed during dancer control. It will not function as		
	deceleration time	FR-E740-230 and 300	15s		second accele	ration/decelerat	ion time.
	Second			0 to 3600/360s	This paramete	r is the decelera	tion time of the mair
45	deceleration time	9999		9999	speed during of	dancer control. It	t will not function as
	deceleration time			9999	second decele	ration time.	
				0	PID action is not performed  PID reverse action  Measured value (terminal 2 of the pipe forward)		
				20	PID reverse		
					action	Measured value (terminal 4)	
				21	PID forward	Set value (term	ninal 2 or <i>Pr. 133</i> )
					action		
				40	PID reverse	Addition	For dancer control
					action	method: fixed	set point ( <i>Pr. 133</i> ),
				41	PID forward	Addition	measured value
128					action	method: fixed	(terminal 4)
	PID action			42	PID reverse	Addition	main speed (speed
	selection	0			action	method: ratio	command of the
				43	PID forward	Addition	operation mode)
					action	method: ratio	
				50	PID reverse	Deviation value	e signal input
					action PID forward	(LonWorks, C	C-Link
				51	action	communication	n)
					PID reverse		
				60	action	Set point and n	neasured value inpu
					PID forward action (LonWorks, CC-Link communication)		C-Link
				61			า)
					If the proportional band is narrow (parameter		
					setting is small), the manipulated variable varies		
					greatly with a slight change of the measured value		
400 . 1	PID proportional	4000/		0.1 to 1000%	Hence, as the proportional band narrows, the		
<b>129</b> *1	band	100%			response sensitivity (gain) improves but the		
					stability deteriorates, e.g. hunting occurs. Gain Kp		
					= 1/proportional band		
				9999	No proportional control		
							Ti) required for only
						action to provide	
<b>130</b> *1	PID integral time	1s		0.1 to 3600s	manipulated variable as that for the proportional (P		
					action. As the integral time decreases, the set poin		
					•		occurs more easily.
				9999	No integral cor		
					Maximum valu		the series of Erro
				0 to 1000/			the setting, the FUF
131	PID upper limit	9999		0 to 100%	-		n input (20mA/5V/
131					10V) of the measured value (terminal 4) is equivalent to 100%.		
				9999	No function	UU 70.	
				9999	Minimum value		
							the setting range
				0 to 100%			the setting range,
132	PID lower limit	9999		0 10 100%	_	I is output. The i	
					(20mA/5V/10V) of the measured value (terminal 4 is equivalent to 100%.		
				0000	-	J 10070.	
				9999	No function		




Parameter Number	Name	Initial Value	Setting Range	Description	
<b>133</b> *1	PID action set	0000	0 to 100%	Used to set the set point for PID control.	
133 *1	point	9999	9999	Always 50%	
<b>134</b> *1	PID differential time			For deviation ramp input, time (Td) required for providing only the manipulated variable for the proportional (P) action.  As the differential time increases, greater response is made to a deviation change.	
			9999	No differential control.	

The above parameters can be set when Pr.160 User group read selection = "0". (Refer to page 177)

\*1 Pr.129, Pr.130, Pr.133 and Pr.134 can be set during operation. They can also be set independently of the operation mode.

#### (1) Dancer control block diagram



\*1 The main speed can be selected from all operation mode such as external (analog voltage input, multi-speed), PU (digital frequency setting), communication (RS-485, CC-Link).

#### Set point and measured value of PID control

	Input	Input Signal	Pr.267 Setting	Current/Voltage Input Switch
Set point	Pr. 133	0 to 100%	_	_
Measured	When measured value is input as current (4 to 20mA)	4mA 0%, 20mA 100%	0	I F
value	When measured value is input as voltage	0V 0%, 5V 100%	1	
	(0 to ±5V or 0 to ±10V)	0V 0%, 10V 100%	2	I V




#### NOTE

- Changing the terminal function using any of *Pr.178 to Pr.184* may affect the other functions. Make setting after confirming the function of each terminal.
- When the Pr. 267 setting was changed, check the voltage/current input switch setting. Different setting may cause a
  fault, failure or malfunction. (Refer to page 165 for setting)

# (2) Dancer control overview


Performs dancer control by setting 40 to 43 in *Pr. 128 PID action selection*. The main speed command is the speed command of each operation mode (external, PU, communication). Performs PID control by the position detection signal of the dancer roller, then the result is added to the main speed command. For acceleration/deceleration of the main speed, set the acceleration time in *Pr. 44 Second acceleration/deceleration time* in *Pr. 45 Second deceleration time*.

\* Set 0s normally to Pr.7 Acceleration time and Pr.8 Deceleration time. When the Pr. 7 and Pr. 8 setting is large, response of dancer control during acceleration/deceleration is slow.



#### (3) Connection diagram

- Source logic
- Pr. 128 = 41
- Pr. 183 = 14
- •Pr. 190 = 15
- Pr. 191 = 14
- •Pr. 192 = 16



- \*1 The main speed command differs according to each operation mode (external, PU, communication)
- \*2 The used output signal terminal changes depending on the Pr. 190 to Pr. 192 (output terminal selection) setting.
- \*3 The used input signal terminal changes depending on the Pr. 178 to Pr. 184(input terminal selection) setting.



#### (4) I/O signals and parameter setting

- •Set "40 to 43" in Pr. 128 to perform dancer control.
- •Set "14" in any of Pr. 178 to Pr. 184 (input terminal function selection) to assign PID control selection signal (X14) to turn the X14 signal on.

When the X14 signal is not assigned, only the Pr. 128 setting makes dancer control valid.

- •Input the main speed command (external, PU, communication). The main speed command in any operation mode can be input. (Note that terminal 4 can not be used as the main speed command.)
- •Input the set point using Pr. 133, then input the measured value signal (dancer roller position detection signal) across terminal 4 and 5 of the inverter.



#### (I) REMARKS

- When Pr. 128 = "0" or X14 signal is off, normal inverter operation is performed without dancer control.
- Turning ON/OFF of bit of the terminal, to which X14 signal is assigned through network as RS-485 communication, enables

S	ignal	Terminal Used	Function	Description	Parameter Setting
	X14			Turn on X14 signal to perform dancer control. *1	Set 14 in any of <i>Pr. 178 to Pr. 184</i> .
Input			Measured value	Input the signal from the dancer roller detector (measured value signal).	<i>Pr.128</i> = 40, 41, 42, 43
	4	4	input	4 to 20mA . 0 to 100%	Pr.267 = 0 *2
			IIIput	0 to 5V 0 to 100%	Pr.267 = 1
				0 to 10V 0 to 100%	<i>Pr.</i> 267 = 2
				Output to indicate that the measured	Pr.128 = 40, 41, 42, 43
	FUP	Depending on <i>Pr. 190</i> to <i>Pr. 192</i>	Upper limit output	value signal exceeded the maximum	<i>Pr.131</i> ≠ 9999
	1 01			value	Set 15 or 115 in any of <i>Pr.190</i> to <i>Pr.192</i> .
				(Pr. 131).	*3
Output	FDN		Lower limit output	Output when the measured value signal falls below the minimum value ( <i>Pr. 132</i> ).	Pr.128 = 40, 41, 42, 43 $Pr.132 \neq 9999$ Set 14 or 114 in any of $Pr.190$ to $Pr.192$ .
	RL		Forward (reverse) rotation direction output	Output is "ON" when the output indication of the parameter unit is forward rotation (FWD) and "OFF" when reverse rotation (REV) or stop (STOP).	•
	PID		During PID control activated	Turns on during PID control.	Set 47 or 147 in any of <i>Pr. 190</i> to <i>Pr. 192</i> . *3
	SE	SE	Output terminal	Common terminal for terminals FUP,	
	OL.	0	common	FDN, RL, and PID	


- When the X14 signal is not assigned, only the Pr. 128 setting makes dancer control valid.
- The shaded area indicates the parameter initial value.
- When 100 or larger value is set in any of Pr. 190 to Pr. 192 (output terminal function selection), the terminal output has negative logic. (For details, Refer to page 134)



- Changing the terminal function using any of Pr. 178 to Pr. 184 and Pr.190 to Pr.192 may affect the other functions. Make setting after confirming the function of each terminal.
  - When the Pr. 267 setting was changed, check the voltage/current input switch setting. Different setting may cause a fault, failure or malfunction. (Refer to page 165 for setting)

## $\overline{\mathbb{Z}}$

#### 5) Parameter details



•When ratio ( $Pr.\ 128 =$  "42, 43") is selected for addition method, PID control × (ratio of main speed) is added to the main speed. The ratio is determined by the  $Pr.\ 125$  Terminal 2 frequency setting gain frequency and C2 ( $Pr.\ 902$ ) Terminal 2 frequency setting bias frequency. The frequency setting signal is set to 0 to 50Hz in the range between 0 to 100% in the initial setting. The ratio is (×100%) when the main speed is 50Hz and (×50%) when 25Hz.



#### **NOTE**

- Even when C4 (Pr. 903) is set to other than 100%, the frequency setting signal is considered as 100%.
- Even when C3 (Pr. 903) is set to other than 0%, the frequency setting signal is considered as 0%.
- When C2 (Pr. 902) is set to other than 0Hz, the frequency setting signal is 0% when C2 (Pr. 902) is less than the set frequency.
- •Turning X14 signal on/off during operation by assigning X14 signal results in the following operation.

When X14 signal is on: Uses output frequency unchanged as the main speed command and continues operation by dancer control.

When X14 signal is off: Ends dancer control and continues operation at the set frequency made valid.

Pr. 128 Setting	PID Action	Addition Method	Set Point	Measured Value	Main Speed Command	
40	Reverse action	Fixed				
41	Forward action	TIXEU	Pr. 133	Terminal 4	Speed command for each operation mode	
42	Reverse action	Ratio				
43	Forward action	Nalio				

- •Action of *Pr. 129 PID proportional band, Pr. 130 PID integral time, Pr. 131 PID upper limit, Pr. 132 PID lower limit, Pr. 134 PID differential time* is the same as PID control. For the relationship of controlled variable (%) of PID control and frequency, 0% is equivalent to the set frequency of *Pr. 902* and 100% to *Pr. 903*.
- •For the *Pr. 133 PID action set point* setting, set frequency of *Pr. 902* is equivalent to 0% and *Pr. 903* to 100%. When *9999* is set in *Pr. 133*, 50% is the set point.



#### > REMARKS

Pr. 127 PID control automatic switchover frequency is invalid.

#### (6) Output signal

•Output terminal assignment during dancer control (PID control) operation

PID signal turns on during dancer control (PID control) or at a stop by PID control (in the status PID operation being performed inside) (The signal is off during normal operation.)

For the terminal used for PID signal output, assign the function by setting "47 (positive logic) or 147 (negative logic)" in any of *Pr. 190* to *Pr. 192* (output terminal function selection).



#### NOTE

• Changing the terminal function using any of *Pr. 178* to *Pr. 184*, *Pr. 190* to *Pr. 192* may affect the other functions. Make setting after confirming the function of each terminal.

#### (7) PID monitor function

- •The PID control set point and measured value can be output to the operation panel monitor display and terminal AM.
- •For each monitor, set the following value in Pr. 52 DU/PU main display data selection and Pr. 158 AM terminal function selection.

Setting	Monitor Description	Minimum	Terminal AM Full	Remarks	
Setting	World Description	Increments	Scale		
52	PID set point	0.1%	100%		
53	PID measured value	0.1%	100%	_	
54	PID deviation value	0.1%		Value cannot be set in Pr. 158.	
34			_	Displays 1000 when the PID deviation is 0%.	

#### (8) Priorities of main speed command


- •The priorities of the main speed speed command source when the speed command source is external are as follows. JOG signal > multi-speed setting signal (RL/RM/RH/REX) > 16 bit digital input (option) > temrinal 2
- •The priorities of the main speed speed command source when "3" is set in *Pr. 79*. Multi-speed setting signal (RL/RM/RH/REX) > set frequency (digital setting by PU, operation panel)
- •Terminal 4 can not be selected as the main speed speed command even when AU terminal is turned on.
- •Even when a remote operation function is selected by setting a value other than "0" in *Pr. 59*, compensation of the remote setting frequency to the main speed is ignored (changes to 0).




#### (9) Adjustment procedure

#### Dancer roller position detection signal adjustment

When terminal 4 input is voltage input, 0V is minimum position and 5V(10V) is maximum position. When current is input, 4mA is minimum position and 20mA is maximum position. (initial value) When 0 to 7V is output from the potentiometer, it is necessary to calibrate C7 (Pr.905) at 7V.





(Example) Control at a dancer center position using a 0 to 7V potentiometer

- 1) After changing the current/voltage input switch to "V", set "2" in Pr. 267 to change terminal 4 input to voltage input.
- 2) Input 0V to across terminal 4 and 5 to calibrate *C6* (*Pr. 904*). (% display displayed at analog calibration is irrelevant to % of the feed back value.)
- 3) By inputting 7V to across terminal 4 to 5, calibrate *C7(Pr. 905)* (% display displayed at analog calibration is irrelevant to % of the feed back value.)
- 4) Set 50% in Pr.133.



#### **NOTE**

When the *Pr.* 267 setting was changed, check the voltage/current input switch setting. Different setting may cause a fault, failure or malfunction. (*Refer to page 165* for setting)



#### REMARKS

- In normal PID control, PID control is stopped when multi-speed operation signal (RH, RM, RL, REX signal) or JOG signal is input. In dancer control, however, PID control continues handling the signals as the main speed.
- During dancer control, Second acceleration/deceleration time of Pr.44 and Pr.45 are the parameters for acceleration/deceleration time setting to the main speed command source. They do not function as the second function.
- When switchover mode is set with "6" in Pr. 79, dancer control (PID control) is invalid.
- Speed command of terminal 4 input from terminal AU is invalid when dancer control is selected.
- Acceleration/deceleration of the main speed command is the same operation as when frequency command is increased/ decreased by analog input.
- Therefore, SU signal remains on even if the starting signal is turned on/off.(always in the constant speed state)
- The DC brake operation starting frequency when turning off the starting signal is not Pr. 10 but a smaller value of either Pr. 13 or 0.5Hz.
- The set frequency monitor is always variable as "main speed command+PID control".
- The main speed setting frequency accelerates for the acceleration/deceleration time set in Pr.~44 and Pr.~45 and the output frequency accelerates/decelerates for the acceleration/deceleration time set in Pr.~7 and Pr.~8. Therefore, when the set time of Pr.~7 and Pr.~8 is longer than Pr.~44 and Pr.~45, the output frequency accelerates/decelerates for the acceleration/deceleration time set in Pr.~7 and Pr.~8.
- For the integral term limit, a smaller value of either the PID manipulated variable (%) value converted from the linear, interpolated *Pr. 1 Maximum frequency* with *Pr. 902* and *Pr. 903*, or 100% is used for limit.
- Although the output frequency is limited by the minimum frequency, operation limit of the integral term is not performed.



#### Parameters referred to

Pr. 59 Remote function selection Refer to page 96

Pr. 73 Analog input selection Refer to page 165

Pr. 79 Operation mode selection TF Refer to page 180

Pr. 178 to Pr. 184 (input terminal function selection) Refer to page 128

Pr. 190 to Pr. 192 (output terminal function selection) Refer to page 134


C2 (Pr. 902) to C7 (Pr. 905) Frequency setting voltage (current) bias/gain 🖫 Refer to page 168

### 4.21.3 Droop control (Pr. 286 to Pr. 287) ADMEVC

This function is designed to balance the load in proportion to the load torque to provide the speed drooping characteristic under advanced magnetic flux vector control.

This function is effective for balancing the load when using multiple inverters

Parameter	Name	Initial	Setting	Description	
Number	Name	Value	Range	Description	
		0%	0	Droop control is invalid (Normal operation)	
286	Droop gain		0.1% to	Droop control is valid Drooping amount at the rated torque as a percentage with	
				respect to the rated motor frequency.	
287	Droop filter time	0.3s	0 to 1s	Time constant of the filter applied on the torque current.	
201	constant			Time constant of the filter applied on the torque current.	



Droop compensation frequency = Torque current after filtering Rated value of torque current

#### (1) Droop control

- The output frequency is changed according to the magnitude of torque current under advanced magnetic flux vector control.
   The drooping amount at the rated torque is set by the droop gain as a percentage using the rated frequency as a reference.
- The maximum droop compensation frequency is 120Hz.

Pr. 84 Rated motor frequency × Pr. 286 Droop gain
100



#### REMARKS

• Set the droop gain to about the rated slip of the motor.

- Droop control is invalid during PID control operation.
- The maximum value of frequency after droop compensation is either 120Hz or Pr. 1 Maximum frequency, whichever is smaller.



#### Parameters referred to

Pr. 1 Maximum frequency Refer to page 86
PID control Refer to page 231



## 4.21.4 Regeneration avoidance function (Pr. 665, Pr. 882, Pr. 883, Pr. 885, Pr. 886)

This function detects a regeneration status and increases the frequency to avoid the regenerative status.

Possible to avoid regeneration by automatically increasing the frequency and continue operation if the fan happens
to rotate faster than the set speed due to the effect of another fan in the same duct.


Parameter Number	Name	Initial Value	Setting Range	Description	
	Regeneration		0	Regeneration avoidance function invalid	
882	avoidance operation	0	1	Regeneration avoidance function is always valid	
002	selection	Ü	2	Regeneration avoidance function is valid only during a constant	
	Sciection		_	speed operation	
	Regeneration			Bus voltage level at which regeneration avoidance operates. When	
883	avoidance operation	n 780VDC	300 to 800V	the bus voltage level is set to low, overvoltage error will be less apt	
000	level			to occur. However, the actual deceleration time increases.	
	levei			The set value must be higher than the "power supply voltage $\times$ $\sqrt{2}$ ".	
	Regeneration avoidance		0 to 10Hz	Limit value of frequency which rises at activation of regeneration	
885		6Hz		avoidance function.	
000	compensation		9999	Fraguency limit involid	
	frequency limit value			Frequency limit invalid	
	Regeneration		0 to 200%		
886	avoidance voltage	100%		0 to 200%	Responsiveness at activation of regeneration avoidance.
	gain			A larger setting will improve responsiveness to the bus voltage	
	Regeneration			change. However, the output frequency could become unstable. When vibration is not suppressed by decreasing the <i>Pr.</i> 886 setting,	
665	avoidance frequency	100%	0 to 200%	set a smaller value in <i>Pr. 665</i> .	
	gain			(B.f. strange 177)	


The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

#### (1) What is regeneration avoidance function? (Pr. 882, Pr. 883)


- •When the regeneration load is large, the DC bus voltage rises and an overvoltage fault (E. OV□) may occur. When this bus voltage rise is detected and the bus voltage level reaches or exceeds *Pr.* 883, increasing the frequency avoids the regeneration status.
- •The regeneration avoidance function is always on when "1" is set in *Pr.* 882 and activated only during a constant speed when "2" is set in *Pr.* 882.

for constant speed





Regeneration avoidance operation example








#### **REMARKS**

- The accel/decel ramp while the regeneration avoidance function is operating changes depending on the regeneration load.
- The DC bus voltage of the inverter is about √2 times as input voltage.
   When the input voltage is 440VAC, bus voltage is approximately 622VDC.
   However, it varies with the input power supply waveform.
- The Pr. 883 setting should be kept higher than the DC bus voltage level. Otherwise, the regeneration avoidance function is always on even in the non-regeneration status and the frequency increases.
- While overvoltage stall ( L) is activated only during deceleration and stops the output frequency, the regeneration avoidance function is always on (Pr. 882 = 1) or activated only during a constant speed (Pr. 882 = 2) and increases the frequency according to the regeneration amount.



### (2) Limit regeneration avoidance operation frequency (Pr. 885)

You can limit the output frequency compensated for (increased) by the regeneration avoidance function.

- •The frequency is limited to the output frequency (frequency prior to regeneration avoidance operation) + *Pr.* 885 Regeneration avoidance compensation frequency limit value during acceleration or constant speed. If the regeneration avoidance frequency exceeds the limit value during deceleration, the limit value is held until the output frequency falls to 1/2 of *Pr.* 885.
- •When the frequency increased by regeneration avoidance function has reached *Pr. 1 Maximum frequency*, it is limited to the maximum frequency.
- •When *Pr.* 885 is set to "9999", regeneration avoidance function operation frequency setting is invalid.

#### (3) Regeneration avoidance function adjustment (Pr. 665, Pr. 886)

•If the frequency becomes instable during regeneration avoidance operation, decrease the setting of *Pr. 886 Regeneration* avoidance voltage gain. Reversely, if sudden regeneration causes an overvoltage alarm, increase the setting.

When vibration is not suppressed by decreasing the *Pr.* 886 setting, set a smaller value in *Pr.* 665 Regeneration avoidance frequency gain.



#### **NOTE**

- When regeneration avoidance operation is performed, \(\sigmi\) (overvoltage stall) is displayed and the OL signal is output.
- When regeneration avoidance operation is performed, stall prevention is also activated at the same time.
- The regeneration avoidance function cannot shorten the actual deceleration time taken to stop the motor. The actual
  deceleration time depends on the regeneration energy consumption capability. When shortening the deceleration
  time, consider using the regeneration unit (FR-BU2, FR-CV, FR-HC) and brake resistor (FR-ABR etc.,) to consume
  regeneration energy at constant speed.
- When using the regeneration unit (FR-BU2, FR-CV, FR-HC) and brake resistor (FR-ABR etc., ), set *Pr. 882* to "0 (initial value)" (regeneration avoidance function invalid). When using the regeneration unit, etc. to consume regeneration energy at deceleration, set *Pr. 882* to "2" (regeneration avoidance function valid only at a constant speed).
- When regeneration avoidance operation is performed, the OL signal output item of *Pr. 156* also becomes the target of  $\Box$  (overvoltage stall). *Pr. 157 OL signal output timer* also becomes the target of  $\Box$  (overvoltage stall).



#### **Parameters referred to**

Pr. 1 Maximum frequency Refer to page 86
Pr. 8 Deceleration time Refer to page 99

Pr. 22 Stall prevention operation level Refer to page 82



### 4.22 Useful functions

Purpose	Parameter th	Parameter that should be Set		
Increase cooling fan life	Cooling fan operation selection	Pr. 244		
	Inverter part life display	Pr. 255 to Pr. 259	248	
To determine the maintenance time of parts.	Maintenance output function	Pr. 503, Pr. 504	252	
or parts.	Current average value monitor signal	Pr. 555 to Pr. 557	253	
Freely available parameter Free parameter		Pr. 888, Pr. 889	255	

## 4.22.1 Cooling fan operation selection (Pr. 244)

You can control the operation of the cooling fan (FR-E740-040 or more) built in the inverter.

Parameter Number	Name	Initial Value	Setting Range	Description
			0	Operates in power-on status.  Cooling fan on/off control invalid (the cooling fan is always on at power on)
244	Cooling fan operation selection	1	1	Cooling fan on/off control valid The fan is always on while the inverter is running. During a stop, the inverter status is monitored and the fan switches on-off according to the temperature.

The above parameters can be set when Pr.160 User group read selection = "0". (Refer to page 177)

- In either of the following cases, fan operation is regarded as faulty, [FN] is shown on the operation panel, and the fan fault (FAN) and alarm (LF) signals are output.
  - Pr. 244 = "0"

When the fan comes to a stop with power on.

•*Pr.* 244 = "1"

When the inverter is running and the fan stops during fan ON command.

• For the terminal used for FAN signal output, set "25 (positive logic) or 125 (negative logic)" to any of *Pr. 190* to *Pr. 192* (output terminal function selection), and for the LF signal, set "98 (positive logic) or 198 (negative logic)".



#### **NOTE**

• Changing the terminal assignment using *Pr. 190 to Pr. 192 (output terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.



#### Parameters referred to

Pr.190 to Pr.192 (output terminal function selection) 👺 Refer to page 134

## 4.22.2 Display of the life of the inverter parts (Pr. 255 to Pr. 259)

Degrees of deterioration of main circuit capacitor, control circuit capacitor, cooling fan and inrush current limit circuit can be diagnosed by monitor.

When any part has approached the end of its life, an alarm can be output by self diagnosis to prevent a fault.

(Use the life check of this function as a guideline since the life except the main circuit capacitor is calculated theoretically.)

For the life check of the main circuit capacitor, the alarm signal (Y90) will not be output if a measuring method of (4) is not performed.


Parameter	Name	Initial Value	Setting	Description	
Number			Range	•	
				Displays whether the control circuit capacitor,	
255	l ife clarm etetus dienley	0	(0 to 15)	main circuit capacitor, cooling fan, and each parts	
233	Life alarm status display	O	(0 to 13)	of the inrush current limit circuit has reached the	
				life alarm output level or not. (Reading only)	
	Inrush current limit circuit			Displays the deterioration degree of the inrush	
256	life display	100%	(0 to 100%)	current limit circuit.	
				(Reading only)	
	Control circuit capacitor life display	100%	(0 to 100%)	Displays the deterioration degree of the control	
257				circuit capacitor.	
				(Reading only)	
	Main circuit capacitor life display	100%	(0 to 100%)	Displays the deterioration degree of the control	
258				circuit capacitor.	
230				(Reading only)	
				The value measured by Pr. 259 is displayed.	
				Setting "1" and turning the power supply off starts	
	Main circuit capacitor life measuring		0.1	the measurement of the main circuit capacitor life.	
259		0	0, 1	When the Pr. 259 value is "3" after powering on	
			(2, 3, 8, 9)	again, the measuring is completed.	
				Writes deterioration degree in Pr. 258.	

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)



#### (1) Life alarm display and signal output (Y90 signal, Pr. 255)

•Whether any of the control circuit capacitor, main circuit capacitor, cooling fan and inrush current limit circuit has reached the life alarm output level or not can be checked by *Pr. 255 Life alarm status display* and life alarm signal (Y90).



Pr. 255 (decimal)	Bit (binary)	Inrush Current Suppression Circuit Life	Cooling Fan Life	Main Circuit Capacitor Life	Control Circuit Capacitor Life
15	1111	0	0	0	0
14	1110	0	0	0	×
13	1101	0	0	×	0
12	1100	0	0	×	×
11	1011	0	×	0	0
10	1010	0	×	0	×
9	1001	0	×	×	0
8	1000	0	×	×	×
7	0111	×	0	0	0
6	0110	×	0	0	×
5	0101	×	0	×	0
4	0100	×	0	×	×
3	0011	×	×	0	0
2	0010	×	×	0	×
1	0001	×	×	×	0
0	0000	×	×	×	×

O: With warnings,  $\times$ : Without warnings

- •The life alarm signal (Y90) turns on when any of the control circuit capacitor, main circuit capacitor, cooling fan and inrush current limit circuit reaches the life alarm output level.
- •For the terminal used for the Y90 signal, set "90" (positive logic) or "190" (negative logic) to any of *Pr. 190 to Pr. 192 (output terminal function selection)*.



#### **NOTE**

• Changing the terminal assignment using *Pr. 190 to Pr. 192 (output terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.

#### (2) Inrush current limit circuit life display (Pr. 256)

- •The life of the inrush current limit circuit (relay, contactor and inrush resistor) is displayed in Pr. 256.
- •The number of contact (relay, contactor, thyristor) ON times is counted, and it is counted down from 100% (1 million times) every 1%/10,000 times.

As soon as 10% (900,000 times) is reached, Pr. 255 bit 3 is turned on and also an alarm is output to the Y90 signal.

#### (3) Control circuit capacitor life display (Pr. 257)

- •The deterioration degree of the control circuit capacitor is displayed in Pr. 257 as a life.
- In the operating status, the control circuit capacitor life is calculated from the energization time and temperature, and is counted down from 100%.

As soon as the control circuit capacitor life falls below 10%, *Pr.* 255 bit 0 is turned on and also an alarm is output to the Y90 signal.

#### (4) Main circuit capacitor life display (Pr. 258, Pr. 259)

- •The deterioration degree of the control circuit capacitor is displayed in Pr. 258 as a life.
- •On the assumption that the main circuit capacitor capacitance at factory shipment is 100%, the capacitor life is displayed in *Pr. 258* every time measurement is made.

When the measured value falls to or below 85%, Pr. 255 bit 1 is turned on and also an alarm is output to the Y90 signal.

- Measure the capacitor capacity according to the following procedure and check the deterioration level of the capacitor capacity.
  - 1) Check that the motor is connected and at a stop.
  - 2) Set "1" (measuring start) in Pr. 259.
  - 3) Switch power off. The inverter applies DC voltage to the motor to measure the capacitor capacity while the inverter is off.
  - 4) After confirming that the LED of the operation panel is off, power on again.
  - 5) Check that "3" (measuring completion) is set in *Pr. 259*, read *Pr. 258*, and check the deterioration degree of the main circuit capacitor.

Pr. 259	Description	Remarks
0	No measurement	Initial value
1	Measurement start	Measurement starts when the
'	Weasurement start	power supply is switched off.
2	During measurement	
3	Measurement complete	Only displayed and cannot be
8	Forced end	set
9	Measurement error	



#### > REMARKS

- When the main circuit capacitor life is measured under the following conditions, "forced end" (Pr. 259 = "8") or "measuring error" (Pr. 259 = "9") occurs or it remains in "measuring start" (Pr. 259 = "1"). Therefore, do not measure in such case.
  - In addition, even when "measurement completion" (Pr. 259 = "3") is confirmed under the following conditions, normal measurement can not be done.
  - (a) FR-HC, FR-CV or FR-BU2 is connected.
  - (b) DC power supply is connected to the terminal P/+ and N/-.
  - (c) The power supply switched on during measurement.
  - (d) The motor is not connected to the inverter.
  - (e) The motor is running (coasting)
  - (f) The motor capacity is two rank smaller as compared to the inverter capacity.
  - (g) The inverter is tripped or a fault occurred when power is off.
  - (h) The inverter output is shut off with the MRS signal.
  - (i) The start command is given while measuring.
  - (j) The parameter unit (FR-PU04/FR-PU07) is connected.
  - (k) Use terminal PC as power supply.
  - (I) I/O terminal of the control terminal block and plug-in option is on (continuity).
  - (m)Plug-in option is fitted. (FR-E740-026 or less)
- Turning the power on during measuring before LED of the operation panel turns off, it may remain in "measuring" (*Pr.* 259 = "2") status. In such case, carry out operation from step 2.



#### **POINT**

For the accurate life measuring of the main circuit capacitor, perform after more than 3 hrs passed since the turn off of the power as it is affected by the capacitor temperature.



When measuring the main circuit capacitor capacity (*Pr. 259 Main circuit capacitor life measuring* = "1"), the DC voltage is applied to the motor for 1s at powering off. Never touch the motor terminal, etc. right after powering off to prevent an electric shock.



#### (5) Cooling fan life display

•The cooling fan speed of 50% or less is detected and "FN" is dislayed on the operation panel and parameter unit (FR-PU04/FR-PU07). As an alarm display, Pr. 255 bit2 is turned on and also an alarm is output to the Y90 signal.



#### • REMARKS

• When the inverter is mounted with two or more cooling fans, the life of even one cooling fan is diagnosed.



For replacement of each part, contact the nearest Mitsubishi FA center.


#### 4.22.3 Maintenance timer alarm (Pr. 503, Pr. 504)

When the cumulative energization time of the inverter reaches the parameter set time, the maintenance timer output signal (Y95) is output. (MT) is displayed on the operation panel.

This can be used as a guideline for the maintenance time of peripheral devices.

Parameter Number	Name	Initial Value	Setting Range	Description
503	Maintenance timer	0	0 (1 to 9998)	Displays the cumulative energization time of the inverter in 100h increments. (Reading only) Writing the setting of "0" clears the cumulative energization time.
504	Maintenance timer alarm output set time	9999	0 to 9998 9999	Time taken until when the maintenance timer alarm output signal (Y95) is output.  No function

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)



- The cumulative energization time of the inverter is stored into the EEPROM every hour and is displayed in Pr. 503 Maintenance timer in 100h increments. Pr. 503 is clamped at 9998 (999800h).
- When the Pr. 503 value reaches the time set to Pr. 504 Maintenance timer alarm output set time (100h increments), the maintenance timer alarm output signal (Y95) is output.
- For the termial used for the Y95 signal output, assign the function by setting "95" (positive logic) or "195" (negative logic) to any of Pr. 190 to Pr. 192 (output terminal function selection).



- The cumulative energization time is counted every hour. The energization time of less than 1h is not counted.
  Changing the terminal assignment using Pr. 190 to Pr. 192 (output terminal function selection) may affect the other functions. Make setting after confirming the function of each terminal.



#### Parameters referred to


Pr. 190 to Pr. 192 (output terminal function selection) 👺 Refer to page 134



#### 4.22.4 Current average value monitor signal (Pr. 555 to Pr. 557)

The average value of the output current during constant speed operation and the maintenance timer value are output as a pulse to the current average value monitor signal (Y93).


The pulse width output to the I/O module of the PLC or the like can be used as a guideline due to abrasion of machines and elongation of belt and for aged deterioration of devices to know the maintenance time. The current average value monitor signal (Y93) is output as pulse for 20s as 1 cycle and repeatedly output during constant speed operation.



Parameter Number	Name	Initial Value	Setting Range	Description
555	Current average time	1s	0.1 to 1.0s	Time taken to average the current during start pulse output (1s).
556	Data output mask time	0s	0.0 to 20.0s	Time for not obtaining (mask) transient state data.
557	Current average value monitor signal output reference current	Rated inverter current	0 to 500A	Reference (100%) for outputting the signal of the current average value.

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.



- The pulse output of the current average value monitor signal (Y93) is shown above.
- For the terminal used for the Y93 signal output, assign the function by setting "93" (positive logic) or "193" (negative logic) to *Pr. 190 RUN terminal function selection*. The function can not be assigned to *Pr. 192 A,B,C terminal function selection*.
- 1) Setting of Pr.556 Data output mask time

The output current is unstable (transient state) right after the operation is changed from the acceleration/deceleration state to the constant speed operation. Set the time for not obtaining (mask) transient state data in *Pr. 556*.

2) Setting of Pr. 555 Current average time

The average output current is calculated during Hi output of start pulse (1s). Set the time taken to average the current during start bit output in *Pr.* 555.

3) Setting of Pr. 557 Current average value monitor signal output reference current


Set the reference (100%) for outputting the signal of the current average value. Obtain the time to output the signal from the following calculation.

# $\frac{\text{Output current average value}}{\textit{Pr. }557 \text{ setting}} \times \text{5s (Output current average value } 100\%/5\text{s)}$

Note that the output time range is 0.5 to 9s and the output time is either of the following values when the output current average value is the corresponding percentage of the *Pr.* 557 setting.

Less than 10% ... 0.5s, more than 180% ... 9s

Example) when Pr. 557 = 10A and the average value of output current is 15A As 15A/10A x 5s=7.5, the current average value monitor signal is output as low pulse shape for 7.5s.




#### 4) Setting of Pr. 503 Maintenance timer

After the output current average value is output as low pulse shape, the maintenance timer value is output as high pulse shape. The output time of the maintenance timer value is obtained from the following calculation.


$$\frac{Pr. 503 \times 100}{40000h} \times 5s \quad \text{(Maintenance timer value 100\%/5s)}$$

Note that the output time range is 2 to 9s, and it is 2s when the *Pr. 503* setting is less than 16000h and 9s when exceeds 72000h.



#### REMARKS

- Mask of data output and sampling of output current are not performed during acceleration/deceleration.
- When the speed is changed to acceleration/deceleration from constant speed during start pulse output, the data is judged as
  invalid, the start pulse is output as high pulse shape for 3.5s, and the end signal is output as low pulse shape for 16.5s.
   The signal is output for at least 1 cycle even when acceleration/deceleration state continues after the start pulse output is
  completed.



- When the output current value (inverter output current monitor) is 0A on completion of the 1 cycle signal output, the signal is not
  output until the speed becomes constant next time
- The current average value monitor signal (Y93) is output as low pulse shape for 20s (without data output) under the following condition.
  - (a) When the motor is in the acceleration/deceleration state on completion of the 1 cycle signal output
  - (b) When 1-cycle signal output was ended during restart operation with the setting of automatic restart after instantaneous power failure (*Pr.* 57 ≠ "9999")
  - (c) When restart operation was being performed at the point of data output mask end with the setting of automatic restart after instantaneous power failure (*Pr.* 57 ≠ "9999")



#### NOTE

• Changing the terminal assignment using *Pr. 190 to Pr. 192 (output terminal function selection)* may affect the other functions. Make setting after confirming the function of each terminal.



#### Parameters referred to

Pr. 57 Restart coasting time Refer to page 151

Pr. 190 to Pr. 192 (output terminal function selection) Refer to page 134

Pr. 503 Maintenance timer Refer to page 252



#### 4.22.5 Free parameter (Pr. 888, Pr. 889)

You can input any number within the setting range 0 to 9999.

For example, the number can be used:

- As a unit number when multiple units are used.
- As a pattern number for each operation application when multiple units are used.
- As the year and month of introduction or inspection.

Parameter Number	Name	Initial Value	Setting Range	Description
888	Free parameter 1	9999	0 to 9999	Any values can be set. Data is held even
889	Free parameter 2	9999	0 to 9999	if the inverter power is turned off.

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr.77 Parameter write selection.



Pr. 888 and Pr. 889 do not influence the inverter operation.

#### 4.23 Setting from the parameter unit and operation panel

Purpose	Parameter	that should be Set	Refer to Page
Selection of rotation direction by  (RUN) of the operation panel	RUN key rotation direction selection	Pr. 40	256
Switch the display language of the parameter unit	PU display language selection	Pr. 145	256
Use the setting dial of the operation panel like a potentiometer for frequency setting.  Key lock of operation panel	Operation panel operation selection	Pr. 161	257
Change the magnitude of change of frequency setting by the setting dial of the operation panel	Magnitude of frequency change setting	Pr. 295	259
Control of the parameter unit buzzer	PU buzzer control	Pr. 990	260
Adjust LCD contrast of the parameter unit	PU contrast adjustment	Pr. 991	260

#### 4.23.1 RUN key rotation direction selection (Pr. 40)

Used to choose the direction of rotation by operating (RUN) of the operation panel.

Parameter Number	Name	Initial Value	Setting Range	Description
40	RUN key rotation direction	0	0	Forward rotation
	selection		1	Reverse rotation

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

#### 4.23.2 PU display language selection(Pr.145)

You can switch the display language of the parameter unit (FR-PU04/FR-PU07) to another.

Parameter Number	Name	Initial Value	Setting Range	Description
			0	Japanese
	PU display language selection	1	1	English
			2	German
145			3	French
145			4	Spanish
			5	Italian
			6	Swedish
			7	Finnish

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)



#### 4.23.3 Operation panel frequency setting/key lock operation selection (Pr. 161)


The setting dial of the operation panel can be used for setting like a potentiometer. The key operation of the operation panel can be disabled.

Parameter Number	Name	Initial Value	Setting Range	Description	
	Frequency setting/key lock operation selection	0	0	Setting dial frequency setting mode	Key lock mode invalid
161			1	Setting dial potentiometer mode	Rey lock mode invalid
			10	Setting dial frequency setting mode	Key lock mode valid
			11	Setting dial potentiometer mode	Rey lock mode valid

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

#### (1) Using the setting dial like a potentiometer to set the frequency.

Operation example Changing the frequency from 0Hz to 50Hz during operation



## • REMARKS

- If the display changes from flickering "50.00" to "0.00", the setting of Pr. 161 Frequency setting/key lock operation selection may not
- Independently of whether the inverter is running or at a stop, the frequency can be set by merely turning the dial.
- When the frequency is changed, it will be stored in EEPROM as the set frequency after 10s.

#### Disable the setting dial and key operation of the operation panel (Press [MODE] long (2s))

- •Operation using the setting dial and key of the operation panel can be made invalid to prevent parameter change, and unexpected start or frequency setting.
- •Set "10 or 11" in Pr. 161, then press (MODE) for 2s to make the setting dial and key operation invalid.
- •When the setting dial and key operation is made invalid, # [] appears on the operation panel. When the setting dial and key operation is invalid, H [] appears if the setting dial or key operation is performed. (When the setting dial or key operation is not performed for 2s, the monitor display appears.)
- •To make the setting dial and key operation valid again, press (MODE) for 2s.



#### • REMARKS

Even if the setting dial and key operation are disabled, the monitor display and (STOP) are valid.





• Release the operation lock to release the PU stop by key operation.



#### 4.23.4 Magnitude of frequency change setting (Pr. 295)

When setting the set frequency with the setting dial, frequency changes in 0.01Hz increments in the initial status. Setting this parameter increases the magnitude of frequency which changes according to the rotated amount of the setting dial, improving operability.


Parameter Number	Name	Initial Value	Setting Range	Description
			0	Function invalid
	Magnitude of frequency		0.01	The minimum varying width when the set
295		0	0.10	frequency is changed by the setting dial can
	change setting		1.00	be set.
			10.00	DE SEL

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

#### (1) Basic operation

When a value other than "0" is set in Pr. 295, the minimum varying width when the set frequency is changed by the setting dial

For example, when "1.00Hz" is set in Pr. 295, one click (one dial gauge) of the setting dial changes the frequency in increments of 1.00Hz→2.00Hz→3.00Hz.





<sup>\*</sup>One rotation of the setting dial equals to 24 clicks (24 dial gauses).

#### • REMARKS

- · When machine speed display is selected with Pr. 37, the minimum increments of the magnitude of change is determined by Pr.295 as well. Note that the setting value may differ as speed setting changes the set machine speed and converts it to the speed dislay again.
- When the set frequency (speed) is 100 or more, frequency is displayed in 0.1 increments. Therefore, the minimum varying width is 0.1 even when Pr. 295 < 0.1.
- When the machine speed setting is 1000 or more, frequency is displayed in 1 increments. Therefore, the minimum varying width is 1 even when Pr. 295 < 1.



- For Pr. 295, unit is not displayed.
- This parameter is valid only in the set frequency mode. When other frequency-related parameters are set, it is not
- When 10 is set, frequency setting changes in 10Hz increments. Note the excess speed. (in potentiometer mode)

#### 4.23.5 Buzzer control (Pr. 990)

You can make the buzzer "beep" when you press the key of the parameter unit (FR-PU04/FR-PU07).

Parame Number	Name	Initial Value	Setting Range	Description
990	PU buzzer control	1	0	Without buzzer
990	FO buzzer control	ļ.	1	With buzzer

The above parameters can be set when Pr. 160 User group read selection = "0". (Refer to page 177)

#### 4.23.6 PU contrast adjustment (Pr. 991)

Contrast adjustment of the LCD of the parameter unit (FR-PU04/FR-PU07) can be performed. Decreasing the setting value makes contrast light.

Parameter Number	Name	Initial Value	Setting Range	Description
991	PU contrast adjustment	58	0 to 63	0: Light ↓ 63: Dark

The above parameter is displayed as simple mode parameter only when the parameter unit FR-PU04/FR-PU07 is connected.

The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.

The above parameters allow its setting to be changed during operation in any operation mode even if "0" (initial value) is set in Pr. 77 Parameter write selection.



#### 4.24 Parameter clear/ All parameter clear




#### **POINT**

- Set "1" in Pr.CL Parameter clear, ALLC all parameter clear to initialize all parameters. (Parameters are not cleared when "1" is set in Pr. 77Parameter write selection.)
- Refer to the extended parameter list on page 52 for parameters cleared with this operation.

## Display -- Operation – 1. Screen at powering on The monitor display appears. 2. Press $\frac{PU}{FXT}$ to choose the PU operation mode. PRM indication is lit 3. Press (MODE) to choose the parameter setting mode. (The parameter number read previously appears.) Parameter clear 4. Turn until Pr.[[ (R[[[]) appears. All parameter clear **5.** Press (SET) to read the currently set value. " [7] "(initial value) appears. 6. Turn to change it to the set value " /".






Flicker --- Parameter setting complete!!

- to read another parameter.
- Press (SET) to show the setting again.
- Press (SET) twice to show the next parameter.

Setting	Description
0	Not executed.
1	Return parameters to the initial values. (Parameter clear returns all parameters except calibration
'	parameters C1 (Pr. 901) to C7 (Pr. 905) to the initial values.




#### • REMARKS



- [PU] is lit and the monitor (4 digit LED) displays "1". (When Pr. 79 = "0" (initial value))
- 2. Carry out operation from step 6 again.

## 4.25 Initial value change list

Displays and sets the parameters changed from the initial value.



- the parameter setting mode.
  - - Turning sets other parameters.
    - (SET) displays the change list again.



#### **NOTE**

- Calibration parameters (C1 (Pr. 901) to C7 (Pr. 905)) are not displayed even they are changed from the initial settings.
- Only simple mode parameter is displayed when simple mode is set (Pr. 160 = 9999)
- Only user group is displayed when user group is set (Pr. 160 = "1").
- Pr. 160 is displayed independently of whether the setting value is changed or not.
- When parameter setting is changed after creating the initial value change list, the setting will be reflected to the initial value change list next time.




#### Parameters referred to

Pr. 160 User group read selection Refer to page 177 C1 (Pr. 901) AM terminal calibration Refer to page 149 C2(Pr. 902) to C7(Pr. 905) (Frequency setting bias/gain parameter) Refer to page 168

### 4.26 Check and clear of the faults history

#### (1) Check for the faults history



#### (2) Clearing procedure



#### **POINT**

• Set "1" in Er.CL Fault history clear to clear the faults history.

Operation –

 Screen at powering on The monitor display appears.

2. Press (MODE) to choose the parameter setting mode.

3. Turn until  $\mathcal{E}_{\mathcal{L}}\mathcal{L}$  (faults history clear) appears.

4. Press (SET) to read the currently set value. "  $\mathcal{G}$  " (initial value) appears.

5. Turn to change it to the set value " \ \lambda".

6. Press (SET) to set.

Display -



PRM indication is lit.



(The parameter number read previously appears.)









Flicker...Faults history clear complete!!

Turn to read another parameter.

Press (SET) to show the setting again.

Press (SET) twice to show the next parameter.



#### Parameters referred to

Pr. 77 Parameter write selection TE Refer to page 176

# 5 / TROUBLESHOOTING

This chapter provides the "TROUBLESHOOTING" of this product.

Always read the instructions before using the equipment

5.1	Reset method of protective function	266
	List of fault or alarm indications	
5.3	Causes and corrective actions	268
5.4	Correspondences between digital and actual characters	276
	Check first when you have some troubles	

#### Reset method of protective function

When a fault occurs in the inverter, the inverter trips and the PU display automatically changes to any of the following fault or alarm indications.

If the fault does not correspond to any of the following faults or if you have any other problem, please contact your sales representative.

- Retention of fault output signal...When the magnetic contactor (MC) provided on the input side of the inverter is opened when a fault occurs, the inverter's control power will be lost and the fault output will not be
- Fault or alarm indication ..........When a fault or alarm occurs, the operation panel display automatically switches to the fault or alarm indication.
- Resetting method ......When a fault occurs, the inverter output is kept stopped. Unless reset, therefore, the inverter cannot restart. (Refer to page 266)
- When any fault occurs, take the appropriate corrective action, then reset the inverter, and resume operation. Not doing so may lead to the inverter fault and damage.

Inverter fault or alarm indications are roughly divided as below.

- (1) Error message
  - A message regarding operational fault and setting fault by the operation panel and parameter unit (FR-PU04 /FR-PU07) is displayed. The inverter does not trip.
- Warnings
  - The inverter does not trip even when a warning is displayed. However, failure to take appropriate measures will lead to a fault.
- (3) Alarm
  - The inverter does not trip. You can also output an alarm signal by making parameter setting.
- - When a fault occurs, the inverter trips and a fault signal is output.

#### 5.1 Reset method of protective function

#### (1) Resetting the inverter

The inverter can be reset by performing any of the following operations. Note that the internal thermal integrated value of the electronic thermal relay function and the number of retries are cleared (erased) by resetting the inverter. Recover about 1s after reset is cancelled.

Operation 1: ..... Using the operation panel, press (STOP)




to reset the inverter.

(This may only be performed when a fault occurs (Refer to page 271 for fault.))

Operation 2: ...... Switch power off once, then switch it on again.



Operation 3: . . .... Turn on the reset signal (RES) for more than 0.1s. (If the RES signal is kept on, "Err." appears (flickers) to indicate that the inverter is in a reset status.)





## 5.2 List of fault or alarm indications

	Operation F		Name	Refer to Page
	E	E	Faults history	263
sage	HOLd	HOLD	Operation panel lock	268
Error message	Er I to Er 4	Er1 to 4	Parameter write error	268
	Err.	Err.	Inverter reset	268
	0L	OL	Stall prevention (overcurrent)	269
	οL	oL	Stall prevention (overvoltage)	269
sbu	rЬ	RB	Regenerative brake prealarm	270
Warnings	ſΗ	ТН	Electronic thermal relay function prealarm	270
	25	PS	PU stop	269
	חר	MT	Maintenance signal output	270
	Uu	UV	Undervoltage	270
Alarm	En	FN	Fan fault	270
	E.DC 1	E.OC1	Overcurrent trip during acceleration	271
	E.002	E.OC2	Overcurrent trip during constant speed	271
	E.003	E.OC3	Overcurrent trip during deceleration or stop	271
	8.0 <sub>0</sub> 1	E.OV1	Regenerative overvoltage trip during acceleration	271
ıt	8.002	E.OV2	Regenerative overvoltage trip during constant speed	272
Fault	E.O u 3	E.OV3	Regenerative overvoltage trip during deceleration or stop	272
	E.F.H.F	E.THT	Inverter overload trip (electronic thermal relay function)	272
	E.C.H.O.	E.THM	Motor overload trip(electronic thermal relay function)	272
	8.81 n	E.FIN	Fin overheat	273

	Operation P Indicatio		Name	Refer to Page
	ELLE	E.ILF *	Input phase loss	273
	E.0 L F	E.OLT	Stall prevention	273
	Е. ЬЕ	E. BE	Brake transistor alarm detection	273
	E. GF	E.GF	Output side earth(ground) fault overcurrentat start	273
	E. LF	E.LF	Output phase loss	274
	8.0HF	E.OHT	External thermal relay operation	274
	E.DP 1	E.OP1	Communication option fault	274
	€. 1	E. 1	Option fault	274
	E. PE	E.PE	Parameter storage device fault	274
ult	<i>E.P.E.2</i>	E.PE2 *	Internal board fault	275
Fault	E.PUE	E.PUE	PU disconnection	275
	8,-81	E.RET	Retry count excess	275
	E. 67 E. 77 E.CPU	E. 6/ E. 7/ E.CPU	CPU fault	275
	E.I. 0H	E.IOH *	Inrush current limit circuit fault	275
	E.R.I. E	E.AIE *	Analog input fault	276
	E.U56	E. USB *	USB communication fault	276
	E.N&4 to E.N&1	E.MB4 to E.MB7	Brake sequence fault	275
	E. 13	E.13	Internal circuit fault	276

 $<sup>\</sup>ast~$  If a fault occurs when using with the FR-PU04, "Fault 14" is displayed on the FR-PU04.

## 5.3 Causes and corrective actions

#### (1) Error message

A message regarding operational troubles is displayed. Output is not shutoff.

Operation panel indication	HOLD HOLD			
Name	Operation par	nel lock		
Description	Operation lock mode is set. Operation other than (STOP) is made invalid. (Refer to page 258)			
Check point	<del></del>			
Corrective action	Press MODE for	r 2s to release lock.		

Operation panel indication	Er1	Er I		
Name	Write disable	error		
Description	write. 2. Frequency	ted to make parameter setting when <i>Pr. 77 Parameter write selection</i> has been set to disable parameter jump setting range overlapped.  I inverter cannot make normal communication.		
<ol> <li>Check the setting of <i>Pr. 77 Parameter write selection.</i> (<i>Refer to page 176</i>).</li> <li>Check point</li> <li>Check the settings of <i>Pr. 31 to Pr. 36 (frequency jump).</i> (<i>Refer to page 87</i>)</li> <li>Check the connection of the PU and inverter.</li> </ol>				

Operation panel indication	Er2	Er2					
Name	Write error du	Write error during operation					
Description	When parameter write was performed during operation with a value other than "2" (writing is enabled independently						
Description	of operation status in any operation mode) is set in Pr. 77 and the STF (STR) is on.						
Chack point	1. Check the Pr. 77 setting. (Refer to page 176).						
Check point	Check point  2. Check that the inverter is not operating.						
Corrective action	1. Set "2" in Pa	r. 77.					
Corrective action	2. After stopping operation, make parameter setting.						

Operation panel indication	Er3	Er 3			
Name	Calibration error				
Description	Description Analog input bias and gain calibration values are too close.				
Check point Check the settings of C3, C4, C6 and C7 (calibration functions). (Refer to page 168).					

Operation panel	Er4	F c 4					
indication	L14	C C 7					
Name	Mode designa	tion error					
Description	<b>Description</b> You attempted to make parameter setting in the NET operation mode when <i>Pr. 77</i> is not 2.						
Check point	1. Check that operation mode is PU operation mode.						
Check point	2. Check the Pr. 77 setting. (Refer to page 176).						
Corrective action	1. After setting the operation mode to the "PU operation mode", make parameter setting. (Refer to page 180)						
Corrective action	2. After setting	"2" in Pr. 77, make parameter setting.					

Operation panel indication	Err.	Err.			
Name	Inverter reset				
Description	Executing reset using RES signal, or reset command from communication or PU				
Description	Displays at powering off.				
Corrective action • Turn off the reset command					



#### (2) Warnings

When a warning occurs, the output is not shut off.

Operation panel	OL	<u> </u>	FR-PU04	OL		
indication		U L	FR-PU07	OL		
Name	Stall prevention	Stall prevention (overcurrent)				
	During acceleration	inverter exceeds the function stops the ifrom resulting in overation level, this	e stall prever ncrease in fre rercurrent trip s function incr	torque when <i>Pr. 277 Stall prevention current switchover</i> = "1") of the ation operation level ( <i>Pr. 22 Stall prevention operation level</i> , etc.), this equency until the overload current decreases to prevent the inverter. When the overload current has reduced below stall prevention reases the frequency again.		
Description	During constant- speed operation	inverter exceeds the function reduces from in overcurrent trip.	torque when <i>Pr. 277 Stall prevention current switchover</i> = "1") of the ation operation level ( <i>Pr. 22 Stall prevention operation level</i> , etc.), this the overload current decreases to prevent the inverter from resulting erload current has reduced below stall prevention operation level, this <i>y</i> up to the set value.			
	During deceleration	When the output current (output torque when <i>Pr. 277 Stall prevention current switchover</i> = "1") of the inverter exceeds the stall prevention operation level ( <i>Pr. 22 Stall prevention operation level</i> , etc.), this function stops the decrease in frequency until the overload current decreases to prevent the inverter from resulting in overcurrent trip. When the overload current has decreased below stall prevention operation level, this function decreases the frequency again.				
	<ol> <li>Check that the <i>Pr. 0 Torque boost</i> setting is not too large.</li> <li>Check that the <i>Pr. 7 Acceleration time</i> and <i>Pr. 8 Deceleration time</i> settings are not too small.</li> </ol>					
Check point	<ul> <li>3. Check that the load is not too heavy.</li> <li>4. Are there any failure in peripheral devices?</li> <li>5. Check that the <i>Pr. 13 Starting frequency</i> is not too large.</li> <li>6. Check that the <i>Pr. 22 Stall prevention operation level</i> is appropriate</li> </ul>					
Corrective action	<ol> <li>Check that the <i>Pr. 22 Stall prevention operation level</i> is appropriate</li> <li>Increase or decrease the <i>Pr. 0 Torque boost</i> setting 1% by 1% and check the motor status. (<i>Refer to page 75</i>)</li> <li>Set a larger value in <i>Pr. 7 Acceleration time</i> and <i>Pr. 8 Deceleration time</i>. (<i>Refer to page 99</i>)</li> <li>Reduce the load weight.</li> <li>Try advanced magnetic flux vector control and general-purpose magnetic flux vector control.</li> <li>Change the <i>Pr. 14 Load pattern selection</i> setting.</li> <li>Set stall prevention operation current in <i>Pr. 22 Stall prevention operation level</i>. (The initial value is 150%.) The acceleration/deceleration time may change. Increase the stall prevention operation level with <i>Pr. 22 Stall prevention operation level</i>, or disable stall prevention with <i>Pr. 156 Stall prevention operation selection</i>. (Operation at OL occurrence can be selected using <i>Pr. 156</i>.)</li> </ol>					

Operation panel	-1	FR-PU04	FR-PU04		
indication	oL	OL	FR-PU07	oL	
Name	Stall prevention	evention (overvoltage)			
Description	During deceleration	<ul> <li>If the regenerative energy of the motor becomes excessive to exceed the regenerative energy consumption capability, this function stops the decrease in frequency to prevent overvoltage trip. As soon as the regenerative energy has reduced, deceleration resumes.</li> <li>If the regenerative energy of the motor becomes excessive when regeneration avoidance function is selected (<i>Pr.</i> 882 =1), this function increases the speed to prevent overvoltage trip. (<i>Refer to page</i> 245).</li> </ul>			
<ul> <li>Check point</li> <li>Check for sudden speed reduction.</li> <li>Check that regeneration avoidance function (Pr. 882, Pr. 883, Pr. 885, Pr. 886) is used. (R.</li> </ul>			Pr. 882, Pr. 883, Pr. 885, Pr. 886) is used. (Refer to page 245).		
Corrective action	The deceleration time may change. Increase the deceleration time using <i>Pr. 8 Deceleration time</i> .				

Operation panel indication	PS	P5	FR-PU04 FR-PU07	PS		
Name	PU stop					
Description	Stop with STOP RESE	Stop with STOP of the PU is set in <i>Pr. 75 Reset selection/disconnected PU detection/PU stop selection</i> . (For <i>Pr. 75 refer to page 173</i> .)				
Check point	Check for a stop made by pressing (STOP) of the operation panel.					
Corrective action	Turn the start signal off and release with $\frac{PU}{EXT}$ .					

Operation panel	20	1	FR-PU04	nn e			
indication	RB	70	FR-PU07	RB			
Name	Regenerative	brake prealarm					
	Appears if the	regenerative brak	e duty reaches	or exceeds 85% of the Pr. 70 Special regenerative brake duty value.			
	When the setting of $Pr. 70$ Special regenerative brake duty is the initial value ( $Pr. 70 = "0"$ ), this warning does not occur. If						
December	the regenerative brake duty reaches 100%, a regenerative overvoltage (E. OV_) occurs.						
Description	The RBP signal can be simultaneously output with the [RB] display. For the terminal used for the RBP signal output,						
	assign the function by setting "7 (positive logic) or 107 (negative logic)" in any of Pr. 190 to Pr. 192 (output terminal						
	function selection). (Refer to page 134).						
Chack point	Check that the brake resistor duty is not high.						
Check point	2. Check that the Pr. 30 Regenerative function selection and Pr. 70 Special regenerative brake duty settings are correct.						
Corrective action	Increase the deceleration time.						
Corrective action	2. Check that	the Pr. 30 Regenera	ative function sele	ection and Pr. 70 Special regenerative brake duty settings.			

Operation panel	TU	T H	FR-PU04	TU			
indication	TH	' '	FR-PU07	ТН			
Name	Electronic the	rmal relay function	prealarm				
	Appears if the	cumulative value	of the <i>Pr. 9 Elec</i>	tronic thermal O/L relay reaches or exceeds 85% of the preset level. If			
	it reaches 100	it reaches 100% of the Pr. 9 Electronic thermal O/L relay setting, a motor overload trip (E. THM) occurs.					
<b>Description</b> The THP signal can be simultaneously output with the [TH] display. For the terminal used for THP signal o							
	assign the function by setting "8 (positive logic) or 108 (negative logic)" in any of Pr. 190 to Pr. 192 (output terminal						
	function selection	on). (Refer to page	134).				
Check point	Check for large load or sudden acceleration.						
Check point	2. Is the Pr. 9 Electronic thermal O/L relay setting is appropriate? (Refer to page 106)						
Corrective action  1. Reduce the load and frequency of operation.							
Confective action	2. Set an appr	opriate value in Pi	r. 9 Electronic the	ermal O/L relay. (Refer to page 106)			

Operation panel	МТ		FR-PU04				
indication	IVI I	111	FR-PU07	MT			
Name	Maintenance s	signal output					
	Indicates that	Indicates that the cumulative energization time of the inverter has reached a given time.					
Description	When the setting of Pr. 504 Maintenance timer alarm output set time is the initial value (Pr. 504 = "9999"), this warning						
	does not occur.						
Chook point	The Pr. 503 Maintenance timer setting is larger than the Pr. 504 Maintenance timer alarm output set time setting						
Check point	page 252).						
Corrective action	Setting "0" in I	Pr. 503 Maintenance	timer erases th	ne signal.			

Operation panel	UV	11	FR-PU04			
indication	UV	UU	FR-PU07	<del></del>		
Name	Undervoltage					
Description	If the power supply voltage of the inverter decreases, the control circuit will not perform normal functions. In addition, the motor torque will be insufficient and/or heat generation will increase. To prevent this, if the power supply voltage decreases below about 230VAC, this function stops the inverter output and displays !!u .  An alarm is reset when the voltage returns to normal.					
Check point	Check that the power supply voltage is normal.					
Corrective action	Check the pov	ver supply system e	equipment suc	h as power supply.		

#### (3) Alarm

When an alarm occurs, the output is not shut off. You can also output an alarm signal by making parameter setting. (Set "98" in any of *Pr. 190 to Pr. 192 (output terminal function selection). Refer to page 134* ).

Operation panel	FN	<b>C</b> _	FR-PU04	FN			
indication	FIN	i- n	FR-PU07	FN			
Name	Fan fault	Fan fault					
Description		For the inverter that contains a cooling fan, $\digamma_{\Box}$ appears on the operation panel when the cooling fan stops due to an alarm or different operation from the setting of $Pr. 244$ Cooling fan operation selection.					
Check point	Check the cooling fan for an alarm.						
Corrective action	Check for fan	Check for fan alarm. Please contact your sales representative.					



#### (4) Fault

When a fault occurs, the inverter trips and a fault signal is output.

Operation panel	E.OC1	E.0.C	1	FR-PU04	OC During Acc	
indication	E.0C1	[.U.L	1	FR-PU07	OC During Acc	
Name	Overcurrent tr	ip during acce	eleratio	on		
Description		When the inverter output current reaches or exceeds approximately 230% of the rated current during acceleration, the protective circuit is activated and the inverter trips.				
Check point	<ol> <li>Check for sudden acceleration.</li> <li>Check that the downward acceleration time is not long in vertical lift application.</li> <li>Check for output short-circuit/ground fault.</li> <li>Check that stall prevention operation is appropriate.</li> <li>Check that regeneration is not performed frequently. (Check that the output voltage becomes larger than the V/F reference value at regeneration and overcurrent occurs due to the high voltage.)</li> </ol>					
Corrective action	Increase the acceleration time. (Shorten the downward acceleration time in vertical lift application.     When "E.OC1" is always lit at starting, disconnect the motor once and start the inverter.  If "F.OC1" is still lit, contact your sales representative.					

Operation panel indication	E.OC2	5.00.3	FR-PU04 FR-PU07	Stedy Spd OC			
Name	Overcurrent tr	ip during constant s	peed				
Description		When the inverter output current reaches or exceeds approximately 230% of the rated current during constant speed operation, the protective circuit is activated and the inverter trips.					
Check point	Check for sudden load change.     Check for output short-circuit/ground fault.     Check that stall prevention operation is appropriate.						
Corrective action	2. Check the v	1. Keep load stable. 2. Check the wiring to make sure that output short circuit/ground fault does not occur. 3. Perform stall prevention operation appropriately. ( <i>Refer to page 82</i> ).					

Operation panel	E.OC3	E.003	FR-PU04	OC During Dog			
indication	E.UC3	C.U.L. 3	FR-PU07	OC During Dec			
Name	Overcurrent tr	ip during deceleration	on or stop				
Description	When the inve	rter output current i	reaches or exc	ceeds approximately 230% of the rated inverter current during			
Description	deceleration (	other than accelerat	tion or constar	nt speed), the protective circuit is activated and the inverter trips.			
	1. Check for s	udden speed reduc	tion.				
Check point	2. Check for output short-circuit/ground fault.						
Check point	3. Check for to	oo fast operation of	the motor's me	echanical brake.			
	4. Check that stall prevention operation is appropriate.						
	1. Increase the	Increase the deceleration time.					
Corrective action  2. Check the wiring to make sure that output short circuit/ground fault does not occur.  3. Check the mechanical brake operation.							
							4. Perform sta

Operation panel indication	E.OV1	E.O	1	FR-PU04 FR-PU07	OV During Acc	
Name	Regenerative overvoltage trip during acceleration				on	
	If regenerative	energy caus	es the	inverter's inte	rnal main circuit DC voltage to reach or exceed the specified value,	
Description	the protective	the protective circuit is activated and the inverter trips. The circuit may also be activated by a surge voltage produced				
in the power supply system.						
Check point	Check for too slow acceleration. (e.g. during downward acceleration in vertical lift load)					
Check point	2. Check that the Pr. 22 Stall prevention operation level is not lower than the no load current.					
	1. • Decrease the acceleration time.					
Corrective action	<ul> <li>Check that</li> </ul>	at regeneration	n avoi	dance function	n (Pr. 882, Pr. 883, Pr. 885, Pr. 886) is used. (Refer to page 245).	
	2. Set a value	larger than th	e no lo	oad current in	Pr. 22 Stall prevention operation level.	

Operation panel	E.OV2	8.002	FR-PU04	Stady and OV		
indication	E.UV2	C.UUC	FR-PU07	Stedy Spd OV		
Name	Regenerative	overvoltage trip dur	ing constant s	peed		
	If regenerative	energy causes the	inverter's inte	rnal main circuit DC voltage to reach or exceed the specified value,		
Description	the protective	circuit is activated t	o stop the inve	erter output. The circuit may also be activated by a surge voltage		
	produced in the power supply system.					
Check point	1. Check for sudden load change.					
Check point	2. Check that the Pr. 22 Stall prevention operation level is not lower than the no load current.					
	1. • Keep load stable.					
Corrective action	• Check that regeneration avoidance function (Pr. 882, Pr. 883, Pr. 885, Pr. 886) is used. (Refer to page 245).					
Corrective action	<ul> <li>Use the b</li> </ul>	rake resistor, brake	unit or power	regeneration common converter (FR-CV) as required.		
	2. Set a value	larger than the no le	oad current in	Pr. 22 Stall prevention operation level.		

Operation panel	E.OV3	E.O. 3	FR-PU04	OV During Doo			
indication	E.0V3	C.UU3	FR-PU07	OV During Dec			
Name	Regenerative	overvoltage trip dur	ing deceleration	on or stop			
	If regenerative	energy causes the	inverter's inte	rnal main circuit DC voltage to reach or exceed the specified value,			
Description	the protective	circuit is activated to	o stop the inve	erter output. The circuit may also be activated by a surge voltage			
	produced in th	produced in the power supply system.					
Check point	Check for sud	Check for sudden speed reduction.					
	Increase the deceleration time. (Set the deceleration time which matches the moment of inertia of the load)						
Corrective action	Longer the brake cycle.						
Corrective action	• Use regeneration avoidance function (Pr. 882, Pr. 883, Pr. 885, Pr. 886). (Refer to page 245).						
	Use the bra	ke resistor, brake ur	nit or power re	generation common converter (FR-CV) as required.			

Operation panel	E.THT	ECHC	FR-PU04	Inv. Overload			
indication	E.1111		FR-PU07	inv. Overload			
Name	Inverter overlo	oad trip (electronic th	nermal relay fu	unction)			
	If the tempera	ture of the output tra	ansistor eleme	nt exceeds the protection level under the condition that a current not			
Description	less than the rated inverter current flows and overcurrent trip does not occur (230% or less), the electronic thermal						
	relay activates to stop the inverter output. (Overload capacity 150% 60s, 200% 3s)						
Check point	1. Check the r	1. Check the motor for use under overload.					
Check point	2. Check for too high ambient temperature.						
Corrective action	1. Reduce the load weight.						
Corrective action	2. Set the amb	pient temperature to	within the spe	ecifications.			

Operation panel indication	E.THM	E.C HO	FR-PU04 FR-PU07	Motor Ovrload					
Name	Motor overloa	Motor overload trip (electronic thermal relay function) *1							
Description	The electronic thermal relay function in the inverter detects motor overheat due to overload or reduced cooling capability during constant-speed operation and pre-alarm (TH display) is output when the I <sup>2</sup> t value reaches 85% of the <i>Pr. 9 Electronic thermal O/L relay</i> setting and the protection circuit is activated to stop the inverter output when the I <sup>2</sup> t value reaches the specified value. When running a special motor such as a multi-pole motor or multiple motors, provide a thermal relay on the inverter output side since such motor(s) cannot be protected by the electronic thermal relay function.								
Check point	<ol> <li>Check the motor for use under overload.</li> <li>Check that the setting of <i>Pr. 71 Applied motor</i> for motor selection is correct. (<i>Refer to page 108</i>).</li> <li>Check that stall prevention operation setting is correct.</li> </ol>								
Corrective action		ant-torque motor, se		i-torque motor in <i>Pr. 71 Applied motor</i> . is correct. ( <i>Refer to page 82</i> ).					

<sup>\*1</sup> Resetting the inverter initializes the internal thermal integrated data of the electronic thermal relay function.



Operation panel	E.FIN	FFI	_	FR-PU04	H/Sink O/Temp				
indication	E.FIN	<u></u>	П	FR-PU07	H/Silik O/Temp				
Name	Fin overheat	Fin overheat							
	If the heatsink	overheats,	the temp	perature sens	or is actuated and the inverter trips.				
	The FIN signa	can be out	out whe	n the tempera	ture becomes approximately 85% of the heatsink overheat protection				
Description	operation temp	operation temperature.							
	For the terminal used for the FIN signal output, assign the function by setting "26 (positive logic) or 126 (negative								
	logic)" in any o	of <i>Pr. 190 to 1</i>	Pr. 192 (d	output terminal	function selection). (Refer to page 134).				
	1. Check for to	o high amb	ient tem	perature.					
Check point	2. Check for he	2. Check for heatsink clogging.							
	3. Check that the cooling fan is not stopped (Check that $\mathcal{F}_{\mathbf{n}}$ is not displayed on the operation panel).								
	Set the ambient temperature to within the specifications.								
Corrective action	2. Clean the h	eatsink.							
	3. Replace the	cooling fan							

Operation panel	E.ILF	FIIF	FR-PU04	Fault 14				
indication	E.ILF		FR-PU07	Input phase loss				
Name	Input phase lo	Input phase loss						
Description	This fault is ou	This fault is output when function valid setting (=1) is set in Pr. 872 Input phase loss protection selection and one phase						
Description	of the three phase power input is lost. (Refer to page 161).							
Check point	Check for a break in the cable for the three-phase power supply input.							
	<ul> <li>Wire the cal</li> </ul>	Wire the cables properly.						
Corrective action • Repair a brake portion in the cable.								
	Check the Pr. 872 Input phase loss protection selection setting.							

Operation panel indication	E.OLT	E.OLT	FR-PU04 FR-PU07	Stll Prev STP (OL shown during stall prevention operation)					
Name	Stall prevention	Stall prevention							
Description		If the output frequency has fallen to 1Hz by stall prevention operation and remains for 3s, a fault (E.OLT) appears and trips the inverter. OL appears while stall prevention is being activated.							
Check point	Check the r	Check the motor for use under overload. (Refer to page 83).							
Corrective action	Reduce the	load weight. Check	the Pr. 22 Stal	l prevention operation level setting.					

Operation panel indication	E.BE	E.	68	FR-PU04 FR-PU07	Br. Cct. Fault			
Name	Brake transisto	Brake transistor alarm detection						
Description	transistor alarr	When a brake transistor alarm has occurred due to the large regenerative energy from the motor etc., the brake transistor alarm is detected and the inverter trips.  In this case, the inverter must be powered off immediately.						
Check point	<ul><li>Reduce the load inertia.</li><li>Check that the frequency of using the brake is proper.</li></ul>							
Corrective action	Replace the in	Replace the inverter.						

Operation panel	F 6F		GF	FR-PU04	Ground Fault			
indication	E.GF	<b>二</b> .	FR-PU07 Ground Fault	Ground Fault				
Name	Output side ea	arth(grou	ınd) fault ov	ercurrent at s	tart			
Description	the inverter's o	The inverter trips if an earth (ground) fault overcurrent flows at start due to an earth (ground) fault that occurred on the inverter's output side (load side). Whether this protective function is used or not is set with <i>Pr. 249 Earth (ground) fault detection at start</i> .						
Check point	Check for a ground fault in the motor and connection cable.							
Corrective action	Remedy the g	Remedy the ground fault portion.						

Operation panel indication	E.LF	Ε.	LF	FR-PU04 FR-PU07	E.LF				
Name	Output phase	Output phase loss							
Description		This function stops the inverter output if one of the three phases (U, V, W) on the inverter's output side (load side) is lost. Whether the protective function is used or not is set with <i>Pr. 251 Output phase loss protection selection</i> .							
Check point		<ul> <li>Check the wiring. (Check that the motor is normal.)</li> <li>Check that the capacity of the motor used is not smaller than that of the inverter.</li> </ul>							
Corrective action	<ul> <li>Wire the cal</li> <li>Check the F</li> </ul>	•	. ,	loss protection	selection Settling				

Operation panel	E.OHT	ESHS	FR-PU04	OH Fault						
indication	L.0111	L.L///	FR-PU07	Off Fault						
Name	External them	External thermal relay operation								
	If the external	thermal relay provid	ed for motor of	overheat protection or the internally mounted temperature relay in the						
Description	motor, etc. sw	motor, etc. switches on (contacts open), the inverter output is stopped.								
Description	Functions when "7" (OH signal) is set to any of <i>Pr. 178 to Pr. 184 (input terminal function selection)</i> .  This protective function does not function in the initial status (OH signal is not assigned).									
Check point	<ul> <li>Check for m</li> </ul>	Check for motor overheating.								
Check point	• Check that the value of 7 (OH signal) is set correctly in any of <i>Pr. 178 to Pr. 184 (input terminal function selection)</i> .									
Corrective action	Reduce the load and frequency of operation									
Corrective action	Even if the	relay contacts are re	eset automation	cally, the inverter will not restart unless it is reset.						

Operation panel indication	E.OP1	<i>E.DP</i>	1	FR-PU04 FR-PU07	Option slot alarm 1				
Name	Communication	Communication option fault							
Description	Stops the inve	Stops the inverter output when a communication line fault occurs in the communication option.							
		Check for a wrong option function setting and operation.      Check that the plug-in option unit is plugged into the connector securely.							
Check point		3. Check for a break in the communication cable.  4. Check that the terminating resistor is fitted properly.							
Corrective action	4. Check that the terminating resistor is fitted properly.  1. Check the option function setting, etc.  2. Connect the plug-in option securely.  3. Check the connection of communication cable.  4. Connect the terminating resistor correctly.								

Operation panel	E. 1	C	,	FR-PU04	Fault 1				
indication	E. 1	C.	•	FR-PU07	rault 1				
Name	Option fault								
	Stops the inve	Stops the inverter output if a contact fault or the like of the connector between the inverter and communication option							
Description	occurs.	occurs.							
	Appears when	Appears when the switch for the manufacturer setting of the plug-in option is changed.							
	Check that the plug-in option unit is plugged into the connector securely.								
Check point	2. Check for e	2. Check for excess electrical noises around the inverter.							
	3. Check the switch position for the manufacturer setting of the plug-in option.								
	1. Connect the	1. Connect the plug-in option securely.							
	2. Take measu	2. Take measures against noises if there are devices producing excess electrical noises around the inverter.							
Corrective action	If the problem still persists after taking the above measure, please contact your sales representative.								
	3. Return the switch position for the manufacturer setting of the plug-in option to the initial status. ( Refer to the instruction manual of each option)								

Operation panel	E.PE	_	PF	FR-PU04	Corrupt Memry				
indication	E.PE	ij	- <u>-</u>	FR-PU07	Corrupt Meinry				
Name	Parameter sto	Parameter storage device fault (control circuit board)							
Description	Appears when	Appears when a fault occurred in the stored parameters. (EEPROM fault)							
Check point	Check for too	Check for too many number of parameter write times.							
	Please contac	Please contact your sales representative.							
Corrective action	When performing parameter write frequently for communication purposes, set "1" in Pr. 342 to enable RAM write. Note								
	that powering off returns the inverter to the status before RAM write.								



Operation Panel	E.PE2	5.99.3	FR-PU04					
Indication	E.PEZ	c.r c c	FR-PU07	PR storage alarm				
Name	Internal board	Internal board fault						
Description	When a comb	When a combination of control board and main circuit board is wrong, the inverter is tripped.						
Check point	_							
Corrective action	Please contact your sales representative.							
Corrective action	(For parts replacement, consult the nearest Mitsubishi FA Center.)							

Operation panel	E.PUE	<i>E.P.U.E</i>	FR-PU04	PU Leave Out
indication	E.PUE	c.r u c	FR-PU07	PO Leave Out
Name	PU disconnec	tion		
Description	parameter up to stop selection.  • This function permissible during the Formula change).  • This function	unit is disconnected, ction.  In stops the inverter number of retries was 485-485 communication also stops the inverted in also stops the inverted.	when "2", "3" output when othen a value of ion with the Pierter output if	nunication between the inverter and PU is suspended, e.g. the "16" or "17" was set in <i>Pr. 75 Reset selection/disconnected PU detection/</i> communication errors occurred consecutively for more than ther than "9999" is set in <i>Pr. 121 Number of PU communication retries</i> U connector (use <i>Pr. 502 Stop mode selection at communication error</i> to communication is broken within the period of time set in <i>Pr. 122 PU</i> S-485 communication with the PU connector.
Check point		the parameter unit ( $Pr. 75$ setting.	FR-PU04/FR-	PU07) is fitted tightly.
Corrective action	Connect the p	arameter unit (FR-F	U04/FR-PU07	7) securely.

Operation panel indication	E.RET	E E.T	FR-PU04 FR-PU07	Retry No Over				
Name	Retry count ex	Retry count excess						
Description	If operation cannot be resumed properly within the number of retries set, this function trips the inverter.  Functions only when <i>Pr. 67 Number of retries at fault occurrence</i> is set.  When the initial value ( <i>Pr. 67</i> = "0") is set, this protective function does not function.							
Check point	Find the cause of fault occurrence.							
Corrective action	Eliminate the	cause of the error pr	eceding this e	error indication.				

	E. 6	Ε.	8		Fault 6				
Operation panel indication	E. 7	wi	ت-	FR-PU04 FR-PU07	Fault 7				
	E.CPU	E.C	70		CPU Fault				
Name	CPU fault								
Description	Stops the inverter output if the communication fault of the built-in CPU occurs.								
Check point		Check for devices producing excess electrical noises around the inverter.							
Corrective action	Take measures against noises if there are devices producing excess electrical noises around the inverter.								
Corrective action	<ul> <li>Please cont</li> </ul>	Please contact your sales representative.							

Operation panel indication	E.MB4 to 7	E.N&Y to	FR-PU04 FR-PU07	E.MB4 Fault to E.MB7 Fault				
Name	Brake sequen	Brake sequence fault						
Description	<ul> <li>The inverter output is stopped when a sequence error occurs during use of the brake sequence function (Pr. 278 Pr. 283). This protective function does not function in the initial status. (Refer to page 124).</li> </ul>							
Check point	,	Find the cause of alarm occurrence.						
Corrective action	Check the set	parameters and per	form wiring p	roperly.				

Operation panel	E.IOH	E.I. O.H.	FR-PU04	Fault 14				
indication	E.IOH		FR-PU07	Inrush overheat				
Name	Inrush current	Inrush current limit circuit fault						
Description	This function is activated when the resistor of the inrush current limit circuit overheats. The inrush current limit circuit							
Description	fault							
Check point	Check that frequent power ON/OFF is not repeated.							
Corrective action	Configure a circuit where frequent power ON/OFF is not repeated.							
Corrective action	If the problem still persists after taking the above measure, please contact your sales representative.							

## 7

Operation panel	E.AIE	E.B.I. E	FR-PU04	Fault 14			
indication	E.AIE	C.71 C	FR-PU07	Analog in error			
Name	Analog input fault						
Description	Appears when 30mA or more is input or a voltage (7.5V or more) is input with the terminal 4 set to current input.						
Check point	Check the setting of Pr. 267 Terminal 4 input selection and voltage/current input switch. (Refer to page 165).						
Corrective action	Either give a frequency command by current input or set Pr. 267 Terminal 4 input selection, and voltage/current input						
Corrective action	switch to voltage input.						

Operation panel	EUSB	8.856	FR-PU04	Fault 14				
indication	E.USB	C.U D O	FR-PU07	USB comm error				
Name	USB commun	ication fault						
Description	When communication has broken during the time set in Pr. 548 USB communication check time interval							
Description	stops the inverter output.							
Check point	Check the USB communication cable.							
	Check the Pr. 548 USB communication check time interval setting.							
Corrective action	Check the USB communication cable.							
Corrective action	• Increase the <i>Pr. 548 USB communication check time interval</i> setting. Or, change the setting to 9999. ( <i>Refer to page</i>							
	230).							

Operation panel indication	E.13	€.	13	FR-PU04 FR-PU07	Fault 13		
Name	Internal circuit fault						
Description	Appears wher	Appears when an internal circuit fault occurred.					
Corrective action	Please contac	t your sal	es represe	ntative.			



#### NOTE

- If protective functions of E.ILF, E.AIE, E.USB, E.IOH, E.PE2 are activated when using the FR-PU04, "Fault 14" is displayed.
  - Also when the faults history is checked on the FR-PU04, the display is "E.14".
- If faults other than the above appear, contact your sales representative.

## 5.4 Correspondences between digital and actual characters

There are the following correspondences between the actual alphanumeric characters and the digital characters displayed on the operation panel:

Actual	Digital
0	$[\bar{D}]$
1	<b>7</b>
2	<u></u>
3	3
4	<b>'-</b> /
5	5
6	E
7	7
8	$\boldsymbol{\varnothing}$
9	9

Actual	Digital
A	
В	
C	<u>[</u>
D	<u></u> /
E	E
F	F
G	
Н	
J	
L	

Actual	Digital
M N O o	
P	



#### 5.5 Check first when you have some troubles



#### **POINT**

If the cause is still unknown after every check, it is recommended to initialize the parameters (initial value) then reset the required parameter values and check again.

#### 5.5.1 Motor will not start

1) Check the Pr. 0 Torque boost setting if V/F control is exercised. (Refer to page 75)

#### 2) Check the main circuit.

- Check that a proper power supply voltage is applied. (Operation panel display is provided.)
- Check that the motor is connected properly.
- Check that the jumper across P/+-P1 is connected.

#### 3) Check the input signals

- Check that the start signal is input.
- Check that both the forward and reverse rotation start signals are not input simultaneously.
- Check that the frequency setting signal is not zero. (When the frequency command is 0Hz and the start command is entered, RUN LED of the operation panel flickers.)
- Check that the AU signal is on when terminal 4 is used for frequency setting.
- Check that the output stop signal (MRS) or reset signal (RES) is not on.
- Check that the sink or source jumper connector is fitted securely. (Refer to page 22)

#### 4) Check the parameter settings

- Check that Pr. 78 Reverse rotation prevention selection is not set.
- Check that the Pr. 79 Operation mode selection setting is correct.
- Check that the bias and gain (calibration parameter C2 to C7) settings are correct.
- Check that the starting frequency Pr. 13 Starting frequency setting is not greater than the running frequency.
- Check that frequency settings of each running frequency (such as multi-speed operation) are not zero. Check that especially the maximum frequency Pr. 1 Maximum frequency is not zero.
- Check that the Pr. 15 Jog frequency setting is not lower than the Pr. 13 Starting frequency value.
- Learning Check that the operation location by *Pr. 550* and *Pr. 551* is appropriate. (Example: write from the operation panel is disabled when USB is connected)
  - (Refer to page 256).

#### 5) Inspection of load

- Check that the load is not too heavy.
- Check that the shaft is not locked.

#### 6) Others

Check that the operation panel display does not show a fault (e.g. E.OC1).

#### 5.5.2 Motor generates abnormal noise

No carrier frequency noises (metallic noises) are generated.

Soft-PWM control to change the motor tone into an unoffending complex tone is factory-set to valid by *Pr. 72 PWM frequency selection*.

Adjust Pr. 72 PWM frequency selection to change the motor tone.

- Check for any mechanical looseness.

Contact the motor manufacturer.

5.5.3	Motor generates heat abnormally	
	Is the fan for the motor is running? (Check for dust accumulated.)  Check that the load is not too heavy. Lighten the load.  Are the inverter output voltages (U, V, W) balanced?  Check that the <i>Pr. 0 Torque boost</i> setting is correct.  Was the motor type set? Check the setting of <i>Pr. 71 Applied motor</i> .  When using any other manufacturer's motor, perform offline auto tuning. ( <i>Refer to page 110</i> .)	
5.5.4	Motor rotates in opposite direction	
	Check that the phase sequence of output terminals U, V and W is correct.  Check that the start signals (forward rotation, reverse rotation) are connected properly. ( <i>Refer to page 19</i> )  Check that the <i>Pr. 40 RUN key rotation direction selection</i> setting is correct. ( <i>Refer to page 256</i> ).	
5.5.5	Speed greatly differs from the setting	
	• Check that the frequency setting signal is correct. (Measure the input signal level.) • Check that the <i>Pr. 1, Pr. 2, Pr. 19, Pr. 245, calibration parameter Pr. 125, Pr. 126, C2 to C7</i> settings are correct. • Check that the input signal lines are not affected by external noise. (use shielded cables) • Check that the load is not too heavy. • Check that the <i>Pr. 31</i> to <i>Pr. 36</i> ( <i>frequency jump</i> ) settings are correct.	
5.5.6	Acceleration/deceleration is not smooth	
	Check that the acceleration and deceleration time settings are not too short.  Check that the load is not too heavy.  Check that the torque boost ( <i>Pr. 0, Pr. 46</i> ) setting is not too large to activate the stall function under V/F control.	
5.5.7	Motor current is large	
	Check that the load is not too heavy.  Check that the <i>Pr. 0 Torque boost</i> setting is correct.  Check that the <i>Pr. 3 Base frequency</i> setting is correct.  Check that the <i>Pr. 19 Base frequency voltage</i> setting is correct.  Check that the <i>Pr. 14 Load pattern selection</i> setting is correct.	
5.5.8	Speed does not increase	
	Check that the <i>Pr. 1 Maximum frequency</i> setting is correct. (If you want to run the motor at 120Hz or more, set <i>Ph. High speed maximum frequency</i> . ( <i>Refer to page 86</i> ).  Check that the load is not too heavy. (In aditators, etc., load may become heavier in winter.)	r. 18

— Check that the torque boost (Pr. 0, Pr. 46) setting is not too large to activate the stall function under V/F control.

— Check that the brake resistor is not connected to terminals P/+-P1 or P1-PR accidentally.



#### 5.5.9 Speed varies during operation

When slip compensation is set under general-purpose magnetic flux vector control, or advanced magnetic flux vector control is exercised, the output frequency varies with load fluctuation between 0 and 2Hz. This is a normal operation and is not a fault.

#### 1) Inspection of load

Check that the load is not varying.

#### 2) Check the input signals

- Check that the frequency setting signal is not varying.
- Check that the frequency setting signal is not affected by noise. Set filter to the analog input terminal using Pr. 74
   Input filter time constant.
- Check for a malfunction due to undesirable currents when the transistor output unit is connected. (Refer to page 23)

#### 3) Others

- Check that the value of Pr. 80 Motor capacity and Pr. 81 Number of motor poles are correct to the inverter capacity and motor capacity under advanced magnetic flux vector control and general-purpose magnetic flux vector control.
- Check that the wiring length is not exceeding 30m when advanced magnetic flux vector control or general-purpose magnetic flux vector control is exercised. Perform offline auto tuning. (Refer to page 110).
- Check that the wiring length is not too long for V/F control.
- Change the Pr. 19 Base frequency voltage setting (about 3%) under V/F control.

#### 5.5.10 Operation mode is not changed properly

If the operation mode does not change correctly, check the following:

1) External input signal

Check that the STF or STR signal is off. When it is on, the operation mode cannot be changed.

#### 2) Parameter setting

Check the Pr. 79 setting.

When the Pr.~79~Operation~mode~selection setting is "0" (initial value), the inverter is placed in the external operation mode at input power-on. At this time, press  $\frac{PU}{EXT}$  on the operation panel (press  $\frac{PU}{EXT}$ ) when the parameter unit (FR-PU04/FR-PU07) is used) to switch to the PU operation mode. For other values (1 to 4, 6, 7), the operation mode is limited accordingly.

- Check that the operation location by *Pr.* 550 and *Pr.* 551 is correct. (Example: write from the operation panel is disabled when USB is connected)

(Refer to page 256).

## 5.5.11 Operation panel display is not operating

- Check that wiring is securely performed and installation is correct.
- Make sure that the connector is fitted securely across terminals P-P1.

## 5.5.12 Parameter write cannot be performed

- Make sure that operation is not being performed (signal STF or STR is not ON).
- Make sure that you are not attempting to set the parameter in the external operation mode.
  - Check Pr. 77 Parameter write selection.
  - Check Pr. 161 Frequency setting/key lock operation selection.
- Check that the operation location by Pr. 550 and Pr. 551 is correct. (Example: write from the operation panel is disabled when USB is connected)

(Refer to page 256).

## **MEMO**

# PRECAUTIONS FOR MAINTENANCE AND INSPECTION

This chapter provides the "PRECAUTIONS FOR MAINTENANCE AND INSPECTION" of this product.

Always read the instructions before using the equipment

3.1	Inspection items	282
3.2	Measurement of main circuit voltages currents and nowers	280

2

3

Ļ

5

5

7

The inverter is a static unit mainly consisting of semiconductor devices. Daily inspection must be performed to prevent any fault from occurring due to the adverse effects of the operating environment, such as temperature, humidity, dust, dirt and vibration, changes in the parts with time, service life, and other factors.

#### Precautions for maintenance and inspection

For some short time after the power is switched off, a high voltage remains in the smoothing capacitor. When accessing the inverter for inspection, wait for at least 10 minutes after the power supply has been switched off, and then make sure that the voltage across the main circuit terminals P/+-N/- of the inverter is not more than 30VDC using a tester, etc.

#### 6.1 Inspection items

#### 6.1.1 Daily inspection

Basically, check for the following faults during operation.

- (1) Motor operation fault
- (2) Improper installation environment
- (3) Cooling system fault
- (4) Abnormal vibration, abnormal noise
- (5) Abnormal overheat, discoloration

During operation, check the inverter input voltages using a tester.

#### 6.1.2 Periodic inspection

Check the areas inaccessible during operation and requiring periodic inspection.

Consult us for periodic inspection.

- (1) Check for cooling system fault......Clean the air filter, etc.
- (2) Tightening check and retightening......The screws and bolts may become loose due to vibration, temperature changes, etc. Check and tighten them.

Tighten them according to the specified tightening torque (Refer to page 16, 24).

- (3) Check the conductors and insulating materials for corrosion and damage.
- (4) Measure insulation resistance.
- (5) Check and change the cooling fan and relay.

#### 6.1.3 Daily and periodic inspection

Area of	Inspection Item			Interval		Corrective Action at	Customer's
Inspection			Description	Daily	Periodic *2	Alarm Occurrence	Check
	Surrounding environment		Check the ambient temperature, humidity, dirt, corrosive gas, oil mist, etc.	0		Improve environment	
General	Overall unit		Check for unusual vibration and noise.	0		Check alarm location and retighten	
	Power supply voltage		Check that the main circuit voltages are normal.*1	0		Inspect the power supply	
			(1) Check with megger (across main circuit terminals and earth (ground) terminal).		0	Contact the manufacturer	
	Gen	eral	(2) Check for loose screws and bolts.		0	Retighten	
			(3) Check for overheat traces on the parts.		0	Contact the manufacturer	
			(4) Check for stain		0	Clean	
			(1) Check conductors for distortion.		0	Contact the manufacturer	
	Con	ductors, cables	(2) Check cable sheaths for breakage and deterioration (crack, discoloration, etc.)		0	Contact the manufacturer	
Main circuit	Tern	ninal block	Check for damage.		0	Stop the device and	
	10111	miai biook	ŭ			contact the manufacturer.	
			(1) Check for liquid leakage.		0	Contact the manufacturer	
	Smoothing aluminum electrolytic capacitor		(2) Check for safety valve projection and bulge.		0	Contact the manufacturer	
			(3) Visual check and judge by the life check of the main circuit capacitor ( <i>Refer to page 284</i> )		0		
	Rela	av.	Check that the operation is normal and no		0	Contact the manufacturer	
	Relay		chatter is heard.			Contact the managedier	
	Operation check		(1) Check that the output voltages across phases with the inverter operated alone is balanced		0	Contact the manufacturer	
Control	Оре	Tation Check	(2) Check that no fault is found in protective and display circuits in a sequence protective operation test.		0	Contact the manufacturer	
circuit,		Overall	(1) Check for unusual odor and		0	Stop the device and	
Protective circuit			discoloration.			contact the manufacturer.	
Circuit	eck		(2) Check for serious rust development		0	Contact the manufacturer	
	arts check	Aluminum electrolytic	(1) Check for liquid leakage in a capacitor and deformation trance		0	Contact the manufacturer	
	۵	capacitor	(2) Visual check and judge by the life check of the main circuit capacitor ( <i>Refer to page 284</i> )		0		
			(1) Check for unusual vibration and noise.	0		Replace the fan	
	Coo	ling fan	(2) Check for loose screws and bolts		0	Retighten	
Cooling			(3) Check for stain		0	Clean	
system	Uasi	toink	(1) Check for clogging		0	Clean	
	Heatsink		(2) Check for stain		0	Clean	
			(1) Check that display is normal.	0		Contact the manufacturer	
Display	Indication		(2) Check for stain		0	Clean	
Display	Meter		Check that reading is normal	0		Stop the device and contact the manufacturer.	
Load motor	Operation check		Check for vibration and abnormal increase in operation noise	0		Stop the device and contact the manufacturer.	
	l		i			i .	

<sup>\*1</sup> It is recommended to install a device to monitor voltage for checking the power supply voltage to the inverter.

<sup>\*2</sup> One to two years of periodic inspection cycle is recommended. However, it differs according to the installation environment. Consult us for periodic inspection.

#### 6.1.4 Display of the life of the inverter parts

The self-diagnostic alarm is output when the life span of the control circuit capacitor, cooling fan and each parts of the inrush current limit circuit is near to give an indication of replacement time.

#### The life alarm output can be used as a guideline for life judgement.

Parts	Judgement Level
Main circuit capacitor	85% of the initial capacity
Control circuit capacitor	Estimated remaining life 10%
Inrush current limit circuit	Estimated remaining life 10%
	(Power on: 100,000 times left)
Cooling fan	Less than 50% of the predetermined speed



#### **POINT**

Refer to page 248 to perform the life check of the inverter parts.

#### 6.1.5 Checking the inverter and converter modules

#### <Preparation>

- (1) Disconnect the external power supply cables (R/L1, S/L2, T/L3) and motor cables (U, V, W).
- (2) Prepare a tester. (Use  $100\Omega$  range.)

#### <Checking method>

Change the polarity of the tester alternately at the inverter terminals R/L1, S/L2, T/L3, U, V, W, P/+ and N/-, and check for continuity.




#### NOTE

- 1. Before measurement, check that the smoothing capacitor is discharged.
- 2. At the time of discontinuity, the measured value is almost  $\infty$ . When there is an instantaneous continuity, due to the smoothing capacitor, the tester may not indicate  $\infty$ . At the time of continuity, the measured value is several to several ten's-of ohms depending on the module type, circuit tester type, etc. If all measured values are almost the same, the modules are without fault.

#### <Module device numbers and terminals to be checked>

		Tester Polarity		Measured		Tester Polarity		Measured
		<b>(+)</b>	$\Theta$	Value		<b>+</b>	$\Theta$	Value
	D1	R/L1	P/+	Discontinuity	D4	R/L1	N/-	Continuity
<u>_</u>	וטו	P/+	R/L1	Continuity	D4	N/-	R/L1	Discontinuity
Converter module	D2	S/L2	P/+	Discontinuity	D5	S/L2	N/-	Continuity
on Noc	D2	P/+	S/L2	Continuity	D3	N/-	S/L2	Discontinuity
0 -	D3	T/L3	P/+	Discontinuity	D6	T/L3	N/-	Continuity
	DS	P/+	T/L3	Continuity		N/-	T/L3	Discontinuity
	TR1	U	P/+	Discontinuity	TR4	U	N/-	Continuity
	IIXI	P/+	U	Continuity		111/4	N/-	U
ter	TR3	V	P/+	Discontinuity	TR6	V	N/-	Continuity
Inverter module		P/+	V	Continuity		N/-	V	Discontinuity
ב∈		W	P/+	Discontinuity	TR2	W	N/-	Continuity
	TR5	P/+	W	Continuity		N/-	W	Discontinuity



(Assumes the use of an analog meter.)

#### 6.1.6 Cleaning

Always run the inverter in a clean status.

When cleaning the inverter, gently wipe dirty areas with a soft cloth immersed in neutral detergent or ethanol.



#### NOTE

Do not use solvent, such as acetone, benzene, toluene and alcohol, as they will cause the inverter surface paint to peel off. The display, etc. of the operation panel and parameter unit (FR-PU04/FR-PU07) are vulnerable to detergent and alcohol. Therefore, avoid using them for cleaning.



#### 6.1.7 Replacement of parts

The inverter consists of many electronic parts such as semiconductor devices.

The following parts may deteriorate with age because of their structures or physical characteristics, leading to reduced performance or fault of the inverter. For preventive maintenance, the parts must be replaced periodically.

Use the life check function as a guidance of parts replacement.

Part Name	Standard Replacement Interval *1	Description
Cooling fan	10 years	Replace (as required)
Main circuit smoothing capacitor	10 years *2	Replace (as required)
On-board smoothing capacitor	10 years	Replace the board (as required)
Relays	_	as required

Replacement years for when the yearly average ambient temperature is 40°C (without corrosive gas, flammable gas, oil mist, dust and dirt etc.)

Output current: equivalent to rating current of the Mitsubishi standard motor (4 poles)



#### NOTE

For parts replacement, consult the nearest Mitsubishi FA Center.

#### (1) Cooling fan

The replacement interval of the cooling fan used for cooling the parts generating heat such as the main circuit semiconductor is greatly affected by the ambient temperature. When unusual noise and/or vibration is noticed during inspection, the cooling fan must be replaced immediately.



For parts replacement, consult the nearest Mitsubishi FA Center.

Inverter Type	Fan Type	Units
FR-E740-040 to 095	MMF-06F24ES-RP1 BKO-CA1638H01	1
FR-E740-120, 170	MMF-06F24ES-RP1 BKO-CA1638H01	2
FR-E740-230, 300	MMF-08D24ES-RP1 BKO-CA1639H01	2

The FR-E740-026 or less are not provided with a cooling fan.

● Removal

1) Push the hooks from above and remove the fan cover.


FR-E740-095 or less



- VI
- 2) Disconnect the fan connectors.


3) Remove the fan.

FR-E740-095 or less




Example for FR-E740-095

FR-E740-120 or more




FR-E740-120 or more



Example for FR-E740-120


### Reinstallation

 After confirming the orientation of the fan, reinstall the fan so that the arrow on the left of "AIR FLOW" faces up.




- 2) Reconnect the fan connectors.
- 3) When wiring, use care to avoid the cables being caught by the fan.

FR-E740-095 or less




4) Reinstall the fan cover.

### FR-E740-095 or less




Example for FR-E740-095

### FR-E740-120 or more



### FR-E740-120 or more



Example for FR-E740-120



### **NOTE**

- Installing the fan in the opposite air flow direction can cause the inverter life to be shorter.
- Prevent the cable from being caught when installing a fan.
- Switch the power off before replacing fans. Since the inverter circuits are charged with voltage even after power off, replace fans only when the inverter cover is on the inverter to prevent an electric shock accident.

### (2) Smoothing capacitors

A large-capacity aluminum electrolytic capacitor is used for smoothing in the main circuit DC section, and an aluminum electrolytic capacitor is used for stabilizing the control power in the control circuit. Their characteristics are deteriorated by the adverse effects of ripple currents, etc. The replacement intervals greatly vary with the ambient temperature and operating conditions. When the inverter is operated in air-conditioned, normal environment conditions, replace the capacitors about every 10 years.

When a certain period of time has elapsed, the capacitors will deteriorate more rapidly. Check the capacitors at least every year (less than six months if the life will be expired soon).

The appearance criteria for inspection are as follows:

- 1) Case: Check the side and bottom faces for expansion
- 2) Sealing plate: Check for remarkable warp and extreme crack.
- 3) Check for external crack, discoloration, liquid leakage, etc. Judge that the capacitor has reached its life when the measured capacitance of the capacitor reduced below 80% of the rating.



### **POINT**

Refer to page 248 to perform the life check of the main circuit capacitor.


### (3) Relays

To prevent a contact fault, etc., relays must be replaced according to the cumulative number of switching times (switching life).


### 6.1.8 Inverter replacement

The inverter can be replaced with the control circuit wiring kept connected. Before replacement, remove the wiring cover of the inverter.

Remove the installation screw of the control circuit terminal block.
 Pull the control circuit terminal downward.



(2) Using care not to bend the pins of the inverter's control circuit connector, reinstall the control circuit terminal block and fix it with the installation screw.





### **NOTE**

- Before starting inverter replacement, switch power off, wait for at least 10 minutes, and then check the voltage with a
  tester and such to ensure safety.
- Calibration bias and gain changes when changing the control circuit terminal block. Use *Pr. 645* and *CI(Pr. 901)* to calibrate again in that case.



## 6.2 Measurement of main circuit voltages, currents and powers


Since the voltages and currents on the inverter power supply and output sides include harmonics, measurement data depends on the instruments used and circuits measured.

When instruments for commercial frequency are used for measurement, measure the following circuits with the instruments given on the next page.

• When installing meters etc. on the inverter output side

When the inverter-to-motor wiring length is large, especially in the 400V class, small-capacity models, the meters and CTs may generate heat due to line-to-line leakage current. Therefore, choose the equipment which has enough allowance for the current rating.

To measure and display the output voltage and output current of the inverter, it is recommended to use the AM-5 terminal output function of the inverter.



**Examples of Measuring Points and Instruments** 

### **Measuring Points and Instruments**

Item	Measuring Point	Measuring Instrument	Remarks (Reference Measured	d Value)
Power supply voltage V1	R/L1-S/L2 S/L2-T/L3 T/L3-R/L1	Moving-iron type AC voltmeter	Commercial power supply Within permissible AC voltage fluctuati page 296)	on (Refer to
Power supply side current	R/L1, S/L2, T/L3 line current	Moving-iron type AC ammeter		
Power supply side power P1	R/L1, S/L2, T/L3 and R/L1-S/L2, S/L2-T/L3, T/L3-R/L1,	Electrodynamic type single- phase wattmeter	P1=W11+W12+W13 (3-wattmeter meth	od)
Power supply side power factor Pf1	Calculate after measuring possible supply side current and power $Pf_1 = \frac{P_1}{\sqrt{3}V_1 \times I_1} \times 100$	er supply side power.		
Output side voltage V2	Across U-V, V-W and W-U	Rectifier type AC voltage meter *1 (moving-iron type cannot measure)	Difference between the phases is within maximum output voltage.	n 1% of the
Output side current	U, V and W line currents	Moving-iron type AC ammeter *2	Difference between the phases is 10% the rated inverter current.	or lower of
Output side power P2	U, V, W and U-V, V-W	Electrodynamic type single- phase wattmeter	P2 = W21 + W22 2-wattmeter method (or 3-wattmeter m	ethod)
Output side power factor Pf2	Calculate in similar manner to $Pf_2 = \frac{P_2}{\sqrt{3}V_2 \times I_2} \times 100$	to power supply side power factors	or.	
Converter output	Across P/+-N/-	Moving-coil type (such as tester)	Inverter LED display is lit. 1.35 x V1 760V maximum during regeneration fo	r 400V class
Frequency setting signal	Across 2(positive)-5 Across 4(positive)-5		0 to 10VDC4 to 20mADC	
Frequency setting power supply	Across 10(positive)-5	Moving-coil type	5.2VDC	"5" is common.
Frequency meter signal	Across AM(positive)-5	(tester and such may be used)	Approx. 10VDC at maximum frequency (without frequency meter)	
Start signal Select signal	STF, STR Across RH, RM, RL - PC (positive)	(internal resistance 50kΩ or more)	When open 20 to 30VDC	"PC" is common.
Reset Output stop	Across RES-PC(positive) Across MRS-PC(positive)		ON voltage: 1V or less	
Fault signal	Across A-C Across B-C	Moving-coil type (such as tester)	Continuity check *3 <normal>  Across A-C Discontinuity Continuity  Across B-C Continuity Disconti</normal>	iity

<sup>\*1</sup> Use an FFT to measure the output voltage accurately. An FA tester or general measuring instrument cannot measure accurately.

<sup>\*2</sup> When the carrier frequency exceeds 5kHz, do not use this instrument since using it may increase eddy-current losses produced in metal parts inside the instrument, leading to burnout. In this case, use an approximate-effective value type.

<sup>\*3</sup> When the setting of Pr. 192 A,B,C terminal function selection is positive logic



### 6.2.1 Measurement of powers


Using an electro-dynamometer type meter, measure the power in both the input and output sides of the inverter using the twoor three-wattmeter method. As the current is liable to be imbalanced especially in the input side, it is recommended to use the three-wattmeter method.

Examples of process value differences produced by different measuring meters are shown below.

An error will be produced by difference between measuring instruments, e.g. power calculation type and two- or three-wattmeter type three-phase wattmeter. When a CT is used in the current measuring side or when the meter contains a PT on the voltage measurement side, an error will also be produced due to the frequency characteristics of the CT and PT.

### [Measurement conditions]


Constant-torque (100%) load, note that 60Hz or more should be constantly output 3.7kW, 4-pole motor, value indicated in 3-wattmeter method is 100%.



Example of Measuring Inverter Input Power

### [Measurement conditions]

Constant-torque (100%) load, note that 60Hz or more should be constantly output 3.7kW, 4-pole motor, value indicated in 3-wattmeter method is 100%.



Example of Measuring Inverter Output Power

### 6.2.2 Measurement of voltages and use of PT

### (1) Inverter input side

As the input side voltage has a sine wave and it is extremely small in distortion, accurate measurement can be made with an ordinary AC meter.

### (2) Inverter output side

Since the output side voltage has a PWM-controlled rectangular wave, always use a rectifier type voltmeter. A needle type tester can not be used to measure the output side voltage as it indicates a value much greater than the actual value. A moving-iron type meter indicates an effective value which includes harmonics and therefore the value is larger than that of the fundamental wave. The value monitored on the operation panel is the inverter-controlled voltage itself. Hence, that value is accurate and it is recommended to monitor values using the operation panel.

### (3) PT

No PT can be used in the output side of the inverter. Use a direct-reading meter. (A PT can be used in the input side of the inverter.)

### 6.2.3 Measurement of currents

Use a moving-iron type meter on both the input and output sides of the inverter. However, if the carrier frequency exceeds 5kHz, do not use that meter since an overcurrent losses produced in the internal metal parts of the meter will increase and the meter may burn out. In this case, use an approximate-effective value type.


Since current on the inverter input side tends to be unbalanced, measurement of three phases is recommended. Correct value can not be obtained by measuring only one or two phases. On the other hand, the unbalanced ratio of each phase of the output side current should be within 10%.


When a clamp ammeter is used, always use an effective value detection type. A mean value detection type produces a large error and may indicate an extremely smaller value than the actual value. The value monitored on the operation panel is accurate if the output frequency varies, and it is recommended to monitor values (provide analog output) using the operation panel. Examples of process value differences produced by different measuring meters are shown below.

### [Measurement conditions]

### [Measurement conditions]

Value indicated by moving-iron type ammeter is 100%. Value indicated by moving-iron type ammeter is 100%.





Example of measuring inverter input current

Example of measuring inverter output current


#### 6.2.4 Use of CT and transducer

A CT may be used in both the input and output sides of the inverter, but the one used should have the largest possible VA ability because an error will increase if the frequency gets lower.

When using a transducer, use the effective value calculation type which is immune to harmonics.

### 6.2.5 Measurement of inverter input power factor

Calculate using effective power and apparent power. A power-factor meter can not indicate an exact value.



#### 6.2.6 Measurement of converter output voltage (across terminals P-N)


The output voltage of the converter is developed across terminals P-N and can be measured with a moving-coil type meter (tester). Although the voltage varies according to the power supply voltage, approximately 540V to 600V is output when no load is connected and voltage decreases when a load is connected.

When regenerative energy is returned from the motor during deceleration, for example, the converter output voltage rises to nearly 800V to 900V maximum.



### 6.2.7 Insulation resistance test using megger

• For the inverter, conduct the insulation resistance test on the main circuit only as shown below and do not perform the test on the control circuit. (Use a 500VDC megger.)



# ( )

### NOTE

- Before performing the insulation resistance test on the external circuit, disconnect the cables from all terminals of the inverter so that the test voltage is not applied to the inverter.
- For the continuity test of the control circuit, use a tester (high resistance range) and do not use the megger or buzzer.

### 6.2.8 Pressure test

Do not conduct a pressure test. Deterioration may occur.

# **MEMO**

# 7 SPECIFICATIONS

This chapter provides the "SPECIFICATIONS" of this product. Always read the instructions before using the equipment

7.1	Rating	296
7.2	Common specifications	297
7.3	Outline dimension drawings	298

ļ

### 7.1 Rating

### 7.1.1 Inverter rating

### • Three-phase 400V power supply

Model FR-E740-□□-EC		016	026	040	060	095	120	170	230	300
Applicable motor capacity (kW)*1		0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15
	Rated capacity (kVA)*2		2.0	3.0	4.6	7.2	9.1	13.0	17.5	23.0
Ħ	# Bata Laurana (A)		2.6	4.0	6.0	9.5	12	17	23	30
Output	Rated current (A)*6	(1.4)	(2.2)	(3.8)	(5.4)	(8.7)	12	17	23	30
0	Overload current rating*3		150% 60s, 200% 3s (inverse-time characteristics)							
	Voltage*4		Three phase 380 to 480V							
<u>&gt;</u>	Rated input voltage/frequency		Three-phase 380 to 480V 50Hz/60Hz							
ddn	Rated input voltage/frequency Permissible AC voltage fluctuation		325 to 528V 50Hz/60Hz							
	8		±5%							
Pow	Permissible frequency fluctuation  Power supply capacity (kVA)*5		2.5	4.5	5.5	9.5	12	17	20	28
Protective structure (JEM1030)		Enclosed type (IP20)								
Cooling system		Self-cooling Forced air cooling								
Approximate mass (kg)		1.4 1.4 1.9 1.9 1.9 3.2 3.2 5.9			5.9					

- \*1 The applicable motor capacity indicated is the maximum capacity applicable for use of the Mitsubishi 4-pole standard motor.
- \*2 The rated output capacity indicated assumes that the output voltage is 440V.
- \*3 The % value of the overload current rating indicated is the ratio of the overload current to the inverter's rated output current. For repeated duty, allow time for the inverter and motor to return to or below the temperatures under 100% load.
- \*4 The maximum output voltage does not exceed the power supply voltage. The maximum output voltage can be changed within the setting range. However, the pulse voltage value of the inverter output side voltage remains unchanged at about  $\sqrt{2}$  that of the power supply.
- \*5 The power supply capacity varies with the value of the power supply side inverter impedance (including those of the input reactor and cables).
- \*6 Setting 2kHz or more in *Pr. 72 PWM frequency selection* to perform low acoustic noise operation with the ambient temperature exceeding 40°C, the rated output current is the value in parenthesis.

## 1

## 7.2 Common specifications


	Control method		Soft-PWM control/high carrier frequency PWM control (V/F control, advanced magnetic flux vector control,
	Control method		general-purpose magnetic flux vector control, optimum excitation control can be selected)
1	Output frequency ra	ange	0.2 to 400Hz
		A I I	0.06Hz/60Hz (terminal2, 4: 0 to 10V/10bit)
Su	Frequency setting resolution	Analog input	0.12Hz/60Hz (terminal2, 4: 0 to 5V/9bit) 0.06Hz/60Hz (terminal4: 4 to 20mA/10bit)
[달	resolution	Digital input	0.01Hz
specifications	Frequency	Analog input	Within ±0.5% of the max. output frequency (25°C ±10°C)
ecil	accuracy	Digital input	Within 0.01% of the set output frequency
g ,			Base frequency can be set from 0 to 400Hz
ᅙ	Voltage/frequency	naracteristics	Constant torque/variable torque pattern can be selected
Control	Starting torque		200% or more (at 0.5Hz)when advanced magnetic flux vector control is set (3.7K or less)
ၓ	Torque boost		Manual torque boost
١. ا	Acceleration/decele	ration time setting	0.01 to 360s, 0.1 to 3600s (acceleration and deceleration can be set individually), linear or S-pattern acceleration
_	DC injection brake		deceleration mode can be selected.  Operation frequency (0 to 120Hz), operation time (0 to 10s), operation voltage (0 to 30%) variable
_	Stall prevention operation level		Operation current level can be set (0 to 200% adjustable), whether to use the function or not can be selected
	otali prevention operation level		Two points
	Frequency setting	Analog input	Terminal 2: 0 to 10V, 0 to 5V can be selected
	signal		Terminal 4: 0 to 10V, 0 to 5V, 4 to 20mA can be selected
		Digital input	Entered from operation panel and parameter unit
	Start signal		Forward and reverse rotation or start signal automatic self-holding input (3-wire input) can be selected.
			Seven points You can select from among multi-speed selection, remote setting, stop-on contact selection, second function
			I selection, terminal 4 input selection, JOG operation selection, PID control valid terminal, brake opening
l l	Input signal		completion signal, external thermal input, PU-external operation switchover, V/F switchover, output stop, start
			self-holding selection, forward rotation, reverse rotation command, inverter reset, PU-NET operation switchover,
,n			external-NET operation switchover, command source switchover, inverter operation enable signal, and PU operation external interlock
ë			Maximum/minimum frequency setting, frequency jump operation, external thermal relay input selection,
äti			automatic restart after instantaneous power failure operation, forward/reverse rotation prevention, remote setting,
ij	Operational functio	ns	brake sequence, second function, multi-speed operation, stop-on contact control, droop control, regeneration avoidance, slip compensation, operation mode selection, offline auto tuning function, PID control, computer link
96			operation (RS-485)
Operation specifications		Open collector	
ij	Output signal points	output	Two points
era	points	Relay output	One point
å			You can select from among inverter operation, up-to-frequency, overload alarm, output frequency detection,
	<u></u>		regenerative brake prealarm, electronic thermal relay function prealarm, inverter operation ready, output current detection, zero current detection, PID lower limit, PID upper limit, PID forward/reverse rotation output, brake
	Operating status	S	opening request, fan alarm*2, heatsink overheat pre-alarm, deceleration at an instantaneous power failure, PID
	<u>s</u>		control activated, during retry, life alarm, current average value monitor, remote output, alarm output, fault output,
	For meter Output points		fault output 3, and maintenance timer alarm
	Output points	Analog output	0 to 10VDC: one point
			You can select from among output frequency, motor current (steady), output voltage, frequency setting, motor
			torque, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output
	For meter		current peak value, converter output voltage peak value, reference voltage output, motor load factor, PID set
			point, PID measured value, output power 0 to 10VDC
			0 to 10VDC You can select from among output frequency, motor current (steady), output voltage, frequency setting,
	Operation panel	Operating state	0 to 10VDC You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, motor torque, converter output voltage, regenerative brake
		Operating status	0 to 10VDC You can select from among output frequency, motor current (steady), output voltage, frequency setting,
	Parameter unit	Operating status	0 to 10VDC You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, motor torque, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value,
		Operating status	0 to 10VDC  You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, motor torque, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, I/O terminal option monitor, output power, cumulative power, motor thermal load factor, and inverter thermal load factor.  Fault definition is displayed when the fault occurs and the past 8 fault definitions (output voltage/current/
dication	Parameter unit (FR-PU07)	Fault definition	0 to 10VDC  You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, motor torque, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, I/O terminal option monitor, output power, cumulative power, motor thermal load factor, and inverter thermal load factor.  Fault definition is displayed when the fault occurs and the past 8 fault definitions (output voltage/current/frequency/cumulative energization time right before the fault occurs) are stored
Indication	Parameter unit (FR-PU07) Additional display	Fault definition Operating status	0 to 10VDC  You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, motor torque, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, I/O terminal option monitor, output power, cumulative power, motor thermal load factor, and inverter thermal load factor.  Fault definition is displayed when the fault occurs and the past 8 fault definitions (output voltage/current/frequency/cumulative energization time right before the fault occurs) are stored  Not used
Indication	Parameter unit (FR-PU07)  Additional display by the parameter	Fault definition Operating status Fault definition	O to 10VDC  You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, motor torque, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, I/O terminal option monitor, output power, cumulative power, motor thermal load factor, and inverter thermal load factor.  Fault definition is displayed when the fault occurs and the past 8 fault definitions (output voltage/current/frequency/cumulative energization time right before the fault occurs) are stored  Not used  Output voltage/current/frequency/cumulative energization time immediately before the fault occurs
Indication	Parameter unit (FR-PU07) Additional display	Fault definition Operating status Fault definition Interactive	0 to 10VDC  You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, motor torque, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, I/O terminal option monitor, output power, cumulative power, motor thermal load factor, and inverter thermal load factor.  Fault definition is displayed when the fault occurs and the past 8 fault definitions (output voltage/current/frequency/cumulative energization time right before the fault occurs) are stored  Not used
Indication	Parameter unit (FR-PU07)  Additional display by the parameter unit (FR-PU04/FR-	Fault definition Operating status Fault definition	O to 10VDC  You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, motor torque, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, I/O terminal option monitor, output power, cumulative power, motor thermal load factor, and inverter thermal load factor.  Fault definition is displayed when the fault occurs and the past 8 fault definitions (output voltage/current/frequency/cumulative energization time right before the fault occurs) are stored  Not used  Output voltage/current/frequency/cumulative energization time immediately before the fault occurs
Indication	Parameter unit (FR-PU07)  Additional display by the parameter unit (FR-PU04/FR-	Fault definition Operating status Fault definition Interactive	O to 10VDC  You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, motor torque, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, I/O terminal option monitor, output power, cumulative power, motor thermal load factor, and inverter thermal load factor.  Fault definition is displayed when the fault occurs and the past 8 fault definitions (output voltage/current/frequency/cumulative energization time right before the fault occurs) are stored  Not used  Output voltage/current/frequency/cumulative energization time immediately before the fault occurs  Function (help) for operation guide  Protective functions>  Overcurrent during acceleration, overcurrent during constant speed, overcurrent during deceleration, overvoltage
Indication	Parameter unit (FR-PU07)  Additional display by the parameter unit (FR-PU04/FR-	Fault definition Operating status Fault definition Interactive	O to 10VDC  You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, motor torque, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, I/O terminal option monitor, output power, cumulative power, motor thermal load factor, and inverter thermal load factor.  Fault definition is displayed when the fault occurs and the past 8 fault definitions (output voltage/current/frequency/cumulative energization time right before the fault occurs) are stored  Not used  Output voltage/current/frequency/cumulative energization time immediately before the fault occurs  Function (help) for operation guide  Protective functions> Overcurrent during acceleration, overcurrent during constant speed, overcurrent during deceleration, inverter protection
Indication	Parameter unit (FR-PU07)  Additional display by the parameter unit (FR-PU04/FR-	Fault definition Operating status Fault definition Interactive	O to 10VDC You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, motor torque, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, I/O terminal option monitor, output power, cumulative power, motor thermal load factor, and inverter thermal load factor.  Fault definition is displayed when the fault occurs and the past 8 fault definitions (output voltage/current/frequency/cumulative energization time right before the fault occurs) are stored  Not used  Output voltage/current/frequency/cumulative energization time immediately before the fault occurs  Function (help) for operation guide <protective functions=""> Overcurrent during acceleration, overcurrent during constant speed, overcurrent during deceleration, overvoltage during acceleration, motor protection thermal operation, heatsink overheat, input phase failure, output side earth (ground) fault overcurrent at start, output phase failure, external thermal relay operation *4, option fault,</protective>
Indication	Parameter unit (FR-PU07)  Additional display by the parameter unit (FR-PU04/FR-	Fault definition Operating status Fault definition Interactive guidance	O to 10VDC  You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, motor torque, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, I/O terminal option monitor, output power, cumulative power, motor thermal load factor, and inverter thermal load factor.  Fault definition is displayed when the fault occurs and the past 8 fault definitions (output voltage/current/frequency/cumulative energization time right before the fault occurs) are stored  Not used  Output voltage/current/frequency/cumulative energization time immediately before the fault occurs  Function (help) for operation guide <protective functions="">  Overcurrent during acceleration, overcurrent during constant speed, overcurrent during deceleration, overvoltage during acceleration, overvoltage during constant speed, overvoltage during deceleration, inverter protection thermal operation, motor protection thermal operation, heatsink overheat, input phase failure, output side earth (ground) fault overcurrent at start, output phase failure, external thermal relay operation *4, option fault, parameter error, internal board fault, PU disconnection, retry count excess *4, CPU fault, brake transistor alarm,</protective>
Indication	Parameter unit (FR-PU07)  Additional display by the parameter unit (FR-PU04/FR- PU07) only	Fault definition Operating status Fault definition Interactive guidance	O to 10VDC  You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, motor torque, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, I/O terminal option monitor, output power, cumulative power, motor thermal load factor, and inverter thermal load factor.  Fault definition is displayed when the fault occurs and the past 8 fault definitions (output voltage/current/frequency/cumulative energization time right before the fault occurs) are stored  Not used  Output voltage/current/frequency/cumulative energization time immediately before the fault occurs  Function (help) for operation guide <protective functions=""> Overcurrent during acceleration, overcurrent during constant speed, overcurrent during deceleration, overvoltage during acceleration, inverter protection thermal operation, motor protection thermal operation, heatsink overheat, input phase failure, output side earth (ground) fault overcurrent at start, output phase failure, external thermal relay operation *4, option fault, parameter error, internal board fault, PU disconnection, retry count excess *4, CPU fault, brake transistor alarm, inrush resistance overheat, communication error, analog input error, USB communication error, brake sequence</protective>
Indication	Parameter unit (FR-PU07)  Additional display by the parameter unit (FR-PU04/FR- PU07) only	Fault definition Operating status Fault definition Interactive guidance	O to 10VDC  You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, motor torque, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, I/O terminal option monitor, output power, cumulative power, motor thermal load factor, and inverter thermal load factor.  Fault definition is displayed when the fault occurs and the past 8 fault definitions (output voltage/current/frequency/cumulative energization time right before the fault occurs) are stored  Not used  Output voltage/current/frequency/cumulative energization time immediately before the fault occurs  Function (help) for operation guide <protective functions="">  Overcurrent during acceleration, overcurrent during constant speed, overcurrent during deceleration, overvoltage during acceleration, overvoltage during constant speed, overvoltage during deceleration, inverter protection thermal operation, motor protection thermal operation, heatsink overheat, input phase failure, output side earth (ground) fault overcurrent at start, output phase failure, external thermal relay operation *4, option fault, parameter error, internal board fault, PU disconnection, retry count excess *4, CPU fault, brake transistor alarm,</protective>
Indication	Parameter unit (FR-PU07)  Additional display by the parameter unit (FR-PU04/FR- PU07) only	Fault definition Operating status Fault definition Interactive guidance	O to 10VDC  You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, motor torque, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, I/O terminal option monitor, output power, cumulative power, motor thermal load factor, and inverter thermal load factor.  Fault definition is displayed when the fault occurs and the past 8 fault definitions (output voltage/current/frequency/cumulative energization time right before the fault occurs) are stored  Not used  Output voltage/current/frequency/cumulative energization time immediately before the fault occurs  Function (help) for operation guide <protective functions="">  Overcurrent during acceleration, overcurrent during constant speed, overcurrent during deceleration, overvoltage during acceleration, overvoltage during deceleration, inverter protection thermal operation, motor protection thermal operation, heatsink overheat, input phase failure, output side earth (ground) fault overcurrent at start, output phase failure, external thermal relay operation *4, option fault, parameter error, internal board fault, PU disconnection, retry count excess *4, CPU fault, brake transistor alarm, inrush resistance overheat, communication error, analog input error, USB communication error, brake sequence error 4 to 7 *4  <vvarning functions="">  Fan alarm*2, overcurrent stall prevention, overvoltage stall prevention, PU stop, parameter write error,</vvarning></protective>
Indication	Parameter unit (FR-PU07)  Additional display by the parameter unit (FR-PU04/FR-PU07) only	Fault definition Operating status Fault definition Interactive guidance ction	O to 10VDC  You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, motor torque, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, I/O terminal option monitor, output power, cumulative power, motor thermal load factor, and inverter thermal load factor.  Fault definition is displayed when the fault occurs and the past 8 fault definitions (output voltage/current/frequency/cumulative energization time right before the fault occurs) are stored  Not used  Output voltage/current/frequency/cumulative energization time immediately before the fault occurs  Function (help) for operation guide <protective functions="">  Overcurrent during acceleration, overcurrent during constant speed, overcurrent during deceleration, overvoltage during acceleration, overvoltage during constant speed, overvoltage during deceleration, inverter protection thermal operation, motor protection thermal operation, heatsink overheat, input phase failure, output side earth (ground) fault overcurrent at start, output phase failure, external thermal relay operation *4, option fault, parameter error, internal board fault, PU disconnection, retry count excess *4, CPU fault, brake transistor alarm, inrush resistance overheat, communication error, analog input error, USB communication error, brake sequence error 4 to 7 *4  <warning functions="">  Fan alarm*2, overcurrent stall prevention, overvoltage stall prevention, PU stop, parameter write error, regenerative brake prealarm *4, electronic thermal relay function prealarm, maintenance output *4, undervoltage</warning></protective>
Indication	Parameter unit (FR-PU07)  Additional display by the parameter unit (FR-PU04/FR-PU07) only  tective/warning fun	Fault definition Operating status Fault definition Interactive guidance ction	O to 10VDC  You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, motor torque, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, I/O terminal option monitor, output power, cumulative power, motor thermal load factor, and inverter thermal load factor.  Fault definition is displayed when the fault occurs and the past 8 fault definitions (output voltage/current/frequency/cumulative energization time right before the fault occurs) are stored  Not used  Output voltage/current/frequency/cumulative energization time immediately before the fault occurs  Function (help) for operation guide <protective functions="">  Overcurrent during acceleration, overcurrent during constant speed, overcurrent during deceleration, overvoltage during acceleration, overvoltage during constant speed, overvoltage during deceleration, inverter protection thermal operation, motor protection thermal operation, heatsink overheat, input phase failure, output side earth (ground) fault overcurrent at start, output phase failure, external thermal relay operation *4, option fault, parameter error, internal board fault, PU disconnection, retry count excess *4, CPU fault, brake transistor alarm, inrush resistance overheat, communication error, analog input error, USB communication error, brake sequence error 4 to 7 *4  <warning functions="">  Fan alarm*2, overcurrent stall prevention, overvoltage stall prevention, PU stop, parameter write error, regenerative brake prealarm *4, electronic thermal relay function prealarm, maintenance output *4, undervoltage-10°C to +50°C (non-freezing) *3</warning></protective>
Indication	Parameter unit (FR-PU07)  Additional display by the parameter unit (FR-PU04/FR-PU07) only  tective/warning fun  Ambient temperatu  Ambient humidity	Fault definition Operating status Fault definition Interactive guidance ction	O to 10VDC  You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, motor torque, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, I/O terminal option monitor, output power, cumulative power, motor thermal load factor, and inverter thermal load factor.  Fault definition is displayed when the fault occurs and the past 8 fault definitions (output voltage/current/frequency/cumulative energization time right before the fault occurs) are stored  Not used  Output voltage/current/frequency/cumulative energization time immediately before the fault occurs  Function (help) for operation guide <protective functions="">  Overcurrent during acceleration, overcurrent during constant speed, overcurrent during deceleration, overvoltage during acceleration, overvoltage during constant speed, overvoltage during deceleration, inverter protection thermal operation, heatsink overheat, input phase failure, output side earth (ground) fault overcurrent at start, output phase failure, external thermal relay operation *4, option fault, parameter error, internal board fault, PU disconnection, retry count excess *4, CPU fault, brake transistor alarm, inrush resistance overheat, communication error, analog input error, USB communication error, brake sequence error 4 to 7 *4  <warning functions="">  Fan alarm*2, overcurrent stall prevention, overvoltage stall prevention, PU stop, parameter write error, regenerative brake prealarm *4, electronic thermal relay function prealarm, maintenance output *4, undervoltage*  -10°C to +50°C (non-freezing) *3  90%RH maximum (non-condensing)</warning></protective>
Indication	Parameter unit (FR-PU07)  Additional display by the parameter unit (FR-PU04/FR-PU07) only  tective/warning fun  Ambient temperatu  Ambient humidity  Storage temperatur	Fault definition Operating status Fault definition Interactive guidance ction	O to 10VDC  You can select from among output frequency, motor current (steady), output voltage, frequency setting, cumulative energization time, actual operation time, motor torque, converter output voltage, regenerative brake duty, electronic thermal relay function load factor, output current peak value, converter output voltage peak value, motor load factor, PID set point, PID measured value, PID deviation, inverter I/O terminal monitor, I/O terminal option monitor, output power, cumulative power, motor thermal load factor, and inverter thermal load factor.  Fault definition is displayed when the fault occurs and the past 8 fault definitions (output voltage/current/frequency/cumulative energization time right before the fault occurs) are stored  Not used  Output voltage/current/frequency/cumulative energization time immediately before the fault occurs  Function (help) for operation guide  Protective functions> Overcurrent during acceleration, overcurrent during constant speed, overcurrent during deceleration, overvoltage during acceleration, inverter protection thermal operation, motor protection thermal operation, heatsink overheat, input phase failure, output side earth (ground) fault overcurrent at start, output phase failure, external thermal relay operation *4, option fault, parameter error, internal board fault, PU disconnection, retry count excess *4, CPU fault, brake transistor alarm, inrush resistance overheat, communication error, analog input error, USB communication error, brake sequence error 4 to 7 *4 <a href="https://www.numencentrell.put.edu/">www.numencentrell.put.edu/</a> <a href="https://www.numencentrell.put.edu/">www.numencentrell.put.edu/</a> <a href="https://www.numencentrell.put.edu/">www.numencentrell.put.edu/</a> <a href="https://www.numencentrell.put.edu/">www.numencentrell.put.edu/</a> <a "="" href="https://www.numencentrell.put.edu/&lt;/a&gt;  &lt;a href=" https:="" www.numencentrell.put.edu="">www.numencentrell.put.edu/</a>

- \*1 Temperatures applicable for a short time, e.g. in transit.
- \*2 As the FR-E740-026 or less is not provided with the cooling fan, this alarm does not function.
- \*3 When using the inverters at the ambient temperature of 40°C or less, the inverters can be installed closely attached (0cm clearance).
- \*4 This protective function does not function in the initial status.


## 7.3 Outline dimension drawings

### (1) 400V class


### ●FR-E740-016 to 095




### ●FR-E740-120, 170




### ●FR-E740-230, 300




### ●Parameter unit (option) (FR-PU07)



### •Parameter unit (option) (FR-PU04)



### •Enclosure surface operation panel (option) (FR-PA07)



# APPENDIX

This chapter provides the "APPENDIX" of this product. Always read the instructions before using the equipment.

### **APPENDIX**

# Appendix1 For customers who have replaced the conventional model with this inverter

### Appendix 1-1 Replacement of the FR-E500 series

### (1) Instructions for installation

- 1) Removal procedure of the front cover was changed. (Refer to page 5)
- 2) The operation panel cannot be removed from the inverter.
- 3) Plug-in options of the FR-E500 series are not compatible.
- 4) Setup software (FR-SW0-SETUP, FR-SW1-SETUP, FR-SW2-SETUP) can not be used.

### (2) Instructions for continuous use of the FR-PU04 (parameter unit)

- 1) For the FR-E700 series, many functions (parameters) have been added. User initial value list and user clear of the HELP function can not be used.
- 2) For the FR-E700 series, many protective functions have been added. These functions activate, but all faults are displayed as "Fault 14". When the faults history has been checked, "E.14" appears. Added faults display will not appear on the parameter unit.
- 3) User initial value setting can not be used.
- 4) User registration/clear (user group 2) can not be used.
- 5) Parameter copy/verification function can not be used.

### (3) Parameter resetting

It is easy if you use setup software (FR Configurator FR-SW3-SETUP).

### (4) Main differences and compatibilities with the FR-E500 Series

Item	FR-E500	FR-E700		
Control method	V/F control General-purpose magnetic flux vector control	V/F control General-purpose magnetic flux vector control Advanced magnetic flux vector control Optimum excitation control		
	Torque boost ( <i>Pr. 0</i> ) initial value FR-E540-1.5K to 3.7K: 6% FR-E540-5.5K, 7.5K: 4% DC injection brake operation voltage ( <i>Pr. 12</i> ) initial value 6%	FR-E740-040 to 095: 4% FR-E740-120, 170: 3%		
	Frequency at 5V (10V) input ( <i>Pr. 38</i> ) Frequency at 20mA input frequency ( <i>Pr. 39</i> ) Second electronic thermal O/L relay ( <i>Pr. 48</i> ) Shortest acceleration/deceleration mode ( <i>Pr. 60</i> )	Parameter number change (Pr. 125 Terminal 2 frequency setting gain frequency) (Pr. 126 Terminal 4 frequency setting gain frequency) (Pr. 51 Second electronic thermal O/L relay) (Pr. 60 Energy saving control selection) (Pr. 292 Automatic acceleration/deceleration)		
	Reverse rotation from the inverter operation panel Press REV .	After setting "1" in <i>Pr. 40 RUN key rotation direction</i> selection , press RUN .		
	AM terminal function selection ( <i>Pr. 158</i> ) setting 0: Output frequency (initial value), 1: Output current, 2: Output voltage	AM terminal function selection ( <i>Pr. 158</i> ) setting  1: Output frequency (initial value),  2: Output current,  3: Output voltage		
	Second applied motor Pr. 71 = 100 to 123	Pr. 450 Second applied motor		
Changed/cleared functions	Terminal 2 0 to 5V, 0 to 10V selection ( <i>Pr. 73</i> ) setting 0: 0 to 5V (initial value), 1: 0 to 10V	Pr. 73 Analog input selection 0: 0 to 10V 1: 0 to 5V (initial value)		
	Operation mode selection ( <i>Pr. 79</i> ) Initial value 1: PU operation mode Setting 8: Operation mode switching by external signal	Initial value 0: External operation mode is selected at power on Setting 8: deleted (X16 signal is used instead)		
	Setting general-purpose magnetic flux vector  Pr. 80 ≠ 9999	Pr. 80 ≠ 9999, Pr. 81 ≠ 9999, Pr. 800 = 30		
	User group 1 (16), user group 2 (16) ( <i>Pr. 160, Pr. 173 to Pr. 175</i> )	User group (16) only, setting methods were partially changed ( <i>Pr. 160, Pr. 172, Pr. 173</i> )		
	Input terminal function selection ( <i>Pr. 180 to Pr. 183</i> ) setting 5: MRS signal (output stop) 6: STOP signal (start self-holding selection)	Pr. 178 to Pr. 184 Input terminal function selection setting 5: JOG signal (jog operation selection) 6: None 24: MRS signal (output stop) 25: STOP signal (start self-holding selection)		
	Cooling fan operation selection( <i>Pr. 244</i> ) initial setting			
	0: Cooling fan operates in power-on status.  Stop selection ( <i>Pr. 250</i> ) setting increments	1: Cooling fan on/off control valid		
	RS-485 communication control source from the PU connector PU operation mode	0.1s  Network operation mode (PU operation mode as FR-E500 when <i>Pr. 551</i> = 2)		
	Earth (ground) fault detection 400V class: Detects always	400V class: Detects only at a start		
Control terminal block	Fixed terminal block (can not be removed) (Phillips screw M2.5)	Removable terminal block (Flathead screw M2 (M3 for terminal A, B, and C only)		
Operation panel	Removable operation panel (PA02)	Integrated operation panel (can not be removed) FR-PU07		
PU	FR-PU04	FR-PU04 (some functions, such as parameter copy, are unavailable.)		
	Dedicated plug-in option (i	nstallation is incompatible)  FR-A7AX E kit : 16bit digital input		
Plug-in option	FR-E5NC : CC-Link communication FR-E5ND : DeviceNet communication FR-E5NL : LonWorks communication	FR-A7AY E kit: Digital output, Extension analog output FR-A7AR E kit: Relay output FR-A7NC E kit: CC-Link communication FR-A7ND E kit: DeviceNet communication		
Installation size		FR-A7NP E kit : PROFIBUS-DP communication FR-A7NL E kit : LonWorks communication		
Installation size	0.1 to 7.5K are compatible in mounting dimensions			

## Appendix2 Index

Numerics	(SU, FU signal, Pr. 41 to Pr. 43)
15-speed selection (combination with three speeds RL, RM,	Display of the life of the inverter parts
RH)(REX signal)92, 128	(Pr. 255 to Pr. 259)
· · · /(· · = · · · · · · · · · · · · · · · · ·	Droop control (Pr. 286 to Pr. 287)244
Α	During PID control activated (PID signal) 134, 231, 238
Acceleration time, deceleration time setting (Pr. 7, Pr. 8, Pr.	During retry (Y64 signal)
20, Pr. 21, Pr. 44, Pr. 45)99	
Acceleration/deceleration pattern (Pr. 29)	E
Actual operation time	Earth (ground) fault detection at start (Pr. 249)167
Advance magnetic flux control (Pr. 71, Pr. 80, Pr. 81, Pr. 89,	Easy operation mode setting (easy setting mode)50
Pr. 800)76	Electronic thermal O/L relay pre-alarm (TH)106, 270
Alarm output (LF signal)	Electronic thermal O/L relay pre-alarm (THP signal) 106, 134
Analog input fault (E.AIE)276	Electronic Thermal Relay Function Load Factor143
Analog input selection(Pr. 73, Pr. 267)	Extended parameter display and user group function (Pr. 160,
Applied motor (Pr. 71, Pr. 450)	Pr. 172 to Pr. 174)
Automatic restart after instantaneous power failure/flying start	External thermal relay input (OH signal)106, 128
(Pr. 30, Pr. 57, Pr. 58, Pr. 96, Pr. 162, Pr. 165, Pr. 298, Pr.	External thermal relay operation (E.OHT)106, 274
299, Pr. 611) <i>151</i>	External/NET operation switchover (turning on X66 selects
Avoid mechanical resonance points (frequency jumps) (Pr. 31	NET operation) (X66 signal)128, 188
to Pr. 36)87	<u>_</u>
	F
3	Fan alarm (FN)247, 270
Base frequency, voltage (Pr. 3, Pr. 19, Pr. 47)88	Fan fault output (FAN signal)134, 247
Basic operation (factory setting)49	Fault or alarm indication143, 263
Bias and gain of frequency setting voltage (current) (Pr. 125,	Fault output (ALM signal)134, 137
Pr. 126, Pr. 241, C2 (Pr. 902) to C7 (Pr. 905))	Fault output 3 (power-off signal) (Y91 signal)134, 137
Brake opening completion signal (BRI signal)124, 128	Faults history (E)
Brake opening request (BOF signal)124, 134	Fin overheat (E.FIN)
Brake sequence fault (E.MB4 to 7)124, 275	Forward rotation command (assigned to STF terminal (Pr.
Brake sequence function (Pr. 278 to Pr. 283, Pr. 292)124	178) only) (STF signal)
Brake transistor alarm detection (E.BE)273	Free parameter (Pr. 888, Pr. 889)
Buzzer control (Pr. 990)260	Frequency setting value
•	Front cover5
	G
Cables and wiring length	
Change the control method (Pr. 80, Pr. 81, Pr. 800)	General-purpose magnetic flux vector control (Pr. 71, Pr. 80, Pr. 81, Pr. 800)
Change the parameter setting value	F1. 01, F1. 000)/
Changing the control logic	Н
Checking the inverter and converter modules284 Cleaning	
Command source switchover (turning on X67 makes Pr. 338	Heatsink overheat pre-alarm (FIN signal)
and Pr. 339 commands valid) (X67 signal)128, 191	riigii speed operation command (Krr signar)
Communication EEPROM write selection (Pr. 342)204	1
Communication option fault (E.OP1)274	Initial settings and specifications of RS-485 communication
Condition selection of function validity by second function	(Pr. 117 to Pr. 120, Pr. 123, Pr. 124, Pr. 549)
selection signal (RT signal)	Input phase loss (E.ILF)
Connection of a DC reactor (FR-HEL)32	Input terminal function selection(Pr. 178 to Pr. 189)
Connection of a dedicated external brake resistor (MRS type,	Input Terminal Status
MYS type, FR-ABR) (0.4K or more)28	Input/output phase loss protection selection
Connection of the brake unit (FR-BU2)30	(Pr. 251, Pr. 872)
Connection of the high power factor converter (FR-HC)31	Inrush current limit circuit fault (E.IOH)275
Connection of the power regeneration common converter	Insulation resistance test using megger
(FR-CV)32	Internal board fault(E.PE2)
Connection to the PU connector	Internal circuit fault (E.13)
Converter Output Voltage	Inverter I/O Terminal Monitor
Converter output voltage peak value	Inverter installation environment
Cooling fan operation selection (Pr. 244)247	Inverter operation ready (RY signal)
Cooling system types for inverter panel9	Inverter output shutoff signal (MRS signal, Pr. 17)
CPU error (E.6, E. 7, E.CPU)275	Inverter overload trip (electronic thermal relay function)
Cumulative energization time143	(E.THT)
Cumulative power143	Inverter placement
Current average value monitor signal (Pr. 555 to Pr. 557) 253	Inverter replacement
Current average value monitor signal (Y93 signal)134, 253	Inverter reset (Err.)
_	Inverter reset (RES signal)
0	Inverter run enable signal(FR-HC/FR-CV connection) (X10
Daily and periodic inspection283	signal)119, 128
Daily inspection282	Inverter running (RUN signal)
Dancer control (Pr. 44, Pr. 45, Pr. 128 to Pr. 134)238	Inverter thermal load factor143
DC injection brake (Pr. 10 to Pr. 12)	Inverter-generated noises and their reduction techniques 36
Detection of output frequency	

J	Output voltage143
Jog operation (Pr. 15, Pr. 16)	Overcurrent trip during acceleration (E.OC1)271
JOG operation selection (JOG signal)94, 128	Overcurrent trip during constant speed (E.OC2)271
	Overcurrent trip during deceleration or stop (E.OC3)271
L	Overload alarm (OL signal)82, 134
Leakage currents and countermeasures	Р
Life alarm (Y90 signal)	•
Load pattern selection (Pr. 14)	Parameter list
Low-speed operation command (RL signal)	Parameter storage device fault (control circuit board) (E.PE)274
М	Parameter write disable selection (Pr. 77)
M	Parameter write error (Er1 to Er4)
Magnitude of frequency change setting (Pr. 295)	Periodic inspection
Maintenance signal output (MT)	Peripheral devices4
Maintenance timer signal (Y95 signal)	PID control (Pr. 127 to Pr. 134)231
Manual torque boost (Pr. 0, Pr. 46)	PID control valid terminal (X14 signal)128, 231, 238
Maximum/minimum frequency (Pr. 1, Pr. 2, Pr. 18)	PID Deviation
Measurement of converter output voltage (across terminals	PID Forward/Reverse Rotation Output
P-N)	(RL signal)
Measurement of currents	PID lower limit (FDN signal)
Measurement of inverter input power factor292	PID Measured Value
Measurement of powers	PID Set Point
Measurement of voltages and use of PT	PID upper limit (FUP signal)134, 231, 238
Middle-speed operation command (RM signal) 92, 128	Power failure deceleration signal (Y46 signal)134, 157
Mitsubishi inverter protocol	Power supply harmonics
(computer link communication)205	Power-failure deceleration stop function (Pr. 261)
Modbus RTU communication specifications (Pr. 117, Pr. 118,	Pressure test
Pr. 120, Pr. 122, Pr. 343, Pr. 502, Pr. 549)	PU contrast adjustment (Pr. 991)
Monitor display selection of DU/PU and terminal AM (Pr. 52,	PU disconnection (E.PUE)
Pr. 158, Pr. 170, Pr. 171, Pr. 268, Pr. 563, Pr. 564) 143	PU display language selection(Pr. 145)
Motor Load Factor 143	PU operation external interlock (X12 signal)
Motor overheat protection (Electronic thermal O/L relay) (Pr.	PU stop (PS)
9, Pr. 51)	operation) (X65 signal)
Motor overload trip (electronic thermal relay function)	PU-external operation switchover (turning on X16 selects
(E.THM)	external operation) (X16)
Motor thermal load factor	
	PWM carrier frequency and soft-PWM control (Pr. 72, Pr.
Motor Torque	PWM carrier frequency and soft-PWM control (Pr. 72, Pr. 240)
Motor Torque	
Motor Torque	
Motor Torque	240)
Names and functions of the operation panel48	240)
N Names and functions of the operation panel	R Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)
N Names and functions of the operation panel	R Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)
N Names and functions of the operation panel	R Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)
N Names and functions of the operation panel	240)
N Names and functions of the operation panel	240)       163         R       Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)       148         Reference voltage output       143, 149         Regeneration avoidance function (Pr. 665, Pr. 882, Pr. 883, Pr. 885, Pr. 886)       245         Regenerative brake duty       119, 143         Regenerative brake prealarm (RB)       119, 270
N Names and functions of the operation panel	240)       163         R       Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)       148         Reference voltage output       143, 149         Regeneration avoidance function (Pr. 665, Pr. 882, Pr. 883, Pr. 885, Pr. 886)       245         Regenerative brake duty       119, 143         Regenerative brake prealarm (RB)       119, 270         Regenerative brake prealarm (RBP signal)       119, 134
N Names and functions of the operation panel	R Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)
N Names and functions of the operation panel	240)       163         R       Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)       148         Reference voltage output       143, 149         Regeneration avoidance function (Pr. 665, Pr. 882, Pr. 883, Pr. 885, Pr. 886)       245         Regenerative brake duty       119, 143         Regenerative brake prealarm (RB)       119, 270         Regenerative brake prealarm (RBP signal)       119, 134         Regenerative overvoltage trip during acceleration (E.OV1)       245, 271
N Names and functions of the operation panel	R Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)
N Names and functions of the operation panel	R  Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)
N Names and functions of the operation panel	R Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)
N Names and functions of the operation panel	R Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)
N Names and functions of the operation panel	R Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)
N Names and functions of the operation panel	R Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)
N Names and functions of the operation panel	R  Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)
N Names and functions of the operation panel	R  Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)
N Names and functions of the operation panel	R  Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)
N Names and functions of the operation panel	R  Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)
N Names and functions of the operation panel	R  Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)
N Names and functions of the operation panel	R  Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)
N Names and functions of the operation panel	R  Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)
N Names and functions of the operation panel	R Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)
N         N         Names and functions of the operation panel	R Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)
N Names and functions of the operation panel	R  Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)
N         N         Names and functions of the operation panel	R  Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)
Nomes and functions of the operation panel	R Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)
Names and functions of the operation panel	R Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)
N         Names and functions of the operation panel	R Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)
Names and functions of the operation panel	R Reference of the terminal AM (analog voltage output) (Pr. 55, Pr. 56)

Selection of a regenerative brake (Pr. 30, Pr. 70)119
Setting dial push5
Shortest acceleration/deceleration (automatic acceleration/
deceleration) (Pr. 61 to Pr. 63, Pr. 292, Pr. 293)
Slip compensation (Pr. 245 to Pr. 247)8
Specification of main circuit terminal
Speed display and speed setting (Pr. 37)
Speed smoothing control (Pr. 653)
Stall prevention (E.OLT)
Stall prevention (overvoltage) (oL)245, 269 Stall prevention operation (Pr. 22, Pr. 23, Pr. 48, Pr. 66, Pr.
156, Pr. 157, Pr. 277)8
Standard control circuit terminal
Start self-holding selection (STOP signal)
Start signal operation selection (STF, STR, STOP signal, Pr.
250)
Starting frequency and start-time hold function (Pr. 13, Pr.
571)
Stop selection (Pr. 250)
Stop-on contact control function (Pr. 6, Pr. 48, Pr. 270, Pr.
275, Pr. 276) <i>12</i>
Stop-on contact selection 0 (RL signal)122, 126
Stop-on contact selection 1 (RT signal)122, 126
T
Terminal 4 input selection (AU signal)128, 165
Terminal AM calibration (calibration parameter Pr. 645, C1
(Pr.901))
Terminal arrangement of the main circuit terminal, power
supply and the motor wiring1
Terminal connection diagram1
To exhibit the best performance of the motor performance
(offline auto tuning) (Pr. 71, Pr. 80 to Pr. 84, Pr. 90 to Pr. 94
Pr. 96, Pr. 859)110
U
Undervoltage (UV)270
Up-to-frequency signal (SU signal)134, 136
USB communication (Pr. 547, Pr. 548)
USB communication fault (E.USB)230, 276
Use of CT and transducer292
V
V/F switchover (V/F cntrol is exercised when X18 is on) (X18
signal)74, 120
W
Wiring and configuation of PUconnector
Wiring cover
Wiring instructions
vviiling of control circuit
Z
Zero current detection (V13 signal) 134 139

# **MEMO**

\*The manual number is given on the bottom left of the back cover.

Print Date	*Manual Number	Revision
Oct., 2007	IB(NA)-0600336ENG-A	First edition
Dec., 2007	IB(NA)-0600336ENG-B	Additions • FR-E740-230, 300

## **1** For Maximum Safety

- Mitsubishi inverters are not designed or manufactured to be used in equipment or systems in situations that can affect or endanger human life.
- When considering this product for operation in special applications such as machinery or systems used in passenger transportation, medical, aerospace, atomic power, electric power, or submarine repeating applications, please contact your nearest Mitsubishi sales representative.
- Although this product was manufactured under conditions of strict quality control, you are strongly advised to
  install safety devices to prevent serious accidents when it is used in facilities where breakdowns of the product
  are likely to cause a serious accident.
- Please do not use this product for loads other than three-phase induction motors.